

OPERATOR'S MANUAL

Cobramatic®

*For use with Push-Pull Torches model K1589, K1590, K1591, K1592
For use with code 10841*

Safety Depends on You

Lincoln arc welding equipment is designed and built with safety in mind. However, your overall safety can be increased by proper installation...and thoughtful operation on your part.

DO NOT INSTALL, OPERATE OR REPAIR THIS EQUIPMENT WITHOUT READING THIS MANUAL AND THE SAFETY PRECAUTIONS CONTAINED THROUGHOUT. And, most importantly, think before you act and be careful.



This manual covers equipment which is no longer in production by The Lincoln Electric Co. Specifications and availability of optional features may have changed.

OPERATOR'S MANUAL

LINCOLN
ELECTRIC

World's Leader in Welding and Cutting Products

Premier Manufacturer of Industrial Motors

Sales and Service through Subsidiaries and Distributors Worldwide

Cleveland, Ohio 44117-1199 U.S.A. TEL: 216.481.8100 FAX: 216.486.1751 WEB SITE: www.lincolnelectric.com

SAFETY

⚠ WARNING



CALIFORNIA PROPOSITION 65 WARNINGS



Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

The Above For Diesel Engines

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

The Above For Gasoline Engines

ARC WELDING CAN BE HAZARDOUS. PROTECT YOURSELF AND OTHERS FROM POSSIBLE SERIOUS INJURY OR DEATH. KEEP CHILDREN AWAY. PACEMAKER WEARERS SHOULD CONSULT WITH THEIR DOCTOR BEFORE OPERATING.

Read and understand the following safety highlights. For additional safety information, it is strongly recommended that you purchase a copy of "Safety in Welding & Cutting - ANSI Standard Z49.1" from the American Welding Society, P.O. Box 351040, Miami, Florida 33135 or CSA Standard W117.2-1974. A Free copy of "Arc Welding Safety" booklet E205 is available from the Lincoln Electric Company, 22801 St. Clair Avenue, Cleveland, Ohio 44117-1199.

BE SURE THAT ALL INSTALLATION, OPERATION, MAINTENANCE AND REPAIR PROCEDURES ARE PERFORMED ONLY BY QUALIFIED INDIVIDUALS.



FOR ENGINE powered equipment.

1.a. Turn the engine off before troubleshooting and maintenance work unless the maintenance work requires it to be running.



1.b. Operate engines in open, well-ventilated areas or vent the engine exhaust fumes outdoors.



1.c. Do not add the fuel near an open flame welding arc or when the engine is running. Stop the engine and allow it to cool before refueling to prevent spilled fuel from vaporizing on contact with hot engine parts and igniting. Do not spill fuel when filling tank. If fuel is spilled, wipe it up and do not start engine until fumes have been eliminated.



1.d. Keep all equipment safety guards, covers and devices in position and in good repair. Keep hands, hair, clothing and tools away from V-belts, gears, fans and all other moving parts when starting, operating or repairing equipment.

1.e. In some cases it may be necessary to remove safety guards to perform required maintenance. Remove guards only when necessary and replace them when the maintenance requiring their removal is complete. Always use the greatest care when working near moving parts.

1.f. Do not put your hands near the engine fan. Do not attempt to override the governor or idler by pushing on the throttle control rods while the engine is running.

1.g. To prevent accidentally starting gasoline engines while turning the engine or welding generator during maintenance work, disconnect the spark plug wires, distributor cap or magneto wire as appropriate.



1.h. To avoid scalding, do not remove the radiator pressure cap when the engine is hot.



ELECTRIC AND MAGNETIC FIELDS may be dangerous

2.a. Electric current flowing through any conductor causes localized Electric and Magnetic Fields (EMF). Welding current creates EMF fields around welding cables and welding machines

2.b. EMF fields may interfere with some pacemakers, and welders having a pacemaker should consult their physician before welding.

2.c. Exposure to EMF fields in welding may have other health effects which are now not known.

2.d. All welders should use the following procedures in order to minimize exposure to EMF fields from the welding circuit:

2.d.1. Route the electrode and work cables together - Secure them with tape when possible.

2.d.2. Never coil the electrode lead around your body.

2.d.3. Do not place your body between the electrode and work cables. If the electrode cable is on your right side, the work cable should also be on your right side.

2.d.4. Connect the work cable to the workpiece as close as possible to the area being welded.

2.d.5. Do not work next to welding power source.

Mar '95





ELECTRIC SHOCK can kill.

- 3.a. The electrode and work (or ground) circuits are electrically "hot" when the welder is on. Do not touch these "hot" parts with your bare skin or wet clothing. Wear dry, hole-free gloves to insulate hands.
- 3.b. Insulate yourself from work and ground using dry insulation. Make certain the insulation is large enough to cover your full area of physical contact with work and ground.
- In addition to the normal safety precautions, if welding must be performed under electrically hazardous conditions (in damp locations or while wearing wet clothing; on metal structures such as floors, gratings or scaffolds; when in cramped positions such as sitting, kneeling or lying, if there is a high risk of unavoidable or accidental contact with the workpiece or ground) use the following equipment:**
- Semiautomatic DC Constant Voltage (Wire) Welder.
 - DC Manual (Stick) Welder.
 - AC Welder with Reduced Voltage Control.
- 3.c. In semiautomatic or automatic wire welding, the electrode, electrode reel, welding head, nozzle or semiautomatic welding gun are also electrically "hot".
- 3.d. Always be sure the work cable makes a good electrical connection with the metal being welded. The connection should be as close as possible to the area being welded.
- 3.e. Ground the work or metal to be welded to a good electrical (earth) ground.
- 3.f. Maintain the electrode holder, work clamp, welding cable and welding machine in good, safe operating condition. Replace damaged insulation.
- 3.g. Never dip the electrode in water for cooling.
- 3.h. Never simultaneously touch electrically "hot" parts of electrode holders connected to two welders because voltage between the two can be the total of the open circuit voltage of both welders.
- 3.i. When working above floor level, use a safety belt to protect yourself from a fall should you get a shock.
- 3.j. Also see Items 6.c. and 8.



ARC RAYS can burn.

- 4.a. Use a shield with the proper filter and cover plates to protect your eyes from sparks and the rays of the arc when welding or observing open arc welding. Headshield and filter lens should conform to ANSI Z87.1 standards.
- 4.b. Use suitable clothing made from durable flame-resistant material to protect your skin and that of your helpers from the arc rays.
- 4.c. Protect other nearby personnel with suitable, non-flammable screening and/or warn them not to watch the arc nor expose themselves to the arc rays or to hot spatter or metal.



FUMES AND GASES can be dangerous.

- 5.a. Welding may produce fumes and gases hazardous to health. Avoid breathing these fumes and gases. When welding, keep your head out of the fume. Use enough ventilation and/or exhaust at the arc to keep fumes and gases away from the breathing zone. **When welding with electrodes which require special ventilation such as stainless or hard facing (see instructions on container or MSDS) or on lead or cadmium plated steel and other metals or coatings which produce highly toxic fumes, keep exposure as low as possible and below Threshold Limit Values (TLV) using local exhaust or mechanical ventilation. In confined spaces or in some circumstances, outdoors, a respirator may be required. Additional precautions are also required when welding on galvanized steel.**
- 5.b. Do not weld in locations near chlorinated hydrocarbon vapors coming from degreasing, cleaning or spraying operations. The heat and rays of the arc can react with solvent vapors to form phosgene, a highly toxic gas, and other irritating products.
- 5.c. Shielding gases used for arc welding can displace air and cause injury or death. Always use enough ventilation, especially in confined areas, to insure breathing air is safe.
- 5.d. Read and understand the manufacturer's instructions for this equipment and the consumables to be used, including the material safety data sheet (MSDS) and follow your employer's safety practices. MSDS forms are available from your welding distributor or from the manufacturer.
- 5.e. Also see item 1.b.

Mar '95



WELDING SPARKS can cause fire or explosion.

- 6.a. Remove fire hazards from the welding area. If this is not possible, cover them to prevent the welding sparks from starting a fire. Remember that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas. Avoid welding near hydraulic lines. Have a fire extinguisher readily available.
- 6.b. Where compressed gases are to be used at the job site, special precautions should be used to prevent hazardous situations. Refer to "Safety in Welding and Cutting" (ANSI Standard Z49.1) and the operating information for the equipment being used.
- 6.c. When not welding, make certain no part of the electrode circuit is touching the work or ground. Accidental contact can cause overheating and create a fire hazard.
- 6.d. Do not heat, cut or weld tanks, drums or containers until the proper steps have been taken to insure that such procedures will not cause flammable or toxic vapors from substances inside. They can cause an explosion even though they have been "cleaned". For information, purchase "Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping That Have Held Hazardous Substances", AWS F4.1 from the American Welding Society (see address above).
- 6.e. Vent hollow castings or containers before heating, cutting or welding. They may explode.
- 6.f. Sparks and spatter are thrown from the welding arc. Wear oil free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes and a cap over your hair. Wear ear plugs when welding out of position or in confined places. Always wear safety glasses with side shields when in a welding area.
- 6.g. Connect the work cable to the work as close to the welding area as practical. Work cables connected to the building framework or other locations away from the welding area increase the possibility of the welding current passing through lifting chains, crane cables or other alternate circuits. This can create fire hazards or overheat lifting chains or cables until they fail.
- 6.h. Also see item 1.c.



CYLINDER may explode if damaged.

- 7.a. Use only compressed gas cylinders containing the correct shielding gas for the process used and properly operating regulators designed for the gas and pressure used. All hoses, fittings, etc. should be suitable for the application and maintained in good condition.
- 7.b. Always keep cylinders in an upright position securely chained to an undercarriage or fixed support.
- 7.c. Cylinders should be located:
 - Away from areas where they may be struck or subjected to physical damage.
 - A safe distance from arc welding or cutting operations and any other source of heat, sparks, or flame.
- 7.d. Never allow the electrode, electrode holder or any other electrically "hot" parts to touch a cylinder.
- 7.e. Keep your head and face away from the cylinder valve outlet when opening the cylinder valve.
- 7.f. Valve protection caps should always be in place and hand tight except when the cylinder is in use or connected for use.
- 7.g. Read and follow the instructions on compressed gas cylinders, associated equipment, and CGA publication P-1, "Precautions for Safe Handling of Compressed Gases in Cylinders," available from the Compressed Gas Association 1235 Jefferson Davis Highway, Arlington, VA 22202.



FOR ELECTRICALLY powered equipment.

- 8.a. Turn off input power using the disconnect switch at the fuse box before working on the equipment.
- 8.b. Install equipment in accordance with the U.S. National Electrical Code, all local codes and the manufacturer's recommendations.
- 8.c. Ground the equipment in accordance with the U.S. National Electrical Code and the manufacturer's recommendations.

Mar '95



PRÉCAUTIONS DE SÛRETÉ

Pour votre propre protection lire et observer toutes les instructions et les précautions de sûreté spécifiques qui paraissent dans ce manuel aussi bien que les précautions de sûreté générales suivantes:

Sûreté Pour Soudage A L'Arc

1. Protégez-vous contre la secousse électrique:
 - a. Les circuits à l'électrode et à la pièce sont sous tension quand la machine à souder est en marche. Eviter toujours tout contact entre les parties sous tension et la peau nue ou les vêtements mouillés. Porter des gants secs et sans trous pour isoler les mains.
 - b. Faire très attention de bien s'isoler de la masse quand on soude dans des endroits humides, ou sur un plancher métallique ou des grilles métalliques, principalement dans les positions assis ou couché pour lesquelles une grande partie du corps peut être en contact avec la masse.
 - c. Maintenir le porte-électrode, la pince de masse, le câble de soudage et la machine à souder en bon et sûr état de fonctionnement.
 - d. Ne jamais plonger le porte-électrode dans l'eau pour le refroidir.
 - e. Ne jamais toucher simultanément les parties sous tension des porte-électrodes connectés à deux machines à souder parce que la tension entre les deux pinces peut être le total de la tension à vide des deux machines.
 - f. Si on utilise la machine à souder comme une source de courant pour soudage semi-automatique, ces précautions pour le porte-électrode s'appliquent aussi au pistolet de soudage.
2. Dans le cas de travail au dessus du niveau du sol, se protéger contre les chutes dans le cas où on recoit un choc. Ne jamais enrouler le câble-électrode autour de n'importe quelle partie du corps.
3. Un coup d'arc peut être plus sévère qu'un coup de soliel, donc:
 - a. Utiliser un bon masque avec un verre filtrant approprié ainsi qu'un verre blanc afin de se protéger les yeux du rayonnement de l'arc et des projections quand on soude ou quand on regarde l'arc.
 - b. Porter des vêtements convenables afin de protéger la peau de soudeur et des aides contre le rayonnement de l'arc.
 - c. Protéger l'autre personnel travaillant à proximité au soudage à l'aide d'écrans appropriés et non-inflammables.
4. Des gouttes de laitier en fusion sont émises de l'arc de soudage. Se protéger avec des vêtements de protection libres de l'huile, tels que les gants en cuir, chemise épaisse, pantalons sans revers, et chaussures montantes.
5. Toujours porter des lunettes de sécurité dans la zone de soudage. Utiliser des lunettes avec écrans latéraux dans les

zones où l'on pique le laitier.

6. Eloigner les matériaux inflammables ou les recouvrir afin de prévenir tout risque d'incendie dû aux étincelles.
7. Quand on ne soude pas, poser la pince à un endroit isolé de la masse. Un court-circuit accidentel peut provoquer un échauffement et un risque d'incendie.
8. S'assurer que la masse est connectée le plus près possible de la zone de travail qu'il est pratique de le faire. Si on place la masse sur la charpente de la construction ou d'autres endroits éloignés de la zone de travail, on augmente le risque de voir passer le courant de soudage par les chaînes de levage, câbles de grue, ou autres circuits. Cela peut provoquer des risques d'incendie ou d'échauffement des chaînes et des câbles jusqu'à ce qu'ils se rompent.
9. Assurer une ventilation suffisante dans la zone de soudage. Ceci est particulièrement important pour le soudage de tôles galvanisées plombées, ou cadmiées ou tout autre métal qui produit des fumées toxiques.
10. Ne pas souder en présence de vapeurs de chlore provenant d'opérations de dégraissage, nettoyage ou pistolage. La chaleur ou les rayons de l'arc peuvent réagir avec les vapeurs du solvant pour produire du phosgène (gas fortement toxique) ou autres produits irritants.
11. Pour obtenir de plus amples renseignements sur la sûreté, voir le code "Code for safety in welding and cutting" CSA Standard W 117.2-1974.

PRÉCAUTIONS DE SÛRETÉ POUR LES MACHINES À SOUDER À TRANSFORMATEUR ET À REDRESSEUR

1. Relier à la terre le chassis du poste conformément au code de l'électricité et aux recommandations du fabricant. Le dispositif de montage ou la pièce à souder doit être branché à une bonne mise à la terre.
2. Autant que possible, l'installation et l'entretien du poste seront effectués par un électricien qualifié.
3. Avant de faire des travaux à l'intérieur de poste, la débrancher à l'interrupteur à la boîte de fusibles.
4. Garder tous les couvercles et dispositifs de sûreté à leur place.

Mar. '93



Thank You

for selecting a **QUALITY** product by MK / Lincoln Electric. We want you to take pride in operating this MK Products Inc. / Lincoln Electric Company product *** as much pride as we have in bringing this product to you!

Please Examine Carton and Equipment For Damage Immediately

When this equipment is shipped, title passes to the purchaser upon receipt by the carrier. Consequently, Claims for material damaged in shipment must be made by the purchaser against the transportation company at the time the shipment is received.

Please record your equipment identification information below for future reference. This information can be found on your machine nameplate.

Model Name and Sales SpecNumber (K-xxx) _____

Date of Purchase _____

Whenever you request replacement parts for or information on this equipment always supply the information you have recorded above.

Read this Operators Manual completely before attempting to use this equipment. There are some important topics covered in the manual about how this system works and how it is different than wire feeders you may be use to. Save this manual and keep it handy for quick reference. Pay particular attention to the safety instructions we have provided for your protection. The level of seriousness to be applied to each is explained below:

⚠ WARNING

This statement appears where the information **must** be followed **exactly** to avoid **serious personal injury or loss of life**.

⚠ CAUTION

This statement appears where the information **must** be followed to avoid **minor personal injury or damage to this equipment**.

The Wire Feeder - Gun section of the welding package is a push-pull system, which means that there is a motor in the wire feeder as well as the welding gun. These must both be set-up properly to achieve maximum benefit from the welding package.

The Wire Feeder - Gun section of the welding package is fully warranted by MK Products and Lincoln Electric and can be serviced at the MK Products Service locations listed inside the back cover of this manual.

Spare parts may be purchased from either company if so indicated by a part number in the respective company part number column in the parts listings.

This page intentionally blank

Table of Contents

Safety Guidelines	2
--------------------------------	----------

Installation	Section A
---------------------------	------------------

Technical Specifications	10
Machine Grounding	10
Machine Location	10
Input Power Connections	10
Wire Threading Procedure	11
Welding Torch Connections	11

Operations	Section B
-------------------------	------------------

General Description	12
Recommended Processes and Equipment	12
Controls and Settings	12
POSA Start Operating Procedure	12

Accessories	Section C
--------------------------	------------------

Optional Kits	14
---------------------	----

Maintenance	Section D
--------------------------	------------------

Routine Maintenance	14
Testing the Feeder	15
Testing the Torch	16

Troubleshooting	Section E
------------------------------	------------------

Troubleshooting Guide	17
-----------------------------	----

Diagrams/Parts List	Section F
----------------------------------	------------------

Main PC Boards	19
Mechanical	20
Electrical	27

Warranty Repair Stations

Safety Warnings

Warranty

This page intentionally blank

Section A

Installation

Technical Specifications

Wire Diameter Capacity030 - 1/16" ALL Types
Wire Capacity	12" Standard (Insulated or Non-Insulated)
Power Input	42 VAC 50/60 Hz, 150 Watts Peak (3 amps)
Weight	41 pounds
Shipping Weight	46 pounds
For Use with these Lincoln Torches	K1589, K1590, K1591, K1592

Support Equipment Required

C.V. or C.C. Power Source of Sufficient Capacity for Your Needs.
Regulated Gas Supply and Hoses.
Properly Sized Power Leads from Power Source to Wire Feeder and Ground.

Coolant Recommendations

Water Source and Hose Capable of Providing a Minimum of **1 qt/min. at 45 p.s.i.** when using water cooled torches.

Use a name-brand additive which does not contain reactive sulphur or chlorine and does not react with copper, brass, or aluminum.

Check coolant periodically to remain within limits of the following:

- A. Coolant Flow rate - 1 quart/minute at 45 p.s.i.**
- B. Resistivity - 10K ohms/centimeter**
- C. Ph Range - 5.5-8.5**
- D. Particle Size - .005"**

MK Recommended Coolant Solution:

- 1 part ethylene glycol
- 3 parts distilled water
- 1 teaspoon liquid glycerin

Machine Grounding

The Cobramatic® and GMAW wire feeders are ground to the power source through the input cable. The power source grounding terminal must be properly connected to electrical ground per the power source operating manual.

Mounting Location

The cabinet should be placed in a location where it can be protected from damage. Lead lengths and accessibility must also be considered when installing the cabinet.

Input Power Connections

Your Wire Feeder comes factory ready with a harness to plug directly into all 14 pin Lincoln Power Sources equipped with 42 VAC auxiliary.

The **42 VAC** is connected to the PC Board on terminal strip **J5 #1** (neutral) and **#2** (hot) and Ground to the Cabinet chassis. See diagram in the appendix.

Wire Threading Procedure

Wire Spool Installation

Release latches, and open right side door of cabinet.

Remove spool retainer from spindle hub.

Raise wire retainer bar to latched position.

Install wire spool onto spindle hub so that wire feeds from bottom of spool towards slave motor. Make sure that the hole in the spool aligns with pin on spindle hub. The white dot on the end of the spindle hub will aid in this alignment.

Replace the spool retainer nut.

Lower the wire retainer bar onto the spool.

Threading Procedure

Place wire size selector switch on front panel to the correct position for the wire being used.

Loosen end of wire from spool and cut off any kinked or bent portions.

Unreel and straighten out first 6" to 8" of wire.

Raise wire type lever to center position.

Route wire into inlet guide, along drive roll groove, and into wire conduit.

Flip wire type lever to show type of wire being used.

Tighten the torch pressure adjusting knob so the wire will be picked up and fed through the contact tip. Proper tension is achieved when wire does not slip if a small amount of pressure is added to the wire as it exits the tip.

Wire Retainer Bar

The design of the patented Cobramatic® Wire Retainer Bar performs two very important and very basic functions of the wire feeder: a) spool drag tension, and b) wire maintenance on the spool.

The spool drag tension is set by lowering the wire retainer bar onto the wire inside of the spool. The spring tension of the wire retainer bar applies enough pressure on the spool so that when the torch trigger is released, engaging the brake pall, the spool does not overrun kicking wire off the spool.

Wire maintenance on the spool is performed by the applied pressure of the wire retainer bar spread across the coiled wire on the spool. The replaceable pad (P/N 437-0255) of the wire retainer bar is designed to hold the wire on the spool, maintaining the smooth layering of the wire and keeping it from jumping off, and possibly, electrically shorting to the cabinet chassis.

Welding Torch Connections

Work Cable

Connect a work lead of sufficient size and length (see table below) between the proper output stud on the power source and the work. Be sure the connection to the work makes tight metal to metal electrical contact. Poor work lead connections can result in poor arc initiation, poor weld results and activation of the ground lead protector.

Current 60% Duty Cycle	Work Lead Lengths	
	Up to 50ft. (15.2m)	10-100ft. (15.2-30.4m)
300A	0 (53mm)	0 (67mm)
400A	00 (67mm)	00 (85mm)
500A	00 (67mm)	00 (85mm)
600A	000 (85mm)	000 (107mm)

Section B

Control Cable

The 7-Pin "W" Clocked connector screws onto the mating receptacle on the front panel of the wire feeder. This provides all electrical signals (motor voltage, potentiometer control & trigger) to and from the feeder to the torch.

Wire Conduit Inlet

Front panel access to attach conduit to front of slave motor assembly.

Power Cable Inlet

Front panel access to attach power cable (air or water) to top of power block.

Gas Inlet

Front panel access to attach gas hose to bottom fitting of power block.

Water Inlet (For Water Cooled Torches)

Front panel access to connect the water hose to the middle fitting on the power block.

Operation

General

The AC slave motor in the feeder runs at a fast, constant speed, but has very low torque. It is always trying to feed more wire than the torch motor wants, and when the motor gets all it wants, it slows the slave motor preventing a bird's nest. Because of the low torque produced by the slave motor, a brake system is used to prevent wire overrun rather than tension. The spool drag tension is produced by the patented Wire Retainer Bar mechanism to keep the wire slightly taut. The 24 VDC torch pull motor is controlled by a solid state speed control and a potentiometer located in the torch.

Recommended Processes and Equipment

The Cobramatic® is recommended for use in the GMAW and FCAW welding applications. It is recommended for use with constant voltage power sources. The Cobramatic® is capable of feeding wires (diameter capacity) ranging from .023" through .045" solid/cored and .030" through 1/16" aluminum.

Controls and Settings

On/Off Switch

Placing the switch in the "ON" position energizes the feeder circuitry and the power indicator light.

Wire Size Selector Switch

The wire size selector switch changes the torque of the slave motor for the wire you are using. When in the .030-.035 aluminum only position, the slave motor produces approximately 1 1/2 lbs. inches and approximately 4 1/2 lbs. inches when in the all other wires position.

NOTE:

Operating the cabinet with the switch in the wrong position will cause wire feed difficulties.

Posa Start Controls

The Posa Start Run-in Speed Control, located on the front panel, provides adjustment for slow wire run-in. Once the arc has been established, the wire feed speed is automatically changed from the slow run-in speed to the welding speed set on the torch potentiometer.

Posa Start Operating Procedure

General

The Posa Start Run-in Speed Control, located on the front panel, provides

adjustment for slow wire run-in. Once the arc has been established, the wire feed speed is automatically changed from the slow run-in speed to the welding speed set on the torch potentiometer.

The Posa Start feature allows the Cobramatic® to be used in combination with constant current DC welding power sources of open circuit voltage in excess of 55 volts - also, any constant voltage welding power source capable of a minimum of 50 amps.

Note:

Reverse polarity MUST be used.

Posa Start Connections

Attach the #14 single black lead which extends from the back of the cabinet to the negative terminal of the power supply or work ground, unless already attached through a 14 pin amphenol supplies with the cabinet. The Posa Start lead is internally connected to the P.C. board on terminal strip J6, terminal 2.

CV Posa Start Operations

Attach Cobramatic® to CV power source according to the installation instructions.

Turn the Cobramatic® to the “**ON**” position and the Posa Start to the “**OFF**” position.

Adjust power source to desired voltage for your weld condition.

Depress gun trigger and adjust wire feed speed at gun to match voltage setting. If approximate wire feed is not known, it is better to start with excess wire feed rather than too little, in order to prevent a “burn-back”.

Turn the Posa Start switch to the “**ON**” position. Press torch trigger and, using Run-in Speed Control, adjust wire feed rate to approximately 10% of welding wire speed set at torch.

Strike an arc, and adjust wire feed rate at gun until correct condition is achieved.

CC Posa Start Operation

Attach the Cobramatic® to a CC power source according to the installation instructions.

Insure power supply high frequency switch is in the “**OFF**” position, and power supply is set to DC reverse polarity.

The power supply contactor should be set to “**Remote**” or “**Tig**” and the amperage control set to “**Panel**” or “**Standard**” depending on power supply.

Turn the Cobramatic® power switch to the “**ON**” position and the Posa Start switch to the “**OFF**” position.

Adjust power source to desired amperage for your weld condition.

Press gun trigger and adjust wire feed speed at gun to match current setting. If approximate wire feed speed is not known, it is better to start with excess wire feed rather than too little, in order to prevent possible damage to the contact tip.

Turn Posa Start switch to the “**ON**” position. Press torch trigger and, using Run-in Speed Control, adjust wire feed speed to approximately 10% of welding wire speed set at torch.

Strike an arc; if the wire stubs out, reduce wire feed rate at gun, or increase amperage setting on power source.

CAUTION:

Do Not operate this wire feeder on a power source having a high-frequency starting circuit before making sure that the high frequency portion of the power source is turned off.
Failure to take this precaution will cause permanent damage to the Posa Start circuitry.

NOTE:

Because the Posa Start Run-in Speed always remains a percentage of the actual welding wire feed rate, the Posa Start run-in speed will always slow down or speed up proportional to any adjustment you now make at the gun. Therefore, if you slow down the welding wire feed speed, you will have to increase the Run-in Speed setting.

Section C

OPTIONAL KITS

The following is a list of Optional Kits available for the Cobra® V Wire Feeder. A detailed description of each kit is given later in this section.

<u>P/N</u>	<u>Description</u>
005-0674	Gas Purge/Trigger Latch Kit
005-0675	Water Pressure Kit

005-0674 Gas Purge/Trigger Latch Kit

The Gas Purge/Trigger Latch Kit is a dual function kit, built into one. The kit includes an easy to install interface control PC board, a 24VAC solenoid for pre and post purge control, a modified valve stem for the welding torch and, a front panel switch for activating the Trigger Latch mechanism.

The gas control times have been preset to 0.5 seconds pre-purge and 1.0 seconds post-purge. This offers an optimum amount of inert gas shielding prior to striking the arc and after the arc has been extinguished.

The Trigger Latch mechanism gives the operator the flexibility of normal trigger operation (pull trigger to weld - release trigger to stop). This also offers the comfort of latched trigger operation (pull trigger once to latch and weld - pull trigger again to unlatch and stop).

005-0675 Water Pressure Kit

By monitoring the pressure from the water recirculator, the switch uses the pressure as the key safety element in protecting the torch from overheating while welding. If there is a loss of water pressure, the switch will keep the arc from igniting so no welding takes place without water cooling the torch. The benefit of the water pressure switch far exceeds the minimal cost of its purchase and installation.

This kit, when installed into the wire feeder, is physically adaptable to all makes and models of water recirculators using standard fittings (left-hand threaded).

Section D

Maintenance

Routine Maintenance

Maintenance of the torch will normally consist of a general cleaning of the wire guide system, including tubes, drive rolls, and conduits at regular intervals.

Remove spatter build-up from inside of nozzles with a hardwood stick.

The only parts on the Cobramatic® system that are subject to normal wear are the conduit, contact tips, gas cups, front body liners, wire guides, drive and idler rolls. A supply of these parts should be maintained on hand.

If repairs do become necessary, any part can easily be replaced by a qualified shop maintenance man.

Your Cobramatic® is designed to provide years of reliable service. Normal wear and component failure may require occasional service.

The number of units in operation and the importance of minimal “down time” will determine to what extent spare parts should be stocked on hand.

Testing the Feeder

Relay K2 Operation

When the torch trigger is pressed, 24VAC is sent to the coil of relay K2. When K2 is energized, AC is sent to the slave motor, spool brake, and the AC contactor. Relay K2 is also responsible for sending 24VAC to the speed control circuit and shorting the torch motor leads together when the trigger is released for the dynamic braking system. K2 also provides the closing contactor signal.

Testing the Input Power Circuits


The AC circuits are protected by fuses F2 and F3. If F2 and F3 continually blow, remove J4 (Brake Solenoid), J7 (slave motor) and J5-3,4 (AC Contactor) from the P.C. Board. Replace fuse, and retrigger system. If fuse does not blow; isolate the problem by plugging in J4, J7, and J5-3,4 one at a time until the fuse blows.

Testing the Speed Control

NOTE:

The torch should be tested first and the amphenol must be connected to the Cobramatic® to perform this test.

Place a voltmeter across diode **D10** and press torch trigger. A reading of **0 - 24VDC** should be observed, as the torch potentiometer varied.



Testing the Torch

Motor Check

Remove the amphenol connector from the cabinet.

Using the torch amphenol, check the resistance across pins "A" and "B" (motor leads). The resistance across the motor should be between **5-10 ohms**.

If an open circuit or short exist, check the motor leads and motor independently.

Testing the Potentiometer - "W" Clocked

Using the torch amphenol, check the resistance across pin "D" (wiper) and pin "C". The resistance should vary from **0 - 5K ohms**.

Check the resistance across pin "D" (wiper) and pin "G". The resistance should vary from **5K - 0 ohms**.

Testing the Micro Switch

Using the torch amphenol, check for continuity across pins "E" and "F" when the trigger is pressed.

Section E Troubleshooting

TROUBLESHOOTING		
SYMPTOM	CAUSE	REMEDY
No wire feed at torch, feeder not operating, i.e., no slave motor or brake solenoid.	F2 & F3 (MDA7 7A Slow Blow) fuse in feeder blown.	Check AC circuit. Replace fuse.
	F1 (4 amp) fuse in feeder blown.	Check motor leads for shorts, then replace fuse.
	Micro-switch defective/not being activated. Broken electrical cable.	Replace switch. Check switch for operation. Check micro switch wires for continuity.
	Relay K2 inoperative.	Check/Replace relay K2.
	Loose J2, J3, P.C. board connector	Check J2, J3 connectors.
Brake solenoid inoperative.	Solenoid defective.	Replace solenoid.
	Relay K2 inoperative.	Check for 42VAC across J4-1 and J4-2
No wire feed at torch, feeder operating properly.	Bad potentiometer.	Check potentiometer with meter.
	Bad torch motor.	Check/Replace motor.
	Broken electrical cable.	Check motor and potentiometer wires for continuity.
	Bad speed control/PCB.	Check/Replace P.C. Board.
Wire feeds, but welding wire is not energized.	Loose or no cable connections.	Check all power connections.
	Relay K2 not sending contactor signal.	Check/Replace relay K2.
	Contactor control cable loose or in wrong position.	Check power supply owners manual for location and type of contactor signal required, i.e. closing contacts or AC.
	Welding power source not working right.	Check power supply for proper operation.
Wire feeds erratically.	Dirty or worn conduit.	Blow out or replace conduit.
	Incorrect pressure on drive rolls.	Adjust pressure at torch.
	Idler roll stuck in torch.	Check for lock washer under idler roll, or replace if damaged or worn.
	Wrong size contact tip.	See contact tip table.
Wire feeds one speed only	Bad potentiometer.	Check with meter.
	Broken electrical cable in lead assy.	Check potentiometer wires for continuity or shorts.
	Bad speed control.	Check/Replace P.C. Board.
Wire walks out of drive rolls	Idler roll upside-down.	Place groove in idler roll towards top.
	Rear wire guide missing.	Replace wire guide.


Section F

Appendices


Diagrams/Parts List

Main P.C. Board Connections..... 19
001-4012 Cobramatic Assembly..... 20
003-2112 Cobramatic Front Panel Assembly 22
003-2068 Cobramatic Slave Motor Assembly 23
003-2063 Cobramatic Power Block Assembly 24
003-2061 Cobramatic Spindle Brake Assembly..... 25
843-0496 Cobramatic Control Cable..... 26
071-0386 Cobramatic Block Diagram 27
071-0270 Cobramatic Main P.C. Board 28
071-0367 Cobramatic Torch Connections 29
003-1721 Main P.C. Board Parts Placement..... 30
003-2001 Front Panel Circuit Board 32

Main P.C. Board Connections




REF	TEST PROCEDURE
46	031-0057
47	031-0058
48	031-0059
49	031-0060
50	031-0061
51	031-0062
52	031-0063
53	031-0064
54	031-0065
55	031-0066
56	031-0067
57	031-0068
58	031-0069
59	031-0070
60	031-0071
61	031-0072
62	031-0073
63	031-0074
64	031-0075
65	031-0076
66	031-0077
67	031-0078
68	031-0079
69	031-0080
70	031-0081
71	031-0082
72	031-0083
73	031-0084
74	031-0085
75	031-0086
76	031-0087
77	031-0088
78	031-0089
79	031-0090
80	031-0091
81	031-0092
82	031-0093
83	031-0094
84	031-0095
85	031-0096
86	031-0097
87	031-0098
88	031-0099
89	031-0100
90	031-0101
91	031-0102
92	031-0103
93	031-0104
94	031-0105
95	031-0106
96	031-0107
97	031-0108
98	031-0109
99	031-0110
100	031-0111
101	031-0112
102	031-0113
103	031-0114
104	031-0115
105	031-0116
106	031-0117
107	031-0118
108	031-0119
109	031-0120
110	031-0121
111	031-0122
112	031-0123
113	031-0124
114	031-0125
115	031-0126
116	031-0127
117	031-0128
118	031-0129
119	031-0130
120	031-0131
121	031-0132
122	031-0133
123	031-0134
124	031-0135
125	031-0136
126	031-0137
127	031-0138
128	031-0139
129	031-0140
130	031-0141
131	031-0142
132	031-0143
133	031-0144
134	031-0145
135	031-0146
136	031-0147
137	031-0148
138	031-0149
139	031-0150
140	031-0151
141	031-0152
142	031-0153
143	031-0154
144	031-0155
145	031-0156
146	031-0157
147	031-0158
148	031-0159
149	031-0160
150	031-0161
151	031-0162
152	031-0163
153	031-0164
154	031-0165
155	031-0166
156	031-0167
157	031-0168
158	031-0169
159	031-0170
160	031-0171
161	031-0172
162	031-0173
163	031-0174
164	031-0175
165	031-0176
166	031-0177
167	031-0178
168	031-0179
169	031-0180
170	031-0181
171	031-0182
172	031-0183
173	031-0184
174	031-0185
175	031-0186
176	031-0187
177	031-0188
178	031-0189
179	031-0190
180	031-0191
181	031-0192
182	031-0193
183	031-0194
184	031-0195
185	031-0196
186	031-0197
187	031-0198
188	031-0199
189	031-0200
190	031-0201
191	031-0202
192	031-0203
193	031-0204
194	031-0205
195	031-0206
196	031-0207
197	031-0208
198	031-0209
199	031-0210
200	031-0211
201	031-0212
202	031-0213
203	031-0214
204	031-0215
205	031-0216
206	031-0217
207	031-0218
208	031-0219
209	031-0220
210	031-0221
211	031-0222
212	031-0223
213	031-0224
214	031-0225
215	031-0226
216	031-0227
217	031-0228
218	031-0229
219	031-0230
220	031-0231
221	031-0232
222	031-0233
223	031-0234
224	031-0235
225	031-0236
226	031-0237
227	031-0238
228	031-0239
229	031-0240
230	031-0241
231	031-0242
232	031-0243
233	031-0244
234	031-0245
235	031-0246
236	031-0247
237	031-0248
238	031-0249
239	031-0250
240	031-0251
241	031-0252
242	031-0253
243	031-0254
244	031-0255
245	031-0256
246	031-0257
247	031-0258
248	031-0259
249	031-0260
250	031-0261
251	031-0262
252	031-0263
253	031-0264
254	031-0265
255	031-0266
256	031-0267
257	031-0268
258	031-0269
259	031-0270
260	031-0271
261	031-0272
262	031-0273
263	031-0274
264	031-0275
265	031-0276
266	031-0277
267	031-0278
268	031-0279
269	031-0280
270	031-0281
271	031-0282
272	031-0283
273	031-0284
274	031-0285
275	031-0286
276	031-0287
277	031-0288
278	031-0289
279	031-0290
280	031-0291
281	031-0292
282	031-0293
283	031-0294
284	031-0295
285	031-0296
286	031-0297
287	031-0298
288	031-0299
289	031-0300
290	031-0301
291	031-0302
292	031-0303
293	031-0304
294	031-0305
295	031-0306
296	031-0307
297	031-0308
298	031-0309
299	031-0310
300	031-0311
301	031-0312
302	031-0313
303	031-0314
304	031-0315
305	031-0316
306	031-0317
307	031-0318
308	031-0319
309	031-0320
310	031-0321
311	031-0322
312	031-0323
313	031-0324
314	031-0325
315	031-0326
316	031-0327
317	031-0328
318	031-0329
319	031-0330
320	031-0331
321	031-0332
322	031-0333
323	031-0334
324	031-0335
325	031-0336
326	031-0337
327	031-0338
328	031-0339
329	031-0340
330	031-0341
331	031-0342
332	031-0343
333	031-0344
334	031-0345
335	031-0346
336	031-0347
337	031-0348
338	031-0349
339	031-0350
340	031-0351
341	031-0352
342	031-0353
343	031-0354
344	031-0355
345	031-0356
346	031-0357
347	031-0358
348	031-0359
349	031-0360
350	031-0361
351	031-0362
352	031-0363
353	031-0364
354	031-0365
355	031-0366
356	031-0367
357	031-0368
358	031-0369
359	031-0370
360	031-0371
361	031-0372
362	031-0373
363	031-0374
364	031-0375
365	031-0376
366	031-0377
367	031-0378
368	031-0379
369	031-0380
370	031-0381
371	031-0382
372	031-0383
373	031-0384
374	031-0385
375	031-0386
376	031-0387
377	031-0388
378	031-0389
379	031-0390
380	031-0391
381	031-0392
382	031-0393
383	031-0394
384	031-0395
385	031-0396
386	031-0397
387	031-0398
388	031-0399
389	031-0400
390	031-0401
391	031-0402
392	031-0403
393	031-0404
394	031-0405
395	031-0406
396	031-0407
397	031-0408
398	031-0409
399	031-0410
400	031-0411
401	031-0412
402	031-0413
403	031-0414
404	031-0415
405	031-0416
406	031-0417
407	031-0418
408	031-0419
409	031-0420
410	031-0421
411	031-0422
412	031-0423
413	031-0424
414	031-0425
415	031-0426
416	031-0427
417	031-0428
418	031-0429
419	031-0430
420	031-0431
421	031-0432
422	031-0433
423	031-0434
424	031-0435
425	031-0436
426	031-0437
427	031-0438
428	031-0439
429	031-0440
430	031-0441
431	031-0442
432	031-0443
433	031-0444
434	031-0445
435	031-0446
436	031-0447
437	031-0448
438	031-0449
439	031-0450
440	031-0451
441	031-0452
442	031-0453
443	031-0454
444	031-0455
445	031-0456
446	031-0457
447	031-0458
448	031-0459
449	031-0460
450	031-0461
451	031-0462
452	031-0463
453	031-0464
454	031-0465
455	031-0466
456	031-0467
457	031-0468
458	031-0469
459	031-0470
460	031-0471
461	031-0472
462	031-0473
463	031-0474
464	031-0475
465	031-0476
466	031-0477
467	031-0478
468	031-0479
469	031-0480
470	031-0481
471	031-0482
472	031-0483
473	031-0484
474	031-0485
475	031-0486
476	031-0487
477	031-0488
478	031-0489
479	031-0490
480	031-0491
481	031-0492
482	031-0493
483	031-0494
484	031-0495
485	031-0496
486	031-0497
487	031-0498
488	031-0499
489	031-0500




ITEM NO.	DESCRIPTION
1	SEE PARTS LIST
2	SEE PARTS LIST
3	SEE PARTS LIST
4	SEE PARTS LIST
5	SEE PARTS LIST
6	SEE PARTS LIST
7	SEE PARTS LIST
8	SEE PARTS LIST
9	SEE PARTS LIST
10	SEE PARTS LIST
11	SEE PARTS LIST
12	SEE PARTS LIST
13	SEE PARTS LIST
14	SEE PARTS LIST
15	SEE PARTS LIST
16	SEE PARTS LIST
17	SEE PARTS LIST
18	SEE PARTS LIST
19	SEE PARTS LIST
20	SEE PARTS LIST
21	SEE PARTS LIST
22	SEE PARTS LIST
23	SEE PARTS LIST
24	

left blank as place
holder - to pull out page
for “B” size drawing




No.	Qty.	Part No.	Description
10	1	351-0835	Snap Btn Ø1/2 Hole Blk
9	1	003-1642	Assy Con 7P 'W' CB
8	1	436-0153	Silkscreen Pnl Fr Lincoln CB
7	1	401-0012	Knob Ø1.0 Blk
6	2	345-0004	Nut Hex Lock 4-40
5	1	341-0050	Nut 3/8-32 St
4	1	301-0023	Grommet Panel Mount
3	1	003-2001	PCB Front Panel 42V CB
2	1	003-1631	Cable Power Assy
1	1	003-1332	Assy Cable Ribbon 26C

No.	REF	Part No.	Description
25		031-0167	Test Procedure
25	A/R	823-0051	Loctite Retaining Compound
24	A/R	835-0001	Grease Mobilux 2
23	A/R	823-0043	Loctite Threadlocking
22	1	753-0062	Guide Wire Inlet Nylon
21	1	511-0206	Drive Roll
20	1	507-0130	Shaft Gear
19	1	501-0207	Bearing Idler Roll
18	1	501-0156	Bearing .875 x .38 x .28
17	1	501-0118	Bearing 1.125 x .50 x .31
16	1	437-0254	Sleeve Spring
15	1	437-0245	Cap Bearing Mold
14	1	437-0232	Arm Idler Mold Slave Motor
13	1	437-0231	Handle Mold Slave Motor
12	1	437-0230	Housing Slave Motor Mold
11	1	435-1582	Plate Locate Slave Motor
10	1	431-1576	Bolt Swing Mod
9	1	419-0211	Spring Comp OD 5/8 x 1/16
8	1	419-0085	Spring Comp 1/32 x DD .40
7	1	345-0018	Nut Lock 5-16-18
6	1	333-0006	Washer Spring Lock #8
5	1	330-0258	Scr Shldr 1/4 x 1/4 x 10-24
4	4	328-0259	Scr Shc B-32 x 1-1/8 Sll
3	2	328-0024	Scr Shc B-32 x 3/8 Sll
2	1	003-2113	Assy Torque Motor 42V
1	1	003-0176	Assy Knob Conduit
No.	Qty.	Part No.	Description



No.	Qty.	Part No.	Description
19	A/R	823-0044	Loctite Pipe Thread Sealant
18	A/R	823-0043	Loctite 242 Threadlock
17	A/R	823-0029	Noalox Pipe Thread Sealant
16	3	753-0475	Aprt 1/4npt M to 5/8-18 Fem LH
15	1	753-0466	Aprt 1/4npt Male to 5/8-18 Fem
14	1	753-0115	Bush 1/4npt Male to 1/8npt Fem
13	1	753-0114	Aprt 1/8npt x 1/8nps
12	1	753-0112	Flg 1/4npt Male to 5/8-18 Male
11	1	435-3038	Bracket Current Sensor
10	1	431-1612	Block Power CB2K
9	1	351-0066	Plug Hole Ø5/16
8	1	342-0395	Spacer Current Sensor
7	2	336-0005	Scr Pn Ph 6-32 x .375 Sll
6	1	333-0252	Wshr Lk Starin #6 St
5	1	331-0777	Washer Flat 0.391 ID x 0.875OD
4	1	331-0002	Washer Flat #6 Sll
3	1	329-0054	Scr Hex 3/8-16 x 5/8
2	1	313-0021	Stud Receiver Push-on
1	1	003-1243	Assy Sensor Posa-Start








FIG. 1

No.	Qty.	Part No.	Description
8	3	330-3063	Scr Shdr Mod .25 x .63 10-24
7	3	331-0063	Whsr Flt .255ID x .505OD
6	3	419-0059	Spr Comp .468 x .437 x .056
5	1	431-0169	Retainer Spool
4	1	431-1266	Ring Backup Plate
3	1	437-0645	Spindle Cobra Plus
2	1	501-0060	Bearing 5/8 Shaft Cobra Plus
1	1	723-0059	Ratchet Disk Brake

843-0496

Cobramatic Control Cable




FRONT VIEW
 PLUG CONNECTIONS
 STRIP OUTER JACKET BACK
 3/4" THIS END




Wire List	
Pin	Wire Color Terminal
A	Not used
B	Green Chassis
C	Red J6-3
D	Orange J6-6
E	Not used
F	Not used
G	Not used
H	Blue J6-2
I	White J5-1
J	Not used
K	Black J5-2
L	Not used
M	Not used
N	Not used

42 V Lincoln Cobramatic Control Cable 843-0496C		
No.	Qty.	Part No. Description
1	1	153-1161 Conn, 14P, X Clocked
2	1	411-0035 Clamp, Cable
3	1	301-0026 Boot, Cable, #12
4	1	301-0021 Boot, Cable, #10
5	8 ft	844-0025 Cable, 7 Conductor, 10 Ga
6	5	185-0003 Lug, Spade, Insul, 18 Ga
7	0.12 ft	739-0004 Tube, HT Shrink, Ø 1/8
8	1	185-0514 Lug, Ring, Insul, #6-18 Ga
9	1	405-0762 Label Self Laminate


071-0386 Cobramatic Block Diagram






THIS DOCUMENT IS THE PROPERTY OF MK PRODUCTS INC. IT MAY NOT BE COPIED, REPRINTED OR DISCLOSED TO A THIRD PARTY, EITHER WHOLLY OR IN PART, OR USED AS A BASIS FOR ANY OTHER PROJECT WITHOUT THE PRIOR WRITTEN CONSENT OF MK PRODUCTS INC.

COBRA I PCB ASSY	F2	F3	JP2	JP3
092-1628 (115V)	NOT INSTALLED	2A	IN	IN
092-1635 (230V)	2A	OUT	OUT	OUT
093-1721 (42V)	7A	7A	IN	OUT





COMPONENTS TO BE REPLACED BY QUALIFIED SERVICE PERSONNEL ONLY.


003-1721**Main P.C. Board Parts List**

<u>COMPONENT #</u>	<u>MK P/N</u>	<u>DESCRIPTION</u>
K1.....	157-0144.....	RELAY, 5V 500 Ohm 200MA
R3.....	115-0154.....	RESISTOR, carbon .25 watt 6.8K ohm
R4, R5.....	115-0042.....	RESISTOR, carbon .50 watt 6.8K ohm
R12, R13.....	115-0120.....	RESISTOR, carbon .25 watt 100 ohm
R6.....	115-0122.....	RESISTOR, carbon .25 watt 150 ohm
R7.....	115-0144.....	RESISTOR, carbon .25 watt 10K ohm
R8.....	115-0138.....	RESISTOR, carbon .25 watt 3.3K ohm
R9.....	115-0129.....	RESISTOR, carbon .25 watt 560 ohm
R10.....	115-0136.....	RESISTOR, carbon .25 watt 2.2K ohm
R11.....	115-0141.....	RESISTOR, carbon .25 watt 5.6K ohm
D1.....	124-0002.....	DIODE, 1 amp 800 volts (IN4006)
D6-D11.....	124-0003.....	DIODE, 2.5 amps 1KV (HEP170)
D4.....	124-0011.....	DIODE, zener 1 watt 10 volts (IN4740)
D5.....	124-0093.....	DIODE, zener 1 watt 5.1 volts (IN4733A)
Q2.....	122-0011.....	TRANSISTOR, NPN 500MA 250 volts (2N5655)
Q3.....	122-0004.....	TRANSISTOR, PNP 1 amp 50 volts (2N4249)
Q4.....	122-0013.....	TRANSISTOR, unijunction 30 volts (2N2646)
Q5.....	125-0028.....	THYRISTOR, 8 amps 400 volts (MCR218-6)
C1, C5, C8, C9.....	101-0016.....	CAPACITOR, ceramic .01uf 600VDC
C2.....	101-0013.....	CAPACITOR, Poly .047uf 200VDC
C4, C6.....	104-0002.....	CAPACITOR, tantalum 10uf 20VDC
C7.....	101-0021.....	CAPACITOR, ceramic .047uf 50VDC
RV1, RV5, RV6, RV7.....	124-0026.....	VARISTOR, 130 volts 10 amps
RV2, RV3, RV4.....	124-0028.....	VARISTOR, 56 volts 8 amps
J1.....	153-0866.....	CONNECTOR, R/A header 2 pin
J2.....	153-0923.....	TERMINAL, header 26 pin
J3.....	153-0842.....	TERMINAL, header 10 pin
J4.....	153-0844.....	TERMINAL, header 2 pin
J5, J6.....	186-0057.....	TERMINAL, strip 4 pin
J7, J8.....	153-0850.....	CONNECTOR, 6 pin
J13, J14.....	153-0867.....	CONNECTOR, R/A header 3 pin
Fuse Holder.....	152-0008.....	FUSE HOLDER, PC mount
F1.....	151-0043.....	FUSE, 3AG 4A 250V
F2, F3.....	151-0021.....	FUSE, MDA7 7A Slow Blow
K2.....	157-0022.....	RELAY, 24VAC 4PDT
K2 Socket.....	173-0026.....	SOCKET, relay 15 pin
Jumper.....	003-1307.....	JUMPER CABLE
Clip.....	157-0023.....	Relay Clip
C10.....	153-0851.....	CONNECTOR, SHDR, 2 Pin External Capacitor

003-2001

Front Panel Circuit Board

COMPONENT #	MK P/N	DESCRIPTION
R1.....	113-0062	RESISTOR, wire wound 30 ohm, 8 watt
R2.....	119-0020	POTENTIOMETER, 100K ohm
R3.....	115-0037	RESISTOR, carbon 2.7K ohm, 1/2 watt
D1.....	124-0045	LED, green
SW1	159-3587	SWITCH, DPDT, p.c. mount
SW2	159-3586	SWITCH, SPDT, p.c. mount
SW3	159-3586	SWITCH, SPDT p.c. mount
J1	153-0842	HEADER, 10pin, 90 degree
J2	153-0924	HEADER, 26pin, 90 degree
J3	153-0860	HEADER, 8pin, 90 degree
J4	153-0860	HEADER, 8pin, 90 degree



MK Warranty Repair Stations

ALABAMA

AIRGAS – SOUTH, INC.
Birmingham, AL
205/251-6835

INDUSTRIAL WELDING SERVICES
Quinton, AL
205/674-3258

WELDING ENGINEERING SUPPLY CO.
Prichard, AL
334/457-8681

WELDING MACHINE HOSPITAL
Montgomery, AL
334/832-9353

ARIZONA

PRAXAIR DISTRIBUTION, INC.
Phoenix, AZ
602/269-2151

ARKANSAS

APPLIED SERVICES, INC.
Benton, AR
501/860-6464

ARKANSAS WELDING IND'L SUPPLY
Hot Springs, AR
501/321-9922

CALIFORNIA

ADVANCED WELDER REPAIR
Commerce, CA
323/263-7383

AIRGAS – WEST, INC.
Gardena, CA
310/523-9355

ALL PHASE WELDER REPAIR & CONSULTING
Sacramento, CA
916/331-0595

ARC PRODUCTS
San Diego, CA
619/628-1022

CAL-WELD SUPPLY
Fresno, CA
209/445-0131

EMCO EAST
Concord, CA
925/798-4411

FRESNO OXYGEN
Fresno, CA
559/233-6684

INDUSTRIAL WELDER REPAIR
LaPuente, CA
626/961-7643

PRAXAIR DISTRIBUTION (ArcRent Div)
Long Beach, CA
562/427-0099

PRAXAIR DISTRIBUTION, INC.
Bakersfield, CA
661/327-5336

R. J. KATES
San Diego, CA
619/565-6960

RED-D-ARC, INC.
Carson, CA
310/233-3327

SOUTHWEST WELDER REPAIR
Fontana, CA
909/357-1661

SWEINHART ELECTRIC CO., INC.
Long Beach, CA
714/521-9100

COLORADO

AIRGAS-INTERMOUNTAIN, INC.
Colorado Springs, CO
719/473-1947

WELDERS & EQUIP. SVC. & TESTING
Littleton, CO
303/932-8755

WESTERN SLOPE WELDER REPAIR
Grand Junction, CO
970/243-9616

FLORIDA

A & I SPECIALTIES
Lehigh Acres, FL
941/368-7435

ACTION WELDING SUPPLY
Jacksonville, FL
904/786-2254

AMVEL CORPORATION
Miami, FL
305/592-5678

ELECTRICAL WELDERS SERVICE
Orlando, FL
407/999-5214

HAUN SYSTEMS REPAIR
Orlando, FL
407/872-0011

J.K. CIRCUIT TECHNOLOGY
Boynton Beach, FL
561/733-7859

ROPER ELECTRIC MOTOR SERVICE
Panama City, FL 32405
850/769-6643

SMITTY'S WELDER SERVICE
West Palm Beach, FL
561/845-1224

TRI-GAS
Miami, FL
305/592-3180

TRI-STATE SALES & LEASING
Lake City, FL
904/397-3340

GEORGIA

B&W INDUSTRIAL SERVICES
Augusta, GA
706/738-8722

MC CULLOUGH ELEC. MOTOR SVC.
Atlanta, GA
404/688-5251

HAWAII

DC ELECTRIC, INC.
Aiea, HI
808/483-8900

IDAHO

NORCO
Boise, ID
208/336-1643

ILLINOIS

INDUSTRIAL WELDER REBUILDERS
Alsip, IL
708/371-5688

PCI ENERGY SERVICES
Lake Bluff, IL
847/680-8100

RELIABLE EQUIPMENT REPAIR
Hamel, IL
618/633-5000

SCHERER INDUSTRIAL GROUP, INC.
Galesburg, IL
309/342-4125 or 888/964-3526

INDIANA

EVANSVILLE ARMATURE, INC.
Evansville, IN
812/428-9034

MODERN SUPPLY CO., INC.
Evansville, IN
812/425-9353

PRAXAIR DISTRIBUTION, INC.
Speedway, IN
317/481-4550

SUTTON-GARTEN COMPANY
Indianapolis, IN
317/264-3236

IOWA

AIRGAS NORTH CENTRAL
Des Moines, IA
515/266-1111

CEDAR RAPIDS WELDING SUPPLY
Cedar Rapids, IA
319/365-1466

ELECTRICAL ENGINEERING & EQUIPMENT
Des Moines, IA
515/266-8890

WRIGHT WELDING SUPPLY
Ft. Dodge, IA
515/576-0640

KANSAS

KANOX
Hutchinson, KS
316/665-5551

KENTUCKY

GENERAL WELDING PRODUCTS
Louisville, KY
502/635-5218

RED-D-ARC
Lexington, KY
800/245-3660

WELDING EQUIPMENT
Louisville, KY
502/636-0545

LOUISIANA

RED BALL OXYGEN CO.
Shreveport, LA
318/425-3211

MICHIGAN
ANN ARBOR WELDING SUPPLY CO.
Ypsilanti, MI
734/572-0444

APEX WELDING GASES & SUPPLY
Muskegon Heights, MI
616/722-3185

AUTOMATIC WELD
Midland, MI
517/496-9245

GREAT LAKES EQUIPMENT
Clare, MI
517/386-4630

HAMILTON ELECTRIC CO.
Saginaw, MI
517/799-6291

SAGINAW WELDING SUPPLY CO.
(FLINT WELDING SUPPLY CO.-Parent Co.)
Saginaw, MI
517/793-9696

SOUTH PARK WELDING
Marysville, MI
810/364-6521

WESAR COMPANY
Three Rivers, MI
616/483-9125

MINNESOTA

MINNEAPOLIS OXYGEN CO.
Minneapolis, MN
612/588-8855

OXYGEN SERVICE CO.
St. Paul, MN
612/644-7273

MISSOURI

CEE-KAY SUPPLY, INC.
St. Louis, MO
324/644-3500

P.G. WALKER
Springfield, MO
417/862-1745

MISSISSIPPI

NORDAN SMITH WELDING SUPPLY
Hattiesburg, MS
601/545-1800

3D SUPPLIES, INC.
Jackson, MS
601/353-3330

NEVADA

SIERRA WELDING SUPPLY CO.
Sparks, NV
775/359-0542

NEW JERSEY

INDUSTRIAL ELECTRIC SERVICE CO.
Hawthorne, NJ
973/423-1212

NEW YORK

HAUN WELDING SUPPLY
Syracuse, NY
315/463-5241

NORTH CAROLINA

HOLOX
Colfax, NC
336/996-1974

M & L WELDER REPAIR
Asheville, NC
828/250-9353

MACHINE AND WELDING SUPPLY CO.
Dunn, NC
910/892-4016

MACHINE AND WELDING SUPPLY CO.
Greenville, NC
252/752-3089

MACHINE AND WELDING SUPPLY CO.
Raleigh, NC
919/772-9500

MACHINE AND WELDING SUPPLY CO.
Winston-Salem, NC
336/723-9651

NATIONAL WELDERS SUPPLY CO.
High Point, NC
910/882-1110

NATIONAL WELDERS SUPPLY CO.
Charlotte, NC
704/392-7317

OHIO

ALBRIGHT WELDING SUPPLY
Wooster, OH
330/264-2021

ARC EQUIPMENT COMPANY
Struthers, OH
333/750-9353

ARC SERVICES, INC.
Toledo, OH
419/478-6204

BELAIR PRODUCTS, INC.
Akron, OH
330/253-3116

BIG RIVER ELECTRIC
Gallipolis, OH
740/446-4360

CnD MACHINE, INC.
Canton, OH 44706
330/478-8811

RICK'S WELDER REPAIR SERVICE
Eastlake, OH
440/269-1204

VALLEY NATIONAL GASES
Hilliard, OH
614/771-1311

VALLEY NATIONAL GASES
Lima, OH
419/228-1008

VALLEY NATIONAL GASES
Toledo, OH
419/241-9114

WELDINGHOUSE, INC.
Cleveland, OH
216/524-1955

VOLLMER ELECTRIC CO.
Columbus, OH
614/476-8800

OKLAHOMA

AIRGAS MID-SOUTH
Tulsa, OK
918/582-0885

BILL'S WELDER REPAIR
Oklahoma City, OK
405/232-4799

OKLAHOMA WELDERS SUPPLY
Madill, OK
580/795-5561

PENNSYLVANIA

GEOVIC WELDING SUPPLY
Milton, PA
717/742-9377

J.A. CUNNINGHAM EQUIPMENT, INC.
Philadelphia, PA
215/426-6650

POWER SOURCE REPAIR CO., INC.
Collingdale, PA
610/532-6460

VALLEY NATIONAL GASES
Pittsburgh, PA
412/281-1835

TENNESSEE

NEXAIR
Memphis, TN
901/523-6821

TRAMCO
Bristol, TN
423/968-4499

NATIONAL RENTRAL & REPAIR
Knoxville, TN
423/584-6390

TEXAS

AIRGAS SOUTHWEST
Houston, TX
713/462-8027

ARC CONTROL
Houston, TX
713/941-4701

DENISON OXYGEN
Denison, TX
903/465-3369

FT. WORTH WELDERS SUPPLY, INC.
Ft. Worth, TX
817/332-8696

RITE-WELD SUPPLY, INC
Fort Worth, TX
817/626-8237

UTAH

C.W. SILVER INDUSTRIAL SERVICE
Salt Lake City, UT
801/531-8888

VIRGINIA

NORFOLK WELDERS SUPPLY
Norfolk, VA
804/622-6571

WASHINGTON

AIRGAS – NORPAC, INC.
Tacoma, WA
253/473-2282

A-L WELDING PRODUCTS
Tukwila, WA
425/228-2218

AMERICAN EQUIPMENT SERVICES
Kent, WA
253/395-9947

HARRIS ELECTRIC, INC.
Seattle, WA
206/782-6668

OXARC, INC
Spokane, WA
509/535-7794

PACIFIC WELDING SUPPLIES
Tacoma, WA
253/572-5302

PRECISION WELDER AND ENGINE REPAIR
Seattle, WA
206/382-6227

WEST VIRGINIA

CARDINAL SALES & SERVICE, INC.
Clarksburg, WV
304/622-7590

WISCONSIN

PRAXAIR DISTRIBUTION, INC.
Brookfield, WI
414/938-6365

CANADA

ARC & GENERATOR REPAIR
Garson, Ontario
705/525-2141

BARRY HAMEL EQUIPMENT LTD.
Coquitlam, B.C.
604/945-9313

ELECTRO-MÉCANIK, INC.
Sainte-Foy, Quebec
418/683-1724

GPR INDUSTRIES 1994 LTD.
Grande Prairie, Alberta
780/532-5900

M.R.T. REPAIR CENTER, INC.
Montreal, Quebec
514/648-0800

LADEL Ltd.
Quebec, Canada
819/376-6577

OZARK ELECTRICAL MARINE LTD.
St. John's Newfoundland
709/726-4554

PEEL ENGINES
Mississauga, Ontario
905/670-1535

PROMOTECH électrique, Inc.
Fleurimont, Québec
819/822-2111

WELDERS SUPPLY
Winnipeg, Manitoba
204/772-9476

WELDING WIDE SERVICES, INC.
Brampton, Ontario
905/874-9992

WELDTEC
B.C., Canada
604/545-3886

INDUSTRIAL ELECTRONIC SERVICES
Calgary, Alberta
403/279-3432

CHINA

PHT GROUP COMPANY

This page intentionally blank

			
WARNING	<ul style="list-style-type: none"> ● Do not touch electrically live parts or electrode with skin or wet clothing. ● Insulate yourself from work and ground. 	<ul style="list-style-type: none"> ● Keep flammable materials away. 	<ul style="list-style-type: none"> ● Wear eye, ear and body protection.
Spanish AVISO DE PRECAUCION	<ul style="list-style-type: none"> ● No toque las partes o los electrodos bajo carga con la piel o ropa mojada. ● Aislense del trabajo y de la tierra. 	<ul style="list-style-type: none"> ● Mantenga el material combustible fuera del área de trabajo. 	<ul style="list-style-type: none"> ● Protégase los ojos, los oídos y el cuerpo.
French ATTENTION	<ul style="list-style-type: none"> ● Ne laissez ni la peau ni des vêtements mouillés entrer en contact avec des pièces sous tension. ● Isolez-vous du travail et de la terre. 	<ul style="list-style-type: none"> ● Gardez à l'écart de tout matériel inflammable. 	<ul style="list-style-type: none"> ● Protégez vos yeux, vos oreilles et votre corps.
German WARNUNG	<ul style="list-style-type: none"> ● Berühren Sie keine stromführenden Teile oder Elektroden mit Ihrem Körper oder feuchter Kleidung! ● Isolieren Sie sich von den Elektroden und dem Erdboden! 	<ul style="list-style-type: none"> ● Entfernen Sie brennbares Material! 	<ul style="list-style-type: none"> ● Tragen Sie Augen-, Ohren- und Körperschutz!
Portuguese ATENÇÃO	<ul style="list-style-type: none"> ● Não toque partes elétricas e electrodos com a pele ou roupa molhada. ● Isole-se da peça e terra. 	<ul style="list-style-type: none"> ● Mantenha inflamáveis bem guardados. 	<ul style="list-style-type: none"> ● Use proteção para a vista, ouvido e corpo.
Japanese 注意事項	<ul style="list-style-type: none"> ● 通電中の電気部品、又は溶材にヒフやぬれた布で触れないこと。 ● 施工物やアースから身体が絶縁されている様にして下さい。 	<ul style="list-style-type: none"> ● 燃えやすいものの側での溶接作業は絶対にはなりません。 	<ul style="list-style-type: none"> ● 目、耳及び身体に保護具をして下さい。
Chinese 警告	<ul style="list-style-type: none"> ● 皮肤或湿衣物切勿接触带电部件及焊条。 ● 使你自已與地面和工件絕緣。 	<ul style="list-style-type: none"> ● 把一切易燃物品移離工作場所。 	<ul style="list-style-type: none"> ● 佩戴眼、耳及身體勞動保護用具。
Korean 위험	<ul style="list-style-type: none"> ● 전도체나 용접봉을 젖은 형집 또는 피부로 절대 접촉하지 마십시오. ● 모재와 접지를 접촉하지 마십시오. 	<ul style="list-style-type: none"> ● 인화성 물질을 접근시키지 마십시오. 	<ul style="list-style-type: none"> ● 눈, 귀와 몸에 보호장구를 착용하십시오.
Arabic تحذير	<ul style="list-style-type: none"> ● لا تلمس الاجزاء التي يسري فيها التيار الكهربائي أو الأقطاب بجهد الجسم أو بالملابس المبللة بالماء. ● ضع عازلا على جسمك خلال العمل. 	<ul style="list-style-type: none"> ● ضع المواد القابلة للاشتعال في مكان بعيد. 	<ul style="list-style-type: none"> ● ضع أدوات وملابس واقية على عينيك وأذنيك وجسمك.

READ AND UNDERSTAND THE MANUFACTURER'S INSTRUCTION FOR THIS EQUIPMENT AND THE CONSUMABLES TO BE USED AND FOLLOW YOUR EMPLOYER'S SAFETY PRACTICES.

SE RECOMIENDA LEER Y ENTENDER LAS INSTRUCCIONES DEL FABRICANTE PARA EL USO DE ESTE EQUIPO Y LOS CONSUMIBLES QUE VA A UTILIZAR, SIGA LAS MEDIDAS DE SEGURIDAD DE SU SUPERVISOR.

LISEZ ET COMPRENEZ LES INSTRUCTIONS DU FABRICANT EN CE QUI REGARDE CET EQUIPMENT ET LES PRODUITS A ETRE EMPLOYES ET SUIVEZ LES PROCEDURES DE SECURITE DE VOTRE EMPLOYEUR.

LESEN SIE UND BEFOLGEN SIE DIE BETRIEBSANLEITUNG DER ANLAGE UND DEN ELEKTRODENEINSATZ DES HERSTELLERS. DIE UNFALLVERHÜTUNGSVORSCHRIFTEN DES ARBEITGEBERS SIND EBENFALLS ZU BEACHTEN.

			
<ul style="list-style-type: none"> ● Keep your head out of fumes. ● Use ventilation or exhaust to remove fumes from breathing zone. 	<ul style="list-style-type: none"> ● Turn power off before servicing. 	<ul style="list-style-type: none"> ● Do not operate with panel open or guards off. 	WARNING
<ul style="list-style-type: none"> ● Los humos fuera de la zona de respiración. ● Mantenga la cabeza fuera de los humos. Utilice ventilación o aspiración para gases. 	<ul style="list-style-type: none"> ● Desconectar el cable de alimentación de poder de la máquina antes de iniciar cualquier servicio. 	<ul style="list-style-type: none"> ● No operar con panel abierto o guardas quitadas. 	Spanish AVISO DE PRECAUCION
<ul style="list-style-type: none"> ● Gardez la tête à l'écart des fumées. ● Utilisez un ventilateur ou un aspirateur pour ôter les fumées des zones de travail. 	<ul style="list-style-type: none"> ● Débranchez le courant avant l'entretien. 	<ul style="list-style-type: none"> ● N'opérez pas avec les panneaux ouverts ou avec les dispositifs de protection enlevés. 	French ATTENTION
<ul style="list-style-type: none"> ● Vermeiden Sie das Einatmen von Schweißrauch! ● Sorgen Sie für gute Be- und Entlüftung des Arbeitsplatzes! 	<ul style="list-style-type: none"> ● Strom vor Wartungsarbeiten abschalten! (Netzstrom völlig öffnen; Maschine anhalten!) 	<ul style="list-style-type: none"> ● Anlage nie ohne Schutzgehäuse oder Innenschutzverkleidung in Betrieb setzen! 	German WARNUNG
<ul style="list-style-type: none"> ● Mantenha seu rosto da fumaça. ● Use ventilação e exaustão para remover fumo da zona respiratória. 	<ul style="list-style-type: none"> ● Não opere com as tampas removidas. ● Desligue a corrente antes de fazer serviço. ● Não toque as partes elétricas nuas. 	<ul style="list-style-type: none"> ● Mantenha-se afastado das partes moventes. ● Não opere com os painéis abertos ou guardas removidas. 	Portuguese ATENÇÃO
<ul style="list-style-type: none"> ● ヒュームから頭を離すようにして下さい。 ● 換気や排煙に十分留意して下さい。 	<ul style="list-style-type: none"> ● メンテナンス・サービスに取りかかる際には、まず電源スイッチを必ず切して下さい。 	<ul style="list-style-type: none"> ● パネルやカバーを取り外したまま機械操作をしないで下さい。 	Japanese 注意事項
<ul style="list-style-type: none"> ● 頭部遠離煙霧。 ● 在呼吸區使用通風或排風器除煙。 	<ul style="list-style-type: none"> ● 維修前切斷電源。 	<ul style="list-style-type: none"> ● 儀表板打開或沒有安全罩時不準作業。 	Chinese 警告
<ul style="list-style-type: none"> ● 얼굴로부터 용접가스를 멀리하십시오. ● 호흡지역으로부터 용접가스를 제거하기 위해 가스제거기나 통풍기를 사용하십시오. 	<ul style="list-style-type: none"> ● 보수전에 전원을 차단하십시오. 	<ul style="list-style-type: none"> ● 판넬이 열린 상태로 작동하지 마십시오. 	Korean 위험
<ul style="list-style-type: none"> ● بعد رأسك بعيداً عن الدخان. ● استعمل التهوية أو جهاز ضغط الدخان للخارج لكي تبعد الدخان عن المنطقة التي تتنفس فيها. 	<ul style="list-style-type: none"> ● قطع التيار الكهربائي قبل القيام بأية صيانة. 	<ul style="list-style-type: none"> ● لا تشغيل هذا الجهاز اذا كانت الاغطية الحديدية الواقية ليست عليه. 	Arabic تحذير

LEIA E COMPREENDA AS INSTRUÇÕES DO FABRICANTE PARA ESTE EQUIPAMENTO E AS PARTES DE USO, E SIGA AS PRÁTICAS DE SEGURANÇA DO EMPREGADOR.

使う機械や溶材のメーカーの指示書をよく読み、まず理解して下さい。そして貴社の安全規定に従って下さい。

請詳細閱讀並理解製造廠提供的說明以及應該使用的銀焊材料，並請遵守貴方的有關勞動保護規定。

이 제품에 동봉된 작업지침서를 숙지하시고 귀사의 작업자 안전수칙을 준수하시기 바랍니다.

اقرأ بتمعن وافهم تعليمات المصنع المنتج لهذه المعدات والمواد قبل استعمالها واتبع تعليمات الوقاية لصاحب العمل.

LIMITED WARRANTY

Effective January 1, 2000

This warranty supersedes all previous MK Products warranties and is exclusive, with no other guarantees or warranties expressed or implied.

LIMITED WARRANTY - MK Products, Inc., Irvine, California warrants that all new and unused equipment furnished by MK Products is free from defect in workmanship and material as of the time and place of delivery by MK Products. No warranty is made by MK Products with respect to trade accessories or other items manufactured by others. Such trade accessories and other items are sold subject to the warranties of their respective manufacturers, if any.

MK Products' warranty does not apply to components having normal useful life of less than one (1) year, such as relay points, wire conduit, tungsten, and welding torch parts that come in contact with the welding wire, including gas cups, gas cup insulators, and contact tips where failure does not result from defect in workmanship or material.

In the case of MK Products' breach of warranty or any other duty with respect to the quality of any goods, the exclusive remedies therefore shall be at MK Products' option:

- (1) repair
- (2) replacement
- (3) where authorized in writing by MK Products, the reasonable cost of repair or replacement at our Irvine, California plant; or
- (4) payment of or credit for the purchase price (less reasonable depreciation based upon actual use) upon return of the goods at customer's risk and expense. Upon receipt of notice of apparent defect or failure, MK Products shall instruct the claimant on the warranty claim procedures to be followed.

As a matter of general policy only, MK Products may honor an original user's warranty claims on warranted equipment in the event of failure resulting from a defect within the following periods from the date of delivery of equipment to the original user:

1. **Torches and Weldheads 1 year**
2. **All Other Equipment 3 years**
3. **Repairs 90 days**



16882 Armstrong Ave.
Irvine, CA 92606
Tel (949)863-1234
Fax (949)474-1428
sales@mkprod.com

Classification of any item into the foregoing categories shall be at the sole discretion of MK Products. Notification of any failure must be made in writing within 30 days of such failure.

A copy of the invoice showing the date of sale must accompany products returned for warranty repair or replacement.

All equipment returned to MK Products for service must be properly packaged to guard against damage from shipping. MK Products will not be responsible for any damages resulting from shipping.

Normal surface transportation charges (both ways) for products returned for warranty repair or replacement will be borne by MK Products, except for products sold to foreign markets.

ANY EXPRESS WARRANTY NOT PROVIDED HEREIN AND ANY IMPLIED WARRANTY, GUARANTY, OR REPRESENTATION AS TO PERFORMANCE, AND ANY REMEDY FOR BREACH OF CONTRACT WHICH, BUT FOR THIS PROVISION, MIGHT ARISE BY IMPLICATION, OPERATION OF LAW, CUSTOM OF TRADE, OR COURSE OF DEALING, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR OF FITNESS FOR PARTICULAR PURPOSE, WITH RESPECT TO ANY AND ALL EQUIPMENT FURNISHED BY MK PRODUCTS, IS EXCLUDED AND DISCLAIMED BY MK PRODUCTS.

EXCEPT AS EXPRESSLY PROVIDED BY MK PRODUCTS IN WRITING, MK PRODUCTS ARE INTENDED FOR ULTIMATE PURCHASE BY COMMERCIAL/INDUSTRIAL USERS AND FOR OPERATION BY PERSONS TRAINED AND EXPERIENCED IN THE USE AND MAINTENANCE OF WELDING EQUIPMENT AND NOT FOR CONSUMERS OR CONSUMER USE. MK PRODUCTS WARRANTIES DO NOT EXTEND TO, AND NO RE-SELLER IS AUTHORIZED TO EXTEND MK PRODUCTS' WARRANTIES TO ANY CONSUMER.

FORM : LW-9MK
DATE : January 1, 2000