#### November, 2006

# RED-D-ARC DC-400

For use with machines having Code Numbers: 10648; 10699; 11038; 11085 and

11128; 11347



## OPERATOR'S MANUAL

### Red-D-Arc Spec-Built Welding Equipment

This **RED-D-ARC** welder is built to **RED-D-ARC Extreme Duty** design specifications by Lincoln Electric.

### Safety Depends on You

This welder is designed and built with safety in mind.

However, your overall safety can be increased by proper installation ... and thoughtful operation on your part.

DO NOT INSTALL, OPERATE OR REPAIR THIS EQUIPMENT WITHOUT READING THIS MANUAL AND THE SAFETY PRECAUTIONS CONTAINED THROUGHOUT.

And, most importantly, think before you act and be careful.

1-800-245-3660

### **A** WARNING



Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

The Above For Diesel Engines

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

The Above For Gasoline Engines

ARC WELDING CAN BE HAZARDOUS. PROTECT YOURSELF AND OTHERS FROM POSSIBLE SERIOUS INJURY OR DEATH. KEEP CHILDREN AWAY. PACEMAKER WEARERS SHOULD CONSULT WITH THEIR DOCTOR BEFORE OPERATING.

Read and understand the following safety highlights. For additional safety information, it is strongly recommended that you purchase a copy of "Safety in Welding & Cutting - ANSI Standard Z49.1" from the American Welding Society, P.O. Box 351040, Miami, Florida 33135 or CSA Standard W117.2-1974. A Free copy of "Arc Welding Safety" booklet E205 is available from the Lincoln Electric Company, 22801 St. Clair Avenue, Cleveland, Ohio 44117-1199.

BE SURE THAT ALL INSTALLATION, OPERATION, MAINTENANCE AND REPAIR PROCEDURES ARE PERFORMED ONLY BY QUALIFIED INDIVIDUALS.



# FOR ENGINE powered equipment.

 Turn the engine off before troubleshooting and maintenance work unless the maintenance work requires it to be running.



 Doperate engines in open, well-ventilated areas or vent the engine exhaust fumes outdoors.



- 1.c. Do not add the fuel near an open flame welding arc or when the engine is running. Stop the engine and allow it to cool before refueling to prevent spilled fuel from vaporizing on contact with hot engine parts and igniting. Do not spill fuel when filling tank. If fuel is spilled, wipe it up and do not start engine until fumes have been eliminated.
- 1.d. Keep all equipment safety guards, covers and devices in position and in good repair. Keep hands, hair, clothing and tools away from V-belts, gears, fans and all other moving parts when starting, operating or repairing equipment.
- 1.e. In some cases it may be necessary to remove safety guards to perform required maintenance. Remove guards only when necessary and replace them when the maintenance requiring their removal is complete. Always use the greatest care when working near moving parts.



- 1.f. Do not put your hands near the engine fan. Do not attempt to override the governor or idler by pushing on the throttle control rods while the engine is running.
- 1.g. To prevent accidentally starting gasoline engines while turning the engine or welding generator during maintenance work, disconnect the spark plug wires, distributor cap or magneto wire as appropriate.



 To avoid scalding, do not remove the radiator pressure cap when the engine is hot



# ELECTRIC AND MAGNETIC FIELDS may be dangerous

- 2.a. Electric current flowing through any conductor causes localized Electric and Magnetic Fields (EMF). Welding current creates EMF fields around welding cables and welding machines
- 2.b. EMF fields may interfere with some pacemakers, and welders having a pacemaker should consult their physician before welding.
- Exposure to EMF fields in welding may have other health effects which are now not known.
- 2.d. All welders should use the following procedures in order to minimize exposure to EMF fields from the welding circuit:
  - 2.d.1. Route the electrode and work cables together Secure them with tape when possible.
  - 2.d.2. Never coil the electrode lead around your body.
  - 2.d.3. Do not place your body between the electrode and work cables. If the electrode cable is on your right side, the work cable should also be on your right side.
  - 2.d.4. Connect the work cable to the workpiece as close as possible to the area being welded.
  - 2.d.5. Do not work next to welding power source.

Mar '95



### **ELECTRIC SHOCK can**

### kill.

3.a. The electrode and work (or ground) circuits are electrically "hot" when the welder is on. Do not touch these "hot" parts with your bare skin or wet clothing. Wear dry, hole-free gloves to insulate hands.

3.b. Insulate yourself from work and ground using dry insulation. Make certain the insulation is large enough to cover your full area of physical contact with work and ground.

In addition to the normal safety precautions, if welding must be performed under electrically hazardous conditions (in damp locations or while wearing wet clothing; on metal structures such as floors, gratings or scaffolds; when in cramped positions such as sitting, kneeling or lying, if there is a high risk of unavoidable or accidental contact with the workpiece or ground) use the following equipment:

- Semiautomatic DC Constant Voltage (Wire) Welder.
- DC Manual (Stick) Welder.
- AC Welder with Reduced Voltage Control.
- 3.c. In semiautomatic or automatic wire welding, the electrode, electrode reel, welding head, nozzle or semiautomatic welding gun are also electrically "hot".
- 3.d. Always be sure the work cable makes a good electrical connection with the metal being welded. The connection should be as close as possible to the area being welded.
- 3.e. Ground the work or metal to be welded to a good electrical (earth) ground.
- 3.f. Maintain the electrode holder, work clamp, welding cable and welding machine in good, safe operating condition. Replace damaged insulation.
- 3.g. Never dip the electrode in water for cooling.
- 3.h. Never simultaneously touch electrically "hot" parts of electrode holders connected to two welders because voltage between the two can be the total of the open circuit voltage of both welders.
- 3.i. When working above floor level, use a safety belt to protect yourself from a fall should you get a shock.
- 3.j. Also see Items 6.c. and 8.



### ARC RAYS can burn.

- 4.a. Use a shield with the proper filter and cover plates to protect your eyes from sparks and the rays of the arc when welding or observing open arc welding. Headshield and filter lens should conform to ANSI Z87. I standards.
- 4.b. Use suitable clothing made from durable flame-resistant material to protect your skin and that of your helpers from the arc rays.
- 4.c. Protect other nearby personnel with suitable, non-flammable screening and/or warn them not to watch the arc nor expose themselves to the arc rays or to hot spatter or metal.



# FUMES AND GASES can be dangerous.

5.a. Welding may produce fumes and gases hazardous to health. Avoid breathing these fumes and gases. When welding, keep your head out of the fume. Use enough ventilation and/or exhaust at the arc to keep

fumes and gases away from the breathing zone. When welding with electrodes which require special ventilation such as stainless or hard facing (see instructions on container or MSDS) or on lead or cadmium plated steel and other metals or coatings which produce highly toxic fumes, keep exposure as low as possible and below Threshold Limit Values (TLV) using local exhaust or mechanical ventilation. In confined spaces or in some circumstances, outdoors, a respirator may be required. Additional precautions are also required when welding on galvanized steel.

- 5. b. The operation of welding fume control equipment is affected by various factors including proper use and positioning of the equipment, maintenance of the equipment and the specific welding procedure and application involved. Worker exposure level should be checked upon installation and periodically thereafter to be certain it is within applicable OSHA PEL and ACGIH TLV limits.
- 5.c. Do not weld in locations near chlorinated hydrocarbon vapors coming from degreasing, cleaning or spraying operations. The heat and rays of the arc can react with solvent vapors to form phosgene, a highly toxic gas, and other irritating products.
- 5.d. Shielding gases used for arc welding can displace air and cause injury or death. Always use enough ventilation, especially in confined areas, to insure breathing air is safe.
- 5.e. Read and understand the manufacturer's instructions for this equipment and the consumables to be used, including the material safety data sheet (MSDS) and follow your employer's safety practices. MSDS forms are available from your welding distributor or from the manufacturer.
- 5.f. Also see item 1.b.

AUG 06



# WELDING SPARKS can cause fire or explosion.

6.a. Remove fire hazards from the welding area. If this is not possible, cover them to prevent the welding sparks from starting a fire. Remember that welding sparks and hot

materials from welding can easily go through small cracks and openings to adjacent areas. Avoid welding near hydraulic lines. Have a fire extinguisher readily available.

- 6.b. Where compressed gases are to be used at the job site, special precautions should be used to prevent hazardous situations. Refer to "Safety in Welding and Cutting" (ANSI Standard Z49.1) and the operating information for the equipment being used.
- 6.c. When not welding, make certain no part of the electrode circuit is touching the work or ground. Accidental contact can cause overheating and create a fire hazard.
- 6.d. Do not heat, cut or weld tanks, drums or containers until the proper steps have been taken to insure that such procedures will not cause flammable or toxic vapors from substances inside. They can cause an explosion even though they have been "cleaned". For information, purchase "Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping That Have Held Hazardous Substances", AWS F4.1 from the American Welding Society (see address above).
- 6.e. Vent hollow castings or containers before heating, cutting or welding. They may explode.
- 6.f. Sparks and spatter are thrown from the welding arc. Wear oil free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes and a cap over your hair. Wear ear plugs when welding out of position or in confined places. Always wear safety glasses with side shields when in a welding area.
- 6.g. Connect the work cable to the work as close to the welding area as practical. Work cables connected to the building framework or other locations away from the welding area increase the possibility of the welding current passing through lifting chains, crane cables or other alternate circuits. This can create fire hazards or overheat lifting chains or cables until they fail.
- 6.h. Also see item 1.c.



# CYLINDER may explode if damaged.

- 7.a. Use only compressed gas cylinders containing the correct shielding gas for the process used and properly operating regulators designed for the gas and pressure used. All hoses, fittings, etc. should be suitable for the application and maintained in good condition.
- 7.b. Always keep cylinders in an upright position securely chained to an undercarriage or fixed support.
- 7.c. Cylinders should be located:
  - Away from areas where they may be struck or subjected to physical damage.
  - A safe distance from arc welding or cutting operations and any other source of heat, sparks, or flame.
- 7.d. Never allow the electrode, electrode holder or any other electrically "hot" parts to touch a cylinder.
- 7.e. Keep your head and face away from the cylinder valve outlet when opening the cylinder valve.
- 7.f. Valve protection caps should always be in place and hand tight except when the cylinder is in use or connected for use
- 7.g. Read and follow the instructions on compressed gas cylinders, associated equipment, and CGA publication P-I, "Precautions for Safe Handling of Compressed Gases in Cylinders," available from the Compressed Gas Association 1235 Jefferson Davis Highway, Arlington, VA 22202.



# FOR ELECTRICALLY powered equipment.

- 8.a. Turn off input power using the disconnect switch at the fuse box before working on the equipment.
- 8.b. Install equipment in accordance with the U.S. National Electrical Code, all local codes and the manufacturer's recommendations.
- 8.c. Ground the equipment in accordance with the U.S. National Electrical Code and the manufacturer's recommendations.

Mar '95

### PRÉCAUTIONS DE SÛRETÉ

Pour votre propre protection lire et observer toutes les instructions et les précautions de sûreté specifiques qui parraissent dans ce manuel aussi bien que les précautions de sûreté générales suivantes:

#### Sûreté Pour Soudage A L'Arc

- 1. Protegez-vous contre la secousse électrique:
  - a. Les circuits à l'électrode et à la piéce sont sous tension quand la machine à souder est en marche. Eviter toujours tout contact entre les parties sous tension et la peau nue ou les vétements mouillés. Porter des gants secs et sans trous pour isoler les mains.
  - b. Faire trés attention de bien s'isoler de la masse quand on soude dans des endroits humides, ou sur un plancher metallique ou des grilles metalliques, principalement dans les positions assis ou couché pour lesquelles une grande partie du corps peut être en contact avec la masse.
  - c. Maintenir le porte-électrode, la pince de masse, le câble de soudage et la machine à souder en bon et sûr état defonctionnement.
  - d.Ne jamais plonger le porte-électrode dans l'eau pour le refroidir.
  - e. Ne jamais toucher simultanément les parties sous tension des porte-électrodes connectés à deux machines à souder parce que la tension entre les deux pinces peut être le total de la tension à vide des deux machines.
  - f. Si on utilise la machine à souder comme une source de courant pour soudage semi-automatique, ces precautions pour le porte-électrode s'applicuent aussi au pistolet de soudage.
- Dans le cas de travail au dessus du niveau du sol, se protéger contre les chutes dans le cas ou on recoit un choc. Ne jamais enrouler le câble-électrode autour de n'importe quelle partie du corps.
- Un coup d'arc peut être plus sévère qu'un coup de soliel, donc:
  - a. Utiliser un bon masque avec un verre filtrant approprié ainsi qu'un verre blanc afin de se protéger les yeux du rayonnement de l'arc et des projections quand on soude ou quand on regarde l'arc.
  - b. Porter des vêtements convenables afin de protéger la peau de soudeur et des aides contre le rayonnement de l'arc.
  - c. Protéger l'autre personnel travaillant à proximité au soudage à l'aide d'écrans appropriés et non-inflammables.
- 4. Des gouttes de laitier en fusion sont émises de l'arc de soudage. Se protéger avec des vêtements de protection libres de l'huile, tels que les gants en cuir, chemise épaisse, pantalons sans revers, et chaussures montantes.

- Toujours porter des lunettes de sécurité dans la zone de soudage. Utiliser des lunettes avec écrans lateraux dans les zones où l'on pique le laitier.
- Eloigner les matériaux inflammables ou les recouvrir afin de prévenir tout risque d'incendie dû aux étincelles.
- Quand on ne soude pas, poser la pince à une endroit isolé de la masse. Un court-circuit accidental peut provoquer un échauffement et un risque d'incendie.
- 8. S'assurer que la masse est connectée le plus prés possible de la zone de travail qu'il est pratique de le faire. Si on place la masse sur la charpente de la construction ou d'autres endroits éloignés de la zone de travail, on augmente le risque de voir passer le courant de soudage par les chaines de levage, câbles de grue, ou autres circuits. Cela peut provoquer des risques d'incendie ou d'echauffement des chaines et des câbles jusqu'à ce qu'ils se rompent.
- Assurer une ventilation suffisante dans la zone de soudage.
   Ceci est particuliérement important pour le soudage de tôles galvanisées plombées, ou cadmiées ou tout autre métal qui produit des fumeés toxiques.
- 10. Ne pas souder en présence de vapeurs de chlore provenant d'opérations de dégraissage, nettoyage ou pistolage. La chaleur ou les rayons de l'arc peuvent réagir avec les vapeurs du solvant pour produire du phosgéne (gas fortement toxique) ou autres produits irritants.
- Pour obtenir de plus amples renseignements sur la sûreté, voir le code "Code for safety in welding and cutting" CSA Standard W 117.2-1974.

### PRÉCAUTIONS DE SÛRETÉ POUR LES MACHINES À SOUDER À TRANSFORMATEUR ET À REDRESSEUR

- Relier à la terre le chassis du poste conformement au code de l'électricité et aux recommendations du fabricant. Le dispositif de montage ou la piece à souder doit être branché à une bonne mise à la terre.
- 2. Autant que possible, l'installation et l'entretien du poste seront effectués par un électricien qualifié.
- 3. Avant de faires des travaux à l'interieur de poste, la debrancher à l'interrupteur à la boite de fusibles.
- Garder tous les couvercles et dispositifs de sûreté à leur place.

V

# Thank You —

for selecting a **QUALITY** product. We want you to take pride in operating this product ••• as much pride as we have in bringing this product to you!

### Please Examine Carton and Equipment For Damage Immediately

When this equipment is shipped, title passes to the purchaser upon receipt by the carrier. Consequently, Claims for material damaged in shipment must be made by the purchaser against the transportation company at the time the shipment is received.

Please record your equipment identification information below for future reference. This information can be found on your machine nameplate.

Product
Model Number
Code Number or Date Code
Serial Number
Date Purchased
Where Purchased
Whenever you request replacement parts or information on this equipment, always supply the information you

Whenever you request replacement parts or information on this equipment, always supply the information you have recorded above. The code number is especially important when identifying the correct replacement parts.

### **On-Line Product Registration**

- Register your machine with Lincoln Electric either via fax or over the Internet.
  - For faxing: Complete the form on the back of the warranty statement included in the literature packet accompanying this machine and fax the form per the instructions printed on it.
- For On-Line Registration: Go to our **WEB SITE at www.lincolnelectric.com.** Choose "Quick Links" and then "Product Registration". Please complete the form and submit your registration.

**Read this Operators Manual completely** before attempting to use this equipment. Save this manual and keep it handy for quick reference. Pay particular attention to the safety instructions we have provided for your protection. The level of seriousness to be applied to each is explained below:

### **A** WARNING

This statement appears where the information **must** be followed **exactly** to avoid **serious personal injury** or **loss of life**.

### **A** CAUTION

This statement appears where the information **must** be followed to avoid **minor personal injury** or **damage to this equipment**.

Installation	
Technical Specifications	
Safety Precautions	
Location	
Input Power Connection	
Output Connections	
Output Cables	
Remote Output Control	
Remote Control Adapter Cable (K864)	
Amptrol Adapter Cable (K843)	
(K843)Amptrol Adapter Installation Instructions	
Hi-Frequency Kit	
Amptrol Adapter for K799 Hi-Frequency Kit	
Multiprocess Switch	
Capacitor Discharge Circuit	
UndercarriagesInstallation of Equipment Required for Recommended Processes	
Connection of DC-400 to LN-22 or LN25	
Auxiliary Power Connections	
Remote Control Connections	
Output Connections	
Input Connections	
Input Line Voltage Compensation	
Solid State Output Control	
Solid State Control System	
Machine Cooling	
Case Features	
Arc Force Selector	
Arc Control	
Mode Switch	
Stick Welding	
Paralleling	
Diode Option	
Machine & Circuit Protection	A-7
Multiprocess Switch	A-8
Operation	
Safety Precautions	
Meanings of Graphic Symbols	
General Machine Description	
Recommended Processes and Equipment	
Operational Features & Controls	
Power Source Operation	B-6 tnru B-8
Accessories	Section C
Factory or Field Installed Options	
Diode Option	
Multi-Process Switch	
Field Installed Options	
Remote Output Control	
Amptrol Adapter Cable	
Remote Control Adapter Cable	
Multi-Process Switch	
Capacitor Discharge Circuit	
Hi-Frequency Kit	
Optional Amptrol Adapter for Hi-Frequency Kit	
Undercarriages	

## TABLE OF CONTENTS

Parts Lists	P355, P239
Wiring Diagrams and Dimension Print	Section F
Troubleshooting Guide	E-2 thru E-6
How to Use Troubleshooting Guide	E-1
Troubleshooting	Section E
Routine Maintenance	D-1
Safety Precautions	D-1
Maintenance	Section D
	Page

### **TECHNICAL SPECIFICATIONS - DC-400**

	INPUT-THREE PH	IAGE ONE!	
Standard	Ir	nput Current at Rated Ou	tput (CVI)
Voltage Frequency	100% Duty Cycle	60% Duty Cycle <sup>(4)</sup>	50% Duty Cycle
230/460/575V/60Hz	400Amps/36V 78/39/31Amps	450Amps/38V 83/42/33Amps	500Amps/40V 84/42/34Amps
	RATED OU	TPUT	
Duty Cycle (1)	Amps	Volts at Rate	d Amps

	RAIED OUT	וטי	
Duty Cycle (1)	Amps	Volts at Rated Amps	
100%	400	36	
60%	450	38	
50%	500	40	

OUTPUT				
OUTPUT	MAXIMUM OPEN CIRCUIT VOLTAGE	AUXILIARY POWER		
Min60A 12V CV(22V CC) Max500A 42V (CC, CV)	57V. (CC) 45.5V. (CVI)	115 VAC, 15 AMPS 42 VAC, 10 AMPS		

RECOMMENDED INPUT WIRE AND FUSE SIZES FOR MAXIMUM RATED OUTPUT				
INPUT	INPUT AMPERE	TYPE 75°C COPPER	TYPE 75°C GROUND	TYPE 75°C
VOLTAGE /	RATING ON	WIRE IN CONDUIT	WIRE IN CONDUIT	SUPER LAG
FREQUENCY	NAMEPLATE	AWG (IEC)	AWG (IEC)	OR BREAKER
	@ 100%	SIZES (mm <sup>2</sup> )	SIZES (mm <sup>2</sup> )	SIZE(AMPS)
	Duty Cycle	40°C(104°F)	, ,	, ,
230/60HZ 460/60HZ 575/60HZ	78 39 31	3(25) 8(10) 10(6)	6(10) 10(6) 10(6)	125 60 50

PHYSICAL DIMENSIONS				
HEIGHT	WIDTH	DEPTH	WEIGHT	
27.50 in.	22.25 in.	32.0 in.	473 lbs.	
699 mm	565 mm	988 mm	215 kg.	

<sup>(1)</sup> Based upon 10 minute time period (i.e., for 60% duty cycle, it is 6 minutes on an 4 minutes off).



### SAFETY PRECAUTIONS

Read this entire section of operating instructions before operating the machine.

**ELECTRIC SHOCK can kill.** 



- Do not touch electrically live parts or electrodes with your skin or wet clothing.
- Insulate yourself from the work and ground.
- Always wear dry insulating gloves.



FUMES AND GASES can be dangerous.

- Keep your head out of fumes.
- Use ventilation or exhaust to remove fumes from breathing zone.



WELDING SPARKS can cause fire or explosion.

- Keep flammable material away.
- Do not weld on containers that have held combustibles.



ARC RAYS can burn.

Wear eye, ear, and body protection.

Observe additional guidelines detailed in the beginning of this manual.

### LOCATION

The machine should be located in a clean dry place where there is free circulation of clean air such that air movement in through the front and out through the back will not be restricted. Dirt and dust that can be drawn into the machine should be kept to a minimum. Failure to observe these precautions can result in excessive operating temperatures and nuisance shutdown of the machine.

### **A** CAUTION

### DO NOT MOUNT OVER COMBUSTIBLE SURFACES.

Where there is a combustible surface directly under stationary or fixed electrical equipment, the surface shall be covered with a steel plate at least .06"(1.6mm) thick, which shall extend not more than 5.90"(150mm) beyond the equipment on all sides.

### INPUT POWER CONNECTIONS

By removing the rear access panel the three phase input power is connected to the three line terminals on the input contactor, and the earth grounding lead to the grounding terminal on the input box floor marked with the symbol (). Install and reconnect panel for the proper input voltage per the diagram pasted inside the access panel cover. See Technical Data on A-1.

### **OUTPUT CABLE CONNECTIONS**

The output leads are connected to the output terminals marked "+" and "-". They are located at the lower right and lower left corners of the front panel. Strain relief for the electrode and work cables is provided by routing the leads through the rectangular holes in the base before connecting them to the output terminals. Lift the output stud cover to gain access to the output studs. Lower stud cover after connecting output leads.

### **OUTPUT CABLES**

Installation of Field Installed Options
CABLE SIZES FOR COMBINED LENGTH OF ELECTRODE AND GROUND CABLE

	MACHINE LOAD		
CABLE LENGTHS	400A (100% DUTY CYCLE)	500A (50% DUTY CYCLE)	
UP TO 50 ft (15m) 50 to 100 ft (15-30 m) 100-150 ft (30-46 m) 150-200 ft (46-61 m) 200-250 ft (67-76 m)	3/0 85 mm <sup>(2)</sup> 3/0 85 mm <sup>(2)</sup> 3/0 85 mm <sup>(2)</sup> 3/0 85 mm <sup>(2)</sup> 4/0 107 mm <sup>(2)</sup>	2/0 87 mm <sup>(2)</sup> 2/0 67 mm <sup>(2)</sup> 3/0 85 mm <sup>(2)</sup> 3/0 85 mm <sup>(2)</sup> 4/0 107 mm <sup>(2)</sup>	


### REMOTE OUTPUT CONTROL

(K857 WITH K864 ADAPTER OR K775)

The K857 has a 6-pin MS-style connector. The K857 requires a K864 adapter cable which connects to the 14-pin connector on the machine.

An optional "remote output control" is available. This is the same remote control that is used on the Lincoln R3R, and DC-600 power sources (K775). The K775 consists of a control box with 28 ft (8.5m) of four conductor cable. This connects to terminals 75, 76, and 77 on the terminal strip and the case grounding screw so marked with the symbol — on the machine. These terminals are located behind the control panel on the front of the power source. This control will give the same control as the output control on the machine.

### **REMOTE CONTROL ADAPTER CABLE (K864)**



A "V" cable 12" (.30m) long to connect a K857 Remote Control, K963 Hand Amptrol or K870 Foot Amptrol (6-pin connector) with a wire-feeder (14-pin connector) and the machine (14-pin connector). If a remote control or amptrol is used alone the wire-feeder connection is then not used.

### **A** WARNING



**ELECTRIC SHOCK can kill.** 

 Turn the power switch of the welding power source "OFF" before installing plugs on cables or when connecting or disconnecting plugs to welding power source.

### AMPTROL™ ADAPTER CABLE (K843)

A five wire cable, 12" (.30m) long, is available for easy connection of standard K963 Hand Amptrol or K870 Foot Amptrol. The cable has a 6-pin MS-style connector which connects to the Amptrol and terminals which connect to 75, 76 and 77 on the machine terminal strip and to the case grounding screw. The Amptrol will control the same range of output as the current control on the welder. (If a smaller range of control is desired for finer adjustment, a K775 Remote may be used in conjunction with the Amptrol Adapter Cable Kit.) The Amptrol arc start switch is nonfunctional unless used with a K799 Hi-Frequency Kit

# K843 AMPTROL™ ADAPTER INSTALLATION INSTRUCTION

For use with: DC-250, DC-400, R3R or Weldanpower 250 (D-10 and Pro) with remote control power sources.

### **A** WARNING




**ELECTRIC SHOCK can kill.** 

 Turn the power switch of the welding power source "OFF" before installing plugs on cables or when connecting or disconnecting plugs to welding power source. This K843 adapter is used to connect AMPTROL™ (K963\*, K813\* or K870), remote control (K775), and HI-FREQ™ (K799) accessories to DC-250, DC-400, R3R or Weldanpower 250 (D-10 and Pro) with remote control power sources. The power source "machine/remote" switch must be in "remote" for Amptrol™ to control current. Accessories may be combined and connected in four different ways, as shown in Figure 1,2,3, & 4.


#### AMPTROL™ ONLY

The Amptrol provides remote current control through the full range of the power source.



### AMPTROL™ PLUS REMOTE LIMIT CONTROL

The Amptrol provides remote current control from the minimum of the power source to a maximum set by the remote limit control.



#### AMPTROL™ AND HI-FREQ.™ KIT

The Amptrol will start the Hi-Freq kit to turn on gas and high frequency starting for DC TIG welding. The Amptrol controls current through the full range of the power source.





FIG. 3

### AMPTROL™ AND HI-FREQ.™ KIT PLUS REMOTE LIMIT CONTROL

The Amptrol switch will start the Hi-Freq kit to turn on gas and high frequency starting for DC TIG welding. The Amptrol controls current from the minimum of the power source to a maximum set by the remote limit control.



**DC-400** 



# HI-FREQUENCY KIT (K799 CODES 8634 AND ABOVE ONLY)

Kit supplies the high frequency plus gas valve for DC TIG welding. The DC-400 is shipped with proper R.F. bypass circuitry installed to protect the control circuit when welding with a HI-FREQ unit. K844 Water Valve Option Kit can be used with K799 when TIG welding with water cooled torches. See Hi-Frequency Kit Instruction Manual for installation information.

### AMPTROL ADAPTER FOR K799 HI-FRE-QUENCY KIT (K915-1, REQUIRES K864 ADAPTER)

A "V" cable to connect a K799 Hi-Freq Kit (5-pin connector) with either a K963 Hand Amptrol or a K870 Foot Amptrol (6-pin connector) and the machine. The cable going to the machine has a 6-pin connector which requires a K864 adapter to connect with the 14-pin connector on the DC-400. Refer to S20909 instructions for connection information.

### **MULTIPROCESS SWITCH (K804-1)**

Kit that mounts on the front of the DC-400, and includes hinged covers over its output studs. The switch has three positions: Positive semiautomatic/automatic, negative semiautomatic /automatic, and stick/air carbon arc. Required when using the DC-400 for both semiautomatic/automatic and stick/air carbon arc.

Install per M17137 instructions included with the field installed kit.

### **CAPACITOR DISCHARGE CIRCUIT (K828-1)**

Circuit that mounts inside the DC-400. Recommended when:

- DC-400 is used in conjunction with any LN-23P or older LN-8 or LN-9 semiautomatic wire-feeder. Eliminates possible arc flash re-start of weld when trigger interlock is used. Not required with current LN-8 (above Code 8700), or LN-9's with serial numbers above 115187 (manufactured after 12/83), or any LN-9 having an L6043-1 Power PC Board.
- DC-400 is used with an LN-22 equipped with an older K279 Contactor-Voltage Control Option. Eliminates electrode overrun when gun trigger is released. Not required when later K279 (above Code 8800) is used.

 DC-400 is used with any semiautomatic wire-feeder and possible small spark, if electrode touches work just after gun trigger is released, is objectionable.

Install per M17060 instructions included with the Kit

### UNDERCARRIAGES (K817, K817R, K841)

For easy moving of the machine, optional undercarriages are available with either steel (K817) or rubber tired (K817R) wheels or a platform undercarriage (K841) with mountings for two gas cylinder at rear of welder.

Install per instructions provided with undercarriage.

# INSTALLATION OF EQUIPMENT REQUIRED FOR RECOMMENDED PROCESSES

# WIRE FEEDER CONTROL CABLE CONNECTIONS

For control cable with 14-pin connector:

Connect control cable to 14-pin connector on the front panel of the machine. See the appropriate connection diagram for the exact instructions for the wire feeder being used. Refer to Section 2.4.1 for connector pin functions.

For control cable with terminal strip connectors:

The control cable from the wire feeding equipment is connected to the terminal strips behind the control panel\*. A strain relief box connector is provided for access into the terminal strip section. A chassis ground screw is also provided below the terminal strip marked with the symbol  $\rightarrow$  for connecting the automatic equipment grounding wire. See the appropriate connection diagram for the exact instructions for the wire feeder being used.

A cover (Lincoln Electric Part Number S17062-3) is available for the unused 14-pin connector to protect it against dirt and moisture.

\* See Terminal Strip Connections section for access to the terminal strips.



### **CONNECTION OF DC-400 TO LN-22 OR LN-25**

- a) Turn off all power.
- b) Place output terminals switch into the "ON" position.
- c) Connect the electrode cable to the output terminal of polarity required by electrode. Connect the work lead to the other terminal.
- d) Place the OUTPUT CONTROL Switch at "LOCAL" position unless a Remote Control is connected to the DC-400.
- e) Place MODE SWITCH in "CONSTANT VOLTAGE (FCAW, GMAW)".

**NOTE:** The output terminals are energized at all times.

# MULTIPROCESS SWITCH CONNECTION AND OPERATION

#### **PURPOSE**

A Multiprocess Switch has been designed for use with the DC-400 or DC-600. With this switch installed on the DC-400, it permits easy changing of the polarity of the wire feed unit connected and also provides separate terminals for connection of stick or air carbon arc. The Multiprocess Switch is available as either a factory installed or field installed option.

NOTE: IF THE DC-400 IS TO BE USED FOR BOTH SEMIAUTOMATIC/AUTOMATIC AND STICK /AIR CARBON ARC, THEN A MULTI-PROCESS SWITCH IS REQUIRED.

### **DESIGN**

The Multiprocess Switch consists of a 3-position switch assembly that is mounted in a sheet metal enclosure that has two output terminals on each end of the box. The two terminals on the left side of the box are for connection of wire feed electrode and work leads. The two terminals on the right side of the box are for connection of work and electrode for stick or air carbon arc. The output terminals are protected against accidental contact by hinged covers.

The switch mounts to the front of the DC-400 by means of a bracket that fastens to the case sides. Two 4/0 (107 mm²) leads connect the switch assembly to each output stud.

- Connect wire feed unit electrode and work cables through the rectangular strain relief holes in the base of the DC-400 to the output studs on the left side of the box.
- Connect wire feeder control cable and make other terminal strip connections as specified on the connection diagram for the Lincoln wire feeder being used. "Electrode" and "Work" are connected to the left side of the Multiprocess Switch.
- Connect stick or air carbon arc electrode and work cables through the rectangular strain relief holes in the base of the DC-400 to the output studs on the right side of the box.

#### **OPERATION**

The operation of the switch is as follows:

A semiautomatic or automatic wire feed unit electrode and work cables are connected to the terminals on the left side of the box. Stick or air carbon arc electrode and work leads are connected to the terminals on the right side of the box. There are three positions on the switch. With the switch in the left position, the wire feed terminals are electrode negative. In the center position, the wire feeder terminals are electrode positive. In both the left and center switch position, the right side stick terminals are disconnected. In the right switch position, the wire feed terminals are disconnected from the DC-400 and the stick terminals connected. The polarity of the stick terminals is marked on the end of the box. To change polarity, the electrode and work leads must be interchanged. In the stick position, the stick terminals are energized at all times.

### **CONNECTIONS**

(For those applications where it is <u>not</u> necessary to have separate work cables for stick and semiautomatic welding.)

If both stick and semiautomatic welding is done on the same workpiece, only one work lead is required. To do this, connect a 4/0 (107 mm²) jumper from the work terminal on the semiautomatic side to the terminal to be used for work on the stick side. The work lead from the semiautomatic side then serves as the work lead for both semiautomatic and stick welding.



### **AUXILIARY POWER CONNECTIONS**

The power source is equipped to furnish nominally 110-115 volt AC and 40-42 volt AC auxiliary power for operating wire feeding equipment, etc. The auxiliary power is available at the 14-pin MS-style connector receptacle on the control panel and/or at a terminal strip behind the hinged control panel on the front of the power source. 110-115V AC is available at receptacle pins A and J (Domestic and Export models only), terminals 31 and 32 (all models) and at duplex receptacle. 40-42V AC is available only at receptacle pins I and K. The 110-115V AC and the 40-42V AC are isolated circuits and each is protected by circuit breakers, 15 amp on 115VAC circuit, and 10A on 42 Vac circuit.

#### REMOTE CONTROL CONNECTIONS

Remote control connections are available both at a 14-pin connector receptacle located on the control panel, and on terminal strips with screw connections located behind the hinged control panel on the front of the power source.

#### **OUTPUT CONNECTIONS**

The output terminals are recessed on the case front and labeled "+" and "-".

#### INPUT CONNECTIONS

The three input lines are brought in through the rear panel of the power source and attached to the input contactor. Removal of the removable access panel makes the contactor accessible for the input cable connections.

### INPUT LINE VOLTAGE COMPENSATION

The power source is equipped with input line voltage compensation as standard. For a line voltage fluctuation of ±10% the output will remain essentially constant. This is accomplished through the feedback network in the control circuit.

### SOLID STATE OUTPUT CONTROL

The output of the welder is electronically controlled by SCR's instead of mechanical contactors, providing extra long life for highly repetitive welding applications.

### **SOLID STATE CONTROL SYSTEM**

The control circuitry consists of six basic circuits: (1) the SCR snubber network, (2) the SCR firing circuit, (3) the control/fault protection circuit, (4) the starting circuit, (5) the power-up delay circuit, and (6) the power circuit.

The SCR snubber board consists of a capacitor and resistor connected across each SCR and across the entire bridge and MOV's to protect the control circuitry and SCR's from transient voltages. The snubber board is mounted on the back of the case front.

The SCR firing circuit, the control fault protection circuit, the power-up delay circuit, and the power circuit are mounted on the control PC board located behind the front control panel. (The front control panel hinges down for easy access to the board.)

The starting circuit board is located on the back of the control box.

### **MACHINE COOLING**

The fan pulls air in through the louvered front of the machine over the internal parts and exhausts out the louvered rear of the machine. The fan motor is fully enclosed, has sealed ball bearings, requires no lubrication, and operates when the power switch is turned on.

### **CASE FEATURES**

The machine uses a 32" (813mm) long base. The low profile case facilitates installation of the machine under a workbench.

The case front incorporates a recessed control panel where all the machine controls are mounted. This recessed panel protects the controls and minimizes the possibilities of accidental contact. This control panel can be easily opened to permit access to the enclosed control section which contains the terminal strips, PC board, etc.

The output lead terminals are also recessed to avoid any object or person accidentally coming in contact with an output terminal. Strain relief is provided by holes in the front of the base. The leads are routed up through these holes to the output terminals. This prevents any damage of the output studs or insulation of same in the event the cables are pulled excessively. An output stud cover protects against accidental contact with the output studs. Cover hinges upward for access to the studs.

The individual case sides are removable for easy access for internal service or inspection.

The case rear, top section, is equipped with a removable access panel. This provides easy access to the input contactor, easy connection and reconnection of input leads, and easy access for service or inspection.

The total construction of the machine permits outdoor operation. The enclosure is designed with air intake louvers that keep dripping water from being drawn into the unit. The transformer, SCR bridge assembly, and choke are double-dipped in a special corrosion resistant coating.

A permanent lifting hook is located at the top of the machine and is positioned so that it acts as nearly as possible through the center of gravity.

### ARC FORCE SELECTOR (Effective only on CC for Stick and TIG Processes)

An ARC FORCE selector is provided similar to that used on the E500. This control allows the user to select the ideal arc force for the procedure and electrode being used.

### ARC CONTROL (Effective Only When Using CVI Mode)

The ARC CONTROL is a five-position switch that changes the pinch effect of the arc. This results in the control of spatter, fluidity, and bead shape. The ARC CONTROL is set to provide optimum welding depending on the process being used, position, electrode, etc. The pinch effect is increased by turning the control clockwise and may be adjusted while the machine is in operation.

### **MODE SWITCH**

A MODE SWITCH selects between Constant Voltage (FCAW/GMAW), Constant Voltage (Submerged Arc), and Constant Current (Stick/TIG).

#### STICK WELDING

When the DC-400 is used for stick welding or air carbon arc, the control leads and welding cables to any semiautomatic or automatic wire feeders must be disconnected from the DC-400 for maximum safety (unless the Multiprocess switch option is installed).

### **PARALLELING**

There are no provisions on the DC-400 to permit paralleling.

### **DIODE OPTION**


The DC-400 Diode option is required to utilize the cold start and cold electrode sensing features of the NA-3, NA-5 or NA-5R. When this option is not used with an NA-3, NA-5 or NA-5R, see the DC-400/NA-3, DC-400/NA-5 or DC-400/NA-5R connection diagram for instructions on how to disable this circuit. If the circuit is not disabled, the wire cannot be inched down.

### **Machine & Circuit Protection** (Thermal Protection Light)

The power source is thermostatically protected with proximity thermostats against overload or insufficient cooling. One thermostat is located on the nose of the center bottom primary coil and a second thermostat is attached to the lead connecting the secondaries. Both thermostats are connected in a series with the 2-4 circuit. If the machine is overloaded, the primary thermostat will be open, the output will be zero, and the amber thermal protection light will be on. The fan will continue to run. The secondary thermostat will open either with an excessive overload or insufficient cooling. The output will be zero and the amber protection light will be on. When the thermostats reset the protection light will be off.

The power source is also protected against overloads on the SCR bridge assembly through an electronic protection circuit. This circuit senses an overload on the power source and limits the output to 550 amps by phasing back the SCR's.

Protection is provided to protect the circuitry from accidental grounds. If the customer accidentally "grounds" 75, 76, or 77 to the positive output lead, the DC-400 will be reduced to a low value, thus preventing any damage to the machine. If the ground occurs between 75, 76, 77 and the negative output lead, one of the PC board "self-restoring" fuses will blow, preventing any machine damage.



### **MULTIPROCESS SWITCH**

To change stick polarity, reverse the leads at the (+) and (-) terminals on the right side of the Multiprocess Switch.

NOTE: When a DC-400 equipped with Multiprocess Switch is mounted on an undercarriage, the undercarriage handle in the resting position can hit the case of the Multiprocess Switch. This does no harm, but if the user desires, a 1/4" or 3/8" bolt and nut may be placed in the hole in the undercarriage tow bar to limit the travel of the undercarriage handle.

### STICK, TIG OR AIR/CARBON ARC \*

- a) Turn off all power.
- b) Disconnect all wire feed unit control, electrode, and work leads.
- c) Place MODE SWITCH in the "CONSTANT CUR-RENT (STICK/TIG)" for air carbon arc.
- d) For stick, TIG or air carbon arc, place OUTPUT TERMINALS switch into the "ON" position. With the DC-400 connected for stick, TIG or air carbon arc welding, the output terminals will be energized at all times.
- \*NOTE: If stick welding, TIG welding or air carbon arc cutting is to be done on the DC-400 along with semi-automatic/automatic welding, then a K804-1 Multiprocess Switch is required. If the Multiprocess Switch is not used, then all control, electrode, and work leads to wire feed equipment <u>must</u> be disconnected from the DC-400 <u>before</u> connecting the DC-400 for stick or air carbon arc cutting.

### SAFETY PRECAUTIONS

Read this entire section of operating instructions before operating the machine.

### **ELECTRIC SHOCK** can kill.



- Have an electrician install and service this equipment.
- Turn the input power off at the fuse box before working on equipment.
- Do not touch electrically hot parts.
- This next section applies to DC-400's without the Capacitor Discharge Option:



FUMES AND GASES can be dangerous.

- Keep your head out of fumes.
- Use ventilation or exhaust to remove fumes from breathing zone.



WELDING SPARKS can cause fire or explosion.

- Keep flammable material away.
- Do not weld on containers that have held combustibles.




ARC RAYS can burn.

Wear eye, ear, and body protection.


See additional waring information under Arc Welding Safety Precautions and in the front of this Operating Manual.

# GRAPHIC SYMBOLS THAT APPEAR ON THIS MACHINE OR IN THIS MANUAL


#### POWER ON-OFF SWITCH



### **OUTPUT CONTROL DIAL**




### **OUTPUT CONTROL "LOCAL-REMOTE" SWITCH**



#### **CIRCUIT BREAKER**



### THERMAL PROTECTION LIGHT







### **ARC CONTROL SWITCH**









\_\_\_\_ - → High Inductance

### **OUTPUT TERMINALS SWITCH**




### ARC FORCE CONTROL DIAL





### **VOLTMETER SWITCH**




### **RATING PLATE**










NEMA EW 1 -- Designates welder complies with National Electrical Manufacturers Association requirements EW 1. (Export Model only)

IEC 974-1 -→ Designates welder complies with International Electrotechnical commission requirements 974-1. (European model only)


3 ∧ , ----→ Three Phase Power

RATING PLATE (Continued)



Degree of protection provided by the enclosure

### **MODE SWITCH**




Do not switch if output voltage or current is present.



**Constant Voltage (Submerged Arc Welding)** 



Constant Voltage (Flux cored arc welding, gas metal arc welding).




Constant Current (shield metal arc welding, gas tungsten arc welding).

### WARNING IDENTIFICATION



### **EARTH GROUND CONNECTION**





### **GENERAL MACHINE DESCRIPTION**

The DC-400 is an SCR controlled three phase DC power source. It is designed with a single range potentiometer control.

When using a DC-400 power source with wire feeders which do not have an electrical trigger interlock (or with wire feeders with the electrical trigger interlock in the OFF position), there will be a small spark if the electrode contacts the work or ground within several seconds after releasing the trigger.

When used with some wire feeders with the electrical trigger interlock in the ON position, the arc can restart if the electrode touches the work or ground during these several seconds.

### **WARNING**

• Be sure to select OUTPUT TERMINALS "REMOTE ON/OFF" for operation with wire feeders that have leads numbered 2 and 4.

# RECOMMENDED PROCESSES & EQUIPMENT

The DC-400 model is designed for all open arc processes including Innershield® and all solid wire and gas procedures within the capacity of the machine, plus the capability of stick and TIG welding and air carbon arc gouging up to 5/16" (8mm) diameter. A mode switch selects CV (FCAW, GMAW), CV Submerged Arc, or CC (Stick/TIG). Stick welding performance is similar to that of the E500.

The DC-400 is designed to be used with the LN-7, LN-7 GMA, LN-8, LN-9, LN-9 GMA, LN-23P, LN-25, or LN-742 semiautomatic wire feeders, the NA-3, NA-5 and NA-5R automatics, and the LT-56 and LT-7 tractors, within the 400 ampere capacity of the machine. The DC-400 Diode Kit option is required to utilize the cold start and cold electrode sensing features of the NA-3, NA-5 and NA-5R.

# OPERATIONAL FEATURES & CONTROLS ARC CHARACTERISTICS

Through the unique combination of the transformer, three phase semiconverter rectifier, capacitor bank, arc control choke, and the solid state control system, outstanding arc characteristics are achieved on constant voltage.

In addition, an arc force control enables the DC-400 to stick weld as well as the E500.

#### **OUTPUT CONTROL**

The OUTPUT control, a small 2 watt potentiometer, is calibrated from 1 to 10. The OUTPUT control serves as a voltage control in the CV position and a current control in the CC position.

# MACHINE OUTPUT CONTROL SWITCH "LOCAL" OR "REMOTE"

The machine output can be controlled by either the OUTPUT control on the machine control panel, the output control on the wire feed unit, or an optional "remote control" that is available. This switch selects the mode of control, either "LOCAL" or "REMOTE".

# OUTPUT TERMINALS "ON" OR OUTPUT TERMINALS "REMOTE"

This switch provides an alternative to the "2 to 4" jumpering function by energizing the machine's output regardless of whether "2 or 4" is jumpered or not.

#### **POLARITY SELECTION**

Polarity selection is made by appropriately connecting the electrode and work welding cables to either the "+" stud or to the "-" stud. Select "VOLTMETER" switch for "+" or "-" electrode, for the remote (#21) work sensing lead.

# VOLTMETER SWITCH "+" ELECTRODE OR "-" ELECTRODE

This switch selects electrode polarity for the remote (#21) work sensing lead of automatic or semiautomatic equipment.

#### 115 VOLT POWER SWITCH

The power input contactor operates from an auxiliary 115 volt transformer that is energized through the POWER toggle switch on the machine control panel. "I" is on and "0" is off.

### **PILOT LIGHT**

A white light on the machine control panel indicates when the power source input contactor is closed. This means the main power transformer and all auxiliary and control transformers are energized.

### THERMAL PROTECTION LIGHT

An amber light on the machine control panel indicates when either of the two protective thermostats have opened. Output power will be removed but input power will still be applied to the machine.

### **INPUT CONTACTOR**

The power source is equipped with an input contactor.



### **POWER SOURCE OPERATION**

### **A WARNING**



### **ELECTRIC SHOCK** can kill.

- Have an electrician install and service this equipment.
- Turn the input power off at the fuse box before working on equipment.
- Do not touch electrically hot parts.

### **Duty Cycle and Time Period**

The DC-400 is rated at the following duty cycles:

DUTY CYCLE *	AMPS	VOLTS
100%	400	36
60%	450	38
50%	500	40

\* Based upon 10 minute time period (i.e., for 60% duty cycle, it is 6 minutes on and 4 minutes off).

Overloading the DC-400 may result in opening of an internal protective thermostat as indicated by the amber thermal protection light turning on.

#### STARTING THE MACHINE

The POWER toggle switch at the extreme right side of the control panel in the "I" position energizes and closes the three phase input contactor from a 115 volt auxiliary transformer. This in turn energizes the main power transformer.

The machine is de-energized when the POWER switch is in the "0" position.

The white light below the POWER switch indicates when the input contactor is energized.

#### **OUTPUT CONTROL DIAL**

The OUTPUT control to the right of the center of the control panel is a continuous control of the machine output. The control may be rotated from minimum to maximum while under load to adjust the machine output.

The machine is equipped with line voltage compensation as a standard feature. This will hold the output constant except at maximum output of the machine, through a fluctuation of ±10% input line voltage.

### **OUTPUT CONTROL "LOCAL-REMOTE" SWITCH®**

The OUTPUT CONTROL toggle switch on the control panel labeled "LOCAL-REMOTE" gives the operator the option of controlling the output at the machine control panel or at a remote station. For remote control, the toggle switch is set in the "REMOTE" position and controlled at the wire feed unit control, or by connecting a K775 control to terminals 75, 76, and 77 on the terminal strip at the front of the machine, or by connecting a K857 control to the 14-pin connector on the front of the machine. For control at the machine control panel, the toggle switch is set in the "LOCAL".

(Exception: When used with an LN-9, LN-9 GMA or NA-5 wire feeder, the OUTPUT CONTROL switch must be in the "REMOTE" position or automatic shutdown of the LN-9 or NA-5 may occur.)

#### **POLARITY SELECTION**

Polarity selection is made by appropriately connecting the electrode and work welding cables to either the "+" stud or to the "-" stud. Select "VOLTMETER" switch for "+" or "-" electrode for the remote (#21) work sensing lead.

#### **VOLTMETER SWITCH**

Select "+" for positive electrode or "-" for negative electrode polarity for the remote (#21) work sensing lead of automatic or semiautomatic equipment.

### THERMAL PROTECTION LIGHT

The amber thermal protection light will be lit if either of the two protective thermostats have opened. The output power will be disabled but input power will still be applied to the welder. (Refer to Machine and Circuit Protection section).

#### **MODE SWITCH**

The large MODE SWITCH on the left side of the machine, labeled "Constant Voltage (Submerged Arc), Constant Voltage (FCAW/GMAW) and Constant Current (Stick/TIG)", is used to select the proper welder characteristics for the process being used.

The CV (FCAW/GMAW) Mode permits the DC-400 to produce essentially a flat output characteristic that can be varied from approximately. 12 to 42 volts.



In this position, the dynamic characteristics of the machine under welding conditions provide optimum welding characteristics for Innershield® welding, other open arc processes including short arc MIG welding, and air carbon arc. Most submerged arc welding can also be done in this mode.

The CV (Submerged Arc) Mode also produces an essentially flat output characteristic that can be varied from approximately 12 to 42 volts. The dynamic characteristics of the CV Submerged Arc Mode make possible improved submerged arc welding over that possible using the Constant Voltage Innershield Mode. The improvement is most noticeable on high deposition, slow travel speed welds.

There are no means provided to switch between any of the modes remotely. Do not change the position of the MODE SWITCH if output voltage or current is present as this may damage the switch.

The CC Mode permits the DC-400 to produce a constant current output characteristic through the range of 60-500 amps with an open circuit voltage of approximately 57 volts (54V on 50/60 Hz). Stick welding and TIG are done with this position of the Mode Switch.

# ARC FORCE CONTROL DIAL (Effective only in CC mode)

The ARC FORCE control is calibrated from one to ten. For most welding, the dial should be set at approximately midrange, 5-6. Adjustments up or down can then be made depending on the electrode, procedures, and operator preference. Lower settings will provide less short circuit current and a softer arc. A setting that is too low may cause the electrode to stick in the puddle. Higher settings will provide a higher short circuit current and a more forceful arc. Excessive spatter may result if the control setting is too high. For most TIG welding applications adjust this control to a minimum for best operating characteristics.

# ARC CONTROL SWITCH (Effective only in CV FCAW/GMAW mode)

The ARC CONTROL is a tapped switch numbered from 1 to 5 and changes the pinch effect of the arc. This control is most useful in processes that utilize a "shorting" metal transfer and controls the spatter, fluidity, and bead shape. The pinch effect is increased by turning the control clockwise.

For all applications, a good starting point for the ARC CONTROL is a midrange dial setting of 3. The control can be increased or decreased as desired.

### **OUTPUT TERMINALS SWITCH**

The OUTPUT TERMINALS toggle switch on the control panel labeled "REMOTE - ON" allows the welder output to be activated remotely or to be always on. For remote operation, the toggle switch is set in "REMOTE" position and the welder output will be activated when 2 and 4 are closed when using a wirefeeder. For welder output to always be activated, set the switch to the "ON" position.

# 110-115V AC and 40-42V AC Auxiliary Power and Control Connections


### 14-PIN CONNECTOR

The 14-pin connector receptacle supplies auxiliary power.

40-42V AC is available at receptacle pins I and K. A 10 amp circuit breaker protects this circuit.

On the Domestic and Export models 110-115V AC is available at receptacle pins A and J. A 10 amp circuit breaker protects this circuit. Note that the 40-42V AC and 110-115V AC circuits are electrically isolated from each other.

# FRONT VIEW OF 14-PIN CONNECTOR RECEPTACLE



PIN	LEAD NO.	FUNCTION
А	32	110 - 115V AC
В	GND	CHASSIS CONNECTION
С	2	TRIGGER CIRCUIT
D	4	TRIGGER CIRCUIT
E	77	OUTPUT CONTROL
F	76	OUTPUT CONTROL
G	75	OUTPUT CONTROL
Н	21	WORK CONNECTION
I	41	40-42V AC
J	31	110-115V AC
K	42	40-42V AC
L		
М		
N		



### **Terminal Strip Connections**

Terminal strip TS2 located behind the hinged control panel on the front of the power source supplies 110-115V AC. A 15 amp circuit breaker protects this circuit. Note that this 110-115V AC is also available in the 14-pin connector on the Domestic and Export models.

To gain access to the terminal strips simply remote the #10 sheet metal screws from the perimeter of the welder nameplate. Tilt panel forward so it rests in a horizontal position. See Table showing Front View of 14-Pin Connector Receptacle for lead number functions.

### **Machine and Circuit Protection**

The power source is thermostatically protected with proximity thermostats against overload or insufficient cooling. One thermostat is located on the nose of the center bottom primary coil and a second thermostat is attached to the lead connection the secondaries. Both thermostats are connected in series with 2-4 circuit. If the machine is overloaded, the primary thermostat will open, the output will be zero, and the amber thermal protection light will be on.

The fan will continue to run. The secondary thermostat will open either with an excessive overload or insufficient cooling. The output will be zero and the amber protection light will be off.

### 115VAC GFCI RECEPTACLE

(Codes 11038 and higher)

The GFCI receptacle is located near the output studs and protected by a 15 amp circuit breaker.

Testing the GFCI Receptacle

- a.) Turn the welder ON. Press the reset button fully. Plug a lamp or radio into the GFCI (and leave it plugged in) to verify that the power is ON. If there is no power, go to Troubleshooting.
- b) Press the TEST button in order to trip the device. This should stop the flow of electricity, making the lamp or radio shut OFF. Note that the RESET button will pop out. If the power stays on, go to troubleshooting. If the power goes OFF, the GFCI is working properly. To restore power, press the RESET button.
- c) Press the TEST button (then RESET button) every month to assure proper operation.

NOTE:

The GFCI receptacle is in a 115v circuit where the neutral is floating with respect to ground. Consequently if a GFCI tester is plugged into the GFCI receptacle, the tester will show that there is an "open ground". This indication of an "open ground" is normal and the GFCI will function properly in the event of a ground fault current as the GFCI is designed to do.



### **Factory Installed Options**

#### DIODE OPTION

This internally installed option allows the use of the cold start and cold electrode sensing features of the NA-3, NA-5 or NA-5R.

#### **MULTIPROCESS SWITCH**

Factory or field installed kit that mounts on the front of the DC-400, and includes hinged covers over its output studs. The switch has three positions: Positive semiautomatic / automatic, negative semiautomatic / automatic, and stick / air carbon arc. Required when using the DC-400 for both semiautomatic/automatic and stick/air carbon arc. The field installed kit equivalent is identified as K804-1. For details on the Multiprocess Switch, see the Installation of Equipment section.

### **Field Installed Options**

# REMOTE OUTPUT CONTROL (K857 WITH K864 ADAPTER OR K775)


The K857 has a 6-pin MS-style connector. The K857 requires a K864 adapter cable which connects to the 14-pin connector on the machine.

An optional "remote output control" is available. This is the same remote control that is used on the Lincoln R3R, and DC-600 power sources (K775). The K775 consists of a control box with 28 ft (8.5m) of four conductor cable. This connects to terminals 75, 76, and 77 on the terminal strip and the case grounding screw so marked with the symbol on the machine. These terminals are located behind the control panel on the front of the power source. This control will give the same control as the output control on the machine.

### AMPTROL™ ADAPTER CABLE (K843)

A five wire cable, 12" (.30m) long, is available for easy connection of standard K963 Hand Amptrol or K870 Foot Amptrol. The cable has a 6-pin MS-style connector which connects to the Amptrol and terminals which connect to 75, 76 and 77 on the machine terminal strip and to the case grounding screw. The Amptrol will control the same range of output as the current control on the welder. (If a smaller range of control is desired for finer adjustment, a K775 Remote may be used in conjunction with the Amptrol Adapter Cable Kit. Connection information is included with the Amptrol Adapter Cable Kit.) The Amptrol arc start switch is nonfunctional in this application.

### **REMOTE CONTROL ADAPTER CABLE (K864)**



A "V" cable 12" (.30m) long to connect a K857 Remote Control, K963 Hand Amptrol or K870 Foot Amptrol (6-pin connector) with a wire-feeder (14-pin connector) and the machine (14-pin connector). If a remote control or amptrol is used alone the wire-feeder connection is then not used.

### **MULTIPROCESS SWITCH (K804-1)**

Field installed kit that mounts on the front of the DC-400, and includes hinged covers over its output studs. The switch has three positions:Positive semiautomatic/automatic, negative semiautomatic/automatic, and stick/air carbon arc. Required when using the DC-400 for both semiautomatic/automatic and stick/air carbon arc. The field installed kit is equivalent to the factory installed option. For details on the Multiprocess Switch, see the section for Installation of Equipment Required for Recommended Processes.

### **CAPACITOR DISCHARGE CIRCUIT (K828-1)**

Circuit that mounts inside the DC-400. Recommended when:

- DC-400 is used in conjunction with any LN-23P or older LN-8 or LN-9 semiautomatic wire-feeder. Eliminates possible arc flash re-start of weld when trigger interlock is used. Not required with current LN-8 (above Code 8700), or LN-9's with serial numbers above 115187 (manufactured after 12/83), or any LN-9 having an L6043-1 Power PC Board.
- DC-400 is used with an LN-22 equipped with an older K279 Contactor-Voltage Control Option. Eliminates electrode overrun when gun trigger is released. Not required when later K279 (above Code 8800) is used.
- DC-400 is used with any semiautomatic wire-feeder and possible small spark, if electrode touches work just after gun trigger is released, is objectionable.



### HI-FREQUENCY KIT (K799 CODES 8634 AND ABOVE ONLY)

Kit supplies the high frequency plus gas valve for DC TIG welding. The DC-400 is shipped with proper R.F. bypass circuitry installed to protect the control circuit when welding with a HI-FREQ unit. K844 Water Valve Option Kit can be used with K799 when TIG welding with water cooled torches.

### OPTIONAL AMPTROL ADAPTER FOR K799 HI-FREQUENCY KIT (K915-1 REQUIRES K864 ADAPTER OR K843 ADAPTER)

A "V" cable to connect a K799 Hi-Freq kit (5-pin connector) with either a K963 Hand Amptrol or a K870 Foot Amptrol (6-pin connector) and the machine. The cable going to the machine has a 6-pin connector which requires either a K864 adapter to connect with the 14-pin connector on the machine or a K843 adapter to connect to terminals 75, 76, 77 and the case grounding screw on the machine.

### UNDERCARRIAGES (K817, K817R, K841)

For easy moving of the machine, optional undercarriages are available with either steel (K817) or rubber tired (K817R) wheels or a platform undercarriage (K841) with mountings for two gas cylinder at rear of welder.

Install per instructions provided with undercarriage.

### **A** WARNING



### ELECTRIC SHOCK can kill.

- Have an electrician install and service this equipment.
- Turn the input power off at the fuse box before working on equipment.
- Do not touch electrically hot parts.

\_\_\_\_\_

### **Routine Maintenance**

- The fan motor has sealed bearings which require no service.
- 2. In extremely dusty locations, dirt may clog the air channels causing the welder to run hot. Blow out the machine at regular intervals.
- 3. In extremely dusty locations, dirt may accumulate on the remote control terminal strip TS1. Wipe or blow this terminal strip off at regular intervals. This is particularly important in damp locations.

### HOW TO USE TROUBLESHOOTING GUIDE

### **A** WARNING

Service and Repair should only be performed by Factory Trained Personnel. Unauthorized repairs performed on this equipment may result in danger to the technician and machine operator and will invalidate your factory warranty. For your safety and to avoid Electrical Shock, please observe all safety notes and precautions detailed throughout this manual.

This Troubleshooting Guide is provided to help you locate and repair possible machine malfunctions. Simply follow the three-step procedure listed below.

### Step 1. LOCATE PROBLEM (SYMPTOM).

Look under the column labeled "PROBLEM (SYMP-TOMS)". This column describes possible symptoms that the machine may exhibit. Find the listing that best describes the symptom that the machine is exhibiting.

### Step 2. POSSIBLE CAUSE.

The second column labeled "POSSIBLE CAUSE" lists the obvious external possibilities that may contribute to the machine symptom.

### Step 3. RECOMMENDED COURSE OF ACTION

This column provides a course of action for the Possible Cause, generally it states to contact your local Authorized Field Service Facility.

If you do not understand or are unable to perform the Recommended Course of Action safely, contact your local Authorized Field Service Facility.

### CAUTION

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your **Local Authorized Field Service Facility** for technical troubleshooting assistance before you proceed.

### **TROUBLESHOOTING**

Observe all Safety Guidelines detailed throughout this manual

PROBLEMS	RECOMMENDED	
(SYMPTOMS)	POSSIBLE CAUSE	COURSE OF ACTION
Input contactor (CR1) chatters.	Faulty input contactor (CR1).     Repair or Replace.     Low line voltage.     Check input power.	
Machine input contactor does not operate.	<ol> <li>Supply line fuse blown. Replace if blown - look for reason first.</li> <li>Contactor power circuit dead. Check control transformer T2 and associated leads.</li> <li>Broken power lead. Check input voltage at contactor.</li> <li>Wrong input voltage. Check voltage against instructions.</li> <li>Open input contactor coil. Replace coil.</li> <li>POWER "I/0" switch (S1) not closing. Replace switch.</li> </ol>	
Machine input contactor operates, but no output when trying to weld.	<ol> <li>Trigger circuit between #2 and #4 leads is not being closed. Make sure trigger circuit is being closed.</li> <li>Electrode or work lead loose or broken. Repair Connection.</li> <li>Open main transformer (T1) primary or secondary circuit. Repair.</li> <li>Defective Control PC Board. Replace. See Procedure for Replacing PC Boards.</li> <li>Primary or secondary thermostats open. Amber thermal protection light is on: Check for overheating; make sure fan is operating and there is no obstruction to free air flow.</li> </ol>	If all recommended possible areas of misadjustment have been checked and the problem persists, Contact your local Authorized Field Service Facility.
Machine has minimum output and no control.	Terminals 75, 76 or 77 grounded to positive output.	

## **▲** CAUTION

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your **Local Authorized Field Service Facility** for technical troubleshooting assistance before you proceed.



### **TROUBLESHOOTING**

Observe all Safety Guidelines detailed throughout this manual

Observe all Safety Guidelines detailed throughout this manual PROBLEMS POSSIBLE RECOMMENDED						
(SYMPTOMS)	CAUSE	COURSE OF ACTION				
Machine has high output or pulsing output and no control.	Terminals 75, 76, or 77 grounded to negative output.					
Machine has low output and no control.	<ol> <li>OUTPUT CONTROL "LOCAL-REMOTE" switch (S2) in wrong position. Check position of switch.</li> <li>OUTPUT CONTROL switch faulty. Check switch &amp; replace if faulty.</li> <li>Open in feedback circuitry.</li> <li>Faulty Control PC Board.</li> <li>OUTPUT control potentiometer circuit open (lead 75).</li> </ol>					
Machine does not have maximum output.	<ol> <li>One input fuse blows. Check and replace if blown after checking for reason for blown fuse.</li> <li>One phase of main transformer open.</li> <li>Faulty Control PC Board.</li> <li>OUTPUT control potentiometer.</li> <li>OUTPUT control potentiometer leads 210, 211 or 75 open.</li> </ol>	If all recommended possible areas of misadjustment have been checked and the problem persists, Contact your local Authorized Field Service Facility.				
Machine will not shut off.	<ol> <li>Input contactor contacts frozen.</li> <li>Defective POWER "1/0" switch, (S1).</li> </ol>					
Variable or sluggish welding arc.	<ol> <li>Poor work or electrode connection. Place switch in "LOCAL".</li> <li>Welding leads too small.</li> <li>Welding current or voltage too low.</li> <li>Defective main SCR bridge.</li> <li>Microswitch S4C or S4D actuator defective.</li> </ol>					
OUTPUT control not functioning on the machine.	<ol> <li>OUTPUT CONTROL switch in wrong position.</li> <li>Faulty OUTPUT control switch.</li> <li>Faulty OUTPUT control potentiometer.</li> <li>Leads or connections open in control circuit.</li> <li>Faulty Control PC Board.</li> </ol>					

## **A** CAUTION

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your **Local Authorized Field Service Facility** for technical troubleshooting assistance before you proceed.



### **TROUBLESHOOTING**

Observe all Safety Guidelines detailed throughout this manual

Observe all Safety Guidelines detailed throughout this manual  PROBLEMS  POSSIBLE  RECOMMENDED					
(SYMPTOMS)	CAUSE	COURSE OF ACTION			
,		occine or Acrien			
OUTPUT control not functioning on "REMOTE" control.	<ol> <li>OUTPUT CONTROL switch in wrong position. Place switch in "REMOTE".</li> <li>Faulty OUTPUT CONTROL switch.</li> <li>Faulty remote control potentiometer.</li> <li>Leads or connections open in control circuit.</li> <li>Faulty Control PC Board.</li> </ol>				
Poor arc striking with semiautomatic or automatic wire feeders.	<ol> <li>Defective start circuit.</li> <li>Poor work connection.</li> <li>Improper procedures.</li> <li>Defective Control PC Board.</li> </ol>	If all recommended possible areas of misadjustment have been checked and the problem persists, Contact			
Poor arc characteristics.	<ol> <li>Start circuit energized at all times (read switch CR3 not closing).</li> <li>Defective Start PC Board.</li> <li>Defective Control PC Board.</li> <li>Capacitor(s) in output circuit failed. A failure is indicated if the small vent plug on top of a capac- itor is raised or blown out.</li> </ol>	your local Authorized Field Service Facility.			
ARC CONTROL has no effect in CV (FCAW/GMAW) mode with short circuit transfer processes.	Defective R1, L1, S4C, S4D actuator or S5.				
115VAC Receptacle not working.	Circuit Breaker Tripped.     Defective Circuit Breaker.     Broken Connection in Wiring.				

### **▲** CAUTION

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your **Local Authorized Field Service Facility** for technical troubleshooting assistance before you proceed.



### PROCEDURE FOR REPLACING PC BOARDS

# **A** WARNING



- **ELECTRIC SHOCK** can kill.
- · Have an electrician install and service this equipment.
- Turn the input power off at the fuse box before working on equipment.
- Do not touch electrically hot parts.

When a PC Board is suspected to be defective, the following procedure must be followed:

- 1. Visually inspect the PC Board. If the board has fuses, check to see if any are blown. Are any of the components damaged? Is a conductor on the back side of the board damaged? If electrical damage is visible on the PC Board, inspect the machine wiring for grounds or shorts to avoid damaging a new PC Board, Install a new PC Board only after a visual inspection of the PC Board and machine wiring is satisfactory.
- 2. If the problem is remedied by a new PC Board, install the old PC Board and see if the problem still exists. If the problem does not return with the old
  - a) Check the PC Board harness plug and PC Board plug for contamination, corrosion or over-
  - b) Check leads in the harness for loose connections.

### CONNECTING THE REMOTE CONTROL TO THE MACHINE

Extreme caution must be observed when installing or extending the wiring of a remote control. Improper connection of this unit can lead to failure of the output control rheostat or the control circuit. Only the green lead can and should be grounded to the machine case. When extending the standard remote control, make sure the leads are the same and the splice is waterproof. Be very careful not to ground the cable when in use and don't let the lugs touch against the case.

### **OUTPUT VOLTAGE**

The output circuit voltage of the machine should be adjustable from 10 to 46 volts in CV. In the CC mode, the open circuit voltage should be approximately 57 volts (54 volts on 50/60 Hz) except at near minimum settings of the output control where it may be lower. If any other condition exists, refer to the Troubleshooting Guide.

### **FAULT PROTECTION OPERATION**

The overload protection circuit, in the Control PC Board will limit the welding current (heat) to 550 amps if a short or overload is applied to the machine. (Refer to the Machine and Circuit Protection section).

### **CHECKING SNUBBER CIRCUIT**

In case of an SCR malfunction or failure the snubber assembly should be checked. Turn the machine off and remove the sides of the machine. (See the instruction manual parts list for the exact location.)

1. Visually inspect the snubber assembly for overheated components or damaged components.

### CHECKING OUTPUT CONTROL RHEOSTAT ON MACHINE

Turn machine off ("0" position).

Remove the control panel screws and open the control panel (see the section on Terminal Strip Connections for screw locations).

Turn the OUTPUT CONTROL switch to "REMOTE".

Disconnect the harness plug from the Control PC Board.

With an ohmmeter on X1K, connect it to lead 210 and 75 on R4.

Exercise caution to avoid damaging POT taps.

### POWER "I/0" SWITCH CHECK

- 1. Turn off the machine power input ("0" position). S1 has 115V across it when the input power is connected.
- 2. Isolate the switch to be tested by removing all connecting leads.
- 3. Check to make sure the switch is making connections with an ohmmeter. The meter should read zero resistance.
- 4. Put the ohmmeter on X1K scale and measure the resistance between the terminal and the case of the machine (touch a self-tapping screw). Reading should be infinite.
- 5. If either step (3) or step (4) fails, replace the switch.

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your Local Authorized Field Service Facility for technical troubleshooting assistance before you proceed.



### REMOTE CONTROL CHECK

Disconnect the remote output control and connect an ohmmeter across 75 to 76 and rotate the rheostat in the remote control. The resistance reading should go from zero to 10K ohms. Repeat with ohmmeter across 75 and 76 with same results. Connect ohmmeter across 75 and 77. The reading should be 10K ohms. A lower reading will indicate a shorted or partially shorted rheostat. A very high reading will indicate an open rheostat. In either of the last two cases, replace rheostat. Check cable for any physical damage.

# POWER RECTIFIER BRIDGE ASSEMBLY CHECKING PROCEDURE



### **A** WARNING

### **ELECTRIC SHOCK** can kill.

- Have an electrician install and service this equipment.
- Turn the input power off at the fuse box before working on equipment.
- Do not touch electrically hot parts.
- 1. Bridge and Device Isolation (See the instruction manual parts list for the exact location.)

Disconnect the following leads from the bridge, shown in Diagram 1:

- a) Unplug P3 (G1, G2, G3 and 204) from the Control PC Board.
- b) Unplug P5 from the Snubber PC Board.
- c) Secondary leads X1, X2, and X3 from the anodes of the SCR's and cathodes of the diodes.
- d) Disconnect positive bridge lead from shunt and positive capacitor bank lead and from lug with triple 204 leads.
- e) Perform the following steps 2 and 3. If diodes and SCR's are not shorted, bridge test is completed. If any device appears shorted, disconnect the cathode lead of each diode (4 total) and repeat Steps 2 and 3.

### 2. Power Diode Test

- a) Establish the polarity of the ohmmeter leads and set to X10 scale.
- b) Connect the ohmmeter positive lead to anode and negative lead to cathode.
- c) Reverse the leads of the ohmmeter from Step b.
- d) A shorted diode will indicate zero or an equally low resistance in both directions. An open diode will have an infinite or high resistance in both directions and a good diode will have a low resistance in Step b and Step a much higher resistance in Step c.


### 3. Power Silicon Controlled Rectifier Test

- a) Connect the ohmmeter (set to m X10 scale) leads to the anode and cathode.
- b) Reverse the leads of the ohmmeter from Step
- c) A shorted SCR will indicate zero or an equally low resistance in one or both directions.
- d) Establish the polarity of the ohmmeter. Connect the positive lead to the gate and the negative lead to the cathode.
- e) An open gate circuit will have an infinite or high resistance. A good gate circuit will read a low resistance, but not zero ohms. If gate circuit reads zero ohms, check gate harness for shorts between gate leads and 204 before replacing SCR.

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your **Local Authorized Field Service Facility** for technical troubleshooting assistance before you proceed.



### **WIRING DIAGRAM FOR CODE 10648**



L9107

The specific diagram for a particular code is pasted inside

Service Department for a replacement. Give the equipment code number.

may not be accurate for all machines covered by this manual.

the diagram is illegible, write to the


the machine on one of the enclosure panels.

This diagram is for reference only

NOTE



### WIRING DIAGRAM FOR CODE 10699 AND ABOVE



L11460

code is pasted inside

Give the equipment code number

for a particular

specific diagram

The

covered by this manual. Service Department for

machines or rite to the \$

the diagram is illegible, write to

for all

be accurate

not

may

for reference only

<u>.s</u>

This diagram

NOTE:


the machine on one of the enclosure panels.

replacement.

Ø



### **WIRING DIAGRAM FOR CODES 11038, 11085, 11128, 11347**





L12058

a particular code is pasted inside

The specific diagram for

It may not be accurate for all machines covered by this manual.

is illegible, write to the

If the diagram

<u>.</u>

enclosure panel

the machine on one of the

This (

NOTE:


diagram is for reference only.

a replacement.


Service Department for

Give the equipment code number..

### POWER RECTIFIER BRIDGE DIAGRAM 1







### N.A-OPTIONAL UNDERCARRIAGE AVAILABLE

Part No.	Туре	Α	В	С	D	F	G	Н
M12244-7	DC-400	32.00	15.39	30.92	1.44	30.02 ±.11	30.02 ±.11	.94

# **NOTES**

WARNING	Do not touch electrically live parts or electrode with skin or wet clothing.     Insulate yourself from work and ground.	● Keep flammable materials away.	Wear eye, ear and body protection.
AVISO DE PRECAUCION	<ul> <li>No toque las partes o los electrodos bajo carga con la piel o ropa moja- da.</li> <li>Aislese del trabajo y de la tierra.</li> </ul>	<ul> <li>Mantenga el material combustible fuera del área de trabajo.</li> </ul>	<ul> <li>Protéjase los ojos, los oídos y el cuerpo.</li> </ul>
ATTENTION	Ne laissez ni la peau ni des vête- ments mouillés entrer en contact avec des pièces sous tension.     Isolez-vous du travail et de la terre.	Gardez à l'écart de tout matériel inflammable.	Protégez vos yeux, vos oreilles et votre corps.
WARNUNG	<ul> <li>Berühren Sie keine stromführenden Teile oder Elektroden mit Ihrem Körper oder feuchter Kleidung!</li> <li>Isolieren Sie sich von den Elektroden und dem Erdboden!</li> </ul>	Entfernen Sie brennbarres Material!	Tragen Sie Augen-, Ohren- und Kör- perschutz!
ATENÇÃO	<ul> <li>Não toque partes elétricas e electrodos com a pele ou roupa molhada.</li> <li>Isole-se da peça e terra.</li> </ul>	Mantenha inflamáveis bem guardados.	<ul> <li>Use proteção para a vista, ouvido e corpo.</li> </ul>
注意事項	● 通電中の電気部品、又は溶材にヒ フやぬれた布で触れないこと。 ● 施工物やアースから身体が絶縁さ れている様にして下さい。	● 燃えやすいものの側での溶接作業 は絶対にしてはなりません。	● 目、耳及び身体に保護具をして下 さい。
Chinese <b>数</b> 生	● 皮肤或濕衣物切勿接觸帶電部件及 銲條。 ● 使你自己與地面和工件絶縁。	●把一切易燃物品移離工作場所。	●佩戴眼、耳及身體勞動保護用具。
Rorean 위험	● 전도체나 용접봉을 젖은 헝겁 또는 피부로 절대 접촉치 마십시요. ● 모재와 접지를 접촉치 마십시요.	●인화성 물질을 접근 시키지 마시요.	●눈, 귀와 몸에 보호장구를 착용하십시요.
Arabic	<ul> <li>♦ لا تلمس الإجزاء التي يسري فيها التيار الكهرباني أو الالكترود بجلد الجسم أو بالملابس المبلئة بالماء.</li> <li>♦ ضع عاز لا على جسمك خلال العمل.</li> </ul>	<ul> <li>ضع المواد القابلة للاشتعال في مكان بعيد.</li> </ul>	<ul> <li>ضع أدوات وملابس واقية على عينيك وأذنيك وجسمك.</li> </ul>

READ AND UNDERSTAND THE MANUFACTURER'S INSTRUCTION FOR THIS EQUIPMENT AND THE CONSUMABLES TO BE USED AND FOLLOW YOUR EMPLOYER'S SAFETY PRACTICES.

SE RECOMIENDA LEER Y ENTENDER LAS INSTRUCCIONES DEL FABRICANTE PARA EL USO DE ESTE EQUIPO Y LOS CONSUMIBLES QUE VA A UTILIZAR, SIGA LAS MEDIDAS DE SEGURIDAD DE SU SUPERVISOR.

LISEZ ET COMPRENEZ LES INSTRUCTIONS DU FABRICANT EN CE QUI REGARDE CET EQUIPMENT ET LES PRODUITS A ETRE EMPLOYES ET SUIVEZ LES PROCEDURES DE SECURITE DE VOTRE EMPLOYEUR.

LESEN SIE UND BEFOLGEN SIE DIE BETRIEBSANLEITUNG DER ANLAGE UND DEN ELEKTRODENEINSATZ DES HERSTELLERS. DIE UNFALLVERHÜTUNGSVORSCHRIFTEN DES ARBEITGEBERS SIND EBENFALLS ZU BEACHTEN.

	*		
Keep your head out of fumes.     Use ventilation or exhaust to remove fumes from breathing zone.	Turn power off before servicing.	Do not operate with panel open or guards off.	WARNING
<ul> <li>Los humos fuera de la zona de respiración.</li> <li>Mantenga la cabeza fuera de los humos. Utilice ventilación o aspiración para gases.</li> </ul>	Desconectar el cable de ali- mentación de poder de la máquina antes de iniciar cualquier servicio.	No operar con panel abierto o guardas quitadas.	AVISO DE PRECAUCION
<ul> <li>Gardez la tête à l'écart des fumées.</li> <li>Utilisez un ventilateur ou un aspirateur pour ôter les fumées des zones de travail.</li> </ul>	Débranchez le courant avant l'entre- tien.	<ul> <li>N'opérez pas avec les panneaux ouverts ou avec les dispositifs de protection enlevés.</li> </ul>	ATTENTION
Vermeiden Sie das Einatmen von Schweibrauch!     Sorgen Sie für gute Be- und Entlüftung des Arbeitsplatzes!	Strom vor Wartungsarbeiten abschalten! (Netzstrom völlig öff- nen; Maschine anhalten!)	<ul> <li>Anlage nie ohne Schutzgehäuse oder Innenschutzverkleidung in Betrieb setzen!</li> </ul>	WARNUNG
<ul> <li>Mantenha seu rosto da fumaça.</li> <li>Use ventilação e exhaustão para remover fumo da zona respiratória.</li> </ul>	<ul> <li>Não opere com as tampas removidas.</li> <li>Desligue a corrente antes de fazer serviço.</li> <li>Não toque as partes elétricas nuas.</li> </ul>	<ul> <li>Mantenha-se afastado das partes moventes.</li> <li>Não opere com os paineis abertos ou guardas removidas.</li> </ul>	ATENÇÃO
<ul><li>ヒュームから頭を離すようにして下さい。</li><li>換気や排煙に十分留意して下さい。</li></ul>	● メンテナンス・サービスに取りか かる際には、まず電源スイッチを 必ず切って下さい。	● パネルやカバーを取り外したまま で機械操作をしないで下さい。	注意事項
●頭部遠離煙霧。 ●在呼吸區使用通風或排風器除煙。	●維修前切斷電源。	●儀表板打開或沒有安全罩時不準作 業。	Chinese
● 얼굴로부터 용접가스를 멀리하십시요. ● 호흡지역으로부터 용접가스를 제거하기 위해 가스제거기나 통풍기를 사용하십시요.	● 보수전에 전원을 차단하십시요.	● 판넬이 열린 상태로 작동치 마십시요.	Rorean 위 험
<ul> <li>• ابعد رأسك بعيداً عن الدخان.</li> <li>• استعمل التهوية أو جهاز ضغط الدخان للخارج</li> <li>لكي تبعد الدخان عن المنطقة التي تتنفس فيها.</li> </ul>	<ul> <li>● اقطع التيار الكهربائي قبل القيام بأية صياتة.</li> </ul>	<ul> <li>◄ لا تشغل هذا الجهاز اذا كانت الاغطية الحديدية الواقية ليست عليه.</li> </ul>	تحذير

LEIA E COMPREENDA AS INSTRUÇÕES DO FABRICANTE PARA ESTE EQUIPAMENTO E AS PARTES DE USO, E SIGA AS PRÁTICAS DE SEGURANÇA DO EMPREGADOR.

使う機械や溶材のメーカーの指示書をよく読み、まず理解して下さい。そして貴社の安全規定に従って下さい。

請詳細閱讀並理解製造廠提供的説明以及應該使用的銀捍材料,並請遵守貴方的有関勞動保護規定。

이 제품에 동봉된 작업지침서를 숙지하시고 귀사의 작업자 안전수칙을 준수하시기 바랍니다.

اقرأ بتمعن وافهم تعليمات المصنع المنتج لهذه المعدات والمواد قبل استعمالها واتبع تعليمات الوقاية لصاحب العمل.

