



**NOTE:** This manual will cover most of the troubleshooting and repair procedures for the code numbers listed. Some variances may exist when troubleshooting/repairing later code numbers.

## **TOMAHAWK® 375 AIR**

For use with machines having Code Numbers:

**11579**

# ***SERVICE MANUAL***



## ⚠ WARNING

### ⚠ CALIFORNIA PROPOSITION 65 WARNINGS ⚠

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

The Above For Diesel Engines

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

The Above For Gasoline Engines

**ARC WELDING can be hazardous. PROTECT YOURSELF AND OTHERS FROM POSSIBLE SERIOUS INJURY OR DEATH. KEEP CHILDREN AWAY. PACEMAKER WEARERS SHOULD CONSULT WITH THEIR DOCTOR BEFORE OPERATING.**

Read and understand the following safety highlights. For additional safety information, it is strongly recommended that you purchase a copy of "Safety in Welding & Cutting - ANSI Standard Z49.1" from the American Welding Society, P.O. Box 351040, Miami, Florida 33135 or CSA Standard W117.2-1974. A Free copy of "Arc Welding Safety" booklet E205 is available from the Lincoln Electric Company, 22801 St. Clair Avenue, Cleveland, Ohio 44117-1199.

**BE SURE THAT ALL INSTALLATION, OPERATION, MAINTENANCE AND REPAIR PROCEDURES ARE PERFORMED ONLY BY QUALIFIED INDIVIDUALS.**



### FOR ENGINE powered equipment.

1.a. Turn the engine off before troubleshooting and maintenance work unless the maintenance work requires it to be running.



1.b. Operate engines in open, well-ventilated areas or vent the engine exhaust fumes outdoors.



1.c. Do not add the fuel near an open flame welding arc or when the engine is running. Stop the engine and allow it to cool before refueling to prevent spilled fuel from vaporizing on contact with hot engine parts and igniting. Do not spill fuel when filling tank. If fuel is spilled, wipe it up and do not start engine until fumes have been eliminated.

1.d. Keep all equipment safety guards, covers and devices in position and in good repair. Keep hands, hair, clothing and tools away from V-belts, gears, fans and all other moving parts when starting, operating or repairing equipment.

1.e. In some cases it may be necessary to remove safety guards to perform required maintenance. Remove guards only when necessary and replace them when the maintenance requiring their removal is complete. Always use the greatest care when working near moving parts.




1.f. Do not put your hands near the engine fan. Do not attempt to override the governor or idler by pushing on the throttle control rods while the engine is running.

1.g. To prevent accidentally starting gasoline engines while turning the engine or welding generator during maintenance work, disconnect the spark plug wires, distributor cap or magneto wire as appropriate.



1.h. To avoid scalding, do not remove the radiator pressure cap when the engine is hot.



### ELECTRIC AND MAGNETIC FIELDS may be dangerous

- 2.a. Electric current flowing through any conductor causes localized Electric and Magnetic Fields (EMF). Welding current creates EMF fields around welding cables and welding machines
- 2.b. EMF fields may interfere with some pacemakers, and welders having a pacemaker should consult their physician before welding.
- 2.c. Exposure to EMF fields in welding may have other health effects which are now not known.
- 2.d. All welders should use the following procedures in order to minimize exposure to EMF fields from the welding circuit:
  - 2.d.1. Route the electrode and work cables together - Secure them with tape when possible.
  - 2.d.2. Never coil the electrode lead around your body.
  - 2.d.3. Do not place your body between the electrode and work cables. If the electrode cable is on your right side, the work cable should also be on your right side.
  - 2.d.4. Connect the work cable to the workpiece as close as possible to the area being welded.
  - 2.d.5. Do not work next to welding power source.



### ELECTRIC SHOCK can kill.

3.a. The electrode and work (or ground) circuits are electrically “hot” when the welder is on. Do not touch these “hot” parts with your bare skin or wet clothing. Wear dry, hole-free gloves to insulate hands.

3.b. Insulate yourself from work and ground using dry insulation. Make certain the insulation is large enough to cover your full area of physical contact with work and ground.

**In addition to the normal safety precautions, if welding must be performed under electrically hazardous conditions (in damp locations or while wearing wet clothing; on metal structures such as floors, gratings or scaffolds; when in cramped positions such as sitting, kneeling or lying, if there is a high risk of unavoidable or accidental contact with the workpiece or ground) use the following equipment:**

- Semiautomatic DC Constant Voltage (Wire) Welder.
- DC Manual (Stick) Welder.
- AC Welder with Reduced Voltage Control.

3.c. In semiautomatic or automatic wire welding, the electrode, electrode reel, welding head, nozzle or semiautomatic welding gun are also electrically “hot”.

3.d. Always be sure the work cable makes a good electrical connection with the metal being welded. The connection should be as close as possible to the area being welded.

3.e. Ground the work or metal to be welded to a good electrical (earth) ground.

3.f. Maintain the electrode holder, work clamp, welding cable and welding machine in good, safe operating condition. Replace damaged insulation.

3.g. Never dip the electrode in water for cooling.

3.h. Never simultaneously touch electrically “hot” parts of electrode holders connected to two welders because voltage between the two can be the total of the open circuit voltage of both welders.

3.i. When working above floor level, use a safety belt to protect yourself from a fall should you get a shock.

3.j. Also see Items 6.c. and 8.



### ARC RAYS can burn.

4.a. Use a shield with the proper filter and cover plates to protect your eyes from sparks and the rays of the arc when welding or observing open arc welding. Headshield and filter lens should conform to ANSI Z87.1 standards.

4.b. Use suitable clothing made from durable flame-resistant material to protect your skin and that of your helpers from the arc rays.

4.c. Protect other nearby personnel with suitable, non-flammable screening and/or warn them not to watch the arc nor expose themselves to the arc rays or to hot spatter or metal.



### FUMES AND GASES can be dangerous.

5.a. Welding may produce fumes and gases hazardous to health. Avoid breathing these fumes and gases. When welding, keep your head out of the fume. Use enough ventilation and/or exhaust at the arc to keep fumes and gases away from the breathing zone. **When welding with electrodes which require special ventilation such as stainless or hard facing (see instructions on container or MSDS) or on lead or cadmium plated steel and other metals or coatings which produce highly toxic fumes, keep exposure as low as possible and within applicable OSHA PEL and ACGIH TLV limits using local exhaust or mechanical ventilation. In confined spaces or in some circumstances, outdoors, a respirator may be required. Additional precautions are also required when welding on galvanized steel.**


5.b. The operation of welding fume control equipment is affected by various factors including proper use and positioning of the equipment, maintenance of the equipment and the specific welding procedure and application involved. Worker exposure level should be checked upon installation and periodically thereafter to be certain it is within applicable OSHA PEL and ACGIH TLV limits.

5.c. Do not weld in locations near chlorinated hydrocarbon vapors coming from degreasing, cleaning or spraying operations. The heat and rays of the arc can react with solvent vapors to form phosgene, a highly toxic gas, and other irritating products.

5.d. Shielding gases used for arc welding can displace air and cause injury or death. Always use enough ventilation, especially in confined areas, to insure breathing air is safe.

5.e. Read and understand the manufacturer’s instructions for this equipment and the consumables to be used, including the material safety data sheet (MSDS) and follow your employer’s safety practices. MSDS forms are available from your welding distributor or from the manufacturer.

5.f. Also see item 1.b.



## WELDING and CUTTING SPARKS can cause fire or explosion.

6.a. Remove fire hazards from the welding area. If this is not possible, cover them to prevent the welding sparks from starting a fire. Remember that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas. Avoid welding near hydraulic lines. Have a fire extinguisher readily available.

- 6.b. Where compressed gases are to be used at the job site, special precautions should be used to prevent hazardous situations. Refer to "Safety in Welding and Cutting" (ANSI Standard Z49.1) and the operating information for the equipment being used.
- 6.c. When not welding, make certain no part of the electrode circuit is touching the work or ground. Accidental contact can cause overheating and create a fire hazard.
- 6.d. Do not heat, cut or weld tanks, drums or containers until the proper steps have been taken to insure that such procedures will not cause flammable or toxic vapors from substances inside. They can cause an explosion even though they have been "cleaned". For information, purchase "Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping That Have Held Hazardous Substances", AWS F4.1 from the American Welding Society (see address above).
- 6.e. Vent hollow castings or containers before heating, cutting or welding. They may explode.
- 6.f. Sparks and spatter are thrown from the welding arc. Wear oil free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes and a cap over your hair. Wear ear plugs when welding out of position or in confined places. Always wear safety glasses with side shields when in a welding area.
- 6.g. Connect the work cable to the work as close to the welding area as practical. Work cables connected to the building framework or other locations away from the welding area increase the possibility of the welding current passing through lifting chains, crane cables or other alternate circuits. This can create fire hazards or overheat lifting chains or cables until they fail.
- 6.h. Also see item 1.c.
- 6.i. Read and follow NFPA 51B "Standard for Fire Prevention During Welding, Cutting and Other Hot Work", available from NFPA, 1 Batterymarch Park, PO box 9101, Quincy, Ma 022690-9101.
- 6.j. Do not use a welding power source for pipe thawing.



## CYLINDER may explode if damaged.

- 7.a. Use only compressed gas cylinders containing the correct shielding gas for the process used and properly operating regulators designed for the gas and pressure used. All hoses, fittings, etc. should be suitable for the application and maintained in good condition.
- 7.b. Always keep cylinders in an upright position securely chained to an undercarriage or fixed support.
- 7.c. Cylinders should be located:
  - Away from areas where they may be struck or subjected to physical damage.
  - A safe distance from arc welding or cutting operations and any other source of heat, sparks, or flame.
- 7.d. Never allow the electrode, electrode holder or any other electrically "hot" parts to touch a cylinder.
- 7.e. Keep your head and face away from the cylinder valve outlet when opening the cylinder valve.
- 7.f. Valve protection caps should always be in place and hand tight except when the cylinder is in use or connected for use.
- 7.g. Read and follow the instructions on compressed gas cylinders, associated equipment, and CGA publication P-1, "Precautions for Safe Handling of Compressed Gases in Cylinders," available from the Compressed Gas Association 1235 Jefferson Davis Highway, Arlington, VA 22202.



## FOR ELECTRICALLY powered equipment.

- 8.a. Turn off input power using the disconnect switch at the fuse box before working on the equipment.
- 8.b. Install equipment in accordance with the U.S. National Electrical Code, all local codes and the manufacturer's recommendations.
- 8.c. Ground the equipment in accordance with the U.S. National Electrical Code and the manufacturer's recommendations.

Refer to <http://www.lincolnelectric.com/safety> for additional safety information.

## PRÉCAUTIONS DE SÛRETÉ

Pour votre propre protection lire et observer toutes les instructions et les précautions de sûreté spécifiques qui paraissent dans ce manuel aussi bien que les précautions de sûreté générales suivantes:

### Sûreté Pour Soudage A L'Arc

1. Protégez-vous contre la secousse électrique:
  - a. Les circuits à l'électrode et à la pièce sont sous tension quand la machine à souder est en marche. Eviter toujours tout contact entre les parties sous tension et la peau nue ou les vêtements mouillés. Porter des gants secs et sans trous pour isoler les mains.
  - b. Faire très attention de bien s'isoler de la masse quand on soude dans des endroits humides, ou sur un plancher métallique ou des grilles métalliques, principalement dans les positions assis ou couché pour lesquelles une grande partie du corps peut être en contact avec la masse.
  - c. Maintenir le porte-électrode, la pince de masse, le câble de soudage et la machine à souder en bon et sûr état de fonctionnement.
  - d. Ne jamais plonger le porte-électrode dans l'eau pour le refroidir.
  - e. Ne jamais toucher simultanément les parties sous tension des porte-électrodes connectés à deux machines à souder parce que la tension entre les deux pinces peut être le total de la tension à vide des deux machines.
  - f. Si on utilise la machine à souder comme une source de courant pour soudage semi-automatique, ces précautions pour le porte-électrode s'appliquent aussi au pistolet de soudage.
2. Dans le cas de travail au dessus du niveau du sol, se protéger contre les chutes dans le cas où on reçoit un choc. Ne jamais enrouler le câble-électrode autour de n'importe quelle partie du corps.
3. Un coup d'arc peut être plus sévère qu'un coup de soliel, donc:
  - a. Utiliser un bon masque avec un verre filtrant approprié ainsi qu'un verre blanc afin de se protéger les yeux du rayonnement de l'arc et des projections quand on soude ou quand on regarde l'arc.
  - b. Porter des vêtements convenables afin de protéger la peau de soudeur et des aides contre le rayonnement de l'arc.
  - c. Protéger l'autre personnel travaillant à proximité au soudage à l'aide d'écrans appropriés et non-inflammables.
4. Des gouttes de laitier en fusion sont émises de l'arc de soudage. Se protéger avec des vêtements de protection libres de l'huile, tels que les gants en cuir, chemise épaisse, pantalons sans revers, et chaussures montantes.
5. Toujours porter des lunettes de sécurité dans la zone de soudage. Utiliser des lunettes avec écrans latéraux dans les zones où l'on pique le laitier.

6. Eloigner les matériaux inflammables ou les recouvrir afin de prévenir tout risque d'incendie dû aux étincelles.
7. Quand on ne soude pas, poser la pince à un endroit isolé de la masse. Un court-circuit accidentel peut provoquer un échauffement et un risque d'incendie.
8. S'assurer que la masse est connectée le plus près possible de la zone de travail qu'il est pratique de le faire. Si on place la masse sur la charpente de la construction ou d'autres endroits éloignés de la zone de travail, on augmente le risque de voir passer le courant de soudage par les chaînes de levage, câbles de grue, ou autres circuits. Cela peut provoquer des risques d'incendie ou d'échauffement des chaînes et des câbles jusqu'à ce qu'ils se rompent.
9. Assurer une ventilation suffisante dans la zone de soudage. Ceci est particulièrement important pour le soudage de tôles galvanisées plombées, ou cadmiées ou tout autre métal qui produit des fumées toxiques.
10. Ne pas souder en présence de vapeurs de chlore provenant d'opérations de dégraissage, nettoyage ou pistolage. La chaleur ou les rayons de l'arc peuvent réagir avec les vapeurs du solvant pour produire du phosgène (gas fortement toxique) ou autres produits irritants.
11. Pour obtenir de plus amples renseignements sur la sûreté, voir le code "Code for safety in welding and cutting" CSA Standard W 117.2-1974.

## PRÉCAUTIONS DE SÛRETÉ POUR LES MACHINES À SOUDER À TRANSFORMATEUR ET À REDRESSEUR

1. Relier à la terre le châssis du poste conformément au code de l'électricité et aux recommandations du fabricant. Le dispositif de montage ou la pièce à souder doit être branché à une bonne mise à la terre.
2. Autant que possible, l'installation et l'entretien du poste seront effectués par un électricien qualifié.
3. Avant de faire des travaux à l'intérieur de poste, la débrancher à l'interrupteur à la boîte de fusibles.
4. Garder tous les couvercles et dispositifs de sûreté à leur place.

## Electromagnetic Compatibility (EMC)

### Conformance

Products displaying the CE mark are in conformity with European Community Council Directive of 15 Dec 2004 on the approximation of the laws of the Member States relating to electromagnetic compatibility, 2004/108/EC. It was manufactured in conformity with a national standard that implements a harmonized standard: EN 60974-10 Electromagnetic Compatibility (EMC) Product Standard for Arc Welding Equipment. It is for use with other Lincoln Electric equipment. It is designed for industrial and professional use.

### Introduction

All electrical equipment generates small amounts of electromagnetic emission. Electrical emission may be transmitted through power lines or radiated through space, similar to a radio transmitter. When emissions are received by other equipment, electrical interference may result. Electrical emissions may affect many kinds of electrical equipment; other nearby welding equipment, radio and TV reception, numerical controlled machines, telephone systems, computers, etc. Be aware that interference may result and extra precautions may be required when a welding power source is used in a domestic establishment.

### Installation and Use

The user is responsible for installing and using the welding equipment according to the manufacturer's instructions. If electromagnetic disturbances are detected then it shall be the responsibility of the user of the welding equipment to resolve the situation with the technical assistance of the manufacturer. In some cases this remedial action may be as simple as earthing (grounding) the welding circuit, see Note. In other cases it could involve construction of an electromagnetic screen enclosing the power source and the work complete with associated input filters. In all cases electromagnetic disturbances must be reduced to the point where they are no longer troublesome.

Note: The welding circuit may or may not be earthed for safety reasons according to national codes. Changing the earthing arrangements should only be authorized by a person who is competent to access whether the changes will increase the risk of injury, e.g., by allowing parallel welding current return paths which may damage the earth circuits of other equipment.

### Assessment of Area

Before installing welding equipment the user shall make an assessment of potential electromagnetic problems in the surrounding area. The following shall be taken into account:

- a) other supply cables, control cables, signaling and telephone cables; above, below and adjacent to the welding equipment;
- b) radio and television transmitters and receivers;
- c) computer and other control equipment;
- d) safety critical equipment, e.g., guarding of industrial equipment;
- e) the health of the people around, e.g., the use of pacemakers and hearing aids;
- f) equipment used for calibration or measurement
- g) the immunity of other equipment in the environment. The user shall ensure that other equipment being used in the environment is compatible. This may require additional protection measures;
- h) the time of day that welding or other activities are to be carried out.

## Electromagnetic Compatibility (EMC)

The size of the surrounding area to be considered will depend on the structure of the building and other activities that are taking place. The surrounding area may extend beyond the boundaries of the premises.

### Methods of Reducing Emissions

#### Mains Supply

Welding equipment should be connected to the mains supply according to the manufacturer's recommendations. If interference occurs, it may be necessary to take additional precautions such as filtering of the mains supply. Consideration should be given to shielding the supply cable of permanently installed welding equipment, in metallic conduit or equivalent. Shielding should be electrically continuous throughout its length. The shielding should be connected to the welding power source so that good electrical contact is maintained between the conduit and the welding power source enclosure.

#### Maintenance of the Welding Equipment

The welding equipment should be routinely maintained according to the manufacturer's recommendations. All access and service doors and covers should be closed and properly fastened when the welding equipment is in operation. The welding equipment should not be modified in any way except for those changes and adjustments covered in the manufacturer's instructions. In particular, the spark gaps of arc striking and stabilizing devices should be adjusted and maintained according to the manufacturer's recommendations.

#### Welding Cables

The welding cables should be kept as short as possible and should be positioned close together, running at or close to floor level.

#### Equipotential Bonding

Bonding of all metallic components in the welding installation and adjacent to it should be considered. However, metallic components bonded to the work piece will increase the risk that the operator could receive a shock by touching these metallic components and the electrode at the same time. The operator should be insulated from all such bonded metallic components.

#### Earthing of the Workpiece

Where the workpiece is not bonded to earth for electrical safety, not connected to earth because of its size and position, e.g., ships hull or building steelwork, a connection bonding the workpiece to earth may reduce emissions in some, but not all instances. Care should be taken to prevent the earthing of the workpiece increasing the risk of injury to users, or damage to other electrical equipment. Where necessary, the connection of the workpiece to earth should be made by a direct connection to the workpiece, but in some countries where direct connection is not permitted, the bonding should be achieved by suitable capacitance, selected according to national regulations.

#### Screening and Shielding

Selective screening and shielding of other cables and equipment in the surrounding area may alleviate problems of interference. Screening of the entire welding installation may be considered for special applications.<sup>1</sup>

---

<sup>1</sup> Portions of the preceding text are contained in EN 60974-10: "Electromagnetic Compatibility (EMC) product standard for arc welding equipment."

	Page
<b>Safety</b> .....	<b>.i-vi</b>
<b>Installation</b> .....	<b>Section A</b>
<b>Operation</b> .....	<b>Section B</b>
<b>Accessories</b> .....	<b>Section C</b>
<b>Maintenance</b> .....	<b>Section D</b>
<b>Theory of Operation</b> .....	<b>Section E</b>
<b>Troubleshooting and Repair</b> .....	<b>Section F</b>
<b>Electrical Diagrams</b> .....	<b>Section G</b>
<b>Parts Manual</b> .....	<b>.P-624</b>
<b>Parts List - Torch</b> .....	<b>.P-210-V</b>



**Installation** ..... **A-1**

    Technical Specifications ..... A-2

    Safety Precautions ..... A-3

    Select Proper Location ..... A-3

    Stacking ..... A-3

    Tilting ..... A-3

    High Frequency Interference Protection ..... A-3

    Input Electrical Connections ..... A-3

    Gas Input Connections ..... A-4

    Output Connections ..... A-4

        Torch ..... A-4

        Built-In Compressor ..... A-4

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

## TECHNICAL SPECIFICATIONS -TOMAHAWK® 375 AIR

### INPUT - SINGLE PHASE 60 HERTZ

#### Standard Voltage

208V, 230V ±10% / 1 / 60Hz

### RATED OUTPUT AT 40° C

Duty Cycle	CURRENT AMPS	VOLTAGE AMPS
100%	13 A	85.2 VDC
60%	18 A	87.2 VDC
35%	25 A	90 VDC

### OUTPUT

Current Range	Open Circuit Voltage	Pilot Current
10-25 Amps	460 VDC	12 Amps

### REQUIRED GAS FLOW RATE

70 PSI @ 125-200 SCFH  
( 5 Bar. @ 80±20 LITERS/MIN.)

### REQUIRED GAS INLET PRESSURE

80 to 110 PSI  
(6 Bar. to 7.5 Bar.)

### RECOMMEND INPUT WIRE AND FUSE SIZES

For all plasma cutting applications  
Based on U.S. National Electrical Code  
Ambient Temperature 30°C or Less

Output	AC Input Voltage at 60 Hertz	Input Cord Plug Size	Fuse (Super Lag) Circuit Breaker (Delay Type)	Type 75°C Copper Wire in Conduit AWG (IEC) Sizes	
				2 Input Supply Wires	1 Ground Wire
25 A	230V-1Ø 208V-1Ø	6-50P	20 AMPS	#12 (3.3 mm <sup>2</sup> )	#12 (3.3 mm <sup>2</sup> )

### PHYSICAL DIMENSIONS

Height	Width	Depth	Weight Including Torch Cable
15.2 in. 385 mm	8.5 in. 215 mm	18.9 in. 480 mm	40 - 40.8 lbs. 18-18.5 kg.

### TEMPERATURE RANGES

OPERATING TEMPERATURE RANGE	STORAGE TEMPERATURE RANGE
-10°C to +40°C	-10°C to +40°C

TOMAHAWK® 375 AIR



Read entire Installation Section before installing the TOMAHAWK® 375 AIR.

## SAFETY PRECAUTIONS

### ⚠ WARNING

#### ELECTRIC SHOCK CAN KILL.



- Only qualified personnel should install this machine.
- Turn the input power OFF at the disconnect switch or fuse box and discharge input capacitors before working inside the equipment.
- Do not touch electrically hot parts.
- Turn the TOMAHAWK® 375 AIR Power Switch OFF when connecting power cord to input power.

#### SELECT PROPER LOCATION

Place the TOMAHAWK® 375 AIR where clean cool air can freely circulate in and out the side louvers. Dirt, dust or any foreign material that can be drawn into the machine should be kept at a minimum. Failure to observe these precautions can result in excessive operating temperatures and nuisance shutdown of the machine.

A source of clean, dry air or nitrogen must be supplied to the TOMAHAWK® 375 AIR when using external air supply. Oil in the air is a severe problem and must be avoided. The supply pressure must be between 80 and 150 psi. The flow rate is approximately 4.0 cfm (113 l/min.). Failure to observe these precautions could result in excessive operating temperatures or damage to the torch.

#### STACKING

The TOMAHAWK® 375 AIR cannot be stacked.

#### TILTING

The TOMAHAWK® 375 AIR must be placed on a stable, level surface so it will not topple over.

## HIGH FREQUENCY INTERFERENCE PROTECTION

The TOMAHAWK® 375 AIR employs a touch start mechanism for arc initiation which eliminates high frequency emissions from the machine as compared with spark gap and solid state type high frequency generators. Keep in mind, though, that these machines may be used in an environment where other high frequency generating machines are operating. By taking the following steps, high frequency interference into the TOMAHAWK® 375 AIR can be minimized

- (1) Make sure the power supply chassis is connected to a good earth ground. The work terminal ground does NOT ground the machine frame.
- (2) Keep the work clamp isolated from other work clamps that have high frequency.
- (3) If the work clamp cannot be isolated, then keep the clamp as far as possible from other work clamp connections.
- (4) When the machine is enclosed in a metal building, several good earth driven electrical grounds around the periphery of the building are recommended.

Failure to observe these recommended installation procedures may cause improper function of the TOMAHAWK® 375 AIR or possibly even damage to the control system or power supply components.

## INPUT ELECTRICAL CONNECTIONS

The TOMAHAWK® 375 AIR is rated for 208VAC and 230VAC input voltage. Before installing the machine, check that input supply voltage, phase, and frequency are the same as the machine's voltage, phase, and frequency as specified on the machine's rating plate.

- The TOMAHAWK® 375 AIR should be connected only by a qualified electrician. Installation should be made in accordance with local codes.

For use on engine drives, keep in mind the above input draw restrictions and the following precaution.

The TOMAHAWK® 375 AIR can be operated on engine driven generators as long as the 230 volt auxiliary meets the following conditions:

- The AC waveform peak voltage is below 400 volts.
- The AC waveform frequency is between 55 and 65 Hz.
- The RMS voltage of the AC waveform is always greater than 208VAC.

The following Lincoln engine drives meet these conditions when run in the high idle mode:

Ranger 250, 250LPG, 305G and 305D engine drives.  
Vantage 300, 400, 500 and Air Vantage engine drives.

Some engine drives do not meet these conditions. Operation of the TOMAHAWK® 375 AIR is not recommended on engine drives not conforming to these conditions. Such combinations may overvoltage the TOMAHAWK® 375 AIR power source.

## GAS INPUT CONNECTIONS

(External Air Supply)

Supply the TOMAHAWK® 375 AIR with clean compressed air or nitrogen.

- Supply pressure must be between 80 psi and 110 psi.
- Flow rate should be approximately 4.0 cfm (113 l/min.).

**NOTE:** Oil in the air supply to the TOMAHAWK® 375 AIR can cause severe problems. Use only a clean air supply.

- Compressed gas can be supplied either through the air fitting supplied with the machine or through the 1/4-19 BSPP thread at the rear of the machine. To use the air fitting supplied with the machine (packaged in the consumable kit), apply teflon tape to the fitting threads and install the fitting in the port at the rear of the machine.
- If compressed air is being used, it is highly recommended that an in line filter be installed in the air supply line ahead of the air connection to the TOMAHAWK® 375 AIR.
- A standard nominal 5 micron in line filter is recommended; however, for optimum performance, select a prefilter with a 3 micron absolute rating.

If these filter ratings are unavailable, anything with a rating less than, or equal to, 20 micron would be acceptable to use. In line filter elements will generally filter the air with little restriction to the airflow until the element is about 75% contaminated. After this point, there will be a noticeable pressure drop in the line. Filter elements should be replaced when a pressure drop of 8-10 psi is indicated; however, for optimum performance of the TOMAHAWK® 375 AIR, the filter element should be replaced at or before the pressure drop reaches 8 psi. Be sure to select a filter that will accommodate the necessary flow rating for the TOMAHAWK® 375 AIR as specified in the Installation section of this instruction manual under the Gas Input Connections heading.

**NOTE:** When using nitrogen gas from a cylinder, the cylinder must have a pressure regulator.

- Maximum psi from a nitrogen gas cylinder to the TOMAHAWK® 375 AIR regulator should never exceed 110 psi.
- Install a hose between the nitrogen gas cylinder regulator and the TOMAHAWK® 375 AIR gas inlet.

## ⚠ WARNING



**CYLINDER** could explode if damaged.

- **Keep cylinder upright and chained to a fixed support.**
- **Keep cylinder away from areas where it could be damaged.**
- **Never lift machine with cylinder attached.**
- **Never allow the cutting torch to touch the cylinder.**
- **Keep cylinder away from live electrical parts.**
- **Maximum inlet pressure 110 psi.**

## OUTPUT CONNECTIONS

### Torch

The TOMAHAWK® 375 AIR is sent from the factory with a cutting torch and work clamp installed. The work clamp must be securely connected to the work piece. If the work piece is painted or extremely dirty it may be necessary to expose the bare metal in order to make a good electrical connection.

### Built-In Compressor

This machine has a built-in compressor that allows operation in areas where an air supply is not available. Only input voltage is necessary! The compressor provides a fixed pressure.

Read and understand this entire section before operating the machine.

TOMAHAWK® 375 AIR



**Operation** ..... **B-1**

    Safety Precautions ..... B-2

    Description ..... B-2

    Preheat Temperature for Plasma Cutting ..... B-2

    User Responsibility ..... B-3

    Design Features and Advantages ..... B-3

    Cutting Capability ..... B-4

    Consumable Life ..... B-4

    Limitations ..... B-5

    Controls and Settings ..... B-5, B-6

    Cutting Process ..... B-6, B-7

    Pilot Arc Discussion ..... B-8

    Procedure Recommendations ..... B-8

        General ..... B-8

        Suggestions for Extra Utility from the TOMAHAWK® 375 AIR System ..... B-9

    Torch Part Configurations ..... B-10

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

## SAFETY PRECAUTIONS

## DESCRIPTION

**⚠ WARNING****ELECTRIC SHOCK can kill.**

- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.

**FUMES AND GASES can be dangerous.**

- Keep your head out of fumes.
- Use ventilation or exhaust to remove fumes from breathing zone.

**WELDING, CUTTING and GOUGING SPARKS can cause fire or explosion**

- Keep flammable material away.
- Do not weld, cut or gouge on containers that have held combustibles.

**ARC RAYS can burn.**

- Wear eye, ear and body protection.

**PLASMA ARC can injure**

- Keep your body away from nozzle and plasma arc.
- Operate the pilot arc with caution. The pilot arc is capable of burning the operator, others or even piercing safety clothing.

Observe additional Safety Guidelines detailed in the beginning of this manual.

The TOMAHAWK® 375 AIR is a constant current, continuous control plasma cutting power source. It provides superior and reliable starting characteristics, cutting visibility and arc stability. The control system has a safety mechanism to insure that the nozzle and electrode are in place before cutting or gouging. This is extremely important due to the high voltages involved.

The TOMAHAWK® 375 AIR comes standard with an air regulator and pressure gauge. The machine also comes with an input power cord, Hand-held torch with a 10' cable length. Consumables are included with each TOMAHAWK® 375 AIR purchase so that cutting can begin right out of the box. Consumables can also be ordered as individual packages.

The TOMAHAWK® 375 AIR initiates the plasma arc with a simple, yet reliable, touch start mechanism. This system eliminates many of the failure problems associated with hi-frequency start systems.

**PREHEAT TEMPERATURE FOR PLASMA CUTTING**

Preheat temperature control is not necessary in most applications when plasma arc cutting or gouging. Preheat temperature control may be necessary on high carbon alloy steels and heat treated aluminum for crack resistance and hardness control. Job conditions, prevailing codes, alloy level, and other considerations may also require preheat temperature control. The following minimum preheat temperature is recommended as a starting point. Higher temperatures may be used as required by the job conditions and/or prevailing codes. If cracking or excessive hardness occurs on the cut face, higher preheat temperature may be required. The recommended minimum preheat temperature for plate thickness up to 1/2" (12.7mm) is 70°F (21.1°C).

## USER RESPONSIBILITY

Because design, fabrication, erection and cutting variables affect the results obtained in applying this type of information, the serviceability of a product or structure is the responsibility of the user. Variation such as plate chemistry, plate surface condition (oil, scale), plate thickness, preheat, quench, gas type, gas flow rate and equipment may produce results different than those expected. Some adjustments to procedures may be necessary to compensate for unique individual conditions. Test all procedures duplicating actual field conditions.

## DESIGN FEATURES AND ADVANTAGES

The TOMAHAWK® 375 AIR design makes plasma cutting uncomplicated. This list of design features and advantages will help you understand the machine's total capabilities so that you can get maximum use from your machine.

- Light weight and portable design for industrial use.
- Continuous control, 10 - 25 amps.
- Reliable touch start mechanism for plasma arc initiation.
- Rapid arc restrike for fast cutting of expanded metal.
- Input over voltage protection.
- Bright 3.0 second timed pilot arc.
- Purge section on output dial.
- Air regulator and pressure gauge included.
- Internal water separator included.
- Parts-in-Place mechanism to detect proper installation of consumables and torch.
- Preflow/Postflow timing. Preflow is eliminated if arc is re-initiated in Postflow.
- Thermostatic Protection.
- Solid state over-current protection.
- Unique electrode and nozzle design for optimum cooling and long life.

### CUTTING CAPABILITY

The TOMAHAWK® 375 AIR is rated at 25 amps, at 35% duty cycle on a 10 minute basis. If the duty cycle is exceeded, a thermal protector will shut off the output of the machine until it cools to the normal operating temperature.



Figure B.1 shows the cut capacity of the TOMAHAWK® 375 AIR when cutting mild steel. (The graph plots cut thickness vs. torch travel speed with a torch standoff of 0.15".)

### CONSUMABLE LIFE

The expected life for the TOMAHAWK® 375 AIR's electrode under normal operating conditions is approximately 1000 starts/cuts. An erosion of .060" is typical for end of electrode life, however, the electrode life may last longer. A green and erratic arc will indicate definite electrode failure and the electrode should be replaced immediately.

It is recommended that consumables be replaced in complete sets. (Example: Electrode and Nozzle). This will maximize the performance of the TOMAHAWK® 375 AIR system.

Figure B.1



TOMAHAWK® 375 AIR



Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC



### LIMITATIONS

Do not exceed output current and duty cycle rating of machine. Do not use the TOMAHAWK® 375 AIR for pipe thawing.


Continuous cutting with the internal compressor can only be performed for approximately 4 minutes. The compressor has an internal thermostat to protect it from over heating.

### CONTROLS AND SETTINGS

(Figure B.2)

TOMAHAWK® 375 AIR front command panel.

FIGURE B.2



1. **Output Current Knob:** Potentiometer used to set the output current used during cutting. Refer to the Technical Specification section for more information about the machine's rated current range.

**Air Purge:** The Output Current Knob completely rotated counterclockwise enables the air purge function. A five minute timeout stops the purge function; this will occur only if the Output Current Knob remains in the purge mode for an extended time.

- 2. **Power ON/OFF green LED:** Illuminates when the machine is ON.
- 3. **Output red LED:** See the following table.
- 4. **Thermal yellow LED:** See the following table.

LEDs		Description
Output (Red)	Thermal (Yellow)	
On	Off	The cutting torch is energized.
On	On	<b>Part in place error:</b> the retaining cap is not properly Attached.  To restore the machine: <ul style="list-style-type: none"> <li>• Install the torch retaining cap firmly in place.</li> <li>• Wait for 5 seconds; during this time the output and thermal LED's blinks alternately.</li> <li>• After 5 seconds the machine is automatically restored and ready to operate.</li> </ul>
Off	On	The machine is overheated and the output has been disabled. This usually occurs when the duty cycle of the machine has been exceeded. Leave the machine On to allow the internal components to cool. When the thermal LED turns off, normal operation is again possible.
Off	Blink	<b>Power undervoltage error:</b> the machine is disabled. When the power returns to the correct range, the machine will restart automatically.
Blink	Off	Low air pressure error.  To check / adjust the air pressure (see recommended values in the Technical Specifications of this manual): <ul style="list-style-type: none"> <li>• Put the machine in Purge mode [1].</li> <li>• Check and adjust the air pressure using the pressure gauge and air pressure regulator knob [6].</li> <li>• If necessary, check and adjust also the inlet air pressure by adjusting the external compressor.</li> </ul>

See more information in the **Troubleshooting Section under Error Codes.**

Return to Section TOC

Return to Master TOC

**5. Internal / External Air selection:** This switch selects the air supply. With the Internal Compressor position selected, the machine operates through the built-in compressor. With the External Air position selected, the internal compressor is completely disabled and the machine operates through an external air supply hose connected to the proper air inlet connection located on the back of the machine.

### ⚠ WARNING

If operating with External Air, be sure to select the External Air switch position in order to completely disable the built-in compressor. Otherwise the compressor may be damaged by the possibility of greater external air pressure.

**6. Air Pressure Gauge and Regulator Knob:** Allows regulation and monitoring of the air pressure.

**Items 7 thru 10 on the back of the TOMAHAWK® 375 AIR (See Figure B.3)**


**7. Fan:** Provides machine cooling. When the machine is switched ON, the fan runs continuously.

**8. Power Switch:** Turns ON / OFF the input power to the machine.

**9. Input cable:** Connects unit to the input power.

**10. Air Inlet:** External Air operating mode only. Compressed Air Connection.

FIGURE B.3



### ⚠ WARNING

**Clean, dry air must be supplied to the machine. A pressure setting above 110 PSI (7.5 bar) could damage the torch. Failure to observe these precautions could result in excessive operating temperatures or damage to the torch.**

### CUTTING PROCESS

When preparing to cut, position the machine as close to the work as possible. Make sure to have all materials needed to complete the job and have taken all safety precautions. It is important to follow these operating steps each time the machine is used.

Turn the machine's ON/OFF POWER SWITCH to the OFF position.

- Select the air supply using AIR select switch.
- Connect the air supply to the machine, if using external air supply mode.
- Turn the main power on and the machine power switch to the ON position.
  - The fan will start.
  - The pre-charge circuit will operate for 3 seconds, then the green "Power" LED will illuminate.
- Attach the work lead clamp to the workpiece before cutting.
- Set the output current control knob to maximum position for higher cutting speed and less dross formation. Reduce the current, if desired to reduce the kerf (cut) width, heat affected zone, or travel speed as required.


**NOTE:** If the circuit breaker trips while cutting at higher amperages - reduce the cutting amperage on the unit, or provide an input circuit with higher current capacity.

- Rotate the output knob into the purge zone to check or set the gas pressure. Pull the pressure regulator cap out and turn it to set the pressure.
  - Adjust the gas regulator for 75-80 PSI (0.50-0.55 MPa).
  - Turn the output knob out of the purge zone.
  - The gas will immediately turn off. The pressure gauge may show an increase in pressure after the air turns off but this is normal. Do NOT reset the pressure while the air is NOT flowing.


TOMAHAWK® 375 AIR



- When ready to cut, place the torch near the work, make certain all safety precautions have been taken and pull the trigger.
  - The air will flow for a preflow time of 2 seconds and the pilot arc will start. (Exceptions: the first time that the trigger is pulled after the machine is turned on, or after a thermal trip out, initial trigger will be ignored. This is a safety feature to prevent the pilot arc from firing unexpectedly or if the torch trigger is inadvertently pressed. The other exception is if the machine is in postflow, then the preflow time is skipped and the pilot arc will start immediately.)
  - The pilot arc will run for 3.0 seconds and shut off unless the arc is brought in contact with the work and the arc is transferred. Avoid excessive pilot arc time by transferring the arc to the workpiece quickly. This will extend consumable life.
  - When the arc is brought within 1/8" - 1/4" from the work piece: the arc will transfer, the current will ramp to the setting on the control panel, and the cut can last indefinitely (or until the duty cycle of the TOMAHAWK® 375 AIR is exceeded).
- Pierce the work piece by slowly lowering the torch onto the metal at a 30° angle away from the operator. This will blow the dross away from the torch tip. Slowly rotate the torch to vertical position as the arc becomes deeper.



- Keep moving while cutting. Cut at a steady speed without pausing. Maintain the cutting speed so that the arc lag is 10° to 20° behind the travel direction.



- Use a 5° - 15° leading angle in the direction of the cut.
- Finish the cut to be made and release the trigger.
- When the trigger is released, the arc will stop.
  - The gas will continue to flow for 15 seconds of postflow. If the trigger is activated within this time period, the pilot arc will immediately restart.
- If the dross is difficult to remove, reduce the cutting speed. High speed dross is more difficult to remove than low speed dross.

### ⚠ WARNING



#### ELECTRIC SHOCK CAN KILL.

- Turn off machine at the disconnect switch on the rear of the machine before tightening, cleaning or replacing consumables.

- Clean spatter and scale from the nozzle frequently.

### TORCH

- During operation, if the Red and Yellow LED's light together:
- Check the assembly of the torch consumables. If they are not properly in place, the machine will not start. **Make sure that the shield cup is hand tight. Do not use pliers or over tighten.**
- Check the conditions of the inside of the nozzle. If debris has collected, rub the electrode on the inside bottom of the nozzle to remove any oxide layer that may have built up. Refer to "Suggestions for Extra Utility from the TOMAHAWK® 375 AIR system".
- Check the condition of the electrode. If the end has a crater-like appearance, replace it along with the nozzle. The maximum wear depth of the electrode is approximately .062". A green and erratic arc will indicate definite electrode failure and the electrode should be replaced immediately.

TOMAHAWK® 375 AIR



- Replace the nozzle when the orifice exit is eroded away or oval shaped.
- After the problem is found, or if there is nothing apparently wrong, reset the machine by turning the power switch OFF and then ON again. (It is possible for electrical noise to trip the safety circuit on rare occasions. This should not be a regular occurrence.)
- If the machine does not reset or continues to trip, consult the Troubleshooting Section.
- Use the proper cutting procedures referred to in Procedure Recommendations.

## PILOT ARC DISCUSSION

The TOMAHAWK® 375 AIR has a smooth, continuous pilot arc. The pilot arc is only a means of transferring the arc to the workpiece for cutting. Repeated pilot arc starts, in rapid succession, is not recommended as these starts will generally reduce consumable life. Occasionally, the pilot arc may sputter or start intermittently. This is aggravated when the consumables are worn or the air pressure is too high. Always keep in mind that the pilot arc is designed to transfer the arc to the workpiece and not for numerous starts without cutting.


The TOMAHAWK® 375 AIR does not utilize high frequency starting. When the pilot arc is started, a slight impulse will be felt in the torch handle. This occurrence is normal and is the mechanism which starts the plasma arc. This impulse can also be used to help troubleshoot a "no start" condition.

## PROCEDURE RECOMMENDATIONS

When properly used, plasma arc cutting is a very economical process. Improper use will result in a very high operating cost.

### General - In All Cases

- Follow safety precautions as printed throughout this operating manual and on the machine.
- If piercing is required, slowly lower the torch at an angle of about 30° to blow the dross away from the torch tip and slowly rotate the torch to a vertical position as the arc becomes deeper. This process will blow a lot of molten metal and dross. Be careful! Blow the dross away from the torch, the operator and any flammable objects.
- The nozzle should not be dragged on the metal surface. A drag spacer is provided to maintain a consistent touch height. Refer to **Touch Parts Configurations** in this Section.



- Where possible, start the cut from the edge of the work piece.
- Keep moving! A steady speed is necessary. Do not pause.

## Suggestions for Extra Utility from the TOMAHAWK® 375 AIR System:

### WARNING



#### ELECTRIC SHOCK CAN KILL.

- Turn off machine at the disconnect switch on the rear of the machine before tightening, cleaning or replacing consumables.

- Set air pressure to recommended setting. A higher or lower pressure will cause turbulence in the plasma arc, eroding the orifice of the nozzle tip.
- Use only Lincoln consumable parts. These parts are patented and using any other replacement consumables may cause damage to the torch or reduce cut quality.

1. Occasionally an oxide layer may form over the tip of the electrode, creating an insulating barrier between the electrode and nozzle. This will result in the tripping of the TOMAHAWK® 375 AIR's safety circuit. When this happens turn the power off, remove the nozzle and electrode and use the electrode to rub against the inside bottom surface of the nozzle. This will help remove any oxide buildup. Replace the nozzle, turn on the power and continue cutting. If the safety circuit continues to trip after cleaning the consumables, then replace them with a new set. Do not continue to try and cut with excessively worn consumables as this can cause damage to the torch head and will degrade cut quality. Do not allow torch cable or body to contact hot surface.

2. To improve consumable life, here are some suggestions that may be useful:

- Make sure the air supply to the TOMAHAWK® 375 AIR is clean and free of oil. Use several extra in line filters if necessary.
- Minimize dross buildup on the nozzle tip by starting the cut from the edge of the plate when possible.
- Pierce cutting should be done only when necessary. If piercing, angle torch about 30° from the plane perpendicular to the work piece, transfer the arc, then bring the torch perpendicular to the work and begin parallel movement.
- Reduce the number of pilot arc starts without transferring to the work.
- Reduce the pilot arc time before transferring to the work.


[Return to Section TOC](#) | [Return to Section TOC](#) | [Return to Section TOC](#) | [Return to Master TOC](#) | [Return to Master TOC](#) | [Return to Master TOC](#)

**TORCH PART CONFIGURATIONS**


The Tomahawk® 375 Air uses a standard cutting setup as described below.

**Standard Cutting Setup:**

In the Standard Cutting configuration the nozzle is designed not to touch the work piece. The advantage of this cutting method is good visibility of the arc. However it requires a steady hand to avoid touching the nozzle to the work piece which will cause premature nozzle wear and a jagged cut. An optional drag spacer can be attached to the retaining cap to maintain a consistent arc height.



STANDARD



Refer to the torch parts decal located on your machine or the parts pages at the back of this manual for the specific part numbers required for each of these setups.

**ALWAYS USE GENUINE LINCOLN ELECTRIC ELECTRODES, NOZZLES, AND EXPENDABLE PARTS FOR THE BEST CUTTING PERFORMANCE.**

**Accessories** ..... **C-1**

    General Options / Accessories ..... C-2

    Torches ..... C-2

    Expendable Parts ..... C-2

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

## GENERAL OPTIONS /ACCESSORIES

The following options/accessories are available for your Tomahawk® Plasma cutter from your local Lincoln Distributor.

### **K2377-1 - Small Canvas Cover**

Protect your machine when not in use. Made from attractive red canvas that is flame retardant, mildew resistant and water repellent. It includes a convenient side pocket to hold the plasma torch.

### **K2886-1 - Plasma Circle Cutting Kit (Tomahawk®) –**

For cutting circles from 3” to 33” in diameter (77mm to 838mm).

## TORCHES

The following replacement torch is available:

### **K2846-1 LC25 Handheld Plasma Torch 10' (3m)**

## EXPENDABLE PARTS

Refer to the torch parts decal located on your machine or the parts pages at the back of this manual for the specific part numbers required for each of the available setups.



**Maintenance** .....D-1

    Safety Precautions .....D-2

    Routine Maintenance .....D-2

    Periodic Maintenance .....D-2

    Thermal Protection .....D-2

    Major Component Locations .....D-3

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

## SAFETY PRECAUTIONS

### ⚠ WARNING



#### ELECTRIC SHOCK CAN KILL.

- Have an electrician install and service this equipment.
- Turn the input power off at the fuse box before working on equipment.
- Do not touch electrically hot parts.

## ROUTINE MAINTENANCE

1. Keep the cutting or gouging area and the area around the machine clean and free of combustible materials. No debris should be allowed to collect which could obstruct air flow to the machine.
2. Every 6 months or so, the machine should be cleaned with a low pressure airstream. Keeping the machine clean will result in cooler operation and higher reliability. Be sure to clean these areas:
  - Printed circuit boards and heat sinks
  - Power switch

### ⚠ CAUTION

- When using a low pressure air stream, wear appropriate eye protection.

3. Examine the sheet metal case for dents or breakage. Repair the case as required. Keep the case in good condition to insure that high voltage parts are protected and correct spacings are maintained. All external sheet metal screws must be in place to insure case strength and electrical ground continuity.
4. Inspect the cable periodically for any slits or puncture marks in the cable jacket. Replace if necessary. Check to make sure that nothing is crushing the cable and blocking the flow of air through the air tube inside. Also, check for kinks in the cable periodically and relieve any so as not to restrict the flow of air to the torch.
5. Regularly clean the compressor air inlet filter.



## PERIODIC MAINTENANCE

### ⚠ WARNING



#### ELECTRIC SHOCK CAN KILL.

- Turn off machine at the disconnect switch on the rear of the machine before tightening, cleaning or replacing consumables.

Change consumables as required.

## THERMAL PROTECTION


Thermal Detection Devices protect the machine from excessive operating temperatures. Excessive temperatures may be caused by a lack of cooling air or operating the machine beyond the duty cycle and output rating. If excessive operating temperatures should occur, the yellow thermal LED will light and the Detection Devices will prevent output voltage or current.

These Detection Devices are self-resetting once the machine cools sufficiently. If the thermostat shutdown was caused by excessive output or duty cycle and the fan is operating normally, the Power Switch may be left on and the reset should occur within a 15 minute period. If the fan is not turning or the air intake louvers were obstructed, then the power must be switched off and the fan problem or air obstruction must be corrected.

A protection circuit is included to monitor the voltage across filter capacitors. In the event that the capacitor voltage is too high, the protection circuit will prevent output.

FIGURE D.1 MAJOR COMPONENT LOCATION

1. Case Front
2. Case Back
3. Handle
4. Base
5. Foot
6. Wraparound
8. Control Panel
9. Nameplate
10. Inverter P.C. Board
11. Control P.C. Board
12. Compressor
13. Air Filter (Internal/External Air)
14. Air Filter (Internal Compressor Air)
15. Pressure Switch
16. Air Inlet Pass Through
17. Gas Solenoid
18. Pressure Gauge w/Pressure Regulator
19. Single Direction Air Valve
20. Switch (Air Selection)
21. Switch (Power)
22. Input Cord
23. Cable Clamp (Input Cord)
24. Workpiece Cable
25. Cable Clamp (Workpiece Clamp)
26. Knob
27. Fan
28. Vibration Mount



TOMAHAWK® 375 AIR



Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

TOMAHAWK® 375 AIR



Theory of Operation .....E-1

General Description .....E-2


Inverter Board .....E-3/E-5

Control Board And Fan Motors .....E-6

Air Compressor .....A-7

Torch Assembly And Work Lead .....E-8


FIGURE E.1 BLOCK LOGIC DIAGRAM



TOMAHAWK® 375 AIR



FIGURE E.2 - GENERAL DISCRPTION



## GENERAL DESCRIPTION

The Tomahawk® 375 AIR is an inverter based constant current, continuous control, plasma cutting power source. The control system has a safety mechanism to insure that the torch nozzle and electrode are correctly in place before cutting or gouging. The Tomahawk® 375 AIR has the capabilities to cut metal material such as mild steel, aluminum, or stainless steel up to ½ inch thick. The input voltage requirement is 208-230VAC, 60Hz. The output voltage is DC positive on the work piece and torch nozzle.

The main elements of the machine are:


- Inverter Board
- Control Board
- Air compressor
- Torch

NOTE: Unshaded areas of Block Logic Diagram are the subject of discussion

TOMAHAWK® 375 AIR



### FIGURE E.3 - INVERTER BOARD



## INVERTER BOARD

This machine is designed on the “single board” concept in which all of the electronic devices are housed on one printed circuit board.

The single phase input voltage (208-230VAC) is connected to the Tomahawk® inverter board via an input cord and power switch located on the back of the machine. The input power is applied first to a filter circuit and then to a pre-charge relay circuit. This pre-charge circuit limits the in-rush current through the input rectifier so that the input capacitors are charged in a controlled manner. When the pre-charge sequence is completed the pre-charge relay closes connecting full input power to the filter capacitors. This rectified and filtered DC voltage (325VDC @ 230VAC input) is used to power the half-wave bridge circuit and generate several DC voltages for the on board CPU and electronics.

NOTE: Unshaded areas of Block Logic Diagram are the subject of discussion

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC


Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

## FIGURE E.4 - INVERTER BOARD



### INVERTER BOARD (continued)

The 325VDC developed at the input bridge and filter capacitors is applied to a half-bridge inverter circuit that utilizes high speed switching transistors. These Insulated Gated Bipolar Transistors (IGBT) operate at 50kHz. and are controlled by the analog inverter control circuit. A green LED provides an indication that the analog inverter control is sending a firing signal to the IGBTs. The output of the IGBTs is pulse width modulated and applied to the primary winding of the ferrite core power transformer. When the current is pulsed through this primary winding, a resultant current is produced on the secondary winding of the power transformer. The DC current flow through the primary winding is redirected or "clamped" back to the filter capacitors when the IGBTs are turned off. This function is required due to the inductance of the transformer's primary winding.

The secondary winding supplies the electrode-to-nozzle (pilot arc) and the electrode-to-work (cutting arc) voltages and the resulting currents. The secondary voltage is rectified and filtered and applied to the torch and work piece for cutting and pilot arc. The pilot arc is turned on and off by an IGBT. The cutting output is regulated via the pulse width modulation applied to the primary winding.

The primary current passes through the primary current feedback device that sends a signal to the analog inverter control circuit. This feedback information and the analog inverter control signal limit the maximum primary current flow through the IGBTs.

NOTE: Unshaded areas of Block Logic Diagram are the subject of discussion

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC


Return to Master TOC

Return to Section TOC

Return to Master TOC



FIGURE E.5 - INVERTER BOARD



## INVERTER BOARD (continued)

There are several other functions and circuits housed on the Inverter Board. The flyback circuit utilizes the (325VDC @ 230VAC) input to generate the auxiliary power supplies (25VDC, 15VDC, and 3.3VDC) for the machine's internal electronic circuitry.

The output cutting current is monitored on the Inverter Board by the TA current transformer. This output feedback information is sent to the Digital Signal Processor Microcontroller where it is compared to the output command signal received from the control board. The cutting output signal is then sent to the Analog Inverter Control. The circuitry associated with the Digital Signal Processor also monitors the input voltage for over or under input voltage conditions. The torch safety "parts-in-place" and trigger circuits are also connected to and monitored by the Inverter Board.

In the case of an overheating condition the thermal sensor (located on the output diode heatsink) will shut down the machine and prevent output.

The Inverter Board monitors the air pressure and controls the air solenoid. When more air pressure is required a compressor control signal is received by an optocoupling circuit and the compressor motor is energized with the input voltage via a triac.

NOTE: Unshaded areas of Block Logic Diagram are the subject of discussion

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC


Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

FIGURE E.6 - CONTROL BOARD AND FAN MOTORS



## CONTROL BOARD AND FAN MOTORS

The control board is located on the front panel of the Tomahawk® 375 Air machine. The function of this board is to house the current setting potentiometer and three signal LED's. The supply voltages and signals are communicated between the control board and the inverter board by a flat ten lead cable.

The different combinations of a steady or blinking LED provides the user with several conditions of the machine's operation and status.

The steady green LED indicates that the input power is applied and the machine is on.


The two cooling fans are operated by the input line voltage and are energized whenever the power switch is turned on.

RED LED	YELLOW LED	MEANING
ON	OFF	The cutting torch is energized.
ON	ON	Torch parts in place error
OFF	ON	The machine is over-heated and the output has been disabled.
OFF	BLINKING	Input under or over voltage. Output has been disabled.
BLINKING	OFF	Low air pressure error. Output has been disabled.

NOTE: Unshaded areas of Block Logic Diagram are the subject of discussion

[Return to Section TOC](#) | [Return to Master TOC](#)

FIGURE E.7 - AIR COMPRESSOR



## AIR COMPRESSOR

The Tomahawk® 375 Air has an internal air compressor so the machine does not need an external air supply to cut metal. The aluminum alloy compressor is driven by a single phase ½ horse power motor. The motor is powered by the input line voltage (208-230VAC) via a triac circuit located on the inverter board.

There is also the option to supply the Tomahawk® using an external air source. If an external air supply is used it is necessary to turn-off the internal compressor using the switch located on the front panel of the Tomahawk®.


When using the **internal** compressor it is necessary to remove the **external** air supply hose from the Tomahawk®.

NOTE: Unshaded areas of Block Logic Diagram are the subject of discussion

TOMAHAWK® 375 AIR



FIGURE E.8 - TORCH ASSEMBLY AND WORK LEAD



## TORCH ASSEMBLY AND WORK LEAD

The torch assembly and work lead are connected directly to the inverter board, inside the machine, using printed circuit board fast-on connections. This torch is designed to provide the best cutting performance and excellent consumable life.

The torch head components are the electrode, swirl ring, nozzle, retaining cap and spacer. This torch has a lift pilot arc striking system which means that during the idle state the electrode and nozzle are touching and shorted together. As soon as the torch trigger is activated the pilot current flows through the electrode and nozzle. When the air flow arrives at the torch head the electrode is "pulled" back and the pilot arc is established between the electrode and nozzle. As the torch is brought closer to the work the pilot arc transfers to the work piece and the cutting arc is established.

NOTE: Unshaded areas of Block Logic Diagram are the subject of discussion

TOMAHAWK® 375 AIR



Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

**Troubleshooting and Repair** .....F-1

    How to Use Troubleshooting Guide .....F-2

    PC Board Troubleshooting Procedures .....F-3

    Troubleshooting Guide .....F-4/F-9

    Error Signals .....F-10

    Test Procedures .....F-11

        Input Filter Capacitor Discharge Procedure .....F-11

        Torch LC25 Test .....F-15

        Inverter Board Test .....F-19

        Air/Gas Solenoid Test .....F-25

        Control Board Potentiometer .....F-27

    Removal and Replacement Procedures .....F-31

        Case Wraparound Removal and Replacement .....F-31

        Nameplate Removal and Replacement .....F-35

        Front Panel Removal and Replacement .....F-39

        Torch LC25 Removal and Replacement .....F-43

        Control Board Removal and Replacement .....F-47

        Regulator / Pressure Gauge Removal and Replacement .....F-51

        Compressor Switch Removal and Replacement .....F-55

        Fan Removal and Replacement .....F-59

        Inverter Board Removal and Replacement .....F-63

        Compressor Removal and Replacement .....F-69

        Pressure Switch Removal and Replacement .....F-73

        Solenoid Valve Removal and Replacement .....F-77

        Oil and Water Trap Removal and Replacement .....F-81

        Oil and Water Air Filter Removal and Replacement .....F-85

    Retest and Repair .....F-88

## HOW TO USE TROUBLESHOOTING GUIDE

**⚠ WARNING**

Service and Repair should only be performed by Lincoln Electric Factory Trained Personnel. Unauthorized repairs performed on this equipment may result in danger to the technician and machine operator and will invalidate your factory warranty. For your safety and to avoid Electrical Shock, please observe all safety notes and precautions detailed throughout this manual.

This Troubleshooting Guide is provided to help you locate and repair possible machine malfunctions. Simply follow the three-step procedure listed below.

**Step 1. LOCATE PROBLEM (SYMPTOM).**

Look under the column labeled "PROBLEM (SYMPTOMS)". This column describes possible symptoms that the machine may exhibit. Find the listing that best describes the symptom that the machine is exhibiting. Symptoms are grouped into the following categories: output problems.

**Step 2. PERFORM EXTERNAL TESTS.**

The second column labeled "POSSIBLE AREAS OF MISADJUSTMENT(S)" lists the obvious external possibilities that may contribute to the machine symptom. Perform these tests/checks in the order listed. In general, these tests can be conducted without removing the case wrap-around cover.

**Step 3. RECOMMENDED COURSE OF ACTION**

The last column labeled "Recommended Course of Action" lists the most likely components that may have failed in your machine. It also specifies the appropriate test procedure to verify that the subject component is either good or bad. If there are a number of possible components, check the components in the order listed to eliminate one possibility at a time until you locate the cause of your problem.

All of the referenced test procedures referred to in the Troubleshooting Guide are described in detail at the end of this chapter. Refer to the Troubleshooting and Repair Table of Contents to locate each specific Test Procedure. All of the specified test points, components, terminal strips, etc. can be found on the referenced electrical wiring diagrams and schematics. Refer to the Electrical Diagrams Section Table of Contents to locate the appropriate diagram.

**⚠ CAUTION**

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact the Lincoln Electric Service Department for technical troubleshooting assistance before you proceed. Call 1-888-935-3877.

## PC BOARD TROUBLESHOOTING PROCEDURES

**WARNING****ELECTRIC SHOCK  
can kill.**

- Have an electrician install and service this equipment. Turn the input power OFF at the fuse box before working on equipment. Do not touch electrically hot parts.

**CAUTION**

Sometimes machine failures appear to be due to PC board failures. These problems can sometimes be traced to poor electrical connections. To avoid problems when troubleshooting and replacing PC boards, please use the following procedure:

1. Determine to the best of your technical ability that the PC board is the most likely component causing the failure symptom.
2. Check for loose connections at the PC board to assure that the PC board is properly connected.
3. If the problem persists, replace the suspect PC board using standard practices to avoid static electrical damage and electrical shock. Read the warning inside the static resistant bag and perform the following procedures:

**PC board can be damaged by static electricity.****ATTENTION  
Static-Sensitive  
Devices  
Handle only at  
Static-Safe  
Workstations**

- Remove your body's static charge before opening the static-shielding bag. Wear an anti-static wrist strap. For safety, use a 1 Meg ohm resistive cord connected to a grounded part of the equipment frame.

- If you don't have a wrist strap, touch an un-painted, grounded, part of the equipment frame. Keep touching the frame to prevent static build-up. Be sure not to touch any electrically live parts at the same time.

- Tools which come in contact with the PC board must be either conductive, anti-static or static-dissipative.

- Remove the PC board from the static-shielding bag and place it directly into the equipment. Don't set the PC board on or near paper, plastic or cloth which could have a static charge. If the PC board can't be installed immediately, put it back in the static-shielding bag.

- If the PC board uses protective shorting jumpers, don't remove them until installation is complete.

- If you return a PC board to The Lincoln Electric Company for credit, it must be in the static-shielding bag. This will prevent further damage and allow proper failure analysis.

4. Test the machine to determine if the failure symptom has been corrected by the replacement PC board.

**NOTE:** It is desirable to have a spare (known good) PC board available for PC board troubleshooting.

**NOTE:** Allow the machine to heat up so that all electrical components can reach their operating temperature.

5. Remove the replacement PC board and substitute it with the original PC board to recreate the original problem.

- a. If the original problem does not reappear by substituting the original board, then the PC board was not the problem. Continue to look for bad connections in the control wiring harness, junction blocks, and terminal strips.

- b. If the original problem is recreated by the substitution of the original board, then the PC board was the problem. Reinstall the replacement PC board and test the machine.

6. Always indicate that this procedure was followed when warranty reports are to be submitted.

**NOTE:** Following this procedure and writing on the warranty report, "INSTALLED AND SWITCHED PC BOARDS TO VERIFY PROBLEM," will help avoid denial of legitimate PC board warranty claims.

Observe Safety Guidelines detailed in the beginning of this manual.

PROBLEMS (SYMPTOMS)	POSSIBLE AREAS OF MISADJUSTMENT(S)	RECOMMENDED COURSE OF ACTION
<b>OUTPUT PROBLEMS</b>		
Input circuit breaker trips repeatedly.	<ol style="list-style-type: none"> <li>1. This may be normal. If output is set to maximum, a 20 amp circuit is required. See Technical Specification page.</li> <li>2. Install a larger input circuit or turn the output control to a lower amperage.</li> </ol>	<ol style="list-style-type: none"> <li>1. Perform the <i>Inverter Board Test</i>.</li> </ol>
No Status indicators light and the fan does not operate 5 seconds after the power switch is turned on.	<ol style="list-style-type: none"> <li>1. Check the input power to be sure it is on and correct (208-230VAC).</li> <li>2. Check the power line fuses, breakers and machine connection.</li> </ol>	<ol style="list-style-type: none"> <li>1. Disconnect input power at fuse/breaker panel and check line switch continuity. Replace line switch if bad.</li> </ol>
No Status indicators light 5 seconds after the power switch is turned on, but the fan operates.	<ol style="list-style-type: none"> <li>1. Possible faulty inverter Board.</li> </ol>	<ol style="list-style-type: none"> <li>1. Perform the <i>Inverter Board Test</i>.</li> </ol>
The Thermal LED does not go out.	<ol style="list-style-type: none"> <li>1. Make sure both fans are operating correctly.</li> <li>2. Check consumables - Thermal and output LED's light when an unsafe condition exists at the torch.</li> </ol>	<ol style="list-style-type: none"> <li>1. Perform the <i>Torch LC25 Test</i>.</li> <li>2. Possible faulty Inverter board.</li> </ol>

**⚠ CAUTION**

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact the Lincoln Electric Service Department for technical troubleshooting assistance before you proceed. Call 1-888-935-3877.

TOMAHAWK® 375 AIR





Observe Safety Guidelines detailed in the beginning of this manual.

PROBLEMS (SYMPTOMS)	POSSIBLE AREAS OF MISADJUSTMENT(S)	RECOMMENDED COURSE OF ACTION
<b>OUTPUT PROBLEMS</b>		
<p>The TOMAHAWK® 375 AIR powers up properly but there is no response when the trigger is pulled and only the POWER LED is lit.</p>	<ol style="list-style-type: none"> <li>1. Turn the output knob to purge zone on the front of the TOMAHAWK® 375 AIR. If air does not flow, then                             <ul style="list-style-type: none"> <li>• The main gas solenoid assembly/pressure sensor may be faulty. Check or replace.</li> </ul> </li> <li>2. Remove the handles (or barrel) of the torch and examine all the connections.</li> </ol>	<ol style="list-style-type: none"> <li>1. Perform the <i>Air Solenoid Test</i>.</li> <li>2. Perform the <i>Inverter Board Test</i>.</li> <li>3. Perform the <i>Torch LC25 Test</i>.</li> <li>4. Perform the <i>Control Potentiometer Test</i>.</li> </ol>

**⚠ CAUTION**

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact the Lincoln Electric Service Department for technical troubleshooting assistance before you proceed. Call 1-888-935-3877.

Return to Section TOC

Return to Master TOC

Observe Safety Guidelines detailed in the beginning of this manual.

PROBLEMS (SYMPTOMS)	POSSIBLE AREAS OF MISADJUSTMENT(S)	RECOMMENDED COURSE OF ACTION
<b>OUTPUT PROBLEMS</b>		
When the trigger is pulled air begins to flow, but there is no pilot arc after at least 3 seconds.	<ol style="list-style-type: none"> <li>1. Check the torch consumables to be sure they are not dirty or greasy, and are in good shape. Replace the consumables if necessary.</li> <li>2. Make sure the air pressure is set correctly.</li> <li>3. Try increasing &amp; decreasing the pressure. Gauge may not be reading correctly. Test in both cases.</li> <li>4. Make sure there are no kinks or restrictions for air flow in the torch cable. Replace cable as needed.</li> <li>5. If a slight thump cannot be felt in the torch when the trigger is pulled, check for loose connection in the torch head.</li> </ol>	<ol style="list-style-type: none"> <li>1. Perform the <i>Inverter Board Test</i>.</li> <li>2. Perform the <i>Torch LC25 Test</i>.</li> </ol>
The air begins to flow and there is a very brief arc that snaps out consistently with repeated trigger pulls.	<ol style="list-style-type: none"> <li>1. Check the torch consumables to be sure they are in tight, not dirty or greasy and in good shape. Replace if necessary.</li> <li>2. Make sure the air pressure is set correctly.</li> </ol>	<ol style="list-style-type: none"> <li>1. Perform <i>Inverter Board Test</i>.</li> <li>2. Perform the <i>Torch LC25 Test</i>.</li> </ol>
The arc starts but sputters badly.	<ol style="list-style-type: none"> <li>1. Check the torch consumables to be sure they are in tight, not dirty or greasy and in good shape. Replace if necessary.</li> <li>2. Check air supply for oil or a great deal of water. If there is oil or a great deal of water, the air must be filtered or the machine switched to nitrogen or bottled air.</li> <li>3. Make sure the air pressure is set correctly.</li> </ol>	<ol style="list-style-type: none"> <li>1. If on internal air, switch to external air supply to test.</li> <li>2. Clean the metal filter on the front of the Tomahawk® with compressed air.</li> </ol>

### ⚠ CAUTION

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact the Lincoln Electric Service Department for technical troubleshooting assistance before you proceed. Call 1-888-935-3877.

TOMAHAWK® 375 AIR



Observe Safety Guidelines detailed in the beginning of this manual.

PROBLEMS (SYMPTOMS)	POSSIBLE AREAS OF MISADJUSTMENT(S)	RECOMMENDED COURSE OF ACTION
<b>OUTPUT PROBLEMS</b>		
Pilot arc starts but will not transfer when brought near work.	<ol style="list-style-type: none"> <li>1. Check work lead for clean, secure connection.</li> <li>2. Plasma will only cut conductive material. Do not attempt to cut fiberglass, plastic, rubber, PVC or any other non-conductive material.</li> <li>3. Make sure work piece is clean and dry. Remove any scale, rust or dross.</li> <li>4. Check all connections to inverter board.</li> </ol>	<ol style="list-style-type: none"> <li>1. Inspect or replace the work lead &amp; clamp if looks defective or questionable for current carrying abilities.</li> <li>2. Possible faulty inverter board.</li> </ol>
Poor consumable life.	<ol style="list-style-type: none"> <li>1. Check for moisture/oil in air.</li> </ol>	<ol style="list-style-type: none"> <li>1. Go to external, bottled or nitrogen air supply.</li> </ol>
Poor cutting performance.	<ol style="list-style-type: none"> <li>1. If on internal air disconnect the external air line. Retry.</li> <li>2. Check internal air line (filter should be the color white) located in the oil water trap. Replace if necessary.</li> <li>3. Try bottled air or a bottle of nitrogen gas to purge line inside the machine.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check all air lines for blockages or restrictions.</li> </ol>

**⚠ CAUTION**

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact the Lincoln Electric Service Department for technical troubleshooting assistance before you proceed. Call 1-888-935-3877.

Return to Section TOC

Return to Master TOC

Observe Safety Guidelines detailed in the beginning of this manual.

PROBLEMS (SYMPTOMS)	POSSIBLE AREAS OF MISADJUSTMENT(S)	RECOMMENDED COURSE OF ACTION
<b>OUTPUT PROBLEMS</b>		
<p>No pilot arc, or hard to establish a pilot arc. No thumping is felt in the torch when air is supplied.</p>	<p>1. Check for air supply to drop around .05 MPA (15PSI) during purge mode or a trigger pull. If the pressure only drops a few PSI, there is a clog in the air supply to the torch head.</p>	<p>1. Torch head may be clogged. Try the suspected bad torch on a known good machine to see if it is a torch head problem or torch cable.</p> <p>2. Check for loose, disconnected or kinked air lines. Look for a dirty air line filter. See "The arc starts but sputters badly" symptoms course of actions.</p> <p>3. Perform the <i>Torch LC25 Test</i>.</p>
<p>Excessive dross (slug) on bottom of plate or cut plate does not drop off smoothly.</p>	<p>See provided chart for correct travel speeds. <i>See Figure B.1.</i></p>	

**⚠ CAUTION**

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact the Lincoln Electric Service Department for technical troubleshooting assistance before you proceed. Call 1-888-935-3877.

Return to Section TOC

Return to Master TOC

Observe Safety Guidelines detailed in the beginning of this manual.

### STATUS BOARD INDICATORS

SYMPTOM	CHECK
Red output LED is blinking or steady with no air flow at trigger pull.	<ol style="list-style-type: none"> <li>1. Make sure there is at least 80 psi connected to the gas connection at the back of the machine.</li> <li>2. Turn the output knob to the purge zone and set the regulator to the correct pressure. The pressure may increase when air stops flowing but this is normal. Do not reset the pressure while the air is OFF.</li> <li>3. Possible faulty Pressure Switch.</li> <li>4. Possible faulty Inverter board.</li> </ol>
The Green, Red and Yellow LED's are lit and steady. Indicates safety circuit is open.	<ol style="list-style-type: none"> <li>1. Turn the power OFF and then ON. If torch and consumables are properly installed and they are the correct parts, the Red and Yellow LED's should turn off. Normal cutting or gouging can resume.</li> </ol>
The Thermal LED is lit.	<ol style="list-style-type: none"> <li>1. The machine's thermostat has tripped due to exceeded duty cycle limits. Do NOT turn the power off. Allow the machine to cool for 15 - 30 minutes and the thermostat will reset itself.</li> <li>2. The machine's air louvers or fans are obstructed such that air cannot flow to properly cool the machine. Remove any foreign material that may block air flow. Blow the machine out with a clean, dry air stream.</li> <li>3. The input voltage is not within <math>\pm 10\%</math> of rated values.</li> <li>4. Possible faulty Inverter board.</li> </ol>
In internal compressor Mode: The cutting arc turns off while cutting and the compressor turns off. All LED's appear normal. Fan is operating.	<ol style="list-style-type: none"> <li>1. The compressor has over heated and tripped it's internal thermostat. Do NOT turn the power off. Allow the machine to cool for 15 - 30 minutes and the thermostat will reset itself.</li> </ol>
When the trigger is pulled, the Red and Yellow LED's are blinking together and the Green light is on.	<ol style="list-style-type: none"> <li>1. Check that nozzle and swirl ring are properly installed and they are the correct parts. <b>Note:</b> Swirl ring can only go in one way, must fit snug in torch head.</li> </ol>
When the trigger is pulled, the Red LED is lit, air flows and no pilot arc occurs.	<ol style="list-style-type: none"> <li>1. Check that the swirl ring is properly installed. <b>Note:</b> Swirl ring can only go in one way.</li> </ol>
The Red and Yellow LED's are blinking alternately.	<ol style="list-style-type: none"> <li>1. The torch safety circuit has been opened, when reconnected this condition should reset automatically.</li> </ol>
When the trigger is pulled no air flows, Red LED is lit, no pilot arc. Then LED goes out.	<ol style="list-style-type: none"> <li>1. Check that the pressure gauge shows pressure. Air supply may not be connected or properly installed.</li> </ol>

## ERROR SIGNALS

Alarm (abnormal condition)	RED LED	YELLOW LED	Blinking fre- quency (Hz)	Reset mode	NOTE
Undervoltage	OFF	Blink	1	Autoreset with hysteresis.	Error and shutdown when the input voltage is less than 187Vac.
Overvoltage signal	Blink	OFF	4	Autoreset with hysteresis.	Error when the input voltage is greater than 270Vac.
Underpressure	Blink	OFF	1	Autoreset.	Error and shutdown when the input air pressure is low.
PIP (Parts In Place)	ON	ON	steady on	Autoreset after 5sec.	Error and shutdown when the retaining cap is not attached properly.
Thermal Shutdown	OFF	ON	steady on	Autoreset after cooling time.	Normal thermal response due to overheating.
OCV	Blink	Blink	1	Autoreset after trigger release.	Safe Mode - if trigger is pulled while turning the machine on, or attaching consumables with the trigger pulled.
Overvoltage shutdown	OFF	Blink	3	Autoreset after 2min of cooling time.	This shutdown occurs if the machine cuts for more than 20sec in overvoltage condition ( $V_{in}>270Vac$ ).

Signal (normal operation)	GREEN LED	RED LED	Blinking fre- quency (Hz)	Reset mode	NOTE
Power on	ON	OFF	steady on	Always on when the machine is energized.	Normal operating condition when trigger is off.
Inverter on	ON	ON	steady on	When the torch trigger is released.	Normal operating condition when trigger is pulled.

---

**INPUT FILTER CAPACITOR DISCHARGE PROCEDURE****⚠ WARNING**

Service and repair should be performed only by Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

---

**TEST DESCRIPTION**


This procedure will aid the technician to make sure the Capacitors are discharged.

**MATERIALS NEEDED**

25 Ohm / 25 Watt Resistor  
Insulated Gloves  
Volt / Ohmmeter

## INPUT FILTER CAPACITOR DISCHARGE PROCEDURE (continued)

FIGURE F.1 – INVERTER BOARD LOCATION



## PROCEDURE

 **WARNING**
**ELECTRIC SHOCK CAN KILL.**

- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.


4. If there is a voltage present at J17 to J22, obtain a high wattage resistor (25 ohm at 25 watts) and carefully apply the resistor at points J17 and J22. **Never use a shorting strap for this procedure.**
5. Check the voltage at points J17 and J22 again. It should be zero volts before performing maintenance or repair to the Tomahawk® 375 AIR.

1. Remove input power.
2. Perform **Case Wraparound Removal Procedure**.
3. Locate the Inverter Board. See Figure F.1. Check for voltage as indicated at test points J17 and J22. **See Figure F.2.**



## INPUT FILTER CAPACITOR DISCHARGE PROCEDURE (continued)

FIGURE F.2 – INVERTER BOARD LEAD LOCATIONS



Return to Section TOC  
 Return to Section TOC  
 Return to Section TOC  
 Return to Section TOC  
 Return to Master TOC  
 Return to Master TOC  
 Return to Master TOC  
 Return to Master TOC



## TORCH LC25 TEST

**⚠ WARNING**

Service and repair should be performed only by Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

**TEST DESCRIPTION**

This procedure will aid the technician in verifying if the Torch is operating properly.

**MATERIALS NEEDED**

Phillips Screwdriver  
Volt / Ohmmeter

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC


Return to Master TOC

Return to Master TOC

Return to Master TOC

## TORCH LC25 TEST (continued)

FIGURE F.3 – INVERTER BOARD MOUNTING SCREW LOCATIONS



## PROCEDURE

**⚠ WARNING****ELECTRIC SHOCK CAN KILL.**

- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.

1. Remove input power.
2. Remove the external input air supply,
3. Perform the **Case Wraparound Removal Procedure**.
4. Perform the **Capacitor Discharge Procedure**.
5. Locate the Torch leads and connection tabs located at the front of the inverter board. See Figure F.3 and **Figure F.4**.

6. To more easily gain access to the Torch leads and connection points, remove the four screws from the name plate assembly and carefully tilt it away from the inverter board.
7. Carefully label and remove the following Torch leads from their respective connection tabs: J7, J8, J9, J10, J27, J28 and J29. **See Figure F.4.**
8. Perform the tests outlined in **Table F.1**.
9. When testing is complete replace the leads that were previously removed.
10. Replace the name plate assembly.
11. Replace the case wraparound.

## TORCH LC25 TEST (continued)


TABLE F.1 – TORCH TEST CONDITIONS

TEST:	TORCH CONDITION:	EXPECTED RESULTS:
TRIGGER	TRIGGER PULLED; consumables in or out doesn't matter	There should be continuity "0 Ohms" between lead J7 to lead J8 trigger wires. Meg ohms to all other Torch leads.
	RELEASE TRIGGER;	There should be Meg ohms between lead J7 to lead J8 trigger wires.
	New consumables IN PLACE in Torch head	See diagram for help. MUST BE ASSEMBLED per parts help diagram and the <b>correct parts used for the LC 25 Torch ONLY.</b> <b>See Figure F.5.</b>
SAFETY	New consumables IN PLACE in Torch head	Continuity "0 ohms" between lead J10 and lead J9 wires. Meg ohms to all other Torch leads.
CUT / PILOT Current PATH	New consumables IN PLACE in Torch head	Continuity "0 ohms" between lead J28 to lead J29 wires same Torch conditions as above test (consumables in place).
	Remove Electrode & Nozzle	No continuity, Meg ohms should be between lead J28 to lead J29 wires.
TORCH HEAD Mechanical - Need a supply of 70 Psi @ 125 to 200 SCFH	Electrode and Nozzle in place	The Torch when connected to this clean air supply (bottled nitrogen or air) should have a thumping felt inside the handle anytime the air is applied abruptly to the Torch. This thump, is the piston of the electrode moving back slightly (approximately 1/8 inch) when the air is applied. This action is required to create a pilot arc <b>inside</b> the Torch electrode nozzle area. The same action can be obtained when going to the Purge setting on the Tomahawk current dial (Blue Dial).
Turn Off input power to the Tomahawk	Remove the Nozzle, Swirl Ring, and Retaining Cap.	Push the electrode in. The distance the electrode should move is approximately 1/8 inch and a spring action back to the original position.



All of the above testing is not a definitive test that the Torch is good or bad. Best to always try the Torch on a different and known good Tomahawk® to confirm that the Torch operates properly or that the original Tomahawk® unit is good or bad. The above testing does not provide the elevated dangerous levels of voltages that may be causing the Torch to break down internally and not function correctly when its connected to the Tomahawk®.

**TORCH LC25 TEST (continued)**

**FIGURE F.4 – TORCH LEAD LOCATIONS**



**FIGURE F.5 – TORCH COMPONENTS AND LEADS**



Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

---

**INVERTER BOARD TEST****⚠ WARNING**

Service and repair should be performed only by Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

---

**TEST DESCRIPTION**

This procedure will aid the technician in determining if the Inverter Board is functioning properly.

**MATERIALS NEEDED**

Volt / Ohmmeter

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC


Return to Master TOC

Return to Master TOC

Return to Master TOC

## INVERTER BOARD TEST (continued)

FIGURE F.6 – INVERTER BOARD LOCATION



## PROCEDURE

**⚠ WARNING**

**ELECTRIC SHOCK CAN KILL.**

- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.

1. Remove input power.
2. Perform the **Case Wraparound Removal Procedure**.
3. Perform the **Capacitor Discharge Procedure**.
4. Locate the Inverter Board. See Figure F.6.
5. Give the Inverter Board a GOOD visual check on both sides, top and bottom. Look for any burnt, darkened or sooty damaged areas and or components. No further test is required to this board if signs of damage are present. Replace the board. **See Inverter Board Removal and Replacement Procedure.**

6. Before turning on the Tomahawk® with the new Inverter Board installed, perform the tests for the **Torch LC25** and **Air / Gas Solenoid** (resistance values only for solenoid).
7. Perform the tests outlined in **Tables F.2 and F.3** and Test Points **Figure F.7**. If any open or shorted components are indicated, replace the Inverter Board. If measurement points can not be reached, remove the board and use the under side of the board traces for test points. **See Inverter Board Removal Procedure.**
8. Meter Settings: Use a Fluke 87 or equivalent. Select "diode test" on meter. Other parts of the test will require "resistance test" as noted.


**Objective of this test method:**

Look for a difference between readings for component tested when the meter leads are swapped across the component test points as indicated. A difference indicates a good component.



INVERTER BOARD TEST (continued)

FIGURE F.7 – INVERTER BOARD TEST POINTS



If there is conduction (beeping from meter) in both meter lead swapping tests, the device is shorted. If there is no conduction (no beeping from the meter) after the lead swapping test the device is open. **See Figure F.8.**


On some components a resistance reading is required. Switch the meter to "resistance test" and check readings per provided figure. **See Table F.3.** Swap the meter leads to the indicated test points. The resistance values should be the same. If not, replace the board after checking the questionable component on the board again with all the boards leads disconnected.

Return to Section TOC

Return to Master TOC

**INVERTER BOARD TEST (continued)**

**FIGURE F.8 – METER PROBE CONNECTIONS**



**TABLE F.2-A – INVERTER BOARD DIODE CHECKS**

CONDITIONS	TEST POINT	TEST POINT	EXPECTED READING	COMMENTS
MACHINE OFF	TP1 + PROBE	TP2 – PROBE	“BEEP” CONDUCTION	FORWARD DIODE READING
MACHINE OFF	TP2 + PROBE	TP1 – PROBE	NO “BEEP” NO CONDUCTION	REVERSE DIODE READING
MACHINE OFF	TP2 + PROBE	TP3 – PROBE	“BEEP” CONDUCTION	FORWARD DIODE READING
MACHINE OFF	TP3 + PROBE	TP2 – PROBE	NO “BEEP” NO CONDUCTION	REVERSE DIODE READING
MACHINE OFF	TP4 + PROBE	TP3 – PROBE	“BEEP” CONDUCTION	FORWARD DIODE READING
MACHINE OFF	TP3 + PROBE	TP4 – PROBE	NO “BEEP” NO CONDUCTION	REVERSE DIODE READING
MACHINE OFF	TP1 + PROBE	TP4 – PROBE	“BEEP” CONDUCTION	FORWARD DIODE READING
MACHINE OFF	TP4 + PROBE	TP1 – PROBE	NO “BEEP” NO CONDUCTION	REVERSE DIODE READING
MACHINE OFF	TP5 + PROBE	TP6 – PROBE	“BEEP” CONDUCTION	FORWARD DIODE READING

Return to Section TOC  
 Return to Section TOC  
 Return to Section TOC  
 Return to Master TOC  
 Return to Master TOC  
 Return to Master TOC

## INVERTER BOARD TEST (continued)

### TABLE F.2-B – INVERTER BOARD DIODE CHECKS

CONDITIONS	TEST POINT	TEST POINT	EXPECTED READING	COMMENTS
MACHINE OFF	TP6 + PROBE	TP5 – PROBE	NO "BEEP" NO CONDUCTION	REVERSE DIODE READING
MACHINE OFF	TP7 + PROBE	TP6 – PROBE	"BEEP" CONDUCTION	FORWARD DIODE READING
MACHINE OFF	TP6 + PROBE	TP7 – PROBE	NO "BEEP" NO CONDUCTION	REVERSE DIODE READING
MACHINE OFF	TP8 + PROBE	TP9 – PROBE	"BEEP" CONDUCTION	FORWARD DIODE READING
MACHINE OFF	TP9 + PROBE	TP8 – PROBE	NO "BEEP" NO CONDUCTION	REVERSE DIODE READING
MACHINE OFF	TP10 + PROBE	TP9 – PROBE	"BEEP" CONDUCTION	FORWARD DIODE READING
MACHINE OFF	TP9 + PROBE	TP10 – PROBE	NO "BEEP" NO CONDUCTION	REVERSE DIODE READING
MACHINE OFF	TP11 + PROBE	TP12 – PROBE	"BEEP" CONDUCTION	FORWARD DIODE READING
MACHINE OFF	TP12 + PROBE	TP11 – PROBE	NO "BEEP" NO CONDUCTION	REVERSE DIODE READING
MACHINE OFF	TP14 + PROBE	TP13 – PROBE	"BEEP" CONDUCTION	FORWARD DIODE READING
MACHINE OFF	TP13 + PROBE	TP14 – PROBE	NO "BEEP" NO CONDUCTION	REVERSE DIODE READING

### TABLE F.2-C – INVERTER BOARD DIODE CHECKS

CONDITIONS	TEST POINT	TEST POINT	EXPECTED READING	COMMENTS
MACHINE OFF	TP15 + PROBE	TP16 – PROBE	"BEEP" CONDUCTION	FORWARD DIODE READING
MACHINE OFF	TP16 + PROBE	TP15 – PROBE	NO "BEEP" NO CONDUCTION	REVERSE DIODE READING
MACHINE OFF	TP17 + PROBE	TP17 – PROBE	"BEEP" CONDUCTION	FORWARD DIODE READING
MACHINE OFF	TP16 + PROBE	TP17 – PROBE	NO "BEEP" NO CONDUCTION	REVERSE DIODE READING
MACHINE OFF	TP18 + PROBE	TP19 – PROBE	"BEEP" CONDUCTION	FORWARD DIODE READING
MACHINE OFF	TP19 + PROBE	TP18 – PROBE	NO "BEEP" NO CONDUCTION	REVERSE DIODE READING
MACHINE OFF	TP20 + PROBE	TP19 – PROBE	"BEEP" CONDUCTION	FORWARD DIODE READING
MACHINE OFF	TP19 + PROBE	TP20 – PROBE	NO "BEEP" NO CONDUCTION	REVERSE DIODE READING
MACHINE OFF	TP24 + PROBE	TP23 – PROBE	"BEEP" CONDUCTION	FORWARD DIODE READING
MACHINE OFF	TP23 + PROBE	TP24 – PROBE	NO "BEEP" NO CONDUCTION	REVERSE DIODE READING
MACHINE OFF	TP26 + PROBE	TP25 – PROBE	"BEEP" CONDUCTION	FORWARD DIODE READING

TOMAHAWK® 375 AIR



## INVERTER BOARD TEST (continued)

TABLE F.2-D – INVERTER BOARD DIODE CHECKS

CONDITIONS	TEST POINT + PROBE	TEST POINT – PROBE	EXPECTED READING	COMMENTS
MACHINE OFF	TP25 + PROBE	TP26 – PROBE	NO “BEEP” NO CONDUCTION	REVERSE DIODE READING
MACHINE OFF	TP28 + PROBE	TP27 – PROBE	“BEEP” CONDUCTION	FORWARD DIODE READING
MACHINE OFF	TP27 + PROBE	TP28 – PROBE	NO “BEEP” NO CONDUCTION	REVERSE DIODE READING
MACHINE OFF	TP29 + PROBE	TP30 – PROBE	“BEEP” CONDUCTION	FORWARD DIODE READING
MACHINE OFF	TP30 + PROBE	TP29 – PROBE	NO “BEEP” NO CONDUCTION	REVERSE DIODE READING
MACHINE OFF	TP29 + PROBE	TP31 – PROBE	“BEEP” CONDUCTION	FORWARD DIODE READING
MACHINE OFF	TP31 + PROBE	TP29 – PROBE	NO “BEEP” NO CONDUCTION	REVERSE DIODE READING
MACHINE OFF	TP33 + PROBE	TP32 – PROBE	“BEEP” CONDUCTION	FORWARD DIODE READING
MACHINE OFF	TP32 + PROBE	TP33 – PROBE	NO “BEEP” NO CONDUCTION	REVERSE DIODE READING

TABLE F.3 – INVERTER BOARD RESISTANCE CHECKS

CONDITIONS	TEST POINT + PROBE	TEST POINT – PROBE	EXPECTED READING	COMMENTS
MACHINE OFF	TP21 + PROBE	TP22 – PROBE	47 Ohms	Resistance Reading
MACHINE OFF	TP31 + PROBE	TP30 – PROBE	100K Ohms	Resistance Reading
MACHINE OFF	TP32 + PROBE	TP34 – PROBE	Variable	Charging Capacitor Effect
MACHINE OFF	TP34 + PROBE	TP33 – PROBE	Variable	Charging Capacitor Effect

---

**AIR / GAS SOLENOID TEST****⚠ WARNING**

Service and repair should be performed only by Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

---

**TEST DESCRIPTION**

This procedure will aid the technician in determining if the Air / Gas Solenoid is functioning properly.

**MATERIALS NEEDED**

Volt / Ohmmeter  
12VDC External Supply

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC


Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

FIGURE F.9 – INVERTER BOARD



### PROCEDURE

#### ⚠ WARNING



#### ELECTRIC SHOCK CAN KILL.

- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.

1. Remove input power.
2. Perform the **Case Wraparound Removal Procedure**.
3. Perform the **Capacitor Discharge Procedure**.
4. Locate the red and black Air/Gas Solenoid leads on the inverter board. See Figure F.9.
5. Carefully remove the leads from terminals CN2 (+Red) and CN15 (- Black).
6. Using the volt / ohmmeter, check the Solenoid coil. Put the positive meter probe on the red Solenoid lead and the negative meter probe on the black Solenoid lead. Then reverse the meter leads with the negative meter probe on the red Solenoid lead and the positive meter probe on the black Solenoid lead. The test results should be similar to testing a diode. The resistance should be higher in the negative polarity and lower when the positive meter probe is on the red Solenoid lead.
7. If the resistance is low or is very high in both polarities the Solenoid may be faulty.
8. The Solenoid may be further tested by applying an external 12VDC supply to the Solenoid coil leads. (Positive to the red lead and negative to the black lead) The Solenoid should activate. If not, the Solenoid is faulty.
9. When the torch trigger is pulled 12VDC should be present at terminals CN2 (+) and CN15 (-). If it is not present, the inverter board may be faulty.
10. When testing is complete replace the two Solenoid leads to their respective terminals. CN2 (Red) and CN15 (Black).
11. Replace the case wraparound cover.

**CONTROL POTENTIOMETER TEST****⚠ WARNING**

Service and repair should be performed only by Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.


**TEST DESCRIPTION**

This procedure will aid the technician in determining if the Control Potentiometer is functioning properly.

**MATERIALS NEEDED**

Volt / Ohmmeter  
Phillips Screwdriver

FIGURE F.10 – CONTROL BOARD TEST POINTS



### PROCEDURE

#### **⚠ WARNING**



#### **ELECTRIC SHOCK CAN KILL.**

- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.


1. Remove input power.
2. Perform the **Case Wraparound Removal Procedure**.
3. Perform the **Capacitor Discharge Procedure**.
4. Test Condition: The control board disconnected from the inverter board.

5. Locate the control board. See Figure F.10.
6. Using the phillips screwdriver, remove the four front panel mounting screws from the nameplate assembly and carefully tilt the nameplate assembly forward. See Figure F.10.



## CONTROL POTENTIOMETER TEST (continued)

FIGURE F.11 – CONTROL BOARD RIBBON CABLE CONNECTOR LOCATION




7. Carefully remove the control board ribbon cable from the inverter board. See Figure F.11.
8. Using the volt/ohmmeter, measure the resistance on the Control Potentiometer that is mounted on the control board. When the Potentiometer shaft is rotated the resistance reading should vary from 0 to 2500 ohms from either outer terminal to the center (wiper) terminal. Measuring at the two outer terminals the resistance reading should be approximately 2500 ohms. **See Figure F.12.**
9. When testing is complete replace the ribbon cable into the inverter board.
10. Replace the nameplate assembly with the four screws previously removed.
11. Replace the case wraparound cover.

# TROUBLESHOOTING AND REPAIR

## CONTROL POTENTIOMETER TEST (continued)

FIGURE F.12 – CONTROL BOARD TEST POINTS



Return to Section TOC  
Return to Section TOC  
Return to Section TOC  
Return to Section TOC  
Return to Master TOC  
Return to Master TOC  
Return to Master TOC  
Return to Master TOC

**CASE WRAPAROUND REMOVAL AND REPLACEMENT PROCEDURE****⚠ WARNING**

Service and repair should be performed only by Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

**TEST DESCRIPTION**

This procedure will aid the technician in the removal and replacement of the Case Wraparound.

**MATERIALS NEEDED**

Phillips Screwdriver

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC


Return to Master TOC

Return to Master TOC

Return to Master TOC

## CASE WRAPAROUND REMOVAL AND REPLACEMENT PROCEDURE (continued)

FIGURE F.13 – HANDLE SCREW LOCATIONS



### PROCEDURE

#### ⚠ WARNING



#### ELECTRIC SHOCK CAN KILL.

- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.

1. Remove input power.
2. Remove the external input air supply.
3. Using a phillips screwdriver, remove the two screws holding the top handle to the casefront and caseback. See Figure F.13.


4. Using a phillips screwdriver, remove the four screws securing the rear panel and the two longer screws on the bottom of rear panel. **See Figure F.14.**
5. Swing the rear panel slightly out of the way. wiring remains connected.
6. Remove the handle from the front section.
7. The Wraparound should come loose from the front section and lift up from the body of the welder towards the rear.

#### ⚠ CAUTION

When remove any Case grounding type leads. Make sure to re-connect this ground lead to the wraparound sheet metal when reassembling machine. Important for noise emissions and safety frame ground requirements.

## CASE WRAPAROUND REMOVAL AND REPLACEMENT PROCEDURE (continued)

FIGURE F.14 – REAR PANEL SCREW LOCATIONS



### REPLACEMENT PROCEDURE

1. Position case Wraparound on machine. Make sure to re-attach any case ground leads.
2. Place handle into position.
3. Place rear panel into place and press firmly into machine.
4. Using a phillips screwdriver, replace the two longer screws on bottom of rear panel and the four screws on the back of the rear panel.
5. Using a phillips screwdriver, attach the two screws securing the handle to case front and case back.

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

TOMAHAWK® 375 AIR



## NAMEPLATE ASSEMBLY REMOVAL AND REPLACEMENT PROCEDURE

### WARNING

Service and repair should be performed only by Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

---

### TEST DESCRIPTION

This procedure will aid the technician in the removal and replacement of the Nameplate Assembly.

### MATERIALS NEEDED

Phillips Screwdriver  
Wiring Diagram

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC


Return to Master TOC

Return to Master TOC

Return to Master TOC

## NAMEPLATE ASSEMBLY REMOVAL AND REPLACEMENT PROCEDURE (continued)

FIGURE F.15 – NAMEPLATE AND MOUNTING SCREW LOCATIONS



### PROCEDURE

#### **⚠ WARNING**



#### **ELECTRIC SHOCK CAN KILL.**


- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.

1. Remove input power.
2. Remove the external input air supply.
3. Perform the **Case Wraparound Removal Procedure**.
4. Perform the **Capacitor Discharge Procedure**.
5. Using phillips screwdriver, remove four Nameplate Assembly mounting screws. See Figure F.15.
6. Label and disconnect the J11 ground lead connecting the Nameplate to the inverter board.
7. Label and disconnect the air hoses connected to the bottom of the regulator / pressure gauge assembly. See Wiring Diagram.
8. Label and disconnect the four leads attached to the compressor switch. See Wiring Diagram.
9. Label and disconnect the CN9 ribbon cable connecting the control board to the inverter board. See Wiring Diagram. **See Figure F.16.**
10. The Nameplate Assembly can now be removed from the machine.



## NAMEPLATE ASSEMBLY REMOVAL AND REPLACEMENT PROCEDURE (continued)

### FIGURE F.16 – RIBBON CABLE CONNECTION LOCATION



## REPLACEMENT PROCEDURE

1. Connect CN9 ribbon cable from control board to inverter board.
2. Connect the four compressor switch leads previously removed.
3. Connect the air hoses to the bottom of the regulator / pressure gauge assembly.
4. Connect the J11 ground lead from the Nameplate Assembly to the inverter board.
5. Perform **Case Wraparound Replacement Procedure**.
6. Replace input air supply. If necessary.

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

TOMAHAWK® 375 AIR



---

**FRONT PANEL REMOVAL AND REPLACEMENT PROCEDURE****⚠ WARNING**

Service and repair should be performed only by Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

---

**TEST DESCRIPTION**


This procedure will aid the technician in the removal and replacement of the Front Panel.

**MATERIALS NEEDED**

Phillips Screwdriver  
9/32" Socket

## FRONT PANEL REMOVAL AND REPLACEMENT PROCEDURE (continued)

FIGURE F.17 – FRONT PANEL MOUNTING SCREW LOCATION



## REMOVAL PROCEDURE

**⚠ WARNING**


**ELECTRIC SHOCK CAN KILL.**

- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.

1. Remove input power.
2. Remove the external input air supply.
3. Perform the **Case Wraparound Removal Procedure**.
4. Perform the **Capacitor Discharge Procedure**.
5. Perform **Nameplate Assembly Removal Procedure**.
6. Using a phillips screwdriver, remove the two screws on the feet of Front Panel. See Figure F.17.
7. Using a phillips screwdriver, remove the two Front Panel screws located behind the nameplate assembly. See Figure F.17.
8. Slide Front Panel 1-2 inches away from the machine.
9. Using a 9/32" socket wrench, label and disconnect the ground lead on the rear side of the Front Panel.
10. Label and disconnect the air hose connecting the torch to solenoid at right back side of the machine by gently pushing in on the retaining ring and removing the air line. **See Figure F.18**.
11. Label and disconnect torch leads J29, J28, J27, J10, J8, J7, and J9. **See Figure F.19**.

## FRONT PANEL REMOVAL AND REPLACEMENT PROCEDURE (continued)


FIGURE F.18 – SOLENOID VALVE LOCATION



12. Route disconnected leads through center divider panel.
13. Disconnect the large air intake line from the compressor.
14. Front Panel can now be removed.

## FRONT PANEL REMOVAL AND REPLACEMENT PROCEDURE (continued)

FIGURE F.19 – FRONT PANEL MOUNTING SCREW LOCATION



## REPLACEMENT PROCEDURE

1. Route torch leads through center divider panel.
2. Connect torch leads J29, J28, J27, J10, J8, J7, and J9 to the inverter board.
3. Connect the torch air hose to the to the solenoid at the right rear side of the machine.
4. Replace the large air intake line to the compressor.
5. Using a 9/32" socket wrench, connect the ground lead to the rear side of the Front Panel.
6. Using a phillips screwdriver, replace the two Front Panel screws securing the Front Panel to the center divider panel.
7. Using a phillips screwdriver, replace the two screws on the feet of the Front Panel.
8. Perform **Nameplate Assembly Replacement Procedure**.
9. Perform the **Case Wraparound Replacement Procedure**.
10. Reconnect the external input air supply.

**TORCH LC25 REMOVAL AND REPLACEMENT PROCEDURE****⚠ WARNING**

Service and repair should be performed only by Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

**TEST DESCRIPTION**

This procedure will aid the technician in the removal and replacement of the Torch LC25.

**MATERIALS NEEDED**

Misc. Hand Tools

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC


Return to Master TOC

Return to Section TOC

Return to Master TOC

## TORCH LC25 REMOVAL AND REPLACEMENT PROCEDURE (continued)

FIGURE F.20 – TORCH LC25



## REMOVAL PROCEDURE

**⚠ WARNING****ELECTRIC SHOCK CAN KILL.**

- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.

6. Carefully remove the Torch air line from the air solenoid by gently pushing in on the retaining ring and removing the air line. **See Figure F.21.**
7. Label and disconnect the six Torch leads (J7, J8, J9, J10, J28, J29) from the inverter board. **See Figure F.22.**
8. Carefully remove the Torch assembly through the front panel.

1. Remove input power.
2. Remove the external input air supply.
3. Perform the **Case Wraparound Removal Procedure**.
4. Perform the **Capacitor Discharge Procedure**.
5. Remove large plastic nut, located on the rear of the front panel, by twisting counter-clockwise.



TORCH LC25 REMOVAL AND REPLACEMENT PROCEDURE (continued)

FIGURE F.21 – SOLENOID VALVE AIR HOSE LOCATION





FIGURE F.22 – TORCH LEAD LOCATIONS



TOMAHAWK® 375 AIR



Return to Section TOC (vertical bar)

---

**TORCH LC25 REMOVAL AND REPLACEMENT PROCEDURE (continued)****REPLACEMENT PROCEDURE**

1. Route Torch leads through the Torch opening in the front panel.
2. Attach large plastic nut securing the Torch to the front panel.
3. Attach the six leads previously removed. **See Figure F.22.**
4. Attach the air hose to the air solenoid.
5. Replace any cable ties previously removed.
6. Perform the **Case Wraparound Replacement Procedure.**

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

**CONTROL BOARD REMOVAL AND REPLACEMENT PROCEDURE****⚠ WARNING**

Service and repair should be performed only by Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

**TEST DESCRIPTION**


This procedure will aid the technician in the removal and replacement of the Control Board.

**MATERIALS NEEDED**

Phillips Screwdriver  
3/32" Allen Wrench  
1/4" Nutdriver  
Flat Screwdriver Or Thin Blade Knife

## CONTROL BOARD REMOVAL AND REPLACEMENT PROCEDURE (continued)

FIGURE F.23 – CONTROL BOARD LOCATION



### PROCEDURE

#### ⚠ WARNING



#### ELECTRIC SHOCK CAN KILL.

- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.

1. Remove input power.
2. Remove the external input air supply.
3. Perform the **Case Wraparound Removal Procedure**.
4. Perform the **Capacitor Discharge Procedure**.
5. Using a phillips screwdriver, remove the four screws from the nameplate assembly. See Figure F.23.
6. Carefully disconnect the CN9 ribbon cable connecting the Control Board to the inverter board. See Wiring Diagram.
7. Using a flat screwdriver or thin blade knife, carefully pry off the red plastic cover on the output current knob. **See Figure F.24.**
8. Using a 1/4" nutdriver, remove the output current knob. **See Figure F.24.**
9. Using a 3/32" allen wrench, remove the two screws securing the Control Board in place to its standoffs. Note washer placement.
10. Route the ribbon cable accordingly to keep from getting caught on components when board is removed.

## CONTROL BOARD REMOVAL AND REPLACEMENT PROCEDURE (continued)

FIGURE F.24 – OUTPUT CURRENT KNOB LOCATION



OUTPUT CURRENT KNOB

### REPLACEMENT PROCEDURE

1. While holding the Control Board in place, place the output control knob into position.
2. Using a 1/4" nutdriver, secure the output control knob to the nameplate assembly.
3. Replace the red plastic cover previously removed.
4. Using a 3/32" allen wrench, secure the two screws that hold the Control Board in place on its standoffs.
5. Route the CN9 ribbon cable accordingly and reconnect to the inverter board.
6. Using the four screws previously removed, replace the nameplate assembly.
7. Perform the **Case Wraparound Replacement Procedure**.
8. Replace the external air supply. If necessary.

TOMAHAWK® 375 AIR



Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

TOMAHAWK® 375 AIR



## REGULATOR / PRESSURE GAUGE REMOVAL AND REPLACEMENT PROCEDURE

### WARNING

Service and repair should be performed only by Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

---

### TEST DESCRIPTION


This procedure will aid the technician in the removal and replacement of the Regulator / Pressure Gauge.

### MATERIALS NEEDED

- Phillips Screwdriver
- 7/32" Nutdriver
- Pliers

## REGULATOR / PRESSURE GAUGE REMOVAL AND REPLACEMENT PROCEDURE (continued)

FIGURE F.25 – REGULATOR / PRESSURE GAUGE



### PROCEDURE

#### ⚠ WARNING



#### ELECTRIC SHOCK CAN KILL.


- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.

1. Remove the input power.
2. Remove the external input air supply.
3. Perform the **Case Wraparound Removal Procedure**.
4. Perform the **Capacitor Discharge Procedure**.
5. Using a phillips screwdriver, remove the four screws from the nameplate assembly. See Figure F.25.
6. Locate the Regulator / Pressure Gauge. See Figure F.25.
7. Remove the large plastic nut located around the adjuster knob of the Regulator / Pressure Gauge assembly. **See Figure F.26.**
8. Label and disconnect the air hoses from the press release fittings. **See Figure F.26.** See Wiring Diagram.
9. Using a 7/32" nutdriver, remove the two small nuts located on the back side of the Regulator / Pressure Gauge assembly.
10. The Regulator / Pressure Gauge assembly can now be removed.



## REGULATOR / PRESSURE GAUGE REMOVAL AND REPLACEMENT PROCEDURE (continued)

FIGURE F.26 – REGULATOR / PRESSURE GAUGE FITTINGS



### REPLACEMENT PROCEDURE

1. Place the Regulator / Pressure Gauge into its proper position.
2. Using a 7/32" nutdriver, tighten the two small nuts securing the Regulator / Pressure Gauge assembly to the rear of the nameplate.
3. Connect the air hoses to their proper press release fittings.
4. Replace the large plastic nut around the adjuster knob of regulator.
5. Using the four screws previously removed, replace the nameplate assembly.
6. Perform the ***Case Wraparound Replacement Procedure***.
7. Replace the external input air supply.

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

TOMAHAWK® 375 AIR



## COMPRESSOR SWITCH REMOVAL AND REPLACEMENT PROCEDURE

### WARNING

Service and repair should be performed only by Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

---

### TEST DESCRIPTION

This procedure will aid the technician in the removal and replacement of the Compressor Switch.

### MATERIALS NEEDED

Phillips Screwdriver  
Wiring Diagram

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC


Return to Master TOC

Return to Master TOC

Return to Master TOC

## COMPRESSOR SWITCH REMOVAL AND REPLACEMENT PROCEDURE (continued)

FIGURE F.27 – NAMEPLATE ASSEMBLY MOUNTING SCREWS



### PROCEDURE

#### ⚠ WARNING



#### ELECTRIC SHOCK CAN KILL.

- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.

1. Remove input power.
2. Remove the external input air supply.
3. Perform the **Case Wraparound Removal Procedure**.
4. Perform the **Capacitor Discharge Procedure**.
5. Using a phillips screwdriver, remove the four screws from the nameplate assembly. See Figure F.27.

6. Locate Compressor Switch. **See Figure F.28.**
7. Label and disconnect the four leads to the Compressor Switch. See Wiring Diagram.
8. Squeeze the four mounting taps on the switch body top and bottom. Press and push simultaneously to free switch from nameplate assembly.

## COMPRESSOR SWITCH REMOVAL AND REPLACEMENT PROCEDURE (continued)

FIGURE F.28 – COMPRESSOR SWITCH LOCATION



### REPLACEMENT PROCEDURE

1. Align Compressor Switch on nameplate and press firmly into place.
2. Connect the four previously removed leads to the Compressor Switch.
3. Using the four screws previously removed, replace the nameplate assembly.
4. Perform the **Case Wraparound Replacement Procedure**.
5. Replace the external input air supply.

TOMAHAWK® 375 AIR



Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

TOMAHAWK® 375 AIR



---

**FAN REMOVAL AND REPLACEMENT PROCEDURE****⚠ WARNING**

Service and repair should be performed only by Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

---

**TEST DESCRIPTION**

This procedure will aid the technician in the removal and replacement of the Fan(s).

**MATERIALS NEEDED**

Drill

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC


Return to Master TOC

Return to Section TOC

Return to Master TOC

## FAN REMOVAL AND REPLACEMENT PROCEDURE (continued)

FIGURE F.29 – FAN LOCATION



## PROCEDURE

**⚠ WARNING****ELECTRIC SHOCK CAN KILL.**

- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.

1. Remove input power.
2. Remove the external input air supply.
3. Perform the **Case Wraparound Removal Procedure**.
4. Perform the **Capacitor Discharge Procedure**.

5. The Fans are Pop Riveted to the rear case support. (4 per Fan). Use the appropriate drill size to remove the pop rivets flatter surface.

**NOTE:** Make sure the remnants of pop rivets are removed from the machines area and inverter board surfaces.

**NOTE:** The input power cord may need to be removed and the case back moved aside to gain access to the mounting rivets.

6. Label and unplug the power leads from the Fan to be replaced. See Figure F.29.
7. Carefully remove the faulty Fan.



---

**FAN REMOVAL AND REPLACEMENT PROCEDURE (continued)**

---

**REPLACEMENT PROCEDURE**

1. Replace the Fan so air flow direction is from the rear to the front of the machine.
2. Using new rivets or the appropriate size bolts, washers and nuts, secure the new Fan to the vertical baffle.
3. Connect previously removed leads.
4. Perform ***Case Wraparound Replacement Procedure***.
5. Replace the external input air supply.

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

TOMAHAWK® 375 AIR



## INVERTER BOARD REMOVAL AND REPLACEMENT PROCEDURE

### WARNING

Service and repair should be performed only by Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

---

### TEST DESCRIPTION

This procedure will aid the technician in the removal and replacement of the Inverter Board.

### MATERIALS NEEDED

Phillips Screwdriver  
Wiring Diagram

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC


Return to Master TOC

Return to Master TOC

Return to Master TOC

## INVERTER BOARD REMOVAL AND REPLACEMENT PROCEDURE (continued)

FIGURE F.30 – INVERTER BOARD LOCATION



### PROCEDURE

#### ⚠ WARNING




#### ELECTRIC SHOCK CAN KILL.

- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.

1. Remove input power.
2. Remove the external input air supply.
3. Perform the **Case Wraparound Removal Procedure**.
4. Perform the **Capacitor Discharge Procedure**.
5. Locate Inverter Board. See Figure F.30.
6. Using a phillips screwdriver, remove the four screws from the nameplate assembly and carefully tilt it away from the Inverter Board.
7. Label and disconnect leads CN3, J13, J12, CN4, CN15, CN2, CN16, J8, J7, J10, J9, J28, J27, J11, J29, CN9, and case ground leads. **See Figure F.31.** See Wiring Diagram.
8. Using a phillips screwdriver, remove the three small screws securing the plastic baffle to the Inverter Board. **See Figure F.32.**
9. Using a phillips screwdriver, remove the five steel screws and one nylon screw securing the Inverter Board to the center divider panel. **See Figure F.33.**
10. Carefully remove the Inverter Board making sure all leads are labeled and cleared.

## INVERTER BOARD REMOVAL AND REPLACEMENT PROCEDURE (continued)

### FIGURE F.31 – INVERTER BOARD LEAD LOCATIONS



TOMAHAWK® 375 AIR



Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC


Return to Section TOC

Return to Master TOC

**INVERTER BOARD  
REMOVAL AND REPLACEMENT PROCEDURE (continued)**

**FIGURE F.32 – PLASTIC BAFFLE MOUNTING SCREWS**


PLASTIC BAFFLE  
MOUNTING SCREWS



**FIGURE F.33 – INVERTER BOARD MOUNTING SCREWS**

METAL INVERTER BOARD  
MOUNTING SCREWS

NYLON INVERTER BOARD  
MOUNTING SCREW



## INVERTER BOARD REMOVAL AND REPLACEMENT PROCEDURE (continued)

### REPLACEMENT PROCEDURE

1. Using a phillips screwdriver, attach the five steel screws and one nylon screw securing the Inverter Board to the center divider panel.  
**NOTE:** Make sure ALL the Inverter Board mounting screws are back in-place and tight after installing the new board. These screws mount the electrical grounding post to case. Insure that the board is grounded properly for noise interference to protect and reduce noise from the board during operation. Make sure ground leads are connected to proper area of board and chassis.
2. Using a phillips screwdriver, attach the three small screws securing the plastic baffle to the Inverter Board.

### CAUTION

Be sure that the clear plastic baffle for the Inverter Board has all its mounting screws in place. This keeps the board cooled correctly and also provides stability and support for the IGBT and diode heat-sinks.

3. Connect all previously removed leads and grounds to the Inverter Board. **See Figure F.31** and Wiring Diagram.
4. Using the four screws previously removed, replace the nameplate assembly.
5. Perform **Case Wraparound Replacement Procedure**.
6. Replace the external input air supply.

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

TOMAHAWK® 375 AIR





## COMPRESSOR REMOVAL AND REPLACEMENT PROCEDURE

### WARNING

Service and repair should be performed only by Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

---

### TEST DESCRIPTION

This procedure will aid the technician in the removal and replacement of the Compressor.

### MATERIALS NEEDED

Phillips Screwdriver  
12mm Wrench

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC


Return to Master TOC

Return to Master TOC

Return to Master TOC

## COMPRESSOR REMOVAL AND REPLACEMENT PROCEDURE (continued)

FIGURE F.34 – COMPRESSOR LOCATION



### REMOVAL PROCEDURE

#### ⚠ WARNING



#### ELECTRIC SHOCK CAN KILL.


- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.

1. Remove input power.
2. Remove the external input air supply.
3. Perform the **Case Wraparound Removal Procedure**.
4. Perform the **Capacitor Discharge Procedure**.
5. Perform the **Front Panel Removal Procedure**.
6. Perform **Inverter Board Removal Procedure**.

7. Locate the Compressor. See Figure F.34.  
**NOTE:** Compressor will be removed from the front of the machine.
8. Route the disconnected leads through the center divider panel of the machine.
9. Label and disconnect the ground lead from the bottom left side of the Compressor.
10. Using a 12mm wrench, loosen the nut securing the copper air line to the left side of the Compressor.
11. Disconnect the copper Compressor air line from the air solenoid and remove out of the left side of the machine.
12. Using a phillips screwdriver, remove the two upper mounting screws located on the top side of the centering divider panel. Note washer placement for reassembly. See Figure F.34.

**COMPRESSOR REMOVAL AND REPLACEMENT PROCEDURE (continued)**


FIGURE F.35 – CONTROL BOARD LOCATION



13. Carefully place machine onto left side.
14. Using a phillips screwdriver, remove the bottom two screws securing the Compressor lower shock mounts to the base sheet metal.
15. The Compressor assembly can now be removed out of the front of the machine.

## COMPRESSOR REMOVAL AND REPLACEMENT PROCEDURE (continued)

FIGURE F.36 – MAIN BOARD MOUNTING SCREW LOCATIONS



### REPLACEMENT PROCEDURE

**NOTE:** The replacement Compressor should have its mounting bracket attached for ease of replacement. Use the old bracket if necessary.

1. Place the new Compressor into position inside machine case.
2. Using a phillips screwdriver, attach the two Compressor upper mounting screws located on the right side of the center divider panel. **See Figure F.34.**
3. Carefully place machine on its side.
4. Using a phillips screwdriver, attach lower mounts to the sheet metal base using two screws.
5. Return machine to upright position.
6. Route Compressor leads through center divider panel.
7. Connect the copper Compressor air line, located on left side of the Compressor, to the air solenoid.
8. Using a 12mm wrench, secure the copper air line to the Compressor.
9. Connect the ground lead to the bottom left side of the Compressor.
10. Perform the ***Inverter Board Replacement Procedure.***
11. Perform the ***Front Panel Replacement Procedure.***
12. Perform the ***Case Wraparound Replacement Procedure.***
13. Replace the external input air supply.

**PRESSURE SWITCH REMOVAL AND REPLACEMENT PROCEDURE****⚠ WARNING**

Service and repair should be performed only by Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

**TEST DESCRIPTION**


This procedure will aid the technician in the removal and replacement of the Pressure Switch.

**MATERIALS NEEDED**

13mm Wrenches  
14mm Wrenches

## PRESSURE SWITCH REMOVAL AND REPLACEMENT PROCEDURE (continued)

FIGURE F.37 – PRESSURE SWITCH LOCATION



### PROCEDURE

#### **⚠ WARNING**



#### **ELECTRIC SHOCK CAN KILL.**

- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.

1. Remove input power.
2. Remove the external input air supply.
3. Perform the **Case Wraparound Removal Procedure**.
4. Perform the **Capacitor Discharge Procedure**.

5. Locate the Pressure Switch assembly. Pressure Switch is located near the bottom rear on the right side of machine. See Wiring Diagram.
6. Label and disconnect the two white wires from the forward area of the Pressure Switch. See Wiring Diagram.
7. Using the 13mm and 14mm wrenches, loosen and remove the brass fitting securing the Pressure Switch to the plastic elbow fitting. The second wrench may be necessary to hold the other fitting secure when loosening or replacing the Pressure Switch body.
8. Remove the Pressure Switch and it's fitting.

## PRESSURE SWITCH REMOVAL AND REPLACEMENT PROCEDURE (continued)

### REPLACEMENT PROCEDURE

1. Using the 13mm and 14mm wrenches, secure the Pressure Switch to the elbow fitting.
2. Reconnect the two white wires to the Pressure Switch. See Wiring Diagram.
3. Perform ***Case Wraparound Replacement Procedure***.
4. Replace the external input air supply.

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

TOMAHAWK® 375 AIR





## SOLENOID VALVE REMOVAL AND REPLACEMENT PROCEDURE

### WARNING

Service and repair should be performed only by Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

---

### TEST DESCRIPTION

This procedure will aid the technician in the removal and replacement of the Solenoid Valve.

### MATERIALS NEEDED

90 Degree Phillips Screwdriver

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC


Return to Master TOC

Return to Master TOC

Return to Master TOC

## SOLENOID VALVE REMOVAL AND REPLACEMENT PROCEDURE (continued)

FIGURE F.38 – SOLENOID VALVE LOCATION



INVERTER BOARD NOT SHOWN FOR ILLUSTRATION PURPOSES ONLY

### PROCEDURE

#### ⚠ WARNING




#### ELECTRIC SHOCK CAN KILL.

- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.


1. Remove input power.
2. Remove the external input air supply.
3. Perform the **Case Wraparound Removal Procedure**.
4. Perform the **Capacitor Discharge Procedure**.
5. Locate Solenoid Valve. The Solenoid Valve is located on right side of machine and is attached to the bottom of the center divider. See Figure F.38.
6. Label and remove the plastic hoses from Solenoid press release fittings (one on each side).
7. Label and disconnect the black CN15 and red CN16 wires attached to the inverter board push release terminals. **See Figure F.40.**
9. Using a 90 degree phillips screwdriver or phillips head socket & ratchet, remove the two larger mounting screws on bottom of Solenoid Valve. **See Figure F.39.**
10. The Solenoid Valve assembly can now be removed from the machine.

## SOLENOID VALVE REMOVAL AND REPLACEMENT PROCEDURE (continued)

### FIGURE F.39 – SOLENOID VALVE ASSEMBLY



### FIGURE F.40 – SOLENOID LEAD LOCATIONS



Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

## SOLENOID VALVE REMOVAL AND REPLACEMENT PROCEDURE (continued)

### REPLACEMENT PROCEDURE

1. Using a 90 degree phillips screwdriver or phillips head socket & ratchet, replace the two larger phillips screws securing the Solenoid Valve assembly to the center divider panel.
2. Route wires through center divider panel.
3. Reconnect the black CN15 and red CN16 wires to the inverter board right side push release terminals. See Wiring Diagram.
4. Connect the plastic hoses to the Solenoid press ring release fittings.
5. Perform the ***Case Wraparound Replacement Procedure***.
6. Replace the external input air

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

## OIL AND WATER TRAP REMOVAL AND REPLACEMENT PROCEDURE

### WARNING

Service and repair should be performed only by Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

---

### TEST DESCRIPTION

This procedure will aid the technician in the removal and replacement of the Oil and Water Trap Assembly.

### MATERIALS NEEDED

3mm Allen Wrench

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC


Return to Master TOC

Return to Master TOC

Return to Master TOC

## OIL AND WATER TRAP REMOVAL AND REPLACEMENT PROCEDURE (continued)

FIGURE F.41 – OIL AND WATER TRAP LOCATION



INVERTER BOARD NOT SHOWN FOR ILLUSTRATION PURPOSES ONLY

### PROCEDURE

#### ⚠ WARNING




#### ELECTRIC SHOCK CAN KILL.

- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.

1. Remove input power.
2. Remove the external input air supply.
3. Perform the **Case Wraparound Removal Procedure**.
4. Perform the **Capacitor Discharge Procedure**.
5. Locate Oil and Water Trap assembly. The Oil and Water Trap assembly is attached to the underside of center divider on right side of machine. See Figure F.41.
6. Label and remove the three air hoses from solenoid press ring release fittings. **See Figure F.42**.
7. Follow the **Inverter Board Removal Procedure** for removal of the board's mounting screws only.
8. Move the loosely mounted board to gain clear access to the four screws.
9. Using a 3mm allen wrench, remove the Oil Water Trap from the center shelf. See Figure F.41.
10. Remove from right side of machine.

## OIL AND WATER TRAP REMOVAL AND REPLACEMENT PROCEDURE (continued)

FIGURE F.42 – OIL AND WATER TRAP ASSEMBLY



### REPLACEMENT PROCEDURE

1. Route the drain hose through the hole in the bottom of the sheet metal base.
2. Using a 3mm allen wrench, secure the four screws to the center divider plate.
3. Follow the ***Inverter Board Replacement Procedure*** for reattaching the inverter board mounting screws.
4. Connect the three hoses to Oil and Water Trap's press ring fittings.
5. Perform the ***Case Wraparound Replacement Procedure***.
6. Replace the external input air supply.

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

TOMAHAWK® 375 AIR





## OIL AND WATER AIR FILTER REMOVAL AND REPLACEMENT PROCEDURE

### WARNING

Service and repair should be performed only by Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

---

### TEST DESCRIPTION


This procedure will aid the technician in the removal and replacement of the Oil Water Air Filter.

### MATERIALS NEEDED

90 Degree Phillips Screwdriver Or Phillips Head Socket And Ratchet

## OIL AND WATER AIR FILTER REMOVAL AND REPLACEMENT PROCEDURE (continued)

FIGURE F.43 – OIL WATER AIR FILTER LOCATION



### PROCEDURE

#### ⚠ WARNING




#### ELECTRIC SHOCK CAN KILL.

- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.

1. Remove input power.
2. Remove the external input air supply.
3. Perform the **Case Wraparound Removal Procedure**.
4. Perform the **Capacitor Discharge Procedure**.
5. Locate oil and water trap assembly. Oil and water trap assembly is attached to underside of center divider on right side of machine. See Figure F.43.
6. Remove plastic drain hose from its press release fitting on the bottom of the clear plastic lower trap sump. Set aside for reinstallation later. **See Figure F.44.**
7. Unscrew the clear plastic lower trap sump. Remove with a tilt action to expose the air filter. **See Figure F.44.**
8. Using a 90 degree phillips screwdriver or phillips head socket & ratchet, remove the screw holding the air filter in place. Make sure o-ring on plastic bowl surface is back in its slot upon replacing bowl. **See Figure F.44.**
9. Route the plastic hose underneath from the base, back into the plastic bowl trap press ring fitting.
10. Leave a short section of hose out on the bottom to drain water. Insure the hose is not kinked.

## OIL AND WATER AIR FILTER REMOVAL AND REPLACEMENT PROCEDURE (continued)

FIGURE F.44 – OIL WATER AIR FILTER ASSEMBLY



### REPLACEMENT PROCEDURE

1. Route the drain hose to the bottom hole to drain water. Insure the hose is not kinked when replacing.
2. Using a 90 degree phillips screwdriver or phillips head socket and ratchet, replace the screw securing the filter in place.
3. Screw the clear plastic lower trap sump into place, making sure the o-ring on plastic bowl surface is back in its slot.
4. Perform the ***Case Wraparound Replacement Procedure***.
5. Replace the external input air supply.

## RETEST AFTER REPAIR

Should a machine under test be rejected for any reason requiring the removal of any mechanical part that could affect the machine's electrical characteristics, or if any electrical components are repaired or replaced, the machine must be retested.

### Machine Input and Output

Input Volts/Hertz	Input Current	Rated Output
230/1/60HZ $\pm 10\%$	11.3 Amps	13A @ 100% Duty Cycle
230/1/60HZ $\pm 10\%$	25 Amps	25A @ 35% Duty Cycle

Output Current Range	10 - 25 Amps DC
----------------------	-----------------

Maximum Open Circuit Range	460 Volts DC
----------------------------	--------------

Pilot Current	12 Amps
---------------	---------

1. Connect the machine to 208/230VAC input power and an air supply (70psi minimum).
2. Turn on the machine and verify the following:
  - Both fans function, top & bottom.
  - The green power LED is lit on the front name plate.
3. Test the pressure switch in the following way:
  - Turn the output control knob to the blue purge area till the air starts flowing from torch.

Note: If left in Purge, Purge will shut off after 5 minutes.

Using the regulator on the machine, slowly lower the air pressure and verify that the output red LED turns on blinking at approximately 45 to 48 psi.  $\approx$  (.31MPa to .33MPa)

With the output red LED blinking on, move from Purge on dial to cut area of dial (RED) then pull the trigger on the torch. Verify that a pilot arc does NOT occur. Release the trigger.

While in Purge mode increase the regulator back to the blue arrow above gauge for proper air pressure for cutting levels, 80psi (.55MPa) Move dial out of Purge area.

4. Test the Purge safety function by dialing into Purge blue region and get air flowing from torch, and then pull the trigger on the torch. Verify that a pilot arc does NOT occur. Release the trigger and move from Purge on dial to the red area to turn off air flow.
5. With no air flowing (postflow), pull the trigger on the torch. Verify that the air flows and the pilot arc is initiated. While continuing to hold the trigger, verify that the pilot arc remains lit for 4 to 6 seconds then turns off automatically. Release the trigger and verify that the air continues to flow for approximately 20 seconds (postflow).
6. Unscrew the shield cup from the torch and verify that the yellow and red LEDs come on. Pull trigger, pilot arc should not occur. Re-tighten the shield cup on the torch and verify that the yellow and red LEDs alternately flash. After the yellow and red LEDs go out pull the trigger of the torch and verify that a pilot arc does occur. Note: There is a delay in re-strike during post-flow time of pilot arc at times.
7. Test cut with Tomahawk® at its maximum material thickness with 3/8" steel max. Turn current dial to maximum.
8. Remove external air supply. Select internal air source, pull torch trigger. Verify Tomahawk® compressor comes on. Perform a cut on steel 3/8".
9. Turn the Tomahawk® off. Test complete.

TOMAHAWK® 375 AIR



Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

**Electrical Diagrams** ..... **G-1**

    Wiring Diagram (M22320) ..... G-2

    Schematic – Complete Machine (M22291) PG 1 ..... G-3

    Schematic – Complete Machine (M22291) PG 2 ..... G-4


    Schematic – Complete Machine (M22291) PG 3 ..... G-5

    Schematic – Complete Machine (M22291) PG 4 ..... G-6

**\* NOTE:** Many PC Board Assemblies are now totally encapsulated, surface mounted and or multi-layered and are therefore considered to be unserviceable. Assembly drawings of these boards are no longer provided.



SCHEMATIC - COMPLETE MACHINE (M22291) PG 1



PROPRIETARY & CONFIDENTIAL: THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OWNED BY LINCOLN GLOBAL, INC. AND MAY NOT BE DUPLICATED, COMMUNICATED TO OTHER PARTIES OR USED FOR ANY PURPOSE WITHOUT THE EXPRESS WRITTEN PERMISSION OF LINCOLN GLOBAL, INC.

MANUFACTURING TOLERANCE PER E2056 UNLESS OTHERWISE SPECIFIED TOLERANCE: ON 2 PLACE DECIMALS IS ± .02 in. (± 0.5 mm) ON 3 PLACE DECIMALS IS ± .002 ON ALL ANGLES IS ± .5 OF A DEGREE MATERIAL TOLERANCE ("I") TO AGREE WITH PUBLISHED STANDARDS.	CONTROL: CLEVELAND	SCALE: NONE IF PRINTED @ A3 SIZE	EQUIPMENT TYPE: TOMAHAWK 375 AIR	PAGE 1 OF 4
DO NOT SCALE THIS DRAWING	DRAWN BY: jmilligan	UNITS: INCH	SUBJECT: SCHEMATIC	DOCUMENT NUMBER: M22291
	ENGINEER: S. McQUERRY		MATERIAL DISPOSITION: NA	DOCUMENT REVISION: A.02
	APPROVED: -		APPROVAL DATE: -	
			PROJECT NUMBER: 5036380-A	
			REFERENCE: -	


NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual.

SCHEMATIC - COMPLETE MACHINE (M22291) PG 2

M22291

ENGINEERING CONTROLLED MANUFACTURER: No

CHANGE DETAIL: CHANGED EQUIPMENT TYPE. ADDED SCHEMATIC AND SHEETS 2, 3 AND 4.



FLAT CABLE PIN OUT

1	GND
2	+25Vdc
3	OUTPUT LED
4	+3V3
5	THERMAL LED
6	+3V3
7	+3V3
8	WIPER POT
9	GND
10	NOT USED

**Inverter Board functions:**

- The board manage the precharge system; create a 325Vdc for the half bridge inverter configuration; create by flyback conf all auxiliary voltage supply;
- receive a PWM control signal for output cutting current; manage lift torch strike and avoid the arc to switch off when you're going out of the work piece;
- Manage all errors and alarms signals; manage air compressor working;

**PROPRIETARY & CONFIDENTIAL**. THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OWNED BY LINCOLN GLOBAL, INC. AND MAY NOT BE DUPLICATED, COMMUNICATED TO OTHER PARTIES OR USED FOR ANY PURPOSE WITHOUT THE EXPRESS WRITTEN PERMISSION OF LINCOLN GLOBAL, INC.


MANUFACTURING TOLERANCE PER E2056 UNLESS OTHERWISE SPECIFIED TOLERANCE: ON 2 PLACE DECIMALS IS ± .02 in. (± 0.5 mm) ON 3 PLACE DECIMALS IS ± .002 ON ALL ANGLES IS ± 5 OF A DEGREE MATERIAL TOLERANCE ("I") TO AGREE WITH PUBLISHED STANDARDS.	CONTROL: CLEVELAND DRAWN BY: jmilligan ENGINEER: S. McQUERRY APPROVED: -	SCALE: NONE IF PRINTED @ A3 SIZE UNITS: INCH	EQUIPMENT TYPE: TOMAHAWK 375 AIR SUBJECT: SCHEMATIC	PAGE 2 OF 4	DOCUMENT NUMBER: M22291 REVISION: A.02
DO NOT SCALE THIS DRAWING			MATERIAL DISPOSITION: NA APPROVAL DATE: - PROJECT NUMBER: 5036380-A REFERENCE: -		

NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual.





SCHEMATIC - COMPLETE MACHINE (M22291) PG 3



EN-166

<b>PROPRIETARY &amp; CONFIDENTIAL:</b> THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OWNED BY LINCOLN GLOBAL, INC. AND MAY NOT BE DUPLICATED, COMMUNICATED TO OTHER PARTIES OR USED FOR ANY PURPOSE WITHOUT THE EXPRESS WRITTEN PERMISSION OF LINCOLN GLOBAL, INC.											
<small>MANUFACTURING TOLERANCE PER E2056 UNLESS OTHERWISE SPECIFIED TOLERANCE: ON 2 PLACE DECIMALS IS ± 0.02 in. (± 0.5 mm) ON 3 PLACE DECIMALS IS ± 0.02 ON ALL ANGLES IS ± 5 OF A DEGREE MATERIAL TOLERANCE ("I") TO AGREE WITH PUBLISHED STANDARDS.</small>			CONTROL: CLEVELAND DRAWN BY: jmilligan ENGINEER: S. McQUERRY APPROVED: -	SCALE: NONE IF PRINTED @ A3 SIZE UNITS: INCH	EQUIPMENT TYPE: <b>TOMAHAWK 375 AIR</b> SUBJECT: <b>SCHEMATIC</b> MATERIAL DISPOSITION: NA APPROVAL DATE: -	PROJECT NUMBER: 5036380-A REFERENCE: -	PAGE <b>3</b> OF <b>4</b> DOCUMENT NUMBER: <b>M22291</b>	DOCUMENT REVISION: <b>A.02</b>			

NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual.

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

SCHEMATIC - COMPLETE MACHINE (M22291) PG 4

M22291


ENGINEERING CONTROLLED MANUFACTURER: No

CHANGE DETAIL: CHANGED EQUIPMENT TYPE. ADDED SCHEMATIC AND SHEETS 2, 3 AND 4.

AIR SYSTEM PATH

AIR TUBE: POLYURETANE TUBE Ø0.24"x0.16" LEI code: W8800320

DRAIN TUBE: POLYURETANE TUBE Ø0.16"x0.1" LEI code: W8800205



INPUT FILTER FUNCTIONS AND REQUIREMENTS. Includes text describing filtration, pressure, and flow, and a cross-sectional diagram of the filter with labels like 'FLOAT', 'VALVE SEAT', and 'BOWL'.

PRESSURE REGULATOR FUNCTIONS AND REQUIREMENTS. Includes text describing the compact manifold regulator and a diagram of the regulator with a pressure gauge and labels like 'OUT', 'IN', and 'Port size: One-touch fitting for Ø6'.

PRESSURE SWITCH FUNCTIONS AND REQUIREMENTS. Includes text describing the switch type and ratings, and a diagram of the switch with electrical and connection port labels.

SOLENOID VALVE FUNCTIONS AND REQUIREMENTS. Includes text describing the valve type and ratings, and a diagram of the valve with 'IN' and 'OUT' ports and electrical connection details.

PROPRIETARY & CONFIDENTIAL: THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OWNED BY LINCOLN GLOBAL, INC. AND MAY NOT BE DUPLICATED, COMMUNICATED TO OTHER PARTIES OR USED FOR ANY PURPOSE WITHOUT THE EXPRESS WRITTEN PERMISSION OF LINCOLN GLOBAL, INC.

Table with technical specifications and metadata including: MANUFACTURING TOLERANCE PER E2056, CONTROL: CLEVELAND, SCALE: NONE, EQUIPMENT TYPE: TOMAHAWK 375 AIR, SUBJECT: SCHEMATIC, DOCUMENT NUMBER: M22291, and DOCUMENT REVISION: A.02.

EN-166

SOLID EDGE

NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual.



Return to Section TOC (vertical text on the left margin)

Return to Master TOC (vertical text on the right margin)