




Operator's Manual

Frontier[®] 400X/Frontier[®] 400X Pipe



For use with machines having Code Numbers:
**12716, 12717, 12781,
13202**



Register your machine:
www.lincolnelectric.com/register

Authorized Service and Distributor Locator:
www.lincolnelectric.com/locator

Save for future reference

Date Purchased

Code: (ex: 10859)

Serial: (ex: U1060512345)

Need Help? Call 1.888.935.3877
to talk to a Service Representative

Hours of Operation:
8:00 AM to 6:00 PM (ET) Mon. thru Fri.

After hours?
Use "Ask the Experts" at lincolnelectric.com
A Lincoln Service Representative will contact you
no later than the following business day.

For Service outside the USA:
Email: globalservice@lincolnelectric.com

THANK YOU FOR SELECTING A QUALITY PRODUCT BY LINCOLN ELECTRIC.

PLEASE EXAMINE CARTON AND EQUIPMENT FOR DAMAGE IMMEDIATELY

When this equipment is shipped, title passes to the purchaser upon receipt by the carrier. Consequently, claims for material damaged in shipment must be made by the purchaser against the transportation company at the time the shipment is received.

SAFETY DEPENDS ON YOU

Lincoln arc welding and cutting equipment is designed and built with safety in mind. However, your overall safety can be increased by proper installation ... and thoughtful operation on your part. **DO NOT INSTALL, OPERATE OR REPAIR THIS EQUIPMENT WITHOUT READING THIS MANUAL AND THE SAFETY PRECAUTIONS CONTAINED THROUGHOUT.** And, most importantly, think before you act and be careful.

WARNING

This statement appears where the information must be followed exactly to avoid serious personal injury or loss of life.

CAUTION

This statement appears where the information must be followed to avoid minor personal injury or damage to this equipment.



KEEP YOUR HEAD OUT OF THE FUMES.

DON'T get too close to the arc. Use corrective lenses if necessary to stay a reasonable distance away from the arc.


READ and obey the Safety Data Sheet (SDS) and the warning label that appears on all containers of welding materials.

USE ENOUGH VENTILATION or exhaust at the arc, or both, to keep the fumes and gases from your breathing zone and the general area.

IN A LARGE ROOM OR OUTDOORS, natural ventilation may be adequate if you keep your head out of the fumes (See below).

USE NATURAL DRAFTS or fans to keep the fumes away from your face.

If you develop unusual symptoms, see your supervisor. Perhaps the welding atmosphere and ventilation system should be checked.



WEAR CORRECT EYE, EAR & BODY PROTECTION

PROTECT your eyes and face with welding helmet properly fitted and with proper grade of filter plate (See ANSI Z49.1).

PROTECT your body from welding spatter and arc flash with protective clothing including woolen clothing, flame-proof apron and gloves, leather leggings, and high boots.

PROTECT others from splatter, flash, and glare with protective screens or barriers.

IN SOME AREAS, protection from noise may be appropriate.

BE SURE protective equipment is in good condition.

Also, wear safety glasses in work area **AT ALL TIMES.**



SPECIAL SITUATIONS

DO NOT WELD OR CUT containers or materials which previously had been in contact with hazardous substances unless they are properly cleaned. This is extremely dangerous.

DO NOT WELD OR CUT painted or plated parts unless special precautions with ventilation have been taken. They can release highly toxic fumes or gases.

Additional precautionary measures

PROTECT compressed gas cylinders from excessive heat, mechanical shocks, and arcs; fasten cylinders so they cannot fall.

BE SURE cylinders are never grounded or part of an electrical circuit.

REMOVE all potential fire hazards from welding area.

ALWAYS HAVE FIRE FIGHTING EQUIPMENT READY FOR IMMEDIATE USE AND KNOW HOW TO USE IT.



SECTION A: WARNINGS



CALIFORNIA PROPOSITION 65 WARNINGS



WARNING: Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects, or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an exposed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel

WARNING: This product, when used for welding or cutting, produces fumes or gases which contain chemicals known to the State of California to cause birth defects and, in some cases, cancer. (California Health & Safety Code § 25249.5 *et seq.*)



WARNING: Cancer and Reproductive Harm
www.P65warnings.ca.gov

ARC WELDING CAN BE HAZARDOUS. PROTECT YOURSELF AND OTHERS FROM POSSIBLE SERIOUS INJURY OR DEATH. KEEP CHILDREN AWAY. PACEMAKER WEARERS SHOULD CONSULT WITH THEIR DOCTOR BEFORE OPERATING.

Read and understand the following safety highlights. For additional safety information, it is strongly recommended that you purchase a copy of "Safety in Welding & Cutting - ANSI Standard Z49.1" from the American Welding Society, P.O. Box 351040, Miami, Florida 33135 or CSA Standard W117.2. A Free copy of "Arc Welding Safety" booklet E205 is available from the Lincoln Electric Company, 22801 St. Clair Avenue, Cleveland, Ohio 44117-1199.

BE SURE THAT ALL INSTALLATION, OPERATION, MAINTENANCE AND REPAIR PROCEDURES ARE PERFORMED ONLY BY QUALIFIED INDIVIDUALS.



FOR ENGINE POWERED EQUIPMENT.

- 1.a. Turn the engine off before troubleshooting and maintenance work unless the maintenance work requires it to be running.



- 1.b. Do not add the fuel near an open flame welding arc or when the engine is running. Stop the engine and allow it to cool before refueling to prevent spilled fuel from vaporizing on contact with hot engine parts and igniting. Do not spill fuel when filling tank. If fuel is spilled, wipe it



up and do not start engine until fumes have been eliminated.

- 1.c. Keep all equipment safety guards, covers and devices in position and in good repair. Keep hands, hair, clothing and tools away from V-belts, gears, fans and all other moving parts when starting, operating or repairing equipment.
- 1.d. In some cases it may be necessary to remove safety guards to perform required maintenance. Remove guards only when necessary and replace them when the maintenance requiring their removal is complete. Always use the greatest care when working near moving parts.
- 1.e. Do not put your hands near the engine fan. Do not attempt to override the governor or idler by pushing on the throttle control rods while the engine is running.
- 1.f. To prevent accidentally starting gasoline engines while turning the engine or welding generator during maintenance work, disconnect the spark plug wires, distributor cap or magneto wire as appropriate.
- 1.g. To avoid scalding, do not remove the radiator pressure cap when the engine is hot.
- 1.h. Using a generator indoors CAN KILL YOU IN MINUTES.
- 1.i. Generator exhaust contains carbon monoxide. This is a poison you cannot see or smell.
- 1.j. NEVER use inside a home or garage, EVEN IF doors and windows are open.
- 1.k. Only use OUTSIDE and far away from windows, doors and vents.
- 1.l. Avoid other generator hazards. READ MANUAL BEFORE USE.



ELECTRIC AND MAGNETIC FIELDS MAY BE DANGEROUS



- 2.a. Electric current flowing through any conductor causes localized Electric and Magnetic Fields (EMF). Welding current creates EMF fields around welding cables and welding machines
- 2.b. EMF fields may interfere with some pacemakers, and welders having a pacemaker should consult their physician before welding.
- 2.c. Exposure to EMF fields in welding may have other health effects which are now not known.
- 2.d. All welders should use the following procedures in order to minimize exposure to EMF fields from the welding circuit:
- 2.d.1. Route the electrode and work cables together - Secure them with tape when possible.
- 2.d.2. Never coil the electrode lead around your body.
- 2.d.3. Do not place your body between the electrode and work cables. If the electrode cable is on your right side, the work cable should also be on your right side.
- 2.d.4. Connect the work cable to the workpiece as close as possible to the area being welded.
- 2.d.5. Do not work next to welding power source.



ELECTRIC SHOCK CAN KILL.



- 3.a. The electrode and work (or ground) circuits are electrically “hot” when the welder is on. Do not touch these “hot” parts with your bare skin or wet clothing. Wear dry, hole-free gloves to insulate hands.
- 3.b. Insulate yourself from work and ground using dry insulation. Make certain the insulation is large enough to cover your full area of physical contact with work and ground.

In addition to the normal safety precautions, if welding must be performed under electrically hazardous conditions (in damp locations or while wearing wet clothing; on metal structures such as floors, gratings or scaffolds; when in cramped positions such as sitting, kneeling or lying, if there is a high risk of unavoidable or accidental contact with the workpiece or ground) use the following equipment:

- Semiautomatic DC Constant Voltage (Wire) Welder.
 - DC Manual (Stick) Welder.
 - AC Welder with Reduced Voltage Control.
- 3.c. In semiautomatic or automatic wire welding, the electrode, electrode reel, welding head, nozzle or semiautomatic welding gun are also electrically “hot”.
 - 3.d. Always be sure the work cable makes a good electrical connection with the metal being welded. The connection should be as close as possible to the area being welded.
 - 3.e. Ground the work or metal to be welded to a good electrical (earth) ground.
 - 3.f. Maintain the electrode holder, work clamp, welding cable and welding machine in good, safe operating condition. Replace damaged insulation.
 - 3.g. Never dip the electrode in water for cooling.
 - 3.h. Never simultaneously touch electrically “hot” parts of electrode holders connected to two welders because voltage between the two can be the total of the open circuit voltage of both welders.
 - 3.i. When working above floor level, use a safety belt to protect yourself from a fall should you get a shock.
 - 3.j. Also see Items 6.c. and 8.



ARC RAYS CAN BURN.



- 4.a. Use a shield with the proper filter and cover plates to protect your eyes from sparks and the rays of the arc when welding or observing open arc welding. Headshield and filter lens should conform to ANSI Z87.1 standards.
- 4.b. Use suitable clothing made from durable flame-resistant material to protect your skin and that of your helpers from the arc rays.
- 4.c. Protect other nearby personnel with suitable, non-flammable screening and/or warn them not to watch the arc nor expose themselves to the arc rays or to hot spatter or metal.




FUMES AND GASES CAN BE DANGEROUS.



- 5.a. Welding may produce fumes and gases hazardous to health. Avoid breathing these fumes and gases. When welding, keep your head out of the fume. Use enough ventilation and/or exhaust at the arc to keep fumes and gases away from the breathing zone. **When welding hardfacing (see instructions on container or SDS) or on lead or cadmium plated steel and other metals or coatings which produce highly toxic fumes, keep exposure as low as possible and within applicable OSHA PEL and ACGIH TLV limits using local exhaust or mechanical ventilation unless exposure assessments indicate otherwise. In confined spaces or in some circumstances, outdoors, a respirator may also be required. Additional precautions are also required when welding on galvanized steel.**
5. b. The operation of welding fume control equipment is affected by various factors including proper use and positioning of the equipment, maintenance of the equipment and the specific welding procedure and application involved. Worker exposure level should be checked upon installation and periodically thereafter to be certain it is within applicable OSHA PEL and ACGIH TLV limits.
- 5.c. Do not weld in locations near chlorinated hydrocarbon vapors coming from degreasing, cleaning or spraying operations. The heat and rays of the arc can react with solvent vapors to form phosgene, a highly toxic gas, and other irritating products.
- 5.d. Shielding gases used for arc welding can displace air and cause injury or death. Always use enough ventilation, especially in confined areas, to insure breathing air is safe.
- 5.e. Read and understand the manufacturer’s instructions for this equipment and the consumables to be used, including the Safety Data Sheet (SDS) and follow your employer’s safety practices. SDS forms are available from your welding distributor or from the manufacturer.
- 5.f. Also see item 1.j.




WELDING AND CUTTING SPARKS CAN CAUSE FIRE OR EXPLOSION.



- 6.a. Remove fire hazards from the welding area. If this is not possible, cover them to prevent the welding sparks from starting a fire. Remember that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas. Avoid welding near hydraulic lines. Have a fire extinguisher readily available.
- 6.b. Where compressed gases are to be used at the job site, special precautions should be used to prevent hazardous situations. Refer to "Safety in Welding and Cutting" (ANSI Standard Z49.1) and the operating information for the equipment being used.
- 6.c. When not welding, make certain no part of the electrode circuit is touching the work or ground. Accidental contact can cause overheating and create a fire hazard.
- 6.d. Do not heat, cut or weld tanks, drums or containers until the proper steps have been taken to insure that such procedures will not cause flammable or toxic vapors from substances inside. They can cause an explosion even though they have been "cleaned". For information, purchase "Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping That Have Held Hazardous Substances", AWS F4.1 from the American Welding Society (see address above).
- 6.e. Vent hollow castings or containers before heating, cutting or welding. They may explode.
- 6.f. Sparks and spatter are thrown from the welding arc. Wear oil free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes and a cap over your hair. Wear ear plugs when welding out of position or in confined places. Always wear safety glasses with side shields when in a welding area.
- 6.g. Connect the work cable to the work as close to the welding area as practical. Work cables connected to the building framework or other locations away from the welding area increase the possibility of the welding current passing through lifting chains, crane cables or other alternate circuits. This can create fire hazards or overheat lifting chains or cables until they fail.
- 6.h. Also see item 1.b.
- 6.i. Read and follow NFPA 51B "Standard for Fire Prevention During Welding, Cutting and Other Hot Work", available from NFPA, 1 Batterymarch Park, PO box 9101, Quincy, MA 022690-9101.
- 6.j. Do not use a welding power source for pipe thawing.



CYLINDER MAY EXPLODE IF DAMAGED.

- 7.a. Use only compressed gas cylinders containing the correct shielding gas for the process used and properly operating regulators designed for the gas and pressure used. All hoses, fittings, etc. should be suitable for the application and maintained in good condition. 
- 7.b. Always keep cylinders in an upright position securely chained to an undercarriage or fixed support.
- 7.c. Cylinders should be located:
 - Away from areas where they may be struck or subjected to physical damage.
 - A safe distance from arc welding or cutting operations and any other source of heat, sparks, or flame.
- 7.d. Never allow the electrode, electrode holder or any other electrically "hot" parts to touch a cylinder.
- 7.e. Keep your head and face away from the cylinder valve outlet when opening the cylinder valve.
- 7.f. Valve protection caps should always be in place and hand tight except when the cylinder is in use or connected for use.
- 7.g. Read and follow the instructions on compressed gas cylinders, associated equipment, and CGA publication P-1, "Precautions for Safe Handling of Compressed Gases in Cylinders," available from the Compressed Gas Association, 14501 George Carter Way Chantilly, VA 20151.



FOR ELECTRICALLY POWERED EQUIPMENT.



- 8.a. Turn off input power using the disconnect switch at the fuse box before working on the equipment.
- 8.b. Install equipment in accordance with the U.S. National Electrical Code, all local codes and the manufacturer's recommendations.
- 8.c. Ground the equipment in accordance with the U.S. National Electrical Code and the manufacturer's recommendations.

Refer to
<http://www.lincolnelectric.com/safety>
for additional safety information.

GRAPHIC SYMBOLS.....	4, 5
INSTALLATION	SECTION A
GENERAL DESCRIPTION	A-1
TECHNICAL SPECIFICATIONS.....	A-1
SAFETY PRECAUTIONS.....	A-2
VRD (VOLTAGE REDUCTION DEVICE).....	A-2
LOCATION AND VENTILATION.....	A-2
STORING.....	A-3
STACKING	A-3
ANGLE OF OPERATION.....	A-3
LIFTING	A-3
ENVIRONMENTAL LIMITATIONS	A-3
HIGH ALTITUDE OPERATION.....	A-3
HIGH TEMPERATURE OPERATION.....	A-3
COLD WEATHER STARTING:.....	A-3
TOWING	A-4
SERVICE TRUCK AND TRAILER INSTALLATION.....	A-4
PRE-OPERATION ENGINE SERVICE.....	A-4
OIL	A-4
FUEL	A-4
ENGINE COOLING SYSTEM.....	A-4
BATTERY CONNECTION.....	A-5
EXHAUST OUTLET PIPE.....	A-5
SPARK ARRESTOR	A-5
AIR CLEANER SERVICE INDICATOR.....	A-5
MACHINE GROUNDING.....	A-6
AUXILIARY POWER RECEPTACLES.....	A-6
120 VAC DUPLEX RECEPTACLES AND GFCI.....	A-6
CIRCUIT BREAKERS	A-6
ELECTRICAL DEVICE USE.....	A-6
WELDING OUTPUT CABLES.....	A-7
CABLE INSTALLATION.	A-7
CABLE INDUCTANCE AND ITS EFFECTS ON WELDING.....	A-8
CROSSLINC TECHNOLOGY	A-8
REMOTE CONTROL CONNECTIONS.	A-8
REMOTE OUTPUT CONTROL.....	A-8
REMOTE WELD TERMINALS.....	A-8
ACCESSORY CONNECTION DIAGRAMS.....	A-9
CROSSLINC WIRE FEEDER SETUP EXAMPLE	A-9
CROSSLINC REMOTE SETUP EXAMPLE.....	A-10
DUAL ARC SETUP EXAMPLE - CROSSLINC WIRE FEEDER AND INVERTER WELDER.....	A-10
TIG SETUP WITH FOOT PEDAL EXAMPLE.....	A-11
OPERATION	SECTION B
ADDITIONAL SAFETY PRECAUTIONS	B-1
RECOMMENDED APPLICATIONS	B-1
ADD FUEL	B-2
BREAK-IN PERIOD.....	B-2
ENGINE OPERATION.....	B-2
STARTING THE ENGINE.....	B-2
STOPPING THE ENGINE.....	B-2
TYPICAL FUEL CONSUMPTION.....	B-2
CONTROLS AND SETTINGS.....	B-3
SYSTEM CONTROLS	B-3
USER INTERFACE CONTROLS AND NAVIGATION.....	B-5
HOME SCREEN AND WELD MODE SELECTION.....	B-6
WELD MODE SCREEN.....	B-7
ACTIVE WELD SCREEN.....	B-8
WELD MODE SETTINGS.....	B-9
ENGINE STATUS SCREEN.....	B-12
SETTING SCREEN.....	B-14

MANAGING RESTRICTIONS.....B-15
 AUTO-STOP/START.....B-16
 MEMORY MODE OPERATION.....B-17
 PRODUCTIVITY METRICS.....B-17
 WELDER OPERATION.....B-18
 CROSSLINCB-18
 DUTY CYCLE.....B-18
 PARALLELING.....B-18
 ARC GOUGING MODE.....B-18
 STICK (SMAW).....B-18
 FLUX-CORED SELF-SHIELD WIRE (FCAW-S), SELF-SHIELD GAS-SHIELDED WIRE (FCAW-G), AND MIG (GMAW).....B-19
 AUXILIARY POWER OPERATION.....B-19
 SIMULTANEOUS WELDING AND AUXILIARY POWER LOADS.....B-20

ACCESSORIESSECTION C
 CROSSLINC ACCESSORIESC-1
 GENERAL ACCESSORIESC-1
 SERVICE KITS.....C-1
 REMOTE CONTROLS.....C-2
 TIG ACCESSORIES.....C-2
 WIRE FEEDERS AND GUNS.....C-2
 CABLE ACCESSORIES.....C-2
 POWER SOURCES.....C-2

MAINTENANCESECTION D
 ROUTINE AND PERIODIC MAINTENANCED-1
 ENGINE MAINTENANCE.....D-2
 AIR FILTERD-2
 FUEL FILTERS.....D-4
 COOLING SYSTEMD-4
 CHECKING AND REPLACING COOLANT.....D-4
 BATTERY HANDLING.....D-5
 ENGINE OIL CHANGED-5
 TIGHTENING THE FAN BELTD-6
 NAMEPLATES / WARNING DECALS MAINTENANCED-6
 GFCI MAINTENANCED-7

TROUBLESHOOTING.....SECTION E

WIRING, CONNECTION DIAGRAMS AND DIMENSION PRINTSECTION F

PARTS LISTPARTS.LINCOLNELECTRIC.COM

CONTENT/DETAILS MAY BE CHANGED OR UPDATED WITHOUT NOTICE. FOR MOST CURRENT INSTRUCTION MANUALS, GO TO PARTS.LINCOLNELECTRIC.COM.




GRAPHIC SYMBOLS

The following graphics appear on the Frontier or in the manual.

	Warning or Caution		Belt Drive		Remote Accessory Type
	Instructions		Battery		Pinch
	Fumes and Gases		Hot Surface		Protective Ground
	Explosion		Fire or Explosion		Circuit Breaker
	Arc Rays		Battery Explosion		Welding Amperage
	Moving Parts		Battery Acid		Welding Voltage
	Falling Equipment		Engine Temperature		Wire Feeder
	Electric Shock		Positive Output		3 phase alternator
U0	Open Circuit Voltage		Negative Output		Direct Current
I2	Output Current		SMAW Welding		Auto Idle
U2	Output Voltage		FCAW-S Welding		High Idle
X	Duty Cycle		GMAW / FCAW-G Welding		Fuel
U _r	Reduced Open Circuit Voltage		GTAW welding		CrossLinc
	Home		Carbon Arc Gouging		Phase
	Remote		APEX® System		Welder Output
	Help		Engine		Voltage Output
	Back		Set-up		Amperage Output
	Oil / Oil Pressure		Hot Start		DigFX™
	Air Filter		Arc Force		
	Water Separator		Weld Terminal		
	Fuel Filter		Memory Setup		
	Engine Coolant		Frequency		

GRAPHIC SYMBOLS

The following graphics appear on the Frontier or in the manual.



GENERAL DESCRIPTION

The Frontier® 400X is a diesel engine driven welding power source. The machine features DC multi-process welding plus 120/240 VAC single-phase and 240 VAC three-phase auxiliary power. The welding control system uses state of the art Chopper Technology® for superior welding performance. The machine utilizes a robust 7" graphical user interface display for simplified controls and advanced features.

The machine has been equipped with Crossline® Technology to provide weld cable communication for voltage control at the arc without the need for a control cable.

TECHNICAL SPECIFICATIONS

INPUT – DIESEL ENGINE	
Make / Model	Description
Perkins® 403F-15T EPA Tier 4 Final Compliant (K3484-1, K3485-1)	Cylinder, 24.7 HP (18.4 kW) Turbocharged Water Cooled Diesel Engine
Capacities	Displacement
Fuel: 20 US gal. (75.7L) Oil: 6.40 qts. (6.0L) Radiator Coolant: 7.20 qts. (6.8L)	91.0 cu. in. (1.5L) Bore / Stroke 3.30" x 3.50" 84mm x 90mm
Make / Model	Description
Kubota® D1503-M EPA Tier 4 Final Compliant (K3484-2, K3485-2)	Cylinder, 24.8 HP (18.5 kW) Water Cooled Diesel Engine
Capacities	Displacement
Fuel: 20 US gal. (75.7L) Oil: 5.90 qts. (5.6L) Radiator Coolant: 7.20 qts. (6.8L)	91.0 cu. in. (1.5L) Bore / Stroke 3.27" x 3.64" 83mm x 92.4mm
Starting System	Speed (RPM)
12 VDC Battery and Starter Manual Glow Plugs	High Idle 1800 Low Idle 1440 Full Load 1800
Battery Size	
BCI Group Size 34 650 Cold Crank Amps	

RATED WELDING OUTPUT @ 104°F(40°C)		
Duty Cycle	Welding Output	Voltage
100%	325 Amps (DC multi-purpose)	33 Volts
60%	400 Amps (DC multi-purpose)	26 Volts

OUTPUT @104°F (40°C) - WELDER AND GENERATOR	
WELDING MODE	OUTPUT RANGE
Stick (SMAW)	30-400 Amps
Flux-Cored Self-Shielded (FCAW-S)	10 to 45 Volts
MIG (GMAW)	10 to 45 Volts
Flux-Cored Gas-Shielded (FCAW-G)	10 to 45 Volts
Arc Gouging (CAC-A)	60-400 Amps
DC TIG (GTAW)	5-400 Amps
Pipe (SMAW)**	30-400 Amps
**Only available on Frontier 400X Pipe model	
Open Circuit Voltage 60 VDC Avg @1800 RPM 71 VDC Peak @1800 RPM	
Auxiliary Power⁽¹⁾ 120 V / 240 V, 60 Hz 10,000 Watts Continuous / 11,500 Watts Peak, Single Phase 11,000 Watts Continuous / 12,500 Watts Peak, Three Phase	

RECEPTACLES		
Receptacle	QTY	Circuit Breaker
120 VAC Duplex (5-20R) GFCI Protected	2	20 Amps
240 VAC Three Phase (15-50R)	1	50 Amps
120/240 VAC Single Phase (14-50R)	1	50 Amps

AGENCY APPROVALS & STANDARDS	
CONFORMITY MARK	CSA
INGRESS PROTECTION RATING	IP23S
IEC STANDARD	60974-1

ENGINE DETAILS	
EPA EMISSION RATING	GOVERNOR
Tier 4 Final Compliant	Electronic
AIR CLEANER	ENGINE IDLER
Single Element	Automatic Idler
FUEL SYSTEM	
Mechanical Fuel Pump with Auto Air Bleed System Electric Shutoff Solenoid Indirect Fuel Injector	
MUFFLER	ENGINE PROTECTION
Low Noise Muffler with Rotating Exhaust Tube and Internal USFS Certified Spark Arrestor	Low Oil Pressure Shutdown High Engine Coolant Temperature
ENGINE WARRANTY INFORMATION	Perkins (www.perkins.com) Kubota (www.kubotaengine.com)

PHYSICAL DIMENSIONS	
Height ⁽²⁾	35.94 in. (913 mm)
Width ⁽³⁾	25.30 in. (643 mm)
Depth	60.00 in. (1524 mm)
Weight ⁽⁴⁾	1035 lbs. (469 kg)

(1) Output rating in watts is equivalent to volt-amperes at unity power factor. Output voltage is within +/- 10% at all loads up to rated capacity. When welding, available auxiliary power will be reduced.

(2) Top of Enclosure. Add 7.9" (200 mm) for exhaust.

(3) Includes Door. Base is 24.0" (610 mm) wide.

(4) Approximate weight less fuel.

INSTALLATION

SAFETY PRECAUTIONS

WARNING

Do not attempt to use this equipment until you have thoroughly read all operating and maintenance manuals supplied with your machine. They include important safety precautions, detailed engine starting, operating and maintenance instructions and parts lists.

ELECTRIC SHOCK can kill.

- Do not touch electrically live parts such as output terminals or internal wiring.
- Insulate yourself from the work and ground.
- Always wear dry insulating gloves.



ENGINE EXHAUST can kill.

- Use in open, well ventilated areas or vent exhaust outside



MOVING PARTS can injure.

- Do not operate with doors open or guards off.
- Stop engine before servicing.
- Keep away from moving parts



Only qualified personnel should install, use or service this equipment.

VRD (VOLTAGE REDUCTION DEVICE)

The VRD reduces the OCV (Open Circuit Voltage) at the welding output terminals while not welding to less than 30 VDC when the resistance of the output circuit is above 200Ω (ohms).

The VRD requires that the welding cable connections be kept in good electrical condition because poor connections will contribute to poor starting. Having good electrical connections also limits the possibility of other safety issues such as heat-generated damage, burns and fires.

This machine has two VRD switches to allow VRD to be switched "ON" or "OFF" in CC modes, CV modes, or both. The machine is shipped with both VRD switches in the "OFF" position.

To utilize the CrossLinc feature on this product, the VRD needs to be switched "OFF" for the given output type.

To turn VRD "ON" or "OFF":

- Turn the engine "OFF"
- Disconnect the negative battery cable
- Lower the front panel by removing 4 mounting screws (See Figure A.1)
- Place the VRD switches in the "ON" or "OFF" position (See Figure A.2).

NOTE: Use the "CC" switch to enable/disable VRD in CC modes or the "CV" switch to enable/disable VRD in CV modes




Figure A.1




Figure A.2

Note: If VRD is ON, an indicator on the user interface will be active

LOCATION AND VENTILATION

The welder should be located to provide an unrestricted flow of clean, cool air to the cooling air inlets and to avoid restricting the cooling air outlets. Also, locate the welder so that the engine exhaust fumes are properly vented to an outside area.

WARNING

Air to cool the engine is drawn in the front and side and exhausted through radiator and case back. It is important that the intake and exhaust air is not restricted. Allow a minimum clearance of 1ft. (0.6m) from the case back and 16 in. (406mm) from either side of the base to a vertical surface. (Failure to resolve these guidelines may result in an overtemp condition resulting in engine shut down).

WARNING

DO NOT MOUNT OVER COMBUSTIBLE SURFACES

Where there is a combustible surface directly under stationary or fixed electrical equipment, that surface should be covered with a steel plate at least .06"(1.6mm) thick, which should extend not less than 5.90"(150mm) beyond the equipment on all sides.

STORING

1. Store the machine in a cool, dry place when it is not in use. Protect it from dust and dirt. Keep it where it can't be accidentally damaged from construction activities, moving vehicles, and other hazards.
2. Drain the engine oil and refill with fresh oil. Run the engine for about five minutes to circulate oil to all the parts. See the ENGINE OPERATION section manual for details on changing oil.
3. Remove the battery, recharge it, and adjust the electrolyte level. Store the battery in a dry, dark place.

STACKING

Frontier® 400X machines cannot be stacked.

ANGLE OF OPERATION

To achieve optimum engine performance the Frontier® 400X should be run in a level position. The maximum angle of continuous operation for the Perkins engine is 25° in all directions, 35° intermittent (less than 10 minutes continuous) in all directions. The Kubota engine is 20° and 30°, respectively. When operating the welder at an angle, provisions must be made for checking and maintaining the oil level at the normal (FULL) oil capacity. Also the effective fuel capacity will be slightly less than the specified 20 gal. (75.5L).

LIFTING

The Frontier® 400X weighs approximately 1174 lbs. (533kg) with a full tank of fuel and 1035 lbs. (469kg) less fuel. A lift bale is mounted to the machine and should always be used when lifting the machine.

WARNING

FALLING EQUIPMENT can cause injury.

- Lift only with equipment of adequate lifting capacity.
- Be sure machine is stable when lifting.
- Do not lift this machine using lift bale if it is equipped with a heavy accessory such as trailer or gas cylinder.
- Do not lift machine if lift bale is damaged.
- Do not operate machine while suspended from lift bale.



ENVIRONMENTAL LIMITATIONS

This machine is IP23S rated for use in an outdoor environment. The machine should not be subjected to falling water during use nor should any parts of it be submerged in water. Doing so may cause improper operation as well as pose a safety hazard. The best practice is to keep the machine in a dry, sheltered area.

HIGH ALTITUDE OPERATION

At higher altitudes, output derating may be necessary.

Perkins: For maximum rating, derate the welder output 2% for every 1000 ft. (305 m) above 5000 ft. (1524 m).

Kubota: For maximum rating, derate the welder output 4% for every 984 ft. (300 m) above 4920 ft. (1500 m).

Contact an Authorized Service Representative for any engine adjustments that may be required.

HIGH TEMPERATURE OPERATION

At temperatures above 104°F (40°C), output voltage derating may be necessary. For maximum output current ratings, derate welder voltage rating 2 volts for every 21°F (10°C) above 104°F (40°C).

COLD WEATHER STARTING:

With a fully charged battery and 0W-40 oil, the engine should start satisfactorily down to -5°F (-20°C). If the engine must be frequently started at or below 0°F (-18°C), it may be desirable to install cold-starting aides. For engines with common rail injection, the mixing of petroleum or kerosene and adding of extra low additives is not permissible. Fuels in accordance with ASTM S975 Grade 1D or DIN EN590-Arctic-Diesel may have no petroleum added. Allow the engine to warm up before applying a load or switching to high idle.

WARNING

Under no conditions should ether or other starting fluids be used with this engine!

TOWING

Use a recommended trailer for use with this equipment for road, in-plant and yard towing by a vehicle⁽¹⁾. If the user adapts a non-Lincoln trailer, they must assume responsibility that the method of attachment and usage does not result in a safety hazard or damage the welding equipment. Some of the factors to be considered are as follows:

1. Design capacity of trailer vs. weight of Lincoln equipment and likely additional attachments.
2. Proper support of, and attachment to, the base of the welding equipment so there will be no undue stress to the framework.
3. Proper placement of the equipment on the trailer to ensure stability side to side and front to back when being moved and when standing by itself while being operated or serviced.
4. Typical conditions of use, i.e., travel speed; roughness of surface on which the trailer will be operated; environmental conditions; like maintenance.
5. Conformance with federal, state and local laws.⁽¹⁾

(1) Consult applicable federal, state and local laws regarding specific requirements for use on public highways.

SERVICE TRUCK AND TRAILER INSTALLATION

The welder should be located to provide an unrestricted flow of clean, cool air to the cooling air inlets and to avoid heated air coming out of the welder recirculating back to the cooling air inlet. Also, locate the welder so that engine exhaust fumes are properly vented to an outside area.

WARNING

- Improperly mounted concentrated loads may cause unstable vehicle handling and tires or other components to fail.
- Only transport this welding equipment on serviceable vehicles which are rated and designed for such loads.
- Distribute, balance and secure loads so vehicle is stable under conditions of use.
- Do not exceed maximum rated loads for components such as suspension, axles and tires.
- Mount equipment base to metal bed or frame of vehicle. Do not mount the welder using rubber mounts.
- Follow vehicle manufacturer's instructions.
- Do not install equipment where air flow is restricted. Equipment or the engine may overheat.
- Do not weld on the base. Welding on the base may cause fuel tank explosion or fire.
- Always ground the equipment frame to the vehicle frame to prevent electric shock and static electricity hazards.
- Do not place propane or shielding gas tanks near hot air or exhaust.

PRE-OPERATION ENGINE SERVICE

READ the engine operating and maintenance instructions supplied with this machine.

WARNING

- Stop engine and allow to cool before fueling.
- Do not smoke when fueling.
- Fill fuel tank at a moderate rate and do not overfill.
- Wipe up spilled fuel and allow fumes to clear before starting engine.
- Keep sparks and flame away from tank.

OIL



The Frontier® 400X is shipped with the engine crankcase filled with high quality SAE 10W-30 Oil that meets (API class CJ-4 or better) for diesel engines. Check the oil level before starting the engine. If it is not up to the full mark on the dip stick, add oil as required. The oil change interval is dependent on the quality of the oil and the operating environment. Refer to the Engine Operator's Manual for more details on specific oil recommendations, break-in information, and proper service and maintenance intervals.

FUEL

WARNING

USE ULTRA-LOW SULFUR DIESEL FUEL IN US AND CANADA



Fill the fuel tank with clean, fresh fuel. The capacity of the tank is 20 gal. (75.7L). When the fuel gauge reads empty the tank contains approximately 2 gal. (7.6L) of reserve fuel.

NOTE: A fuel shut off valve is located just before the pre-filter/sediment filter. Place the valve in the closed position when the welder is not used for extended periods of time.

ENGINE COOLING SYSTEM

WARNING

**HOT COOLANT can burn skin.
Do not remove cap if radiator is hot.**



The welder is shipped with the engine and radiator filled with a 50% mixture of ethylene glycol and water. See the MAINTENANCE section and the engine Operator's Manual for more information on coolant.

BATTERY CONNECTION**CAUTION**

Use caution as the electrolyte is a strong acid that can burn skin and damage eyes.

The Frontier® 400X is shipped with the negative battery cable disconnected. Make certain that the RUN/STOP/IDLE switch is in the STOP position. Remove the four screws from the battery tray using a screwdriver or a 3/8" (10mm) socket. Attach the negative battery cable to the negative battery terminal and tighten using a 1/2" (13mm) socket or wrench.

NOTE: This machine is furnished with a wet charged battery; if unused for several months, the battery may require a booster charge. Be careful to charge the battery with the correct polarity. (See Battery in MAINTENANCE section)

WARNING**GASES FROM BATTERY can explode.**

- Keep sparks, flame and cigarettes away from battery.



To prevent EXPLOSION when:

- **INSTALLING A NEW BATTERY** — disconnect negative cable from old battery first and connect to new battery last.
- **CONNECTING A BATTERY CHARGER** — remove battery from welder by disconnecting negative cable first, then positive cable and battery clamp. When reinstalling, connect negative cable last. Keep well ventilated.
- **USING A BOOSTER** — connect positive lead to battery first then connect negative lead to negative battery lead at engine foot.

BATTERY ACID can burn eyes and skin.

- Wear gloves and eye protection and be careful when working near battery.
- Follow instructions printed on battery.



IMPORTANT: To prevent ELECTRICAL DAMAGE WHEN:

- Installing new batteries.
- Using a booster.

Use correct polarity — **Negative Ground.**

EXHAUST OUTLET PIPE

Remove cap from muffler pipe protruding from roof.

Using the clamp provided secure the outlet pipe to the outlet tube with the pipe positioned such that it will direct the exhaust in the desired direction away from the air intake. Tighten using a wrench (See Figure A.3).


SPARK ARRESTOR

Some federal, state or local laws may require that gasoline or diesel engines be equipped with exhaust spark arrestors when they are operated in certain locations where unarrested sparks may present a fire hazard.

The muffler on the Frontier 400X has an internal USFS certified Spark Arrestor.

AIR CLEANER SERVICE INDICATOR

Air cleaner service indicator provides a Go/No-Go visual indication of useful filter service life. The indicator is located inside the service door.

FIGURE A.3


MACHINE GROUNDING

Because this portable engine driven welder creates its own power, it is not necessary to connect its frame to an earth ground, unless the machine is connected to premises wiring (home, shop, etc.).

To prevent dangerous electric shock, other equipment powered by this engine driven welder must:

- be grounded to the frame of the welder using a grounded type plug, or
- be double insulated.

When this welder is mounted on a truck or trailer, its frame must be securely connected to the metal frame of the vehicle. When this engine driven welder is connected to premises wiring such as that in a home or shop, its frame must be connected to the system earth ground. See further connection instructions in the section entitled STANDBY POWER CONNECTIONS as well as the article on grounding in the latest National Electrical Code and the local codes.

In general, if the machine is to be grounded, it should be connected with a #8 or larger copper wire to a solid earth ground such as a metal ground stake going into the ground for at least 10 ft. (3.1m) or to the metal framework of a building which has been effectively grounded. The National Electric Code lists a number of alternate means of grounding electrical equipment. A machine grounding stud marked with the symbol is  provided on the front of the welder.

AUXILIARY POWER RECEPTACLES

Start the engine and set the RUN/STOP/IDLE control switch to the "High Idle" position. Voltage is now correct at the receptacles for auxiliary power. This must be done before a tripped GFCI can be reset properly. See the MAINTENANCE section for more detailed information on testing and resetting the GFCI.

The auxiliary power of the Frontier® 400X consists of two 20 Amp 120 VAC (5-20R) duplex receptacles with GFCI protection, one 50 Amp 120/240 VAC single phase (14-50R) receptacle and one 50 Amp 240 VAC three phase (15-50R) receptacle.

The auxiliary power capacity is 10,000 watts continuous of 60 Hz, single phase power. The auxiliary power capacity rating in watts is equivalent to volt-amperes at unity power factor.

The 240 VAC single phase output can be split to provide two separate 120 VAC outputs with a max permissible current of 50 amps per output to two separate 120 VAC branch circuits. NOTE: These circuits are opposite polarities and cannot be paralleled. Output voltage is within $\pm 10\%$ at all loads up to rated capacity.

The three phase auxiliary power capacity is 11,000 watts continuous at 60 Hz.

120 VAC DUPLEX RECEPTACLES AND GFCI

A GFCI protects the two 120 VAC auxiliary power receptacles.


A GFCI (Ground Fault Circuit Interrupter) is a device to protect against electric shock should a piece of defective equipment connected to it develop a ground fault. If this situation should occur, the GFCI will trip, removing voltage from the output of the receptacle. If a GFCI is tripped see the MAINTENANCE section for detailed information on testing and resetting it. A GFCI should be properly tested before each use.

The 120 VAC auxiliary power receptacles should only be used with three wire grounded type plugs or approved double insulated tools with two wire plugs. The current rating of any plug used with the system must be at least equal to the current capacity of the associated receptacle.

CIRCUIT BREAKERS

All auxiliary power is protected by circuit breakers. The 120 VAC duplex receptacles have 20 amp circuit breakers for each receptacle. The 120/240V single phase and the 240V three phase receptacles have a 50 amp 3-pole circuit breaker that disconnects both hot leads and all three phases simultaneously. (See Figure A.4)

FIGURE A.4 - AUXILIARY POWER RECEPTACLES



ELECTRICAL DEVICE USE

This machine has been designed to support the power requirements of common jobsite tools and equipment. However, due to the nature of auxiliary power output, it is recommended for the operator to review the sensitivity and protections of any tools or equipment used with this machine to prevent any damage or failures.

WELDING OUTPUT CABLES

With the engine off, connect to the terminals provided. These connections should be checked periodically and tightened if necessary.

Listed in Table A.1 are copper cable sizes recommended for the rated current and duty cycle. Lengths stipulated are the distance from the welder to work and back to the welder again. Cable sizes are increased for greater lengths primarily for the purpose of minimizing cable voltage drop.

TABLE A.1

OUTPUT CABLE GUIDELINES						
Amperes	Percent Duty Cycle	CABLE SIZES FOR COMBINED LENGTHS OF ELECTRODE AND WORK CABLES [RUBBER COVERED COPPER - RATED 167°F (75°C)]**				
		0 to 50 Ft.	50 to 100 Ft.	100 to 150 Ft.	150 to 200 Ft.	200 to 250 Ft.
200	60	2	2	2	1	1/0
200	100	2	2	2	1	1/0
250	30	3	3	2	1	1/0
250	40	2	2	1	1	1/0
250	60	1	1	1	1	1/0
250	100	1	1	1	1	1/0
300	60	1	1	1	1/0	2/0
300	100	2/0	2/0	2/0	2/0	3/0
350	40	1/0	1/0	2/0	2/0	3/0
400	60	2/0	2/0	2/0	3/0	4/0
400	100	3/0	3/0	3/0	3/0	4/0

** Tabled values are for operation at ambient temperatures of 104°F (40°C) and below. Applications above 104°F (40°C) may require cables larger than recommended, or cables rated higher than 167°F (75°C).

 **CAUTION**

- Loose connections will cause the output terminals to overheat. The terminals may eventually melt.
- Do not cross the welding cables at the output terminal connection. Keep the cables isolated and separate from one another.

CABLE INSTALLATION

Install the welding cables to your Frontier® 400X as follows.


 **WARNING**

1. The engine must be OFF to install welding cables.
2. Remove the flanged nuts from the output terminals.
3. Connect the electrode holder and work cables to the weld output terminals. The terminals are identified on the case front.
4. Tighten the flanged nuts securely.
5. Be certain that the metal piece you are welding (the “work”) is properly connected to the work clamp and cable.
6. Check and tighten the connections periodically.

CABLE INDUCTANCE AND ITS EFFECTS ON WELDING

Excessive cable inductance will cause the welding performance to degrade. There are several factors that contribute to the overall inductance of the cabling system including cable size, number of loops, and total loop area. The loop area is defined by the separation distance between the electrode and work cables and the overall welding loop length. Welding loop length = electrode cable (A) + work cable (B) + work path (C) (See Figure A.6).

FIGURE A.6




To minimize inductance always use the appropriate size cables, and whenever possible, run the electrode and work cables in close proximity to one another to minimize the loop area. Since the most significant factor in cable inductance is the welding loop length, avoid excessive lengths and do not coil excess cable. Excess cable should be placed in a straight or zig-zag pattern between the machine and work per Figure A.7.

If a spooling mechanism is used to store the welding cables, unspool the cables. Avoid leaving more than 30 feet of cable on each storage spool, and for best performance, completely unspool the welding cables.

For long work piece lengths, a sliding ground should be considered to keep the total welding loop length as short as possible.

FIGURE A.7



CROSSLINC TECHNOLOGY

This machine features CrossLinc technology, which allows for remote control of the welding output via the weld cables rather than a control cable. As result, the control cable is no longer needed when connected to a CrossLinc compatible wire feeder or remote control.

This machine will function with all CrossLinc compatible wire feeders except for the oldest LN-25X models. Incompatible models include:

Code # 12432

Code # 12504

REMOTE CONTROL CONNECTIONS

The Frontier® 400X is equipped with a 12-pin remote connector for attaching remote control accessories.

NOTE: To connect accessories with a 6-pin connector, use the 6-pin to 12-pin adapter (K2909-1).

REMOTE OUTPUT CONTROL

To enable remote control capabilities, turn on remote control with the button on the user interface. When remote control is enabled, output is controlled through the 12-pin connector and the output control knob on the Frontier will be disabled.

When a CrossLinc device is connected, the remote output control is disabled, and the CrossLinc device is in control of the output.

REMOTE WELD TERMINALS

By default, the weld terminals are ON when a weld mode is selected. To use a remote output control switch or a foot pedal, the weld terminals can be changed to REMOTE in the weld settings within the desired weld mode.

ACCESSORY CONNECTION DIAGRAMS

WARNING

Shut off welder before making or removing any electrical connections.


When connecting an accessory to the Frontier® 400X, the following steps should be taken:

- Shut off the welder.
- Connect your leads for the desired accessory. For electrode positive, connect the electrode cable to the “+” terminal of the welder and work cable to the “-” terminal of the welder.

For electrode negative, connect the electrode cable “-” terminal of the welder and work cable to the “+” terminal of the welder. Installation diagrams for common setups are included on the following pages.

CROSSLINC WIRE FEEDER SETUP EXAMPLE


FIGURE A.8



Description	Product Number	QTY
Frontier® 400X Welder/Generator	K3484-1	1
LN-25X Wire Feeder	K4267-2	1
K126® PRO Innershield® 350A FCAW-S Welding Gun	K126-12	1
Electrode Cable - 2/0, 50 ft. (15.3 m), Black	K2485-2	2
Electrode Cable - 2/0, 10 ft. (3.1 m), Black	K2483-2	1
Work Clamp	K910-1	1
Cable Connectors - TWECO to Lug Adaptor	K2487-1	2

CROSSLINC REMOTE SETUP EXAMPLE

FIGURE A.9




Description	Product Number	QTY
Frontier® 400X Welder/Generator	K3484-1	1
CrossLinc® Remote	K4345-1	1
EH-305D Electrode Holder	K909-7	1
Electrode Cable - 2/0, 50 ft. (15.3 m), Black	K2485-2	2
Electrode Cable - 2/0, 10 ft. (3.1 m), Black	K2483-2	1
Work Clamp	K910-1	1
Cable Connectors - TWECO to Lug Adaptor	K2487-1	2

DUAL ARC SETUP EXAMPLE - CROSSLINC WIRE FEEDER AND INVERTER WELDER


Description	Product Number	QTY
Frontier® 400X Welder/Generator	K3484-1	1
LN-25X Wire Feeder	K4267-2	1
K126® PRO Innershield® 350A FCAW-S Welding Gun	K126-12	1
Gas Regulator and Hose Kit	K586-1	1
Electrode Cable - 2/0, 50 ft. (15.3 m), Black	K2485-2	2
Electrode Cable - 2/0, 10 ft. (3.1 m), Black	K2483-2	2
Work Clamp	K910-1	2
Cable Connectors - TWECO to Lug Adaptor	K2487-1	2
Invertec® V276	K4868-1	1
EH-305D Electrode Holder	K909-7	1

FIGURE A.10



TIG SETUP WITH FOOT PEDAL EXAMPLE

Description	Product Number	QTY
Frontier® 400X Welder/ Generator	K3484-1	1
PTA-26V TIG Torch - 25 ft. (7.6 m)	K1783-9	1
Foot Pedal	K870-2	1
Gas Regulator and Hose Kit	K586-1	1
Electrode Cable - 2/0, 50 ft. (15.3 m), Black	K2485-2	2
Electrode Cable - 2/0, 10 ft. (3.1 m), Black	K2483-2	1
Work Clamp	K910-1	1
Cable Connectors - TWECO to Lug Adaptor	K2487-1	2

FIGURE A.12

OPERATION

SAFETY PRECAUTIONS

Read and understand this entire section before operating your Frontier® 400X.

WARNING

Do not attempt to use this equipment until you have thoroughly read the engine manufacturer's manual supplied with your welder. It includes important safety precautions, detailed engine starting, operating and maintenance instructions, and parts lists.

ELECTRIC SHOCK can kill.

- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground
- Always wear dry insulating gloves.



ENGINE EXHAUST can kill.

- Use in open, well ventilated areas or vent exhaust outside
- Do not stack anything near the engine.



MOVING PARTS can injure.

- Do not operate with doors open or guards off.
- Stop engine before servicing.
- Keep away from moving parts



The serviceability of a product or structure utilizing the welding modes is and must be the sole responsibility of the builder/user. Many variables beyond the control of The Lincoln Electric Company affect the results obtained in applying these programs. These variables include, but are not limited to, welding procedure, plate chemistry and temperature, weldment design, fabrication methods and service requirements. The available range of a welding mode may not be suitable for all applications, and the builder/user is and must be solely responsible for welding mode selection.

RECOMMENDED APPLICATIONS

WELDER - The Frontier® 400X provides excellent constant current DC welding output for stick (SMAW) and TIG (GTAW) welding, as well as excellent constant voltage DC welding output for MIG (GMAW), Innershield (FCAW), Outershield (FCAW-G) and Metal Core (GMAW-C) welding. In addition the Frontier™ 400X can be used for Arc Gouging with carbons up to 5/16" (8.0 mm) in diameter.

GENERATOR - The Frontier® 400X provides smooth 120/240 VAC single phase and 240V three phase output for auxiliary power and emergency standby power.

The Frontier® 400X is **NOT RECOMMENDED** for pipe thawing.

WARNING

Pipe Thawing with an arc welder can cause fire, explosion, damage to electric wiring or to the arc welder if done improperly.

The use of an arc welder for pipe thawing is not approved by the CSA, nor is it recommended or supported by Lincoln Electric.

ADDING FUEL

WARNING

DIESEL FUEL can cause fire.

- Stop engine while fueling.
- Do not smoke when fueling.
- Keep sparks and flame away from tank.
- Do not leave unattended while fueling.
- Wipe up spilled fuel and allow fumes to clear before starting engine.
- Do not overfill tank, fuel expansion may cause overflow.

USE ULTRA-LOW SULFUR DIESEL FUEL ONLY

- Remove the fuel tank cap.
- Fill the tank. **DO NOT FILL THE TANK TO THE POINT OF OVERFLOW.**
- Replace the fuel cap and tighten securely.
- See Engine Owner's Manual for specific fuel recommendations.

BREAK-IN PERIOD

The engine will use a small amount of oil during its "break-in" period. The break-in period is about 50 running hours. Change the oil after the first 50 hours of operation. Thereafter, follow the engine service and maintenance schedule located in the Engine Operator's Manual.

CAUTION

During break-in, subject the engine driven welder to moderate loads. Avoid long periods running at idle. Before stopping the engine, remove all loads and allow the engine to cool several minutes.

ENGINE OPERATION

Before starting the engine:

- Be sure the machine is on a level surface.
- Open side engine door and remove the engine oil dipstick and wipe it with a clean cloth. Reinsert the dipstick and check the level on the dipstick.
- Add oil (if necessary) to bring the level up to the full mark. Do not overfill. Close engine door.
- Check radiator for proper coolant level. (Fill if necessary).
- See Engine Owner's Manual for specific oil and coolant recommendations.

STARTING THE ENGINE

1. Remove all plugs connected to the AC power receptacles.
2. Set RUN / STOP / IDLE switch to AUTO IDLE / RUN position.
3. Press the GLOW PLUG button to preheat the engine before starting if needed. Then, press and hold the START button until the machine turns over.
4. Release the engine START button immediately when the engine starts.
5. The engine will run at high idle speed for approximately 12 seconds and then drop to low idle speed. Allow the engine to warm up at low idle for several minutes before applying a load and/or switching to high idle.

NOTE: Allow a longer warm up time in cold weather.

CAUTION

- Do not allow the starter motor to run continuously for more than 20 seconds.
- Do not push the START button while the engine is running because this can damage the ring gear and/or the starter motor.

STOPPING THE ENGINE

Remove all welding and auxiliary power loads and allow the engine to run at low idle speed for a few minutes to cool the engine.

Turn off the engine by placing the RUN / STOP / IDLE switch in the STOP position.

NOTE: A fuel shut off valve is located on the fuel pre-filter.

TYPICAL FUEL CONSUMPTION

Refer to the table below for typical fuel consumption of the Frontier® 400 X Engine for various operating scenarios.

(Perkins 403F-15T) Fuel Consumption

	GAL. / HR.	L / HR.	RUN TIME (HRS.) WITH FULL TANK*
High Idle, no load	0.56	2.11	35.84
Low Idle, no load	0.34	1.28	59.14
Welding - 100A @ 24V	0.68	2.56	29.57
Welding - 200A @ 28V	1.18	4.48	16.90
Welding - 300A @ 32V	1.23	4.64	16.32
Welding - 325A @ 33V	1.31	4.96	15.26
Welding - 400A @ 26V	1.33	5.02	15.07
Auxiliary - 10kW Single Phase Power	1.12	4.26	17.79
Auxiliary - 11kW Three Phase Power	1.21	4.58	16.54

*Full Tank equals 20 gal. (75.7L)

TYPICAL FUEL CONSUMPTION (CONT)

(Kubota D1503-M) Fuel Consumption


	GAL. / HR.	L / HR.	RUN TIME (HRS.) WITH FULL TANK*
High Idle, no load	0.43	1.63	46.39
Low Idle, no load	0.29	1.09	69.58
Welding - 100A @ 24V	0.58	2.21	34.29
Welding - 200A @ 28V	0.80	3.01	25.17
Welding - 300A @ 32V	1.12	4.26	17.79
Welding - 325A @ 33V	1.27	4.80	15.77
Welding - 400A @ 26V	1.25	4.74	15.98
Auxiliary - 10kW Single Phase Power	1.19	4.51	16.78
Auxiliary - 11kW Three Phase Power	1.28	4.86	15.56

*Full Tank equals 20 gal. (75.7L)

CONTROLS AND SETTINGS

All welder and engine controls are located on the case front panel. Refer to Figure B.1 and the explanations that follow.

FIGURE B.1 CASE FRONT PANEL CONTROLS



SYSTEM CONTROLS

1. START PUSH BUTTON - Energizes the starter motor to crank the engine.

2. GLOW PLUG PUSH BUTTON - Activates the glow plugs when pushed. Hold for approximately 10 seconds prior to engine starting in cold weather. Glow plug should not be activated for more than 20 seconds continuously.

3. 10A BREAKER FOR 40V APEX® SYSTEM

4. 10A BREAKER FOR 12V ENGINE BATTERY

5. RUN / STOP / IDLE SWITCH - The switch has three positions. The right position is OFF, the middle position is AUTO IDLE / RUN, and the left position is HIGH IDLE / RUN.

- a. In the OFF position, the engine will turn off.
- b. In the HIGH IDLE position, the engine runs at the high idle speed controlled by the governor.
- c. In the AUTO IDLE position, the idler operates as follows:
 - When switched from HIGH to AUTO or after starting the engine, the engine will operate at full speed for approximately 12 seconds and then go to low idle speed.

- When the electrode touches the work or power is drawn for lights or tools (approximately 100 watts minimum) the engine accelerates and operates at full speed.
- When welding ceases and the auxiliary power load is turned off, a fixed time delay of approximately 12 seconds starts.
- If the welding or auxiliary power load is not restarted before the end of the time delay, the idler reduces the engine speed to low idle speed.
- The engine will automatically return to high idle speed when the welding load or auxiliary power load is reapplied.


6. 120 VAC SINGLE PHASE RECEPTACLES - NEMA 5-20R receptacles that provides 120 VAC single-phase auxiliary power. Each receptacle has a 20 amp rating.

7. GFCI MODULES - Protects the 120 VAC duplex receptacles.

8. GRAPHICAL USER INTERFACE - Controls and displays information about the machine. See section USER INTERFACE CONTROLS for operation information.

SYSTEM CONTROLS CONT.

- 9. APEX® SYSTEM CONNECTORS** - Optional connectors available via separate kit. Kit includes needed components to power an APEX® System.
- 10. 12-PIN CONNECTOR** - Used for attaching optional remote control equipment. The K2909-1 (12-pin to 6-pin) adapter can be used for attaching to accessories requiring the 6-pin connector.
- 11. 120/240 VAC SINGLE PHASE RECEPTACLE** - A NEMA 14-50R receptacle that provides 240 VAC or can be split for 120 VAC single-phase auxiliary power. This receptacle has a 50 amp rating. Refer to the AUXILIARY POWER RECEPTACLES section in the INSTALLATION chapter for further information about this receptacle
- 12. 240 VAC THREE PHASE RECEPTACLE** - A NEMA 15-50R receptacle that provides 240 VAC three-phase auxiliary power. This receptacle has a 50 amp rating.
- 13. 50A BREAKER FOR 120V/240V AND 240V RECEPTACLES**
- 14. 20A BREAKER FOR 120V RECEPTACLE**
- 15. GROUND STUD** - Provides a connection point for connecting the machine case to earth ground. Refer to MACHINE GROUNDING in the INSTALLATION section for proper machine grounding information.
- 16. WELD TERMINALS** - These 1/2" - 13 studs with flange nuts provide welding connection points for the electrode and work cables. For positive polarity welding the electrode cable connects to the "+" positive terminal and the work cable connects to this "-" negative terminal. For negative polarity welding the work cable connects to the "+" positive terminal and the electrode cable connects to this "-" negative terminal.

USER INTERFACE CONTROLS & NAGIVATION


- 1. KNOB AND PUSH BUTTON** - Rotate the knob to adjust values and move through the menus and push the knob to select values.
- 2. HOME BUTTON** - Will return you to the home screen from any menu.
- 3. REMOTE BUTTON** - Enable/Disable Remote Control
- 4. HELP / READY.SET.WELD®** - Press to get more information about a highlighted feature or setting. After selecting a welding process, press to enter READY.SET.WELD®.
- READY.SET.WELD® is a guided setup feature that provides a recommended output range based off a given material, material thickness, electrode type, and electrode diameter.
- 5. BACK** - Return to the previous screen.
- 6. MEMORY 1** - Recall saved Memory 1 process and settings or press and hold to store new memory.
- 7. MEMORY 2** - Recall saved Memory 2 process and settings or press and hold to store new memory.
- 8. MEMORY 3** - Recall saved Memory 3 process and settings or press and hold to store new memory.
- 9. MEMORY 4** - Recall saved Memory 4 process and settings or press and hold to store new memory.
- 10. USB PORT** - Conduct machine updates by inserting a USB drive.

HOME SCREEN AND WELD MODE SELECTION

Use the knob to navigate between the following weld processes; press the knob to select desired welding mode as shown in Figure B.3.

The machine comes with the available welding modes:


1. Stick (SMAW)
2. Flux-Cored Self-Shielded Wire (FCAW-S)
3. Flux-Cored Gas-Shielded Wire (FCAW-G)
4. MIG (GMAW)
5. Gouging (CAC-A)
6. TIG (GTAW)
7. Pipe (SMAW)**

**Only available on Frontier 400X Pipe model

Selecting a weld mode determines the output characteristics of the Frontier® 400X power source. The proper weld mode should be used based off desired application. Many variables beyond the control of The Lincoln Electric Company affect the results obtained in applying these programs. These variables include, but are not limited to, welding procedure, plate chemistry and temperature, weldment design, fabrication methods and service requirements.

See the WELDER OPERATION section for more details on each weld mode.

FIGURE B.3



WELD MODE SCREEN

After selecting the weld process, use the center knob to adjust the welding output (See Figure B.4).

In constant current modes, the knob adjusts the welding amperage; while in constant voltage modes, the knob adjusts the welding voltage.

On the left hand side of the screen, the operator can see status indicators of the machine. From top to bottom:

1. ENGINE TEMPERATURE - Displays the engine coolant temperature.
2. OIL PRESSURE - Displays the engine oil pressure when the engine is running.
3. BATTERY VOLTAGE - Displays the battery voltage and indicates that the charging system is functioning properly.
4. FUEL LEVEL - Displays the level of diesel fuel in the fuel tank.

If the machine status moves outside of the recommended operating ranges, the icons will change color:

Black - Normal operation

Yellow - Warning


Red - Critical

A warning message will appear. The operator will need to click to acknowledge it.

Next to the engine indicators are weld setting and operation indicators. From top to bottom:

5. OUTPUT STATUS - Identifies if the welding studs are ON or OFF.
6. WELDING MODE - Indicates the current welding mode of the machine.
7. STANDBY TIMER - When Auto Stop/Start is enabled, a countdown timer will appear on the top of the screen (Timer display not shown in Figure B.4).
8. WELD MODE SETTING - Specifies the weld mode setting such as Arc Force and Hot Start. Press the knob to access the mode settings. See the WELD MODE SETTINGS section for more details.
9. CROSSLINC INDICATOR - Shows the machine is actively communicating with a CrossLinc accessory.
10. REMOTE STATUS - Indicates if a remote output control is ON or OFF.
11. VRD INDICATOR - When VRD is active, a red indicator will appear on the UI if the OCV (Open Circuit Voltage) is equal to or greater than 30V and a green light will appear if the OCV is less than 30V. **NOTE:** These indicators do not appear during welding, See page A-2 to change the ON/OFF position of the VRD switches.
12. WORK POINT - Indicates the output where the machine has been set.

FIGURE B.4



ACTIVE WELD SCREEN

After striking an welding arc, the screen will change to the ACTIVE WELD SCREEN to show the real time amperage and voltage. Once the arc been terminated, the screen will flash the amperage and voltage for approximately 5 seconds, and the UI will automatically return to the weld mode screen. This allows the operator to read the actual current and voltage just prior to when welding was ceased.

The accuracy of the meters is +/- 3%.

When CrossLinc® wire feeder with True Voltage Technology (TVT) is connected, the screen will display the actual machine output. This will vary from the preset voltage on the wire feeder because TVT compensates for the voltage drop in the welding loop.

FIGURE B.5




WELD MODE SETTINGS

Within an active welding process, press the knob to view additional arc options.

Each mode offers several welding options to fine tune the arc welding performance. The options available will depend on the weld mode selected. Welding settings are remembered between each weld mode.


FIGURE B.6



Push knob to access the Weld Settings screen

- Remote Control Range - Allows the user to refine the output range that can be controlled remotely.


FIGURE B.7



WELD MODE SETTINGS CONT

- Hot Start - Provides a temporary increase of the output current during the start of a weld. This helps ignite the arc quickly and reliably, preventing the electrode from sticking. The setting can be adjusted from 0 (Off) to +10. The higher the value the greater the output current during arc strike.

FIGURE B.8



- Arc Force - Used to prevent the electrode from sticking during welding. It provides a temporary increase in current when the arc length becomes very short. Increasing the value from -10 (Soft) to +10 (Crisp) increases the short circuit current and prevents sticking of the electrode to the plate while welding, while decreasing the value reduces the amount of spatter.

FIGURE B.9




- Pinch - Changes the rate of current rise will change when the electrode short circuits to the work. Increasing the pinch from -10 to +10 may reduce spatter, while decreasing the pinch will make the puddle more fluid, resulting in a flatter and smoother weld bead.

WELD MODE SETTINGS CONT

- Weld Terminal - Allows the operator to select if the welding terminals are always electrically hot or turned on or off via a remote trigger.
- Memory Mode - Allows the operator save a memory based off the current weld mode and welding settings or recall a previously saved memory.

FIGURE B.10



- Frequency - Adjusting the frequency from “OFF” to a value between 0.1-20 Hz will turn on pulse TIG. The frequency changes the number of pulses per second. Pulse TIG can help to minimize burn through on thin materials by reducing the heat input.
- Percent Peak Current - If pulse frequency is ON, this setting changes percentage of time spent at the peak current vs the background current. The operator can set the value from 5% up to 95%, which affects the amount of heat input into the weld. The default setting is 50%.
- Remote Accessory Type - Allows the operator to change between a Foot Pedal or Hand Control.
- Start Type - Choose between Touch Start and Scratch Start. Touch Start is a cleaner process needing only a light, quick touch of the tungsten to the work piece. Scratch start requires dragging the tungsten across the work much like striking a match. Scratch start can be easier to use but could potentially contaminate the weld and the tungsten.

NOTE: Touch Start mode avoids tungsten contamination without the use of a high frequency unit. During the time the tungsten is touching the work, there is very little voltage or current and, in general, this avoids tungsten contamination. Then, the tungsten is gently lifted off the work in a rocking motion, which establishes the arc. To stop the arc, simply lift the TIG torch away from the work piece. When the arc voltage reaches approximately 30 volts, the arc will go out and the machine will automatically reset to the touch start current level. The tungsten may then be retouched to the work piece to restrike the arc. The arc may also be started and stopped with an amptrol or arc start switch.


While using TOUCH START TIG mode, it is important to use the proper welding cable size to ensure expected performance levels.

ENGINE STATUS SCREEN

The Engine Status Screen provides information about the engine servicing and operation. In the MAIN MENU, use the knob to scroll and press to select the ENGINE SCREEN (See Figure B.11).

If a yellow indicator is present, the machine has an active alert.

FIGURE B.11




ENGINE STATUS SCREEN CONT

Within the screen, six engine parts are monitored for service:

- Oil
- Air Filter
- Water Separator
- Fuel Filter
- Engine Coolant
- Alternator Belt

FIGURE B.12




The status bars are based off the recommended service intervals and indicate the remaining time before service is required. A warning indicator will appear if a service item is nearing the end of its service life. The default warning threshold is 10%. The threshold can be configured in the SETTINGS menu.

- Green = Normal operation
- Yellow = Service is required soon
- Red = Service is overdue


To view detailed information about each item, highlight and select the item from the list to display the number of hours remaining before service is required.

FIGURE B.13




After service has been performed on an item, select it from the list and press and hold the knob for 5 seconds to reset the service indicator.

FIGURE B.14




Also within the ENGINE STATUS SCREEN, the engine hours and RPMs can be found near the upper left-hand corner.

FIGURE B.15



If the HELP (?) button is pressed in this screen, a list of service parts will appear for the engine. The screen can be cleared by pressing the knob.

FIGURE B.16



SETTINGS SCREEN

The SETTINGS menu allows the operator to customize the machine to their preferences (See Figure B.17).

FIGURE B.17





FIGURE B.18



Inside the screen, the additional machine options listed below:


- Display Units - Choose between Imperial and Metric units
 - Language - Choose between English, Spanish, or French
 - Factory Reset - Restore Factory Default Settings
 - Manage Restrictions - Set up or disable Supervisor and Operator PIN numbers (See MANAGING RESTRICTIONS section below)
 - Weld Mode Customization – Enable or disable weld modes depending on preferences
 - Engine Service Alerts - Change the percentage of item life remaining before an alert will be displayed
 - Clock - Set/Display the local time
 - Auto-Stop/Start - Enable or Disable the Auto-Stop/Start Function (See AUTO STOP/START section below)
- Note:** If Auto Stop/Start is Enabled, options will appear to set the No Load and Standby Periods
- Display Brightness - Adjust the brightness of the display from 5-100%
 - Diagnostics Information – Find information about the machine Serial Number, Code Number, K Number, Engine Serial Number, and Machine Hours.
 - Software Version – Check the software version of the User Interface and the Chopper Control Boards

MANAGING RESTRICTIONS

Do not forget the PIN (personal identification number)! The PIN may only be reset by a Lincoln authorized service shop.


The MANAGING RESTRICTIONS section of the settings menu may be used to restrict unauthorized access to the machine or operator access to the engine and settings menus. To enable restrictions, first set a Supervisor PIN and then set an Operator PIN. Use the knob to select each digit and press to accept it. To go back to the previous digits use the back button.

SUPERVISOR SECURITY - When the Supervisor PIN is enabled, the ENGINE and SETTING SCREENS may be restricted.



OPERATOR SECURITY - When the Operator PIN is enabled, the user interface will be locked and the engine will not start until the proper PIN has been entered. A time delay may be entered that will allow the user interface to remain unlocked and the machine to be restarted throughout the day without needing to reenter the PIN.

FIGURE B.19




AUTO-STOP/START

Auto-Stop/Start is a feature that can help save significant fuel costs for users that do not weld continuously. When Auto-Stop/Start is enabled, the machine will automatically shut off the engine after a period of inactivity and remotely restart the engine when needed. To enable and use Auto-Stop/Start:

1. Enable Auto-Stop/Start in the Settings Menu.
2. Set the “No Load Period” (The period of time the engine will remain running without a load).
 - a. Choose from 5 to 120 minutes in the Settings Menu
3. Set the “Standby Period” (The period of time the machine will allow a remote engine start before fully shutting down).
 - a. Choose from 10 to 120 minutes in the Settings Menu
4. A countdown timer appears on the top of the user interface to indicate the remaining time until shutdown.

FIGURE B.20



To restart the engine remotely, tap the stick electrode to the work piece:

Stick Electrode

1. Tap and hold a stick electrode to the work piece for 0.1 to 1 second. Ensure that the electrode makes good electrical contact to the plate.
2. Pull electrode away from work piece and allow the engine to come up to speed


Note: Auto-Stop/Start will not work and will automatically be disabled if either the electrode is shorted to work when the engine shuts off or if welding electrode-negative polarity and the machine and the work piece share a common earth ground.

Additionally, the engine coolant temperature must be above 140° F (60°C) for before the engine will shutdown if Auto-Stop/Start is enabled.

MEMORY MODE OPERATION

The machine features 4 global memories slots, which can be used to save and recall settings. The operator can use the MEMORY MODE under the WELD MODE settings or the four buttons labelled 1 – 4 along the bottom of the user interface (See Figure B.21)

FIGURE B.21



To save a memory, hold the desired memory button until the screen indicates that the memory has been saved.

To recall a memory, press and release the desired memory button.

When a memory is selected, the corresponding memory LED will be lit. If any settings are changed, the LED will go out. The settings will revert to the saved values if the memory button is pressed again.

Memory usage with remote – If a memory is saved with a remote control connected, the remote control must be connected for the memory to function.

PRODUCTIVITY METRICS

FIGURE B.22



The Productivity Metrics screen provides information and statistics on how the machine is being utilized. Five statistics are monitored:

- Arc Hours - Time spent using the machine for welding.
- Auxiliary Hours - Time spent using the auxiliary power on the machine.
- Utilization Percentage - Represents how efficiently the machine is being used. It shows the percentage of time the machine is being loaded with respect to the total hours on the machine.
- Standby Hours - The number of hours the machine is in Standby Mode.
- Fuel Saved w/ Auto-Start - The number of US gallons of fuel saved from utilizing the Auto-Stop/Start feature.

FIGURE B.23

Productivity Metrics		
77 °F	Arc Hours	578 Hours
18 PSI	Auxiliary Hours	234 Hours
13.9 V	Utilization Rate	64 %
	Standby Hours	126 Hours
	Fuel Savings	84 Gallons

Push & hold to reset

In order to reset any of these metrics, rotate the knob until the desired item is highlighted in red. Then, press and hold the knob on the selected parameter for 5 seconds.

WELDER OPERATION

TABLE B.2

CROSSLINC® TECHNOLOGY

This machine has been equipped with CrossLinc® Technology to provide voltage and amperage control at the arc without the need for additional cables. CrossLinc technology allows for remote control of the welding output using the weld cables rather than a separate cable when connected to a CrossLinc compatible wire feeder or remote control.

To start CrossLinc, simply connect a CrossLinc enabled accessory to the machine using the standard weld power cable and the attached the sense lead from the accessory to work piece. When weld output is ON, the CrossLinc accessory will automatically link to the machine, and a CrossLinc indicator light will appear on both the accessory and machine to show active communication. No additional pairing of the machine to the device is needed.

When CrossLinc is active, the remote control is disabled and the CrossLinc device will set values remotely.

For Touch Start TIG applications, the machine should be placed on HIGH idle to ensure the most robust CrossLinc connection.

CrossLinc technology uses a communication protocol coupled in the electrode and work cables. For best performance the total voltage drop in the welding loop should be kept under 10V. CrossLinc is not compatible with High Frequency TIG. If high frequency is in the area, the cables need to be routed as far as possible from each other. Also, follow all high frequency best practices, including a driven earth ground.

DUTY CYCLE

Duty cycle is the percentage of time the load is being applied in a 10 minute period. For example, a 60% duty cycle represents 6 minutes of load and 4 minutes of no load in a 10 minute period.

NOTE: The duty cycles for the IEC rated output and max output are listed on the rating plate of the machine.

PARALLELING

When paralleling machines in order to combine their outputs, all units must be operated in a constant current (CC) mode at the same output settings. To achieve this, select the STICK weld mode. Operation in other modes may produce erratic outputs, and large output imbalances between the units.

ARC GOUGING MODE

For optimal performance when arc gouging, select to the GOUGING weld mode and use the knob to adjust output current to the desired level for the gouging electrode being used according to the ratings in Table B.2 above.

For optimal performance when arc gouging, it is recommended to set the machine to HIGH IDLE.

NOTE: If desired the CV-WIRE mode can be used for arc gouging applications.

ELECTRODE DIAMETER	CURRENT RANGE DCEP (+)
1/8" (3.2 mm)	30-60 Amps
5/32" (4.0 mm)	90-150 Amps
3/16" (4.8 mm)	200-250 Amps
1/4" (6.4 mm)	300-400 Amps
5/16" (7.9 mm)	350-450 Amps

Maximum current setting is limited to 400 amps.

STICK (SMAW)

The Frontier® 400X can be used with a broad range of DC stick electrodes.

The Stick (SMAW) weld mode is designed for horizontal, vertical-up and over head welding with all types of stick electrodes, especially low hydrogen. Once the mode is selected, the output can be adjust by using the knob located on the user interface.

ARC FORCE sets the short circuit current during stick welding. Increasing the number from -10 (Soft) to +10 (Crisp) increases the short circuit current and prevents sticking of the electrode to the plate while welding. This can also increase splatter. It is recommended that the ARC FORCE be set to the minimum number without electrode sticking. Start with the knob set at 0.

TIG (GTAW)

The Frontier® 400X can be used in a wide variety of DC TIG welding applications.

Once TIG (GTAW) mode is selected, the operator has the option to select TOUCH START TIG or SCRATCH START from within the weld settings.

If TOUCH START TIG is selected, to initiate a weld, set the output to the desired current and the tungsten is touched to the work. During the time the tungsten is touching the work, there is very little voltage or current and, in general, this avoids tungsten contamination. Then, the tungsten is gently lifted off the work in a rocking motion, which establishes the arc.

To stop the arc, simply lift the TIG torch away from the work piece. When the arc voltage reaches approximately 30 volts, the arc will go out and the machine will automatically reset to the touch start current level. The tungsten may then be retouched to the work piece to restrike the arc. The arc may also be started and stopped with an amptrol or arc start switch.

NOTE: While using TOUCH START TIG mode, it is important to use the proper welding cable size to ensure expected performance levels.

If SCRATCH START is selected, the operator can scratch the tungsten against the work to initiate the arc.

Further, the operator can activate pulsed TIG by adjusting the frequency from "OFF" to a value between 0.1-20 Hz will turn on pulse TIG. The frequency changes the number of pulses per second. Pulse TIG can help to minimize burn through on thin materials by reducing the heat input.

If FREQUENCY is ON, the PERCENT PEAK CURRENT setting appears and allows the operator to change percentage of time spent at the peak current vs the background current. The operator can set the value from 5% up to 95%, which affects the amount of heat input into the weld. The default setting is 50%.

FLUX-CORED SELF-SHIELDED WIRE (FCAW-S), SELF-SHIELD GAS-SHIELDED WIRE (FCAW-G), AND MIG (GMAW) MODES

Connect a wire feeder to the Frontier® 400X and set welder controls according to the instructions listed earlier in this section. The Frontier® 400X permits it to be used with a broad range of flux cored wire (Innershield® and Outershield®) electrodes and solid wires for GMAW (MIG) welding. The machine features welding modes precisely tuned for each welding process. Once the welding mode has been selected, the welding can be fine adjusted using the PINCH setting. Turning the PINCH setting clockwise from -10 (soft) to +10 (crisp) changes the arc from soft and washed-in to crisp and narrow. It acts as an inductance control. The proper setting depends on the procedure and operator preference. Start with the knob set at 0.

PIPE (SMAW) MODE

****Only available on the Frontier 400X Pipe model****

The Pipe (SMAW) weld mode is designed specifically for downhill pipe welding applications to provide superior welding performance for cellulosic and low-hydrogen stick electrodes. Operators can utilize DigFX™ arc tuning controls to adjust for variabilities in the pipe and personal welding techniques.

Once the mode is selected, the output can be adjust by using the knob located on the user interface. DigFX™ is used to adjust response time of the machine to provide optimal arc and puddle characteristics. This setting provides the user with the ability to fine-tune the machine to fit the electrode, material, joint fit-up, and user technique. By changing the value towards -10 (Soft), the machine will create a softer welding arc with a more fluid puddle and less spatter, which is excellent for fill and cap passes as well as wide gaps. Meanwhile, by changing the value towards +10 (Stiff), the user will experience a stiffer welding arc with more drive and a narrow, fast-freezing puddle, which is excellent for root passes, especially with a tight or closed gap. The factory default setting is 0.

For best welding performance, the mode should be utilized with a 250 ft. (76.2 m) welding loop - 200 ft. (61.0 m) weld cable, 25 ft. (7.6 m) electrode holder, and 25 ft. (7.6 m) ground cable.

AUXILIARY POWER OPERATION

Start the engine and set the RUN / STOP / IDLE switch to the desired operating mode. Full power is available regardless of the welding control settings, if no welding current is being drawn.

The auxiliary power of the Frontier® 400X consists of two 20 amp 120 VAC (5-20R) duplex receptacles with GFCI protection, one 50 amp 120/240 VAC single phase (14-50R) receptacle and one 50 amp 240 VAC three phase (15-50R) receptacle.

The auxiliary power capacity is 10,000 watts of 60 Hz, single phase power or 11,000 watts of 60 Hz, three phase power. The auxiliary power capacity rating in watts is equivalent to volt-amperes at unity power factor. The maximum permissible current of the 240 VAC output is 50 A. The 240 VAC single phase output can be split to provide two separate 120 VAC outputs with a maximum permissible current of 50 A per output to two separate 120 VAC branch circuits. Output voltage is within $\pm 10\%$ at all loads up to rated capacity.

NOTE: The two 120V GFCI receptacles and the two 120V circuits of the 120/240V receptacle are connected to different phases and cannot be paralleled.

The auxiliary power receptacles should only be used with three wire grounded type plugs or approved double insulated tools with two wire plugs.

The current rating of any plug used with the system must be at least equal to the current capacity of the associated receptacle.

SIMULTANEOUS WELDING AND AUXILIARY POWER LOADS

The auxiliary power capacity previously stated is maintained without any welding load. If a welding load is present, the available auxiliary power will decrease.

Simultaneous welding and power loads are specified in Table B.3. The permissible currents shown assume that current is being drawn from either the 120 VAC or 240 VAC supply (not both at the same time).

TABLE B.3

FRONTIER® 400X Simultaneous Welding and Power Loads							
Weld Amps	1 PHASE		3 PHASE		BOTH 1 & 3 PHASE		
	WATTS	AMPS	WATTS	AMPS	WATTS	AMPS	
0	10,000	42	11,000	27	10,000	-	
100	8300	35	8500	20	8300	-	
200	5300	22	5700	14	5300	-	
250	3500	15	3500	8	3500	-	
300	400	2	800	2	400	-	
400	0	0	0	0	0	0	

TABLE B.4 FRONTIER® 400X EXTENSION CORD LENGTH RECOMMENDATIONS

Current (Amps)	Voltage (Volts)	Load (Watts)	Maximum Allowable Cord Length in ft. (m) for Conductor Size											
			14 AWG		12 AWG		10 AWG		8 AWG		6 AWG		4 AWG	
15	120	1800	30	(9)	40	(12)	75	(23)	125	(38)	175	(53)	300	(91)
15	240	3600	60	(18)	75	(23)	150	(46)	225	(69)	350	(107)	600	(183)
20	120	2400			30	(9)	50	(15)	88	(27)	138	(42)	225	(69)
20	240	4800			60	(18)	100	(30)	175	(53)	275	(84)	450	(137)
25	240	6000					90	(27)	150	(46)	225	(69)	250	(76)
30	240	7200					75	(23)	120	(37)	175	(53)	300	(91)
38	240	9000							100	(30)	150	(46)	250	(76)
50	240	12000									125	(38)	200	(61)

Conductor size is based on maximum 2.0% voltage drop.

ACCESSORIES

CROSSLINC ACCESSORIES

LN-25X

True Voltage Technology (TVT) is now included with the LN-25X portable wire feeder. When used with a CrossLinc compatible power source, control cables are eliminated and voltage can be controlled right at the feeder. TVT compensates for voltage drop when using long welding power cables.

Order: K4267-2

Activ8X

Rugged, light-weight, portable across-the-arc wire feeder that fits up to an 8" dia. spool. Includes CrossLinc and TVT capability to remotely set voltage from the feeder without a control cable and to ensure the set voltage regardless of power cable lengths.

Order: K3519-1

Activ8X Pipe

Ideal pipeline solution for GMAW and FCAW welding applications in a rugged and compact design. Features root-to-cap weld processes – including STT® and Pulsed MIG – specifically optimized for cross country pipe welding.

Order: K4717-1

CrossLinc Remote

Utilized with CrossLinc compatible equipment to control output for CC-processes like stick or TIG welding. Remote control is added in-line with the welding power cable to allow for remote output control of the power source through the weld cable without additional control cables.

Order: K4345-1

GENERAL ACCESSORIES

Compact Medium Welder Trailer

Two-wheeled trailer with a standard 2" ball hitch for heavy-duty road, off-road, plant, and yard use. For highway use, consult applicable federal, state, and local laws regarding possible additional requirements. Optional fender and light package available.

Order: K5270-1 Compact Medium Trailer

K5276-1 Fender Kit

K2640-2 Cable Rack

K5278-1 Spare Tire Kit

K5279-1 Fire Extinguisher Bracket / Document Holder

Four-Wheeled Steerable Trailer

Four-wheeled trailer with a standard Duo-Hitch™ (2" Ball and Lunette Eye combination hitch) for plant and yard towing. Includes 13" wheels and an automatically engaging drawbar lock.

Order: K2641-2

Full KVA Power Plug Kit

Provides four 115V plugs rated at 20 amps each, and one dual voltage, full KVA plug rated at 115/230V, 50 amps.

Order: K802N

Full KVA Adaptor

Provides convenient connection through the full-KVA receptacle on engine-driven welders for portable power sources needing 240V AC 1-phase power (NEMA 6-50P).

Order: K1816-1

APEX® System Connector

A field install kit to add 5-pin and 4-pin to the front panel of the machine. Allows for capability with APEX systems for mechanized welding solutions.

Order: K5171-1

User Interface Protective Cover

Installed over the UI to provide extra protection against accidental impacts while on the jobsite or transporting the machine.

Order: K5226-1

Storage Cover

A flame retardant, mildew resistant, and water repellent cover to protect the engine drive when not in use.

Order: K5292-1

SERVICE KITS

Engine Service Kits

One easy-to-purchase kit including all the needed engine filters to maintain peak welder performance. Includes air filter, fuel filter, oil filter, and fuel water separator.

Order: K3598-4 Perkins 403F-15T
K3599-5 Kubota D1503-M

REMOTE CONTROLS

Remote Output Control

Portable control provides same dial range as the output control on the welder. The remote features a convenient 12-pin plug for easy connection to the welder.

Order: K857-2 25 ft (7.6 m)
K857-3 100 ft (30.4 m)

Remote Output Control w/ 120V Receptacles

Portable control features a convenient 12-pin plug for easy connection to the welder. Includes a detachable control box that can be stowed in a truck or job box to deter job site theft. The control box has a 120V duplex receptacle to power lights, grinders, and other tools right at the arc.

Order: K5312-1 125 ft (38.1 m)

12-pin to 6-pin Adaptor

Used to connect 6-pin remotes into the 12-pin connector on the front of the welder.

Order: K2909-1

Wireless Remote Control

A field installed kit to allow operators to add a wireless remote to the machine to switch between welding processes, adjust welding parameters, recall saved memories, and start/stop the machine from a distance.

Order: K5265-1

TIG ACCESSORIES

Pro-Torch PTA-26 TIG Torch

Air-cooled 200 amp torch (2 piece) equipped with valve for gas low control with 25 ft. (7.6 m) of cable length. Expendables parts kit available.

Order: K1783-9 PTA-26 TIG Torch
KP509 Magnum Parts Kit for PTA-26 TIG Torch

Foot Amptrol

Remote output control foot pedal for TIG welding with a 25 ft. (7.6 m) cable featuring a 12-pin connector.

Order: K870-2

Hand Amptrol

Remote output control hand control for TIG welding with a 25 ft. (7.6 m) cable featuring a 12-pin connector. Includes hook and loop straps to secure torch. (One size fits all Pro-Torch TIG Torches.)

Order: K963-4

Arc Start Switch

ON/OFF switch used for TIG welding when an Amptrol® is not used. Attaches to the TIG torch for convenient finger control - 25 ft. (7.6 m) of cable length.

Order: K814-2

WIRE FEEDERS & GUNS

K126 Pro Innershield® Gun

Feature replaceable liners, interchangeable backend, long life Magnum® PRO contact tips, improved heat resistant gun tubes, and better trigger lead protection. For self-shielded .062-5/64 in. (1.6-2.0 mm) wire with 15 ft. (4.5 m) cable. Includes K466-10 Connector Kit.

Order: K126-12

CABLE ACCESSORIES

Tweco® Adaptors

Allows for quick cable changeovers on the jobsite.

Order: K2487-1 Stud to Tweco Female Adapter – LENCO (CT-40FS)

K2946-1 Tweco Style Cam-Lock Adapter Plug for 2/0 (50 mm²) cable

K3416-70 Tweco Style Plug (Male, 1/0 thru 2/0)

K3416-90 Tweco Style Plug (Male, 3/0 thru 4/0)

K3417-70 Tweco Style Receptacle (Female, 1/0 thru 2/0)

K3417-90 Tweco Style Receptacle (Female, 3/0 thru 4/0)

POWER SOURCES

Square Wave TIG 200

Portable TIG and stick welding machine that provides smooth and stable AC TIG welding on aluminum and DC TIG welding on steel, stainless steel and chrome-moly.

Order: K5126-1

PowerMIG 210MP

Multi-process welder with MIG, stick, TIG, and flux-cored welding. The push-and-turn digital controls and color display screen make setup and operation intuitive and easy, while the all-metal wire drive and sturdy sheet-metal construction make it rugged and ready for any job. Runs off auxiliary power to provide an additional welding arc.

Order: K3963-1

Tomahawk 1000 Plasma Cutter

Cuts metal using the AC generator power from the engine-driven welder. Requires the T12153-10 Full-KVA Power Plug (NEMA 15-50P).

Order: K2808-1

Invertec V276

Proven, portable CC power source for Stick or TIG welding featuring digital weld meters. Runs off the auxiliary power to provide an additional welding arc.

Order: K4868-1

MAINTENANCE

SAFETY PRECAUTIONS

READ AND UNDERSTAND ENTIRE SECTION BEFORE OPERATING MACHINE.

WARNING

- Have a qualified technician do the maintenance and troubleshooting work.
- Turn the engine off before working inside the machine.
- Remove guards only when necessary and replace them when the maintenance requiring their removal is complete.
- Always use the greatest care when working near moving parts.

Read the Safety Precautions in front of this manual and the engine instruction manual before working on this machine.

Keep all equipment safety guards, covers and devices in position and in good repair. Keep hands, hair, clothing and tools away from V-belts, gears, fans and all other moving parts when starting, operating or repairing the equipment.

WARNING

HOT PARTS AND FLUID can burn or cause fire.

- Do not touch hot parts with bare hands or allow hot fluid to contact skin.
- Allow equipment to completely cool before servicing.
- Handle hot parts using proper tools and wear heavy insulated welding gloves and clothing to prevent burns.
- Do not place unit on, over, or near combustible surfaces.
- Keep all flammable material away from unit



WARNING

Before carrying out service, maintenance and/or repair jobs, fully disconnect power to the machine.



Use Personal Protective Equipment (PPE), including safety glasses, dust mask and gloves to avoid injury. This also applies to persons who enter the work area.



MOVING PARTS can injure.

- Do not operate with doors open or guards off.
- Stop engine before servicing.
- Keep away from moving parts.



Have qualified personnel do all maintenance and troubleshooting work.



ROUTINE AND PERIODIC MAINTENANCE

DAILY

- Check the engine oil level.
- Refill the fuel tank to minimize moisture condensation in the tank.
- Open the water drain valve located on the bottom of the water separator element 1 or 2 turns and allow to drain into a container suitable for diesel fuel for 2 to 3 seconds. Repeat the above drainage procedure until diesel fuel is detected in the container.
- Clean interior of machine with a low pressure air stream. Make a thorough inspection of all components.
- Look for signs of overheating, broken leads, or other obvious problems. Many problems can be uncovered with a good visual inspection.

PERIODIC

Blow out the machine with low pressure air periodically. In particularly dirty locations, this may be required once a week.

BRUSH REMOVAL AND REPLACEMENT

It is normal for the brushes and slip rings to wear and darken slightly. Inspect the brushes when a generator overhaul is necessary.

WARNING

Do not attempt to polish slip rings while the engine is running.

ENGINE MAINTENANCE

Refer to the SERVICE PLAN section of the Engine Operator's Manual for the recommended maintenance schedule of the following:

- a) Engine Oil and Filter
- b) Air Cleaner
- c) Fuel Filter and Delivery System
- d) Alternator Belt
- e) Battery
- f) Cooling System

Refer to Table D.1 at the end of this section for various engine maintenance components.

AIR FILTER



WARNING

- **Excessive air filter restriction will result in reduced engine life.**
- **Never use gasoline or low flash point solvents for cleaning the air cleaner element. A fire or explosion could result.**
- **Never run the engine without the air cleaner. Rapid engine wear will result from contaminants, such as dust and dirt being drawn into the engine.**

The diesel engine is equipped with a dry type air filter. Never apply oil to it. Service the air cleaner per instructions on page D-3.

Replace the air filter element as needed per the service indicator. If no indicator is present, clean as needed and replace every 500 hours of operation. Under dusty conditions, replace sooner.

Service Instructions


Single- and Two-Stage Engine Air Cleaners

1 Remove the Filter



Rotate the filter while pulling straight out.


Unfasten or unlatch the service cover. Because the filter fits tightly over the outlet tube to create the critical seal, there will be some initial resistance, similar to breaking the seal on a jar. Gently move the end of the filter back and forth to break the seal then rotate while pulling straight out. Avoid knocking the filter against the housing.



If your air cleaner has a safety filter, replace it every third primary filter change. Remove the safety filter as you would the primary filter. Make sure you cover the air cleaner outlet tube to avoid any unfiltered contaminant dropping into the engine.


2 Clean Both Surfaces of the Outlet Tube and Check the Vacuator™ Valve

Use a clean cloth to wipe the filter sealing surface and the inside of the outlet tube. Contaminant on the sealing surface could hinder an effective seal and cause leakage. Make sure that all contaminant is removed before the new filter is inserted. Dirt accidentally transferred to the inside of the outlet tube will reach the engine and cause wear. Engine manufacturers say that it takes only a few grams of dirt to "dust" an engine! Be careful not to damage the sealing area on the tube.



Outer edge of the outlet tube

Wipe both sides of the outlet tube clean.



Inner edge of the outlet tube


If your air cleaner is equipped with a Vacuator Valve

Visually check and physically squeeze to make sure the valve is flexible and not inverted, damaged or plugged.



3 Inspect the Old Filter for Leak Clues

Visually inspect the old filter for any signs of leaks. A streak of dust on the clean side of the filter is a telltale sign. Remove any cause of leaks before installing new filter.



4 Inspect the New Filter for Damage


Inspect the new filter carefully, paying attention to the inside of the open end, which is the sealing area. NEVER install a damaged filter. A new Donaldson radial seal filter may have a dry lubricant on the seal to aid installation.



5 Insert the New Radial Seal Filter Properly

If you're servicing the safety filter, this should be seated into position before installing the primary filter.

Insert the new filter carefully. Seat the filter by hand, making certain it is completely into the air cleaner housing before securing the cover in place.



The critical sealing area will stretch slightly, adjust itself and distribute the sealing pressure evenly. To complete a tight seal, apply pressure by hand at the outer rim of the filter, not the flexible center. (Avoid pushing on the center of the urethane end cap.) No cover pressure is required to hold the seal. NEVER use the service cover to push the filter into place! Using the cover to push the filter in could cause damage to the housing, cover fasteners and will void the warranty.

If the service cover hits the filter before it is fully in place, remove the cover and push the filter (by hand) further into the air cleaner and try again. The cover should go on with no extra force.

Once the filter is in place, secure the service cover.



Caution

NEVER use the service cover to push the filter into place! Using the cover to push the filter in could cause damage to the housing, cover fasteners and will void the warranty.



6 Check Connectors for Tight Fit

Make sure that all mounting bands, clamps, bolts, and connections in the entire air cleaner system are tight. Check for holes in piping and repair if needed. Any leaks in your intake piping will send dust directly to the engine!

FUEL FILTERS**⚠ WARNING****When working on the fuel system**

- **Keep naked lights away, do not smoke!**
- **Do not spill fuel!**



The Frontier® 400X is equipped with a fuel pre-filter / water separator before the electric lift pump and a fuel filter after the lift pump and before the injectors. Open the drain on the fuel pre-filter / water separator and drain out any water daily. Close drain when diesel fuel starts to come out. If excessive water is in the fuel, the engine will not start. The procedure for changing the filter is as follows.

1. Close the fuel shutoff valve.
2. Clean the area around the fuel filter head. Remove the filter. Clean the gasket surface of the filter head and replace the o-ring.
3. Fill the clean filter with clean fuel, and lubricate the o-ring seal with clean lubricating oil.
4. Install the filter as specified by the filter manufacturer.

⚠ WARNING

Mechanical over tightened will distort the threads, filter element seal or filter can.

COOLING SYSTEM

The cooling system of the engine needs to be checked and cleaned periodically. (Consult the Engine Owner's Manual for the proper procedures and frequency).

Coolant needs to be added at the radiator filler neck after removing cap when system is cool. Fill to top of filler neck. Engine will not start if coolant level is too low.

The coolant system is equipped with an internal expansion tank located inside the top radiator tank. This allows for normal thermal expansion and contraction of the engine coolant.

CHECKING AND REPLACING COOLANT**⚠ WARNING**

HOT COOLANT can burn skin. Do not remove cap if radiator is hot.

Check the coolant level by observing the level in the radiator. Add 50/50 antifreeze / water solution if the level is low by removing the radiator cap and adding coolant into the radiator. Fill up to the tube in the radiator filler neck.

To drain the coolant, open the valve at the bottom of the radiator. Open the radiator cap to allow complete drainage. (Tighten the valve and refill with a 50/50 antifreeze/water solution.) Use an automotive grade (low silicate) ethylene glycol antifreeze. The cooling system capacity is 7.2 qts. (6.8L). Squeeze upper and lower radiator hoses while filling to bleed air from system coolant. Replace and tighten the radiator cap.

Periodically remove the dirt from the radiator fins.

Periodically check the fan belt and radiator hoses. Replace if signs of deterioration are found.

⚠ CAUTION

Always premix the antifreeze and clean tap water before adding to the radiator. It is very important that a precise 50/50 solution be used with this engine year round. This gives proper cooling during hot weather and freezing protection to -34° F (-37° C).

Cooling solution exceeding 50% ethylene glycol can result in engine overheating and damage to the engine. Coolant solution must be premixed before adding to radiator.

BATTERY HANDLING**⚠ WARNING****GASES FROM BATTERY can explode.**

- Keep sparks, flame and cigarettes away from battery.

**To prevent EXPLOSION when:**

- **INSTALLING A NEW BATTERY** - disconnect negative cable from old battery first and connect to new battery last.
- **CONNECTING A BATTERY CHARGER** - Remove battery from welder by disconnecting negative cable first, then positive cable and battery clamp. When reinstalling, connect negative cable last. Keep well ventilated.
- **USING A BOOSTER** - connect positive lead to battery first then connect negative lead to engine foot.

**BATTERY ACID CAN BURN EYES AND SKIN.**

- Wear gloves and eye protection and be careful when working near battery. Follow instructions printed on battery.

**PREVENTING ELECTRICAL DAMAGE**

1. When replacing, jumping, or otherwise connecting the battery to the battery cables, the proper polarity must be observed. Failure to observe the proper polarity could result in damage to the charging circuit. The positive (+) battery cable has a red terminal cover.
2. If the battery requires charging from an external charger, disconnect the negative battery cable first and then the positive battery cable before attaching the charger leads. Failure to do so can result in damage to the internal charger components. When reconnecting the cables, connect the positive cable first and the negative cable last.

PREVENTING BATTERY DISCHARGE - Turn the RUN/STOP switch to stop when engine is not running.

PREVENTING BATTERY BUCKLING - Tighten nuts on battery clamp until snug.

CHARGING THE BATTERY -When you charge, jump, replace, or otherwise connect battery cables to the battery, be sure the polarity is correct. Improper polarity can damage the charging circuit. The Frontier™ 400X positive (+) battery terminal has a red terminal cover.

If you need to charge the battery with an external charger, disconnect the negative cable first, then the positive cable before you attach the charger leads. After the battery is charged, reconnect the positive battery cable first and the negative cable last. Failure to do so can result in damage to the internal charger components.

Follow the instructions of the battery charger manufacturer for proper charger settings and charging time.

ENGINE OIL CHANGE

Drain the engine oil while the engine is warm to assure rapid and complete draining. It is recommended that each time the oil is changed the oil filter be changed as well.

- Be sure the unit is off. Disconnect the negative battery cable to ensure safety.
- Locate oil drain hose and valve in bottom of base and pull through the hole in the battery access panel on the welder.
- Remove the cap from the drain valve. Push valve in and twist counterclockwise. Pull to open and drain the oil into a suitable container for disposal.
- Close the drain valve by pushing in and twisting clockwise. Replace the cap.
- Re-fill the crankcase to the upper limit mark on the dipstick with the recommended oil. Replace and tighten the oil filler cap securely.
- Push oil drain hose and valve back into unit, re-connect negative battery cable, and close doors and engine top cover before restarting unit. Wash your hands with soap and water after handling used motor oil. Please dispose of used motor oil in a manner that is compatible with the environment. We suggest you take it in a sealed container to your local service station or recycling center for reclamation. DO NOT throw it in the trash, pour it on the ground, or down a drain.

SAE 10W-30 oil that meets API class CJ-4 or better is recommended for general, all temperature use, 5F to 104F (-15C to 40C).

See Engine Owner's Manual for more specific information on oil viscosity recommendations.

Oil Filter Change

- Drain the oil.
- Remove the oil filter with an oil filter wrench and drain the oil into a suitable container. Discard the used filter. Note: Care should be taken during filter removal to not disrupt or damage in any way the fuel lines.
- Clean the filter mounting base and coat the gasket of the new filter with clean engine oil.
- Screw the new filter on by hand until the gasket contacts the mounting base. Using an oil filter wrench, tighten the filter an additional 1/2 to 7/8 of a turn.
- Refill the crankcase with the specified amount of the recommended engine oil. Reinstall the oil filler cap and tighten securely.
- Start the engine and check for oil filter leaks.
- Stop the engine and check the oil level. If necessary, add oil to the upper limit mark on the dipstick.

TIGHTENING THE FAN BELT

If the fan belt is loose, the engine can overheat and the battery lose its charge. Check tightness by pressing on the belt midway between the pulleys. For tightness requirements, please refer to the Engine Owner's Manual.

NAMEPLATES / WARNING DECALS MAINTENANCE

Whenever routine maintenance is performed on this machine - or at least yearly - inspect all nameplates and labels for legibility. Replace those which are no longer clear. Refer to the parts list for the replacement item number.

ENGINE SERVICE			KUBOTA D1503-M 24.8 HP	
EVERY DAY OR EVERY 8 HOURS			www.kubotaengine.com	
FIRST SERVICE (50 HOURS)			MAINTENANCE ITEM	
EVERY 100 HOURS OR 3 MONTHS			TYPE OR QUANTITY	
EVERY 150 HOURS OR 4 MONTHS				
EVERY 300 HOURS OR 9 MONTHS				
EVERY 400 HOURS OR 12 MONTHS				
EVERY 500 HOURS OR 15 MONTHS				
EVERY 800 HOURS				
ENGINE SERVICE (NOTE 2)				
I			Coolant level	
		I	Concentration of antifreeze	50/50 Water/Ethylene Glycol
			Coolant (NOTES 3, 4, 5 & 6)	7.6 qt., 7.2 L
I			Engine oil level (NOTE 1)	
R	R		Engine oil (NOTE 1 & 3)	5.9 qt., 5.6 L (including filter)
R	R		Engine oil filter	*Kubota #HH164-32430
	C		Drain water separator & fuel strainer	
		R	Water separator element	*Donaldson #P502166 Lincoln #M20840-A
		R	Fuel filter canister	*Kubota #16631-43560
	I		Tension of alternator drive belt	
			Alternator drive belt wear	
		R	Alternator drive belt	Kubota #17480-97010
	C		Air filter (earlier check may be req'd)	
I		R	Air filter element	*Donaldson #P822686 Lincoln #M19801-1A
		I	Valve clearances	Intake .0071"-.0086", Exhaust .0071"-.0086"
		I	Electrical systems	
		I	All nuts and bolts for tightness	
I			Leaks or engine damage	
	I	I	Battery & Electrolyte Level	BCI Group 34
			*Engine Service Kit	K3599-5

I = Inspect C = Clean R = Replace *Items Included in Engine Service Kit

Notes:

- Consult Engine Operators Manual for oil recommendations.
- Consult Engine Operators Manual for additional maintenance schedule information.
- Fill slowly! Ensure correct quantity is used.
- Top off with distilled water if level gets low.
- Clean and flush cooling system every 500 hours.
- Replace coolant every 24 months.
- Engine Service Kit includes oil filter, air filter, fuel filter & water separator element.

Above operations to be carried out by trained personnel with reference to the workshop manual where necessary.

These preventative maintenance periods apply to average conditions of operation. If necessary use shorter periods.

WARRANTY WORK PERFORMED ON THE ENGINE CONTAINED IN THIS MACHINE, IF NOT BILLABLE TO THE ENGINE MANUFACTURER, SHOULD BE PRE-APPROVED BY CALLING THE LINCOLN ELECTRIC COMPANY AT 888-935-3877

S33102-1 VM

ENGINE SERVICE			Perkins 403F-15T 24.7 HP	
EVERY DAY OR EVERY 8 HOURS			www.perkins.com	
FIRST SERVICE (20 / 50 HOURS)			MAINTENANCE ITEM	
EVERY 100 HOURS OR 3 MONTHS			TYPE OR QUANTITY	
EVERY 200 HOURS OR 6 MONTHS				
EVERY 500 HOURS OR 12 MONTHS				
EVERY 1000 HOURS OR ANNUALLY				
ENGINE SERVICE (NOTE 2)				
I			Coolant level	
		R	Concentration of antifreeze	50/50 Water/Ethylene Glycol
			Coolant (NOTE 3)	7.6 qt., 7.2 L
I			Engine oil level (NOTE 1)	
R	R		Engine oil (NOTE 1 & 3)	6.5 qt., 6 L (including filter)
R	R		Engine oil filter	Perkins #140517050
	C		Drain water separator & fuel strainer	
		R	Water separator element	Donaldson #P502166 Lincoln #M20840-A
		R	Fuel filter canister	Perkins #4429491
	I		Tension of alternator drive belt	
			Alternator drive belt wear	
		R	Alternator drive belt	Perkins #T80109080
	C		Air filter (earlier check may be req'd)	
		R	Air filter element	Donaldson #P822686 Lincoln #M19801-1A
		R	Renew the engine breather	
		I	Tighten cylinder head	
		I	Valve clearances	Intake .008", exhaust .008"
		I	Electrical systems	
		I	All nuts and bolts for tightness	
		I	Injector performance	Contact Perkins
I			Leaks or engine damage	
		I	Battery	BCI Group 34
		C	Clean turbocharger impeller casting and the turbocharger compressor casting	
			Engine Service Kit	K3598-4

I = Inspect C = Clean R = Replace

Notes:

- Consult Engine Operators Manual for oil recommendations.
- Consult Engine Operators Manual for additional maintenance schedule information.
- Fill slowly! Ensure correct quantity is used.
- Engine Service Kit includes oil filter, air filter, fuel filter & water separator element.

Above operations to be carried out by trained personnel with reference to the workshop manual where necessary.

These preventative maintenance periods apply to average conditions of operation. If necessary use shorter periods.

WARRANTY WORK PERFORMED ON THE ENGINE CONTAINED IN THIS MACHINE, IF NOT BILLABLE TO THE ENGINE MANUFACTURER, SHOULD BE PRE-APPROVED BY CALLING THE LINCOLN ELECTRIC COMPANY AT 888-935-3877

S33102 VM

GFCI MODULE


WARNING

- An electric shock can result in serious injury or death.
- Always perform the GFCI test before using the generator. If the GFCI system fails the test, the machine must be repaired by an authorized service center.
- If the GFCI fails to trip when the test button is pressed ("ON" light does not go off or "STATUS light is RED) or fails to reset ("ON" light does not go on or "STATUS light is blinking) the device is inoperative and should be replaced immediately.
- If the GFCI tests properly without any appliance connected to it but trips each time an appliance is connected to it, the appliance has a ground fault and needs to be repaired or replaced. **DO NOT USE THE APPLIANCE IF THIS CONDITION OCCURS: A REAL SHOCK HAZARD MAY EXIST.**
- Due to the risk of power interruption, do not power life support equipment from this machine.
- GFCI's do not protect against short circuits or overloads.
- Unplug accessories and tools before attempting service.
- Close the front service doors protecting the receptacles when operating the machine.
- Do not test or reset the GFCI while at idle speed.
- If the LED blinks, stop using the GFCI receptacle and have it replaced by an authorized service center.
- Long extension cords or cords with poor insulation may allow enough leakage current to trip the GFCI.

The GFCI module protects the (2) 120 VAC duplex receptacles. Two different types of modules are used in the Rangers.

Machines manufactured approximately September 2021 or earlier

The GFCI is an auto reset GFCI. It is identified by the "ON" LED located below the buttons.




- Auto Reset: Immediately supplies power to the load when power is applied to the line.
- "ON" LED illuminates red when the load has power.

To test this GFCI, press the "TEST" button. The "ON" red LED should turn off. Then press the "RESET" button. The "ON" red LED should turn on. If the "ON" red LED does not turn off and on as indicated, the GFCI failed the test and should be replaced.

Machines manufactured approximately October 2021 or later

The GFCI is an auto reset, self-testing GFCI. It is identified by the "STATUS" LED located above the buttons.



- Auto Reset: Immediately supplies power to the load when power is applied to the line.
- "STATUS" LED illuminates Green when the GFCI is functioning properly.
- "STATUS" LED illuminates Red when the GFCI has "tripped". Press the reset button.
- "STATUS" LED illuminates flashing Red when the GFCI has failed and needs replaced.

While this GFCI has a self-testing feature, to manually test this GFCI, press the "TEST" button. The "STATUS" LED should turn red. Then press the "RESET" button. The "STATUS" LED should turn green. If the "STATUS" LED does not turn red and green as indicated, or flashes red, the GFCI failed the test and should be replaced."

TROUBLESHOOTING

HOW TO USE TROUBLESHOOTING GUIDE



WARNING

Service and Repair should only be performed by Lincoln Electric Factory Trained Personnel. Unauthorized repairs performed on this equipment may result in danger to the technician and machine operator and will invalidate your factory warranty. For your safety and to avoid Electrical Shock, please observe all safety notes and precautions detailed throughout this manual.

This Troubleshooting Guide is provided to help you locate and repair possible machine malfunctions. Simply follow the three-step procedure listed below.

Step 1. LOCATE PROBLEM (SYMPTOM).

Look under the column labeled "PROBLEM (SYMPTOMS)". This column describes possible symptoms that the machine may exhibit. Find the listing that best describes the symptom that the machine is exhibiting.

Step 2. POSSIBLE CAUSE.

The second column labeled "POSSIBLE CAUSE" lists the obvious external possibilities that may contribute to the machine symptom.

Step 3. RECOMMENDED COURSE OF ACTION

This column provides a course of action for the Possible Cause, generally it states to contact your local Lincoln Authorized Field Service Facility.

If you do not understand or are unable to perform the Recommended Course of Action safely, contact your local Lincoln Authorized Field Service Facility.



If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your Lincoln Authorized Service Facility for technical troubleshooting assistance before you proceed.

WWW.LINCOLNELECTRIC.COM/LOCATOR

Observe all Safety Guidelines detailed throughout this manual

PROBLEMS (SYMPTOMS)	POSSIBLE CAUSE	RECOMMENDED COURSE OF ACTION
ENGINE PROBLEMS		
Major Physical or Electrical Damage is Evident.	1. Contact your Local Lincoln Authorized Field Service Facility.	If all recommended possible areas of misadjustment have been checked and the problem persists, Contact your local Lincoln Authorized Field Service Facility.
Engine will not crank	1. Battery low. 2. Check 10A Battery Circuit Breaker. 3. Loose battery cable connections which may need Inspected, cleaned, or tightened. 4. Faulty wiring in engine starting circuit. 5. Faulty engine starter. Contact authorized local Engine Service Shop.	
Engine will crank but not start.	1. Out of fuel. 2. Fuel shut off valve is in the off position make sure the valve lever is in the open position 3. Fuel Filter or water separator element dirty/clogged. 4. High coolant temperature or low oil pressure.	
Engine shuts down shortly after starting.	1. Low oil pressure. Check oil level (Consult engine service dealer). 2. High coolant temperature. Check engine cooling system. 3. Faulty oil pressure switch. 4. Faulty coolant temperature switch. Contact authorized local Engine Service shop. 5. Check coolant level.	
Engine shuts down while under a load.	1. High coolant temperature. 2. Machine output limits exceeded.	
Engine runs rough.	1. Dirty fuel. 2. Water in fuel. 2. Air filter may need to be cleaned.	
Engine will not shut off.	1. Faulty Idler Switch. 2. Faulty EGC Relay.	



If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your Lincoln Authorized Service Facility for technical troubleshooting assistance before you proceed.

WWW.LINCOLNELECTRIC.COM/LOCATOR

Observe all Safety Guidelines detailed throughout this manual

PROBLEMS (SYMPTOMS)	POSSIBLE CAUSE	RECOMMENDED COURSE OF ACTION
FUNCTION PROBLEMS		
Battery does not stay charged.	<ol style="list-style-type: none"> 1. Faulty battery. 2. Faulty engine alternator. 3. Loose or broken lead in charging circuit. 4. Loose fan belt may need tightening. 	<p>If all recommended possible areas of misadjustment have been checked and the problem persists, Contact your local Lincoln Authorized Field Service Facility.</p>
Engine will not idle down to low speed.	<ol style="list-style-type: none"> 1. Idler switch in HIGH idle position, make sure switch is set to AUTO. 2. Faulty Idler Switch. 3. Faulty Idle Relay. 	
Engine will not go to high idle when attempting to weld.	<ol style="list-style-type: none"> 1. Poor work lead connection to work. Poor lead connections to machine. 2. Welding output is OFF. (No open circuit voltage at output studs) 3. Faulty Idle Relay. 	
Engine will not go to high idle when using auxiliary power.	<ol style="list-style-type: none"> 1. Broken wire in auxiliary current sensor wiring. 2. Auxiliary power load is less than 100W. 3. Faulty Auxiliary Sense Toroid. 4. Faulty Idle Relay. 	



If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your Lincoln Authorized Service Facility for technical troubleshooting assistance before you proceed.

WWW.LINCOLNELECTRIC.COM/LOCATOR

Observe all Safety Guidelines detailed throughout this manual

PROBLEMS (SYMPTOMS)	POSSIBLE CAUSE	RECOMMENDED COURSE OF ACTION
FUNCTION PROBLEMS		
Engine goes to low idle but does not stay at low idle.	<ol style="list-style-type: none"> 1. Faulty Idle Relay. 2. Intermittent Auxiliary load 3. Remote trigger input is present. 	<p>If all recommended possible areas of misadjustment have been checked and the problem persists, Contact your local Lincoln Authorized Field Service Facility.</p>
No welding output or auxiliary output.	<ol style="list-style-type: none"> 1. Broken lead in rotor circuit. 2. Faulty field bridge diode. 3. Faulty rotor. 	
Welder has some/ no output and no control. Auxiliary output OK	<ol style="list-style-type: none"> 1. Faulty remote kit. 2. Faulty output control potentiometer. 3. Faulty output control wiring. 	
No welding output. Auxiliary output OK.	<ol style="list-style-type: none"> 1. Output terminals may be set to Remote in the settings. 	
No auxiliary power.	<ol style="list-style-type: none"> 1. Open breakers may need to be reset. 2. GFCI tripped. 3. Faulty breaker(s), receptacle, or GFCI. 4. Faulty auxiliary circuit wiring. 	




If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your Lincoln Authorized Service Facility for technical troubleshooting assistance before you proceed.

WWW.LINCOLNELECTRIC.COM/LOCATOR

FRONTIER 400X (PERKINS) WIRING DIAGRAM

ELECTRICAL SYMBOLS PER E1537
ALL CABINET COMPONENTS SHOWN VIEWED FROM REAR




CLEVELAND, OHIO, U.S.A.

NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual. The specific diagram for a particular code is pasted inside the machine on one of the enclosure panels. If the diagram is illegible, write to the Service Department for a replacement. Give the equipment code number.


FRONTIER 400X (KUBOTA) WIRING DIAGRAM

ELECTRICAL SYMBOLS PER E1537
ALL COMPONENTS SHOWN VIEWED FROM REAR





CLEVELAND, OHIO, U.S.A.

NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual. The specific diagram for a particular code is pasted inside the machine on one of the enclosure panels. If the diagram is illegible, write to the Service Department for a replacement. Give the equipment code number.



N.A. CENTER OF GRAVITY WITH OIL IN ENGINE, COOLANT IN RADIATOR, AND EMPTY FUEL TANK.
 N.B. CASEFRONT GRAPHICS MAY NOT MATCH ALL CODES.



This page intentionally left blank.

This page intentionally left blank.

This page intentionally left blank.

			
WARNING	<ul style="list-style-type: none"> Do not touch electrically live parts or electrode with skin or wet clothing. Insulate yourself from work and ground. 	<ul style="list-style-type: none"> Keep flammable materials away. 	<ul style="list-style-type: none"> Wear eye, ear and body protection.
Spanish AVISO DE PRECAUCION	<ul style="list-style-type: none"> No toque las partes o los electrodos bajo carga con la piel o ropa mojada. Aíslese del trabajo y de la tierra. 	<ul style="list-style-type: none"> Mantenga el material combustible fuera del área de trabajo. 	<ul style="list-style-type: none"> Protéjase los ojos, los oídos y el cuerpo.
French ATTENTION	<ul style="list-style-type: none"> Ne laissez ni la peau ni des vêtements mouillés entrer en contact avec des pièces sous tension. Isolez-vous du travail et de la terre. 	<ul style="list-style-type: none"> Gardez à l'écart de tout matériel inflammable. 	<ul style="list-style-type: none"> Protégez vos yeux, vos oreilles et votre corps.
German WARNUNG	<ul style="list-style-type: none"> Berühren Sie keine stromführenden Teile oder Elektroden mit Ihrem Körper oder feuchter Kleidung! Isolieren Sie sich von den Elektroden und dem Erdboden! 	<ul style="list-style-type: none"> Entfernen Sie brennbares Material! 	<ul style="list-style-type: none"> Tragen Sie Augen-, Ohren- und Körperschutz!
Portuguese ATENÇÃO	<ul style="list-style-type: none"> Não toque partes elétricas e electrodos com a pele ou roupa molhada. Isole-se da peça e terra. 	<ul style="list-style-type: none"> Mantenha inflamáveis bem guardados. 	<ul style="list-style-type: none"> Use proteção para a vista, ouvido e corpo.
Japanese 注意事項	<ul style="list-style-type: none"> 通電中の電気部品、又は溶材にヒフやぬれた布で触れないこと。 施工物やアースから身体が絶縁されている様にして下さい。 	<ul style="list-style-type: none"> 燃えやすいものの側での溶接作業は絶対にしてはなりません。 	<ul style="list-style-type: none"> 目、耳及び身体に保護具をして下さい。
Chinese 警告	<ul style="list-style-type: none"> 皮肤或湿衣物切勿接触带电部件及焊条。 使你自已与地面和工作件绝缘。 	<ul style="list-style-type: none"> 把一切易燃物品移离工作场所。 	<ul style="list-style-type: none"> 佩戴眼、耳及身体劳动保护用具。
Korean 위험	<ul style="list-style-type: none"> 전도체나 용접봉을 젖은 형갑 또는 피부로 절대 접촉치 마십시오. 모재와 접지를 접촉치 마십시오. 	<ul style="list-style-type: none"> 인화성 물질을 접근시키지 마십시오. 	<ul style="list-style-type: none"> 눈, 귀와 몸에 보호장구를 착용하십시오.
Arabic تحذير	<ul style="list-style-type: none"> لا تلمس الاجزاء التي يسري فيها التيار الكهربائي أو الألكترود بجسدك أو بالملابس المبللة بالماء. ضع عازلا على جسمك خلال العمل. 	<ul style="list-style-type: none"> ضع المواد القابلة للاشتعال في مكان بعيد. 	<ul style="list-style-type: none"> ضع أدوات وملابس واقية على عينيك وأذنيك وجسمك.

READ AND UNDERSTAND THE MANUFACTURER'S INSTRUCTION FOR THIS EQUIPMENT AND THE CONSUMABLES TO BE USED AND FOLLOW YOUR EMPLOYER'S SAFETY PRACTICES.

SE RECOMIENDA LEER Y ENTENDER LAS INSTRUCCIONES DEL FABRICANTE PARA EL USO DE ESTE EQUIPO Y LOS CONSUMIBLES QUE VA A UTILIZAR, SIGA LAS MEDIDAS DE SEGURIDAD DE SU SUPERVISOR.

LISEZ ET COMPRENEZ LES INSTRUCTIONS DU FABRICANT EN CE QUI REGARDE CET EQUIPMENT ET LES PRODUITS A ETRE EMPLOYES ET SUIVEZ LES PROCEDURES DE SECURITE DE VOTRE EMPLOYEUR.

LESEN SIE UND BEFOLGEN SIE DIE BETRIEBSANLEITUNG DER ANLAGE UND DEN ELEKTRODENEINSATZ DES HERSTELLERS. DIE UNFALLVERHÜTUNGSVORSCHRIFTEN DES ARBEITGEBERS SIND EBENFALLS ZU BEACHTEN.

			
<ul style="list-style-type: none"> ● Keep your head out of fumes. ● Use ventilation or exhaust to remove fumes from breathing zone. 	<ul style="list-style-type: none"> ● Turn power off before servicing. 	<ul style="list-style-type: none"> ● Do not operate with panel open or guards off. 	WARNING
<ul style="list-style-type: none"> ● Los humos fuera de la zona de respiración. ● Mantenga la cabeza fuera de los humos. Utilice ventilación o aspiración para gases. 	<ul style="list-style-type: none"> ● Desconectar el cable de alimentación de poder de la máquina antes de iniciar cualquier servicio. 	<ul style="list-style-type: none"> ● No operar con panel abierto o guardas quitadas. 	Spanish AVISO DE PRECAUCION
<ul style="list-style-type: none"> ● Gardez la tête à l'écart des fumées. ● Utilisez un ventilateur ou un aspirateur pour ôter les fumées des zones de travail. 	<ul style="list-style-type: none"> ● Débranchez le courant avant l'entretien. 	<ul style="list-style-type: none"> ● N'opérez pas avec les panneaux ouverts ou avec les dispositifs de protection enlevés. 	French ATTENTION
<ul style="list-style-type: none"> ● Vermeiden Sie das Einatmen von Schweißrauch! ● Sorgen Sie für gute Be- und Entlüftung des Arbeitsplatzes! 	<ul style="list-style-type: none"> ● Strom vor Wartungsarbeiten abschalten! (Netzstrom völlig öffnen; Maschine anhalten!) 	<ul style="list-style-type: none"> ● Anlage nie ohne Schutzgehäuse oder Innenschutzverkleidung in Betrieb setzen! 	German WARNUNG
<ul style="list-style-type: none"> ● Mantenha seu rosto da fumaça. ● Use ventilação e exaustão para remover fumo da zona respiratória. 	<ul style="list-style-type: none"> ● Não opere com as tampas removidas. ● Desligue a corrente antes de fazer serviço. ● Não toque as partes elétricas nuas. 	<ul style="list-style-type: none"> ● Mantenha-se afastado das partes moventes. ● Não opere com os painéis abertos ou guardas removidas. 	Portuguese ATENÇÃO
<ul style="list-style-type: none"> ● ヒュームから頭を離すようにして下さい。 ● 換気や排煙に十分留意して下さい。 	<ul style="list-style-type: none"> ● メンテナンス・サービスに取りかかる際には、まず電源スイッチを必ず切して下さい。 	<ul style="list-style-type: none"> ● パネルやカバーを取り外したまま機械操作をしないで下さい。 	Japanese 注意事項
<ul style="list-style-type: none"> ● 頭部遠離煙霧。 ● 在呼吸區使用通風或排風器除煙。 	<ul style="list-style-type: none"> ● 維修前切斷電源。 	<ul style="list-style-type: none"> ● 儀表板打開或沒有安全罩時不準作業。 	Chinese 警告
<ul style="list-style-type: none"> ● 얼굴로부터 용접가스를 멀리하십시오. ● 호흡지역으로부터 용접가스를 제거하기 위해 가스제거기나 통풍기를 사용하십시오. 	<ul style="list-style-type: none"> ● 보수전에 전원을 차단하십시오. 	<ul style="list-style-type: none"> ● 판넬이 열린 상태로 작동치 마십시오. 	Korean 위험
<ul style="list-style-type: none"> ● ابعد رأسك بعيداً عن الدخان. ● استعمل التهوية أو جهاز ضغط الدخان للخارج لكي تبعد الدخان عن المنطقة التي تتنفس فيها. 	<ul style="list-style-type: none"> ● اقطع التيار الكهربائي قبل القيام بأية صيانة. 	<ul style="list-style-type: none"> ● لا تشغيل هذا الجهاز اذا كانت الاغطية الحديدية الواقية ليست عليه. 	Arabic تحذير

LEIA E COMPREENDA AS INSTRUÇÕES DO FABRICANTE PARA ESTE EQUIPAMENTO E AS PARTES DE USO, E SIGA AS PRÁTICAS DE SEGURANÇA DO EMPREGADOR.

使う機械や溶材のメーカーの指示書をよく読み、まず理解して下さい。そして貴社の安全規定に従って下さい。

請詳細閱讀並理解製造廠提供的說明以及應該使用的銀焊材料，並請遵守貴方的有閣勞動保護規定。

이 제품에 동봉된 작업지침서를 숙지하시고 귀사의 작업자 안전수칙을 준수하시기 바랍니다.

اقرأ بتمعن وافهم تعليمات المصنع المنتج لهذه المعدات والمواد قبل استعمالها واتبع تعليمات الوقاية لصاحب العمل.

CUSTOMER ASSISTANCE POLICY

The business of Lincoln Electric is manufacturing and selling high quality welding equipment, automated welding systems, consumables, and cutting equipment. Our challenge is to meet the needs of our customers, who are experts in their fields, and to exceed their expectations. On occasion, purchasers may ask Lincoln Electric for information or technical information about their use of our products. Our employees respond to inquiries to the best of their ability based on information and specifications provided to them by the customers and the knowledge they may have concerning the application. Our employees, however, are not in a position to verify the information provided or to evaluate the engineering requirements for the particular weldment, or to provide engineering advice in relation to a specific situation or application. Accordingly, Lincoln Electric does not warrant or guarantee or assume any liability with respect to such information or communications. Moreover, the provision of such information or technical information does not create, expand, or alter any warranty on our products. Any express or implied warranty that might arise from the information or technical information, including any implied warranty of merchantability or any warranty of fitness for any customers' particular purpose or any other equivalent or similar warranty is specifically disclaimed.

Lincoln Electric is a responsive manufacturer, but the definition of specifications, and the selection and use of specific products sold by Lincoln Electric is solely within the control of, and remains the sole responsibility of the customer. Many variables beyond the control of Lincoln Electric affect the results obtained in applying these types of fabrication methods and service requirements.

WELD FUME CONTROL EQUIPMENT

The operation of welding fume control equipment is affected by various factors including proper use and positioning of the equipment, maintenance of the equipment and the specific welding procedure and application involved. Worker exposure level should be checked upon installation and periodically thereafter to be certain it is within applicable OSHA PEL and ACGIH TLV limits.



THE LINCOLN ELECTRIC COMPANY

22801 St. Clair Avenue • Cleveland, OH • 44117-1199 • U.S.A.
Phone: +1.216.481.8100 • www.lincolnelectric.com