


INSTRUCTION MANUAL

FLEXTEC® 335XS



For use with Product/Code Numbers: 13075, 13757



Register your machine:

www.lincolnelectric.com/register

Authorized Service and Distributor Locator:

www.lincolnelectric.com/locator

Save for future reference

Date Purchased		
Code: (ex: 10859)		

Serial: (ex: U1060512345)

Contents

INSTALLATION	A-1
SAFTEY PRECAUTIONS	A1
ELECTROMAGNETIC COMPATIBILITY (EMC)	
TECHNICAL SPECIFICATIONS	A4
DUTY CYCLE	A5
LOCATION	A5
TILTING	A5
LIFTING	A5
STACKING	A5
ENVIRONMENTAL LIMITATIONS	A5
HIGH FREQUENCY PROTECTION	
INPUT AND GROUNDING CONNECTIONS	
INPUT FUSE AND SUPPLY WIRE CONSIDERATIONS	A6
INPUT VOLTAGE SELECTION	A6
OPERATION	B-1
POWER-UP SEQUENCE	B1
GENERAL DESCRIPTION	B1
DESIGN FEATURES	
RECOMMENDED PROCESSES	
PRODUCT SPECIFIC INSTALLATION LIMITATIONS	
PROCESS LIMITATIONS	
CASE FRONT ORIENTATION	
CASE BACK ORIENTATION	
REMOTE CONNECTOR PIN LAYOUT	
RECOMMENDED ELECTRODE AND WORK CABLE SIZES	
REMOTE SENSE LEAD SPECIFICATIONS	
THERMAL PROTECTION	
COMMON EQUIPMENT PACKAGES	
FEEDER CONNECTION DIAGRAMS	
DEFINITION OF WELD MODES	
BASIC MODES OF OPERATION	
MAINTENANCE	
SAFTEY PRECAUTIONS	
VISUAL INSPECTION	
ROUTINE MAINTENANCE	
TROUBLESHOOTING	
TROUBLESHOOTING	
BASIC TROUBLESHOOTING	
STATUS LED TROUBLESHOOTING	
ERROR CODES	
WIRING DIAGRAMS	1
PRINTS	
GRAPHIC SYMBOL DESCRIPTIONS	
CUSTOMER ASSISTANCE POLICY	

SAFETY

THANK YOU FOR SELECTING A QUALITY PRODUCT BY LINCOLN ELECTRIC

PLEASE EXAMINE CARTON AND EQUIPMENT FOR DAMAGE IMMEDIATELY

When this equipment is shipped, title passes to the purchaser upon receipt by the carrier. Consequently, claims for material damaged in shipment must be made by the purchaser against the transportation company at the time the shipment is received.

SAFETY DEPENDS ON YOU

Lincoln welding and cutting equipment is designed and built with safety in mind. However, your overall safety can be increased by proper installation ... and thoughtful operation on your part. DO NOT INSTALL, OPERATE OR REPAIR THIS EQUIPMENT WITHOUT READING THIS MANUAL AND THE SAFETY PRECAUTIONS CONTAINED THROUGHOUT. And, most importantly, think before you act and be careful.

A DANGER



This statement indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

MARNING



This statement indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

↑ CAUTION



This statement indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury.

Notice: This statement indicates the possibility of damage to equipment if the potential risk is not avoided.

KEEP YOUR HEAD OUT OF THE FUMES



- DON'T get too close to the weld. Use corrective lenses if necessary to stay a reasonable distance away from the weld.
- USE ENOUGH VENTILATION or exhaust at the weld, or both, to keep the fumes and gases from your breathing zone and the general area.
- IN A LARGE ROOM OR OUTDOORS, natural ventilation may be adequate if you keep your head out of the fumes.
- USE NATURAL DRAFTS or fans to keep the fumes away from your face. If you develop unusual symptoms, see your supervisor.
- READ and obey the Safety Data Sheet (SDS) and the warning label that appears on all containers of welding materials.

Perhaps the welding atmosphere and ventilation system should be checked.

WEAR CORRECT EYE, EAR AND BODY PROTECTION



- PROTECT your eye and face with properly fitted and with proper grade of filter plate (See ANSI Z49.1).
- PROTECT your body from welding spatter and arc flash with protective clothing including woolen clothing, Flame-proof apron and gloves, leather leggings, and high boots.
- **PROTECT** others from splatter, flash, and glare with protective screens or barriers.
- PROTECT your eyes and face with welding helmet
- **IN SOME AREAS**, protection from noise may be appropriate.
- **BE SURE** protective equipment is in good condition.



AT ALL TIMES, wear safety glasses in work area.

- DO NOT WELD OR CUT containers or materials which previously had been in contact with hazardous substances unless they are properly cleaned. This is extremely dangerous.
- DO NOT WELD OR CUT painted or plated parts unless special precautions with ventilation have been taken. They can release highly toxic fumes or gases.
- **PROTECT** compressed gas cylinders from excessive heat, mechanical shocks, and arcs; fasten cylinders so they cannot fall.
- **BE SURE** cylinders are never grounded or part of an electrical circuit.
- REMOVE all potential fire hazards from welding area.



 ALWAYS HAVE FIRE FIGHTING EQUIPMENT READY FOR IMMEDIATE USE AND KNOW HOW TO USE IT.

CALIFORNIA PROPOSITION 65 WARNINGS

MARNING



Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects, or other reproductive harm.

Always start and operate the engine in a well-ventilated area.

If in an exposed area, vent the exhaust to the outside.

Do not modify or tamper with the exhaust system.

Do not idle the engine except as necessary.

MARNING



This product, when used for welding or cutting, produces fumes or gases which contain chemicals known to the State of California to cause birth defects and, in some cases, cancer. (California Health & Safety Code § 25249.5 et seq.)

For more information go to www.P65 warnings.ca.gov/diesel

ARC WELDING CAN BE HAZARDOUS

PROTECT YOURSELF AND OTHERS FROM POSSIBLE SERIOUS INJURY OR DEATH. KEEP CHILDREN AWAY. PACEMAKER WEARERS SHOULD CONSULT WITH THEIR DOCTOR BEFORE OPERATING.

Read and understand the following safety highlights. For additional safety information, it is strongly recommended that you purchase a copy of "Safety in Welding & Cutting - ANSI Standard Z49.1" from the American Welding Society, P.O. Box 351040, Miami, Florida 33135 or CSA Standard W117.2. A Free copy of "Arc Welding Safety" booklet E205 is available from the Lincoln Electric Company, 22801 St. Clair Avenue, Cleveland, Ohio 44117-1199.

BE SURE THAT ALL INSTALLATION, OPERATION, MAINTENANCE AND REPAIR PROCEDURES ARE PERFORMED ONLY BY QUALIFIED INDIVIDUALS.

FOR ENGINE POWERED EQUIPMENT



 Turn the engine off before troubleshooting and maintenance work unless the maintenance work requires it to be running.



Do not add the fuel near an open flame welding arc or when the engine is running. Stop the engine and allow it to cool before refueling to prevent spilled fuel from vaporizing on contact with hot engine parts and igniting. Do not spill fuel when filling tank. If fuel is spilled, wipe it up and do not start engine until fumes have been eliminated.



- Keep all equipment safety guards, covers and devices in position and in good repair.
 Keep hands, hair, clothing and tools away from V-belts, gears, fans and all other moving parts when starting, operating or repairing equipment.
- In some cases it may be necessary to remove safety guards to perform required maintenance. REMOVE GUARDS ONLY when necessary and replace them when the maintenance requiring their removal is complete. Always use the greatest care when working near moving parts.
- DO NOT put your hands near the engine fan.
 Do not attempt to override the governor or idler by pushing on the throttle control rods while the engine is running.
- To prevent accidentally starting gasoline engines while turning the engine or welding generator during maintenance work, disconnect the spark plug wires, distributor cap or magneto wire as appropriate.



To avoid scalding, do not remove the radiator pressure cap when the engine is hot.





- Generator exhaust contains carbon monoxide. This is a poison you cannot see or smell.
- Using a generator indoors CAN KILL YOU IN MINUTES.
- NEVERuse inside a home or garage, EVEN IF doors and windows are open.





 ONLY use OUTSIDE and far away from windows, doors and vents.

 Avoid other generator hazards. READ MANUAL BEFORE USE.

ELECTRIC AND MAGNETIC FIELDS MAY BE DANGEROUS



- Electric current flowing through any conductor causes localized Electric and Magnetic Fields (EMF). Welding current creates EMF fields around welding cables and welding machines.
- EMF fields may interfere with some pacemakers, and welders having a pacemaker should consult their physician before welding.
- Exposure to EMF fields in welding may have other health effects which are now not known.
 All welders should use the following procedures in order to minimize exposure to EMF fields from the welding circuit:
- Route the electrode and work cables together -Secure them with tape when possible.
- Never coil the electrode lead around your body.
- Do not place your body between the electrode and work cables. If the electrode cable is on your right side, the work cable should also be on your right side.
- Connect the work cable to the workpiece as close as possible to the area being welded.
- Do not work next to welding power source.

ELECTRIC SHOCK CAN KILL



 The electrode and work (or ground) circuits are electrically "hot" when the welder is on. Do not touch these "hot" parts with your bare skin or wet clothing. Wear dry, hole-free gloves to insulate hands.

 Insulate yourself from work and ground using dry insulation. Make certain the insulation is large enough to cover your full area of physical contact with work and ground.

In addition to the normal safety precautions, if welding must be performed under electrically hazardous conditions (in damp locations or while wearing wet clothing; on metal structures such as floors, gratings or scaffolds; when in cramped positions such as sitting, kneeling or lying, if there is a high risk of unavoidable or accidental contact with the workpiece or ground) use the following equipment:

- Semiautomatic DC Constant Voltage (Wire) Welder.
- DC Manual (Stick) Welder.
- AC Welder with Reduced Voltage Control.
- In semiautomatic or automatic wire welding, the electrode, electrode reel, welding head, nozzle or semiautomatic welding gun are also electrically "hot".
- Always be sure the work cable makes a good electrical connection with the metal being welded. The connection should be as close as possible to the area being welded.
- Ground the work or metal to be welded to a good electrical (earth) ground.
- Maintain the electrode holder, work clamp, welding cable and welding machine in good, safe operating condition. Replace damaged insulation.
- Never dip the electrode in water for cooling.
- Never simultaneously touch electrically "hot" parts of electrode holders connected to two welders because voltage between the two can be the total of the open circuit voltage of both welders.
- When working above floor level, use a safety belt to protect yourself from a fall should you get a shock.
- Also see WELDING AND CUTTING SPARKS CAN <u>CAUSE FIRE OR EXPLOSION</u> on page -viii and <u>FOR ELECTRICALLY POWERED EQUIPMENT</u> on page -ix

ARC RAYS CAN BURN



Use a shield with the proper filter and cover plates to protect your eyes from sparks and the rays of the arc when welding or

- observing open arc welding. Headshield and filter lens should conform to ANSI Z87. I standards.
- Use suitable clothing made from durable flame-resistant material to protect your skin and that of your helpers from the arc rays.
- Protect other nearby personnel with suitable, non-flammable screening and/or warn them not to watch the arc nor expose themselves to the arc rays or to hot spatter or metal.

FUMES AND GASES CAN BE DANGEROUS

1.



Welding may produce fumes and gases hazardous to health. Avoid breathing these fumes and gases. When welding, keep your head out of the fume. Use enough ventilation and/or exhaust at the arc to keep fumes and gases away from the breathing zone.

When welding hardfacing (see instructions on container or SDS) or on lead or cadmium plated steel and other metals or coatings which produce highly toxic fumes, keep exposure as low as possible and within applicable OSHA PEL and ACGIH TLV limits using local exhaust or mechanical ventilation unless exposure assessments indicate otherwise. In confined spaces or in some circumstances, outdoors, a respirator may also be required. Additional precautions are also required when welding on galvanized steel.

- 2. The operation of welding fume control equipment is affected by various factors including proper use and positioning of the equipment, maintenance of the equipment and the specific welding procedure and application involved. Worker exposure level should be checked upon installation and periodically thereafter to be certain it is within applicable OSHA PEL and ACGIH TLV limits.
- **3.** Do not weld in locations near chlorinated hydrocarbon vapors coming from degreasing,

FLEXTEC® 335XS vii

- cleaning or spraying operations. The heat and rays of the arc can react with solvent vapors to form phosgene, a highly toxic gas, and other irritating products.
- **4.** Shielding gases used for welding can displace air and cause injury or death. Always use enough ventilation, especially in confined areas, to insure breathing air is safe.
- 5. Read and understand the manufacturer's instructions for this equipment and the consumables to be used, including the Safety Data Sheet (SDS) and follow your employer's safety practices. SDS forms are available from your welding distributor or from the manufacturer.
- **6.** Also see <u>FOR ENGINE POWERED EQUIPMENT</u> on page -v

WELDING AND CUTTING SPARKS CAN CAUSE FIRE OR EXPLOSION



- Remove fire hazards from the welding area. If this is not possible, cover them to prevent the welding sparks from starting a fire. Remember that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas. Avoid welding near hydraulic lines. Have a fire extinguisher readily available.
- Where compressed gases are to be used at the job site, special precautions should be used to prevent hazardous situations. Refer to "Safety in Welding and Cutting" (ANSI Standard Z49.1) and the operating information for the equipment being used.
- When not welding, make certain no part of the electrode circuit is touching the work or ground. Accidental contact can cause overheating and create a fire hazard.
- Do not heat, cut or weld tanks, drums or containers until the proper steps have been taken to insure that such procedures will not cause flammable or toxic vapors from substances inside. They can cause an explosion even though they have been "cleaned". For information, purchase "Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping That Have

- Held Hazardous Substances", **AWS F4.1** from the American Welding Society
- Vent hollow castings or containers before heating, cutting or welding. They may explode.
- Sparks and spatter are thrown from the welding arc. Wear oil free protective garments such as leather gloves, heavy shirt, cuff-less trousers, high shoes and a cap over your hair. Wear ear plugs when welding out of position or in confined places. Always wear safety glasses with side shields when in a welding area.
- Connect the work cable to the work as close to the welding area as practical. Work cables connected to the building framework or other locations away from the welding area increase the possibility of the welding current passing through lifting chains, crane cables or other alternate circuits. This can create fire hazards or overheat lifting chains or cables until they fail.
- Read and follow NFPA 51B "Standard for Fire Prevention During Welding, Cutting and Other Hot Work", available from NFPA, 1 Batterymarch Park, PO box 9101, Quincy, MA 022690-9101.
- **DO NOT** use a welding power source for pipe thawing.

CYLINDER MAY EXPLODE IF DAMAGED



- Use only compressed gas cylinders containing the correct shielding gas for the process used and properly operating regulators designed for the gas and pressure used. All hoses, fittings, etc. should be suitable for the application and maintained in good condition.
- Always keep cylinders in an upright position securely chained to an undercarriage or fixed support.

Cylinders should be located:

- Away from areas where they may be struck or subjected to physical damage.
- A safe distance from arc welding or cutting operations and any other source of heat, sparks, or flame.
- Never allow the electrode, electrode holder or any other electrically "hot" parts to touch a cylinder.

viii FLEXTEC® 335XS

- Keep your head and face away from the cylinder valve outlet when opening the cylinder valve.
- Valve protection caps should always be in place and hand tight except when the cylinder is in use or connected for use.
- Read and follow the instructions on compressed gas cylinders, associated equipment, and CGA publication P-l, "Precautions for Safe Handling of Compressed Gases in Cylinders," available from the Compressed Gas Association, 14501 George Carter Way Chantilly, VA 20151.

ADDITIONAL SAFETY INFORMATION

Refer to http://www.lincolnelectric.com/safety for additional safety information

FOR ELECTRICALLY POWERED EQUIPMENT



- Turn off input power using the disconnect switch at the fuse box before working on the equipment.
- Install equipment in accordance with the U.S. National Electrical Code, all local codes and the manufacturer's recommendations.
- Ground the equipment in accordance with the U.S. National Electrical Code and the manufacturer's recommendations.

INSTALLATION

SAFTEY PRECAUTIONS

Additional **SAFETY** on page -iv

MARNING

ELECTRICAL SHOCK CAN KILL



Do not touch electrically live parts or electrode with skin or wet clothing. Insulate yourself from work and ground.

Always wear dry insulating gloves.

Do not operate with panels removed.

Disconnect input power before servicing.

MARNING

FUMES AND GASES CAN BE DANGEROUS



Keep your head out of fumes.

Use ventilation or exhaust to remove fumes from breathing zone and general area.

N WARNING



WELDING SPARKS CAN CAUSE FIRE OR EXPLOSION

Keep flammable material away
Do not weld on closed containers

MARNING



ARC RAYS CAN BURN EYES AND SKIN

Wear eye, ear and body protection.

Observe all safety information throughout this manual.

ELECTROMAGNETIC COMPATIBILITY (EMC)

Conformance

Products displaying the CE mark are in conformity with European Community Council Directive of 15 Dec 2004 on the approximation of the laws of the Member States relating to electromagnetic compatibility, 2004/108/EC. It was manufactured in conformity with a national standard that implements a harmonized standard: EN 60974-10 Electromagnetic Compatibility (EMC) Product Standard for Arc Welding Equipment. It is for use with other Lincoln Electric equipment. It is designed for industrial and professional use.

Introduction

All electrical equipment generates small amounts of electromagnetic emission. Electrical emission may be transmitted through power lines or radiated through space, similar to a radio transmitter. When emissions are received by other equipment, electrical interference may result. Electrical emissions may affect many kinds of electrical equipment; other nearby welding equipment, radio and TV reception, numerical controlled machines, telephone systems, computers, etc.

MARNING



This Class A equipment is not intended for use in residential locations where the electrical power is provided by the public low-voltage supply system. There may be potential difficulties in ensuring electro-magnetic compatibility in those locations, due to conducted as well as radiated disturbances.

Installation and Use

The user is responsible for installing and using the welding equipment according to the manufacturer's instructions. If electromagnetic disturbances are detected then it shall be the responsibility of the user of the welding equipment to resolve the situation with the technical assistance of the manufacturer. In some cases this remedial action may be as simple as earthing (grounding) the welding circuit, see Note. In other cases it could involve constructing an electromagnetic screen enclosing the power source and the work complete with associated input filters. In all cases electromagnetic disturbances must be reduced to the point where they are no longer troublesome.

Note: The welding circuit may or may not be earthed for safety reasons. Follow your local and national standards for installation and use. Changing the earthing arrangements should only be authorized by a person who is competent to assess whether the changes will increase the risk of injury, e.g., by allowing parallel welding current return paths which may damage the earth circuits of other equipment.

Assessment of area

Before installing welding equipment the user shall make an assessment of potential electromagnetic problems in the surrounding area. The following shall be taken into account:

- **1.** other supply cables, control cables, signaling and telephone cables; above, below and adjacent to the welding equipment;
- 2. radio and television transmitters and receivers;
- 3. computer and other control equipment;
- 4. safety critical equipment, e.g., quarding of industrial equipment;
- 5. the health of the people around, e.g., the use of pacemakers and hearing aids;
- 6. equipment used for calibration or measurement;

A-2 FLEXTEC® 335XS

- **7.** the immunity of other equipment in the environment. The user shall ensure that other equipment being used in the environment is compatible. This may require additional protection measures;
- **8.** the time of day that welding or other activities are to be carried out.

The size of the surrounding area to be considered will depend on the structure of the building and other activities that are taking place. The surrounding area may extend beyond the boundaries of the premises.

Methods of Reducing Emissions

Public Supply System

Welding equipment should be connected to the public supply system according to the manufacturer's recommendations. If interference occurs, it may be necessary to take additional precautions such as filtering of the system. Consideration should be given to shielding the supply cable of permanently installed welding equipment, in metallic conduit or equivalent. Shielding should be electrically continuous throughout its length. The shielding should be connected to the welding power source so that good electrical contact is maintained between the conduit and the welding power source enclosure.

Maintenance of the Welding Equipment

The welding equipment should be routinely maintained according to the manufacturer's recommendations. All access and service doors and covers should be closed and properly fastened when the welding equipment is in operation. The welding equipment should not be modified in any way except for those changes and adjustments covered in the manufacturer's instructions. In particular, the spark gaps of arc striking and stabilizing devices should be adjusted and maintained according to the manufacturer's recommendations.

Welding Cables

The welding cables should be kept as short as possible and should be positioned close together, running at or close to the floor level.

Equipotential Bonding

Bonding of all metallic components in the welding installation and adjacent to it should be considered. However, metallic components bonded to the work piece will increase the risk that the operator could receive a shock by touching these metallic components and the electrode at the same time. The operator should be insulated from all such bonded metallic components.

Earthing of the Workpiece

Where the workpiece is not bonded to earth for electrical safety, nor connected to earth because of its size and position, e.g., ship's hull or building steelwork, a connection bonding the workpiece to earth may reduce emissions in some, but not all instances. Care should be taken to prevent the earthing of the workpiece increasing the risk of injury to users, or damage to other electrical equipment. Where necessary, the connection of the workpiece to earth should be made by a direct connection to the workpiece, but in some countries where direct connection is not permitted, the bonding should be achieved by suitable capacitance, selected according to national regulations.

Screening and Shielding

Selective screening and shielding of other cables and equipment in the surrounding area may alleviate problems of interference. Screening of the entire welding installation may be considered for special applications₁.

₁Portions of the preceding text are contained in EN 60974-10: "Electromagnetic Compatibility (EMC) product standard for arc welding equipment."

TECHNICAL SPECIFICATIONS

Flextec 335XS (Tweco®)

Flextec 335XS (Twist Mate™)

	POWER SOURCES - INPUT VOLTAGE AND CURRENT						
PRODUCT #	DUTY	CYCLE	INPUT VOLTAGE ± 10%	INPUT AMPERES	IDLE .	AMPS	POWER FACTOR
K4851-1	60% R	ATING	380/460/575V	25/24/22	0.76/0.	84/0.84	.87/.77/.62
K4850-1	100% F	RATING	3PH	23/21/19			.84/.70/.61
	POWER SOURCES - RECOMMENDED INPUT WIRE AND FUSE SIZES₁						
VOLTAGI	E	INP	UT AMPERES	FUSE (SUPER LA BREAKER SIZ	•	AND SJT WIT	, SJ, SJO, SOOW FLEXIBLE CORD TH AMBIENT RATURE OF 30C
380/3/50/6	60	23A		35A	•	10 <i>A</i>	AWG / 8 AWG
460/3/50/	60	21A		35A		10 A	AWG / 8 AWG
575/3/50/6	60		19A	35A		10 <i>A</i>	AWG / 8 AWG

Note:

- ₁ Cord and Fuse Sizes based upon the U.S. National Electric Code and maximum output
- $_2$ Also called 'inverse time' or 'thermal/magnetic' circuit breakers; circuit breakers that have a delay in tripping action that decreases as the magnitude of current increases.

RATED OUTPUT						
PROCESS	DUTY CYC	LE	VOLTS AT RATED AMPERES	Δ	MPERES	EFFICIENCY (AT RATED OUTPUT)
GMAW (CV)	60%		30.8V		335A	0.89/0.88/0.88
	100%		29V		300A	0.89/0.88/0.87
SMAW (CC)	60%		33.4V		335A	0.87/0.86/0.85
	100%		32V		300A	0.89/0.88/0.87
FCAW-GS (CV)	60%		30.8V		335A	0.89/0.88/0.88
	100%		29V		300A	0.88/0.88/0.88
FCAW-SS (CV)	60%		30.8V		335A	0.89/0.88/0.88
	100% 29V 300A 0.88/0.88/0.88					0.88/0.88/0.88
		RA	TED OUTPUT IEC6097	'4-1		
DUTY CY	CLE	VO	LTS AT RATED AMPER	RES	ı e	AMPERES
60%			33.4			335
100%			32			300
		PI	HYSICAL DIMENSION	1S		
MODEL	HEIGHT	1	WIDTH		DEPTH	WEIGHT
K4850-1	13.16IN (334.3	3mm) 23.37 IN (593.6		23.3	37 IN (593.6	50 LBS (23 KG)
K4851-1	OAL	mm) OAL		r	nm) OAL	
	TEMPERATURE RANGES					
OPERATING TEM	IPERATURE	ST	ORAGE TEMPERATU	RE	INSUL	ATION CLASS
-4°F TO 131°F (-10	°C TO 55°C)*	-40°l	TO 185°F (-40°C TO 8	35°C)	CLASS H (18	0°C), CLASS F (155°)

A-4 FLEXTEC® 335XS

AGENCY APPROVALS					
MODEL	MARKET	CONFORMITY MARK	STANDARD		
ALL	US AND CANADA	_C CSA _{US}	CAN/CSA - E60974-1		
			ANSI/IEC - 60974-1		
			IEC 60974-1		

Note: *Power Source is derated at temperatures above 40°C

DUTY CYCLE

The Flextec 335XS is capable of welding at a 100% duty cycle (continuous welding) at 300 Amps rated output.

The 60% duty cycle rating is 335 amps (based off of a ten minute cycle – 6 minutes on time and 4 minutes off time). The maximum output of the machine is 425 amps.

LOCATION

Locate the welder in a dry location where there is free circulation of clean air into the brickwork in the back and the louvers out the front and side. A location that minimizes the amount of smoke and dirt drawn into the rear brickwork reduces the chance of dirt accumulation that can block air passages and cause overheating.

TILTING

Place the machine directly on a secure or level surface. The machine may topple over if this procedure is not followed.

LIFTING

The Flextec 335XS has a single handle located on the top that can be used to lift the machine.

Note: If lifting overhead, there is a secondary lifting location at the bottom rear of the machine that must be used.

STACKING

The Flextec 335XS cannot be stacked.

ENVIRONMENTAL LIMITATIONS

The Flextec 335XS is IP23 rated for use in an outdoor environment. The machine should not be subjected to falling water during use nor should any parts of it be submerged in water. Doing so may cause improper operation as well as pose a safety hazard. The best practice is to keep the machine in a dry, sheltered area.

Do not mount the Flextec 335XS over combustible surfaces. Where there is a combustible surface directly under stationary or fixed electrical equipment, that surface shall be covered with a steel plate at least .060" (1.6mm) thick, which shall extend not less than 5.90" (150mm) beyond the equipment on all sides.

HIGH FREQUENCY PROTECTION

Locate the Flextec 335XS away from radio controlled machinery. The normal operation of the Flextec 335XS may adversely affect the operation of RF controlled equipment, which may result in bodily injury or damage to the equipment.

INPUT AND GROUNDING CONNECTIONS

The Flextec 335XS comes standard with a power cord. Connect the supply lines to 3 phase power and the ground according to your local and national electrical codes.

INPUT FUSE AND SUPPLY WIRE CONSIDERATIONS

Refer to technical specifications for recommended fuse, wire sizes and type of the copper wires. Fuse the input circuit with the recommended super lag fuse or delay type breakers (also called "inverse time" or "thermal/magnetic" circuit breakers). Choose input and grounding wire size according to local or national electrical codes. Using input wire sizes, fuses or circuit breakers smaller than recommended may result in "nuisance" shut-offs from welder inrush currents, even if the machine is not being used at high currents.

INPUT VOLTAGE SELECTION

The Flextec 335XS automatically adjusts to work with different input voltages. No reconnect switches or bus bars are required.

A-6 FLEXTEC® 335XS

OPERATION

POWER-UP SEQUENCE

When power is applied to the Flextec 335XS, the LED's will illuminate and the machine electronics will complete the power up sequence. Any ArcLink® wire feeders present and connected to the 5-pin circular connector will also initialize and begin a power up sequence once power is applied to the machine.

For machines connected to CrossLinc® compatible feeders the green CrossLinc LED will light indicating a connection to the feeder over the electrode cable.

GENERAL DESCRIPTION

The Flextec 335XS is a CrossLinc or ArcLink inverter-based, multi-process DC power source with an output range of 5 to 425 Amps. It supports welding in both CC and CV modes with common wire types and sizes and is also capable of gouging in Stick or CV modes.

The Flextec 335XS is only compatible with CrossLinc or ArcLink feeders. All Flextec 335XS models come standard with a 5-pin ArcLink digital feeder connector and include the CrossLinc interface, allowing for remote voltage setting with CrossLinc-compatible feeders or remote controls.

The Flextec 335XS offers welding modes for GMAW, FCAW, and SMAW, accommodating a variety of materials such as mild steel, some cored wires, gas-shielded wires, and aluminum wires. Additionally, the ArcLink connector on the front enables synergic welding modes, including Pulse and STT, when using an ArcLink-compatible feeder or an Activ8X Pipe.

DESIGN FEATURES

- Multiple process DC output range: 5 425 Amps
- Thermostatically protected Indicated by a Thermal Light.
- Simple and Easy to Use No case front controls and automatic weld mode selection based on polarity and connected CrossLinc accessory (Process Select Assist)
- Flexible Multi-Process Capability Including stick, MIG, Flux-cored and CAG.
- Compact, Durable Case Tough IP23 enclosure rating ensures the ability to withstand extreme field environments.
- Low Operating Cost Operates at a high efficiency
- Procedure Control Utilize ArcLink Feeder capabilities such as user memories, preference options, and procedure lockouts
- CrossLinc technology allows for remote control of the welding output using the weld cables rather than a control cable when connected to a CrossLinc compatible wire feeder or remote control.

- 380 575 VAC, 50/60Hz Voltage Input Offers the ability to be connected anywhere in the world without manual reconnect switches or bus hars
- Voltage Compensation and Reliable Input Voltage Connection – Provides consistent operation over ±10% input voltage variation.
- **Severe Duty** IP23 rated, can be stored outdoors.
- ArcLink Wire Feeder Compatible unlock synergic modes to increase productivity and control
- Synergic Modes for easy, repeatable welds
- Transport Reversible handles for ease of lifting.
- Process Selection Assist (PSA) Automatically selects the appropriate weld mode based on polarity and what accessory/feeder is connected

RECOMMENDED PROCESSES

Flextec 335XS is designed for CC-SMAW, CV-GMAW, CV-FCAW-SS, CV-FCAW-G welding processes.

WELD MODE	PROCESS	COMMON MATERIALS	COMMON ELECTRODES
SMAW	STICK-CC	ALUMINUM, STAINLESS,	6010, 6011, 7018
		STEEL	
CV	MIG (GMAW)	ALUMINUM, STAINLESS,	L-50, L-56
	FCAW-GS	STEEL	
CV-INNERSHIELD	FCAW-SS	STAINLESS, STEEL	NR-203, NR-211,
			NR-440NI2

PRODUCT SPECIFIC INSTALLATION LIMITATIONS

The Flextec 335XS is reliant on either a CrossLinc or ArcLink accessory/feeder to function properly

CrossLinc technology uses a communication protocol coupled on the electrode and work cables. For best performance the total voltage drop in the system should be kept under 10V.

CrossLinc is not compatible with High Frequency TIG. If HF is in the area, the cables need to routed as far as possible from each other. Also follow all high frequency best practices, including the driven earth ground.

PROCESS LIMITATIONS

The Flextec 335XS is only suitable for the processes listed.

CASE FRONT ORIENTATION




Figure 1: CASE FRONT

1. Negative Welding Output Connection

- K4850-1 Tweco Style Connector
- K4851-1 Twist Mate Style Connector

B-2 FLEXTEC® 335XS

2. 5-Pin Wire Feeder Connector

• Used to connect Arclink feeders to the Flextec 335XS

3. Positive Welding Output Connection

- K4850-1 Tweco Style Connector
- K4851-1 Twist Mate Style Connector
- 4. CrossLinc LED
- **5.** Status Indicator LED
 - Solid Green = Voltage not present at Welding Output Connections
 - Blinking Green = Voltage present at Welding Output Connections
 - Solid Yellow = Thermal Fault
 - Blinking Yellow = All Other Faults.

Note:

See **ERROR CODES** on page D-3 to determine the fault

CASE BACK ORIENTATION




Figure 2: CASE BACK

- 1. ON/OFF Power Switch
- 2. Input Power Cord
- 3. USB Connector
- 4. Overhead Strap Lifting Location

REMOTE CONNECTOR PIN LAYOUT





Figure 3: Case Front Connector Location

ARCLINK WIRE FEEDER & DIGITAL ACCESSORY CONNECITIVITY



RECOMMENDED ELECTRODE AND WORK CABLE SIZES

Connect the electrode and work cables between the appropriate output plugs of the equipment per the following guidelines:

• Most welding applications run with the electrode being positive (+). For those applications, connect the electrode cable between the wire drive input power connector and the positive (+) output stud on the power source. Connect a work lead from the negative (-) power source output stud to the work piece.

B-4 FLEXTEC® 335XS

• When negative electrode polarity is required, such as in some Innershield® applications, reverse the output connections at the power source (electrode cable to the negative (-) stud, and work cable to the positive (+) stud).

The following recommendations apply to all output polarities and weld modes:

• Select the appropriate size cables per the "Output Cable Guidelines" below. Excessive voltage drops caused by undersized welding cables and poor connections often result in unsatisfactory welding performance. Always use the largest welding cables (electrode and work) that are practical, and be sure all connections are clean and tight.

Note: Excessive heat in the weld circuit indicates undersized cables and/or bad connections.

- Route all cables directly to the work and wire feeder, avoid excessive lengths and do not coil excess cable. Route the electrode and work cables in close proximity to one another to minimize the loop area and therefore the inductance of the weld circuit.
- Always weld in a direction away from the work (ground) connection.

Tabulated below are copper cable sizes recommended for different currents and duty cycles. Lengths stipulated are the distance from the welder to work and back to the welder again. Cable sizes are increased for greater lengths primarily for the purpose of minimizing voltage drop.

Table 1: RECOMMENDED CABLE SIZES*

	PERCENT	CABLE SIZES FOR COMBINED LENGTHS OF ELECTRODE AN CABLES				
Amperes	DUTY CYCLE	0 to 50Ft. (0 to15m)	50 to 100Ft. (15 to 30m)	100 to 150 Ft. (30 to 46m)	150 to 200 Ft. (46 to 61m)	200 to 250 Ft. (61 to 76m)
200	60	2	2	2	1	1/0
200	100	2	2	2	1	1/0
225	20	4 or 5	3	4 or 5	1	1/0
225	40 & 30	3	3	3	1	1/0
250	30	3	3	3	1	1/0
250	40	2	2	2	1	1/0
250	60	1	1	1	1	1/0
250	100	1	1	1	1	1/0
300	60	1	1	1	1/0	1/0
350	100	2/0	2/0	2/0	2/0	2/0
350	60	1/0	1/0	1/0	2/0	3/0
400	60	2/0	2/0	2/0	3/0	4/0
400	100	3/0	3/0	3/0	3/0	4/0
500	60	2/0	2/0	2/0	3/0	4/0

Note: *Rubber covered copper - rated 167°F OR 75°C, values in the table are for operation at ambient temperatures of 104°F(40°C) and below. Applications above 104°F(40°C) may require cables larger than recommended, or cables rated higher than 167°F(75°C).

REMOTE SENSE LEAD SPECIFICATIONS

Genuine Lincoln Electric control cables should be used at all times (except where noted otherwise). Lincoln Electric cables are specifically designed for the communication and power needs of the Flextec 335XS. Most are designed to be connected end-to-end for ease of extension. Generally, it is recommended that the total length not exceed 100 feet (30.5 m). The use of non-standard cables, especially in lengths greater than 25 feet, can lead to communication problems (system shutdowns), poor motor acceleration (poor arc starting),

and low wire driving force (wire feeding problems). Always use the shortest length of control cable possible, and DO NOT coil excess cable.

Regarding cable placement, best results will be obtained when control cables are routed separate from the weld cables. This minimizes the possibility of interference between the high currents flowing through the weld cables, and the low level signals in the control cables.

THERMAL PROTECTION

Thermostats protect the machine from excessive operating temperatures. Excessive temperatures may be caused by a lack of cooling air or operating the machine beyond the duty cycle and output rating. If excessive operating temperature should occur, the thermostat will disable the output and run the cooling fan. The thermal light will be illuminated during this time. Thermostats are self-resetting once the machine cools sufficiently. If the thermostat shutdown was caused by excessive output or duty cycle and the fan is operating normally, the Power Switch may be left on and the reset should occur within a 15 minute period.

For the Flextec 335XS, machines the welding output will start again as soon as the thermostats close.

COMMON EQUIPMENT PACKAGES

COMMON OPTIONAL ACCESORY				
K4345-1 CROSSLINC REMOTE				
COMPATIBLE WIRE FEEDERS - CROSSLINC & ARCLINK FEEDERS				
PF25M, PF84 POWER FEED® SERIES (40VDC INPUT)				
	DLF-82			
ALL MODELS	ACTIV8X, ACTIV8X PIPE			
	LN-25X® WITH CROSSLINC TECHNOLOGY			

FEEDER CONNECTION DIAGRAMS


CONNECTING LN-25X FEEDERS TO THE FLEXTEC 335XS

ITEM	PRODUCT NUMBER	DESCRIPTION
1	K4850-1	FLEXTEC 335XS (TWECO)
'	K4267-2	LN-25X (TWECO)
2	K2485-2	WELD POWER CABLE
3	K4531-2-10-45	WELDING GUN
4	K2484-2	WORK CABLE
5	K910-2	WORK CLAMP
6*	KP1696-1	DRIVE ROLL KIT

Note: *Not shown

ITEM	PRODUCT NUMBER	DESCRIPTION
1	K4851-1	FLEXTEC 335X (TWIST MATE)
	K4267-4	LN-25X (TWIST MATE)


B-6 FLEXTEC® 335XS



CONNECTING THE CROSLINC REMOTE TO THE Flextec 335XS

ITEM	PRODUCT NUMBER	DESCRIPTION
	K4850-1	FLEXTEC 335XS (TWECO)
1	K4851-1	FLEXTEC 335X (DINSE)
	K3445-1	CROSSLINC REMOTE
2	K2485-2	WELD POWER CABLE*
3	K5161-2-15	ELECTRODE HOLDER AND LEAD#2
		(TWECO), 15FT
4	K2484-2	WORK CABLE*
5	K910-2	WORK CLAMP

 $\textbf{Note: } ^{\star} \text{A Tweco to Dinse adapter would be required is connecting to the K4851-1 FLEXTEC 335XS (DINSE) model}$




CONNECTING ACTIV8X PIPE TO THE FLEXTEC 335XS

ITEM	PRODUCT NUMBER	DESCRIPTION	
1	K4850-1	FLEXTEC 335XS (TWECO)	
I	K4273-1	ACTIV8X PIPE (TWECO)	
2	K2485-2 (QTY 2)	WELD POWER CABLE	
3	K4531-2-10-45 WELDING GUN		
4	K2484-2	WORK CABLE	
5	K910-2	WORK CLAMP	
6*	KP1696-1	DRIVE ROLL KIT	

Note: *Not shown

ITEM	PRODUCT NUMBER	DESCRIPTION	
1	K4851-1	FLEXTEC 335X (TWIST MATE)	
	K5240-1	ACTIV8X PIPE (TWIST MATE)	



DEFINITION OF WELD MODES

NON-SYNERGIC WELDING MODES

• A non-synergic welding mode requires all welding process variables to be set by the operator.

SYNERGIC WELDING MODES

• A synergic welding mode offers the simplicity of single knob control. The machine will select the correct voltage and amperage based on the wire feed speed (WFS) set by the operator.

BASIC MODES OF OPERATION

Below is list of basic modes of operation. for in-depth connection diagrams for each mode, see <u>FEEDER</u> <u>CONNECTION DIAGRAMS</u> on page B-6

SMAW

This weld mode is a constant current (CC) mode featuring continuous control from 15 – 425 Amps. It is intended for the SMAW stick welding processes when used with the CrossLinc® remote controller.

B-8 FLEXTEC® 335XS

CV-Gas

This weld mode is a constant voltage (CV) mode featuring continuous control from 10 to 45 volts. It is intended for the GMAW, FCAW-GS, MCAW welding processes and arc gouging.

CV-INNERSHIELD

This weld mode is a constant voltage (CV) mode featuring continuous control from 10 to 45 volts. It is intended for the FCAW-SS welding process and arc gouging.

ARCLINK

This weld mode is intended to unlock basic non-synergic and synergic modes intended for use with compatible ArcLink wire feeders. Controlling the power source is accomplished from the wire feeder user interface.

CROSSI INC®

CrossLinc[®] is a welding system communication technology. When using a CrossLinc[®] enabled power source such as the Flextec 335XS and a CrossLinc[®] enabled wire feeder or controller such as the LN-25X, welding voltage can be controlled remotely without the use of an additional control cable.

The digital meters on the LN-25X will show the pre-set values for wire feed speed and voltage prior to welding. During welding, the meters will show actual current and voltage present at the wire feeder. After welding the meters will then flash the last welding current and voltage that was present during welding for 10- seconds after welding. If WFS or V is adjusted during this 10 second period, the meters will go back to the pre-set value.

• When an LN-25X CrossLinc® enabled feeder is connected with the Flextec 335XS using the standard weld power cable and the LN-25X sense lead is attached to the work piece, the CrossLinc light will automatically illuminate on both the Flextec 335XS and the LN-25X. No additional pairing of the machine to the feeder is needed. This light indicates the CrossLinc® connection is active and that control of the Flextec 335XS voltage can be made at the LN-25X feeder.

PROCESS SELECTION ASSIST (PSA)

When using a CrossLinc® capable feeder*, the Flextec 335XS will automatically select the process reflected by the polarity of the feeder. For instance, the process selected by the Flextec 335XS will automatically change to "CV" when connected electrode positive and "CV Innershield" when connected electrode negative.

When using a CrossLinc® Remote*, the Flextec 335XS will automatically select the process reflected by the polarity of the remote. For instance, the process selected by the Flextec 335XS will automatically change to "SMAW" when connected electrode positive and "GTAW" mode when connected electrode negative.

Note: *Standard CrossLinc functionality will work but in order to use the Process Selection Assist, the CrossLinc device must be manufactured after December 2022.

OPERATION


B-10 FLEXTEC® 335XS

MAINTENANCE

SAFTEY PRECAUTIONS

Additional **SAFETY** on page -iv

MARNING





Before carrying out service, maintenance and/or repair jobs, fully disconnect power to the machine.

MARNING





Keep your head out of fumes.

Use ventilation or exhaust to remove fumes from breathing zone and general area.

MARNING



WELDING SPARKS CAN CAUSE FIRE OR EXPLOSION

Keep flammable material away
Do not weld on closed containers

MARNING



ARC RAYS CAN BURN EYES AND SKIN

Wear eye, ear and body protection.

WARNING



Have qualified personnel do all maintenance and troubleshooting work.

Observe all safety information throughout this manual.

VISUAL INSPECTION

Clean interior of machine with a low pressure air stream. Make a thorough inspection of all components. Look for signs of overheating, broken leads or other obvious problems. Many problems can be uncovered with a good visual inspection.

ROUTINE MAINTENANCE

Every six months the machine should be cleaned with a low pressure air stream. Keeping the machine clean will result in cooler operation and higher reliability. Be sure to clean the following areas:

- All printed circuit boards
- Power switch
- · Main transformer
- Input rectifier
- Heatsink fins
- Auxiliary Transformer
- Fan (Blow air through the rear brickwork)

Examine the sheet metal case for dents or breakage. Repair the case as required. Keep the case in good condition to ensure that high voltage parts are protected and correct spacing is maintained throughout. All external sheet metal screws must be in place to ensure case strength and electrical ground continuity.

C-2 FLEXTEC® 335XS

TROUBLESHOOTING

TROUBLESHOOTING

MARNING



Service and Repair should only be performed by Lincoln Electric Factory Trained Personnel. Unauthorized repairs performed on this equipment may result in danger to the technician and machine operator and will invalidate your factory warranty. For your safety and to avoid Electrical Shock, please observe all safety notes and precautions detailed throughout this manual.

This Troubleshooting Guide is provided to help you locate and repair possible machine malfunctions. Simply follow the three-step procedure listed below.

1. LOCATE PROBLEM (SYMPTOM)

Look under the column labeled "PROBLEM (SYMPTOMS)". This column describes possible symptoms that the machine may exhibit. Find the listing that best describes the symptom that the machine is exhibiting.

2. POSSIBLE CAUSE

The second column labeled "POSSIBLE CAUSE" lists the obvious external possibilities that may contribute to the machine symptom.

3. RECOMMENDED COURSE OF ACTION

This column provides a course of action for the Possible Cause, generally it states to contact your local Lincoln Authorized Field Service Facility.

A CAUTION



If you do not understand or are unable to perform the Recommended Course of Action safely, contact your local Lincoln Authorized Field Service Facility.

Observe all additional safety guidelines detailed throughout this manual.

BASIC TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	RECOMMENDED COURSE OF ACTION	
Major physical or electrical damage is evident when the sheet metal covers are removed.	Contact your local authorized Lincoln Electric Field Service facility for technical assistance.		
Machine won't weld, can't get any output.	If the thermal symbol is lit refer to the thermal section.		
Thermal symbol is lit	 Check for proper fan operation. Check for material blocking intake or exhaust louvers. Blow air in the rear brickwork to clear dirt from the fan. Note: The Fan As Needed circuitry automatically shuts off the fan 5 minutes after welding has stopped with ArkLink peripherals Welding output ratings may have been exceeded. Allow the machine to cool down and reset. 	If all recommended areas of possible cause have been checked and the problem persists, Contact your local authorized Lincoln Electric Field Service facility for assistance	
Wire feeder won't work. Apparently no power to wire feeder	 Check the control cable connectors on the case front of the machine to make sure it is properly connected. Check the control cable between the power source and the wire feeder for continuity. 		

CAUTION



If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your Lincoln Authorized Service Facility for technical troubleshooting assistance before you proceed. To locate your nearest service provider please visit www.mylincolnelectric.com

STATUS LED TROUBLESHOOTING

Not all of the Flextec 335XS errors will be blinked out using the status LED. If a problem occurs it is important to note the condition of the status lights. **Therefore, prior to cycling power to the system, check the power source status light for error sequences as noted below.** This status light corresponds to the main control board's status.

Included in this section is information about the Status Light and some basic troubleshooting charts. The status light is a dual-color LED. Normal operation for the status LED is steady or blinking green.

Error conditions are indicated in the following Table 2: Status LED on page -3

D-2 FLEXTEC® 335XS

Table 2: Status LED

Light Condition	Meaning Main control board status light
Steady Green	System OK. Power source is operational, and is communicating normally with all healthy peripheral equipment connected to its ArcLink network.
Blinking Green	Occurs during power up or a system reset, and indicates the Flextec 335XS is mapping (identifying) each component in the system. Normal for first 1-10 seconds after power is turned on, or if the system configuration is changed during operation. After power on, a slow blinking green will indicate that voltage is present at the output terminals. Non-recoverable system fault. If the Status LED is flashing any combination of yellow an errors is present. Read the error code(s) before the machine
	is turned off.
Alternating Green and Yellow	Error Code interpretation through the Status light is detailed in the Service Manual. Individual code digits are flashed in yellow with a long pause between digits. If more than one code is present, the codes will be separated by a green light. Only active error conditions will be accessible through the Status Light.
Steady Yellow	Thermal fault
Blinking Yellow	Not applicable
Status LED Off	Not applicable

ERROR CODES

Note: Observe all Safety Guidelines detailed throughout this manual

The following is a partial list of possible error codes for the Flextec 335XS. For a complete listing consult the Service Manual for this machine.


ERROR CODE	SHORT DESCRIPTION	INDICATION
#		
31	Primary Over Current	Indicates a high primary current has caused a fault. If Cycling the input power on the machine does not clear the error, contact your local authorized service facility.
37	Soft Start Error	Indicates a problem with inverter soft start circuitry. If cycling the input power on the machine does not clear the error, contact your local authorized service facility.
54	Secondary (Output) over current error	The long term average secondary (weld) current limit has been exceeded. Note: The long term average secondary current limit is 440 amps.
Other	N/A	Error codes that contain three or four digits are defined as fatal errors. These codes generally indicate internal errors on the Power Source Control Board. If cycling the input power on the machine does not clear the error, contact your local authorized service facility.

TROUBLESHOOTING

D-4 FLEXTEC® 335XS

WIRING DIAGRAMS


WIRING DIAGRAM - CODES 13075 & 13757




WIRING DIAGRAMS

PRINTS

DIMENSIONAL PRINT





GRAPHIC SYMBOL DESCRIPTIONS

SYMBOL	DESCRIPTION	SYMBOL	DESCRIPTION
\bigcirc	INPUT POWER	3 THREE PHASE	
1	ON	===	DIRECT CURRENT
0	OFF	U _r	REDUCED OPEN CIRCUIT VOLTAGE
ŧ	HIGH TEMPERATURE	U ₀	OPEN CIRCUIT VOLTAGE
00	CIRCUIT BREAKER	U ₁	INPUT VOLTAGE
00	WIRE FEEDER	U ₂	OUTPUT VOLTAGE
$\overrightarrow{0}$	COLD FEED FORWARD	I1 INPUT CURRENT	
	COLD FEED REVERSE	I ₂	OUTPUT CURRENT

SYMBOL **DESCRIPTION SYMBOL DESCRIPTION** 7 PIN INPUT POSITIVE OUTPUT **NEGATIVE OUTPUT** 3[^] ✓ ✓ ✓ ✓ 3 PHASE INVERTER PROTECTIVE GROUND INPUT POWER CONNECTION DANGEROUS VOLTAGE GAS IN EXTERNAL CONTROL LOCKED **STATUS** (OUTPUT) UNLOCKED ■ WORK CLAMP (SAFETY LOOP) (OUTPUT) **LASER APERTURE**

CUSTOMER ASSISTANCE POLICY

CUSTOMER ASSISTANCE POLICY

The business of Lincoln Electric is manufacturing and selling high quality welding equipment, automated welding systems, consumables, and cutting equipment. Our challenge is to meet the needs of our customers, who are experts in their fields, and to exceed their expectations. On occasion, purchasers may ask Lincoln Electric for information or technical information about their use of our products. Our employees respond to inquiries to the best of their ability based on information and specifications provided to them by the customers and the knowledge they may have concerning the application. Our employees, however, are not in a position to verify the information provided or to evaluate the engineering requirements for the particular weldment, or to provide engineering advice in relation to a specific situation or application. Accordingly, Lincoln Electric does not warrant or guarantee or assume any liability with respect to such information or communications. Moreover, the provision of such information or technical information does not create, expand, or alter any warranty on our products. Any express or implied warranty that might arise from the information or technical information, including any implied warranty of merchantability or any warranty of fitness for any customers' particular purpose or any other equivalent or similar warranty is specifically disclaimed.

Lincoln Electric is a responsive manufacturer, but the definition of specifications, and the selection and use of specific products sold by Lincoln Electric is solely within the control of, and remains the sole responsibility of the customer. Many variables beyond the control of Lincoln Electric affect the results obtained in applying these types of fabrication methods and service requirements.

WELD FUME CONTROL EQUIPMENT

The operation of welding fume control equipment is affected by various factors including proper use and positioning of the equipment, maintenance of the equipment and the specific welding procedure and application involved. Worker exposure level should be checked upon installation and periodically thereafter to be certain it is within applicable OSHA PEL and ACGIH TLV limits.

PARTS LIST

Content/Details may be changed or updated without notice. For most current Instruction Manuals, go to PARTS.LINCOLNELECTRIC.COM.