


**Service Manual**

***Dual Maverick<sup>®</sup> 200/200X***



For use with machines having Code Numbers:  
**12765**



**Register your machine:**  
[www.lincolnelectric.com/register](http://www.lincolnelectric.com/register)

**Authorized Service and Distributor Locator:**  
[www.lincolnelectric.com/locator](http://www.lincolnelectric.com/locator)

**Save for future reference**

Date Purchased

Code: (ex: 10859)

Serial: (ex: U1060512345)

**Need Help? Call 1.888.935.3877**  
to talk to a Service Representative

**Hours of Operation:**  
8:00 AM to 6:00 PM (ET) Mon. thru Fri.

**After hours?**  
Use "Ask the Experts" at [lincolnelectric.com](http://lincolnelectric.com)  
A Lincoln Service Representative will contact you  
no later than the following business day.

**For Service outside the USA:**  
Email: [globalservice@lincolnelectric.com](mailto:globalservice@lincolnelectric.com)

# THANK YOU FOR SELECTING A QUALITY PRODUCT BY LINCOLN ELECTRIC.

## PLEASE EXAMINE CARTON AND EQUIPMENT FOR DAMAGE IMMEDIATELY

When this equipment is shipped, title passes to the purchaser upon receipt by the carrier. Consequently, claims for material damaged in shipment must be made by the purchaser against the transportation company at the time the shipment is received.

## SAFETY DEPENDS ON YOU

Lincoln arc welding and cutting equipment is designed and built with safety in mind. However, your overall safety can be increased by proper installation ... and thoughtful operation on your part. **DO NOT INSTALL, OPERATE OR REPAIR THIS EQUIPMENT WITHOUT READING THIS MANUAL AND THE SAFETY PRECAUTIONS CONTAINED THROUGHOUT.** And, most importantly, think before you act and be careful.

### **WARNING**

This statement appears where the information must be followed exactly to avoid serious personal injury or loss of life.

### **CAUTION**

This statement appears where the information must be followed to avoid minor personal injury or damage to this equipment.



## KEEP YOUR HEAD OUT OF THE FUMES.

**DON'T** get too close to the arc. Use corrective lenses if necessary to stay a reasonable distance away from the arc.


**READ** and obey the Safety Data Sheet (SDS) and the warning label that appears on all containers of welding materials.

**USE ENOUGH VENTILATION** or exhaust at the arc, or both, to keep the fumes and gases from your breathing zone and the general area.

**IN A LARGE ROOM OR OUTDOORS**, natural ventilation may be adequate if you keep your head out of the fumes (See below).

**USE NATURAL DRAFTS** or fans to keep the fumes away from your face.

If you develop unusual symptoms, see your supervisor. Perhaps the welding atmosphere and ventilation system should be checked.



## WEAR CORRECT EYE, EAR & BODY PROTECTION

**PROTECT** your eyes and face with welding helmet properly fitted and with proper grade of filter plate (See ANSI Z49.1).

**PROTECT** your body from welding spatter and arc flash with protective clothing including woolen clothing, flame-proof apron and gloves, leather leggings, and high boots.

**PROTECT** others from splatter, flash, and glare with protective screens or barriers.

**IN SOME AREAS**, protection from noise may be appropriate.

**BE SURE** protective equipment is in good condition.

Also, wear safety glasses in work area **AT ALL TIMES.**



## SPECIAL SITUATIONS

**DO NOT WELD OR CUT** containers or materials which previously had been in contact with hazardous substances unless they are properly cleaned. This is extremely dangerous.

**DO NOT WELD OR CUT** painted or plated parts unless special precautions with ventilation have been taken. They can release highly toxic fumes or gases.

## Additional precautionary measures

**PROTECT** compressed gas cylinders from excessive heat, mechanical shocks, and arcs; fasten cylinders so they cannot fall.

**BE SURE** cylinders are never grounded or part of an electrical circuit.

**REMOVE** all potential fire hazards from welding area.

**ALWAYS HAVE FIRE FIGHTING EQUIPMENT READY FOR IMMEDIATE USE AND KNOW HOW TO USE IT.**



## SECTION A: WARNINGS



### CALIFORNIA PROPOSITION 65 WARNINGS



**WARNING:** Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects, or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an exposed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to [www.P65warnings.ca.gov/diesel](http://www.P65warnings.ca.gov/diesel)

**WARNING:** This product, when used for welding or cutting, produces fumes or gases which contain chemicals known to the State of California to cause birth defects and, in some cases, cancer. (California Health & Safety Code § 25249.5 *et seq.*)



**WARNING:** Cancer and Reproductive Harm  
[www.P65warnings.ca.gov](http://www.P65warnings.ca.gov)

**ARC WELDING CAN BE HAZARDOUS. PROTECT YOURSELF AND OTHERS FROM POSSIBLE SERIOUS INJURY OR DEATH. KEEP CHILDREN AWAY. PACEMAKER WEARERS SHOULD CONSULT WITH THEIR DOCTOR BEFORE OPERATING.**

Read and understand the following safety highlights. For additional safety information, it is strongly recommended that you purchase a copy of "Safety in Welding & Cutting - ANSI Standard Z49.1" from the American Welding Society, P.O. Box 351040, Miami, Florida 33135 or CSA Standard W117.2. A Free copy of "Arc Welding Safety" booklet E205 is available from the Lincoln Electric Company, 22801 St. Clair Avenue, Cleveland, Ohio 44117-1199.

**BE SURE THAT ALL INSTALLATION, OPERATION, MAINTENANCE AND REPAIR PROCEDURES ARE PERFORMED ONLY BY QUALIFIED INDIVIDUALS.**



### FOR ENGINE POWERED EQUIPMENT.

- Turn the engine off before troubleshooting and maintenance work unless the maintenance work requires it to be running.
- Operate engines in open, well-ventilated areas or vent the engine exhaust fumes outdoors.
- Do not add the fuel near an open flame welding arc or when the engine is running. Stop the engine and allow it to cool before refueling to prevent spilled fuel from vaporizing on contact



with hot engine parts and igniting. Do not spill fuel when filling tank. If fuel is spilled, wipe it up and do not start engine until fumes have been eliminated.

- Keep all equipment safety guards, covers and devices in position and in good repair. Keep hands, hair, clothing and tools away from V-belts, gears, fans and all other moving parts when starting, operating or repairing equipment.
- In some cases it may be necessary to remove safety guards to perform required maintenance. Remove guards only when necessary and replace them when the maintenance requiring their removal is complete. Always use the greatest care when working near moving parts.
- Do not put your hands near the engine fan. Do not attempt to override the governor or idler by pushing on the throttle control rods while the engine is running.
- To prevent accidentally starting gasoline engines while turning the engine or welding generator during maintenance work, disconnect the spark plug wires, distributor cap or magneto wire as appropriate.
- To avoid scalding, do not remove the radiator pressure cap when the engine is hot.
- Using a generator indoors CAN KILL YOU IN MINUTES.
- Generator exhaust contains carbon monoxide. This is a poison you cannot see or smell.
- NEVER use inside a home or garage, EVEN IF doors and windows are open.
- Only use OUTSIDE and far away from windows, doors and vents.
- Avoid other generator hazards. READ MANUAL BEFORE USE.



### ELECTRIC AND MAGNETIC FIELDS MAY BE DANGEROUS



- Electric current flowing through any conductor causes localized Electric and Magnetic Fields (EMF). Welding current creates EMF fields around welding cables and welding machines
- EMF fields may interfere with some pacemakers, and welders having a pacemaker should consult their physician before welding.
- Exposure to EMF fields in welding may have other health effects which are now not known.
- All welders should use the following procedures in order to minimize exposure to EMF fields from the welding circuit:
  - Route the electrode and work cables together - Secure them with tape when possible.
  - Never coil the electrode lead around your body.
  - Do not place your body between the electrode and work cables. If the electrode cable is on your right side, the work cable should also be on your right side.
  - Connect the work cable to the workpiece as close as possible to the area being welded.
  - Do not work next to welding power source.



## ELECTRIC SHOCK CAN KILL.



- 3.a. The electrode and work (or ground) circuits are electrically “hot” when the welder is on. Do not touch these “hot” parts with your bare skin or wet clothing. Wear dry, hole-free gloves to insulate hands.
- 3.b. Insulate yourself from work and ground using dry insulation. Make certain the insulation is large enough to cover your full area of physical contact with work and ground.

**In addition to the normal safety precautions, if welding must be performed under electrically hazardous conditions (in damp locations or while wearing wet clothing; on metal structures such as floors, gratings or scaffolds; when in cramped positions such as sitting, kneeling or lying, if there is a high risk of unavoidable or accidental contact with the workpiece or ground) use the following equipment:**

- Semiautomatic DC Constant Voltage (Wire) Welder.
  - DC Manual (Stick) Welder.
  - AC Welder with Reduced Voltage Control.
- 3.c. In semiautomatic or automatic wire welding, the electrode, electrode reel, welding head, nozzle or semiautomatic welding gun are also electrically “hot”.
  - 3.d. Always be sure the work cable makes a good electrical connection with the metal being welded. The connection should be as close as possible to the area being welded.
  - 3.e. Ground the work or metal to be welded to a good electrical (earth) ground.
  - 3.f. Maintain the electrode holder, work clamp, welding cable and welding machine in good, safe operating condition. Replace damaged insulation.
  - 3.g. Never dip the electrode in water for cooling.
  - 3.h. Never simultaneously touch electrically “hot” parts of electrode holders connected to two welders because voltage between the two can be the total of the open circuit voltage of both welders.
  - 3.i. When working above floor level, use a safety belt to protect yourself from a fall should you get a shock.
  - 3.j. Also see Items 6.c. and 8.



## ARC RAYS CAN BURN.



- 4.a. Use a shield with the proper filter and cover plates to protect your eyes from sparks and the rays of the arc when welding or observing open arc welding. Headshield and filter lens should conform to ANSI Z87.1 standards.
- 4.b. Use suitable clothing made from durable flame-resistant material to protect your skin and that of your helpers from the arc rays.
- 4.c. Protect other nearby personnel with suitable, non-flammable screening and/or warn them not to watch the arc nor expose themselves to the arc rays or to hot spatter or metal.




## FUMES AND GASES CAN BE DANGEROUS.



- 5.a. Welding may produce fumes and gases hazardous to health. Avoid breathing these fumes and gases. When welding, keep your head out of the fume. Use enough ventilation and/or exhaust at the arc to keep fumes and gases away from the breathing zone. **When welding hardfacing (see instructions on container or SDS) or on lead or cadmium plated steel and other metals or coatings which produce highly toxic fumes, keep exposure as low as possible and within applicable OSHA PEL and ACGIH TLV limits using local exhaust or mechanical ventilation unless exposure assessments indicate otherwise. In confined spaces or in some circumstances, outdoors, a respirator may also be required. Additional precautions are also required when welding on galvanized steel.**
- 5.b. The operation of welding fume control equipment is affected by various factors including proper use and positioning of the equipment, maintenance of the equipment and the specific welding procedure and application involved. Worker exposure level should be checked upon installation and periodically thereafter to be certain it is within applicable OSHA PEL and ACGIH TLV limits.
- 5.c. Do not weld in locations near chlorinated hydrocarbon vapors coming from degreasing, cleaning or spraying operations. The heat and rays of the arc can react with solvent vapors to form phosgene, a highly toxic gas, and other irritating products.
- 5.d. Shielding gases used for arc welding can displace air and cause injury or death. Always use enough ventilation, especially in confined areas, to insure breathing air is safe.
- 5.e. Read and understand the manufacturer’s instructions for this equipment and the consumables to be used, including the Safety Data Sheet (SDS) and follow your employer’s safety practices. SDS forms are available from your welding distributor or from the manufacturer.
- 5.f. Also see item 1.b.




## WELDING AND CUTTING SPARKS CAN CAUSE FIRE OR EXPLOSION.



- 6.a. Remove fire hazards from the welding area. If this is not possible, cover them to prevent the welding sparks from starting a fire. Remember that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas. Avoid welding near hydraulic lines. Have a fire extinguisher readily available.
- 6.b. Where compressed gases are to be used at the job site, special precautions should be used to prevent hazardous situations. Refer to "Safety in Welding and Cutting" (ANSI Standard Z49.1) and the operating information for the equipment being used.
- 6.c. When not welding, make certain no part of the electrode circuit is touching the work or ground. Accidental contact can cause overheating and create a fire hazard.
- 6.d. Do not heat, cut or weld tanks, drums or containers until the proper steps have been taken to insure that such procedures will not cause flammable or toxic vapors from substances inside. They can cause an explosion even though they have been "cleaned". For information, purchase "Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping That Have Held Hazardous Substances", AWS F4.1 from the American Welding Society (see address above).
- 6.e. Vent hollow castings or containers before heating, cutting or welding. They may explode.
- 6.f. Sparks and spatter are thrown from the welding arc. Wear oil free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes and a cap over your hair. Wear ear plugs when welding out of position or in confined places. Always wear safety glasses with side shields when in a welding area.
- 6.g. Connect the work cable to the work as close to the welding area as practical. Work cables connected to the building framework or other locations away from the welding area increase the possibility of the welding current passing through lifting chains, crane cables or other alternate circuits. This can create fire hazards or overheat lifting chains or cables until they fail.
- 6.h. Also see item 1.c.
- 6.i. Read and follow NFPA 51B "Standard for Fire Prevention During Welding, Cutting and Other Hot Work", available from NFPA, 1 Batterymarch Park, PO box 9101, Quincy, MA 022690-9101.
- 6.j. Do not use a welding power source for pipe thawing.



## CYLINDER MAY EXPLODE IF DAMAGED.

- 7.a. Use only compressed gas cylinders containing the correct shielding gas for the process used and properly operating regulators designed for the gas and pressure used. All hoses, fittings, etc. should be suitable for the application and maintained in good condition. 
- 7.b. Always keep cylinders in an upright position securely chained to an undercarriage or fixed support.
- 7.c. Cylinders should be located:
  - Away from areas where they may be struck or subjected to physical damage.
  - A safe distance from arc welding or cutting operations and any other source of heat, sparks, or flame.
- 7.d. Never allow the electrode, electrode holder or any other electrically "hot" parts to touch a cylinder.
- 7.e. Keep your head and face away from the cylinder valve outlet when opening the cylinder valve.
- 7.f. Valve protection caps should always be in place and hand tight except when the cylinder is in use or connected for use.
- 7.g. Read and follow the instructions on compressed gas cylinders, associated equipment, and CGA publication P-1, "Precautions for Safe Handling of Compressed Gases in Cylinders," available from the Compressed Gas Association, 14501 George Carter Way Chantilly, VA 20151.



## FOR ELECTRICALLY POWERED EQUIPMENT.



- 8.a. Turn off input power using the disconnect switch at the fuse box before working on the equipment.
- 8.b. Install equipment in accordance with the U.S. National Electrical Code, all local codes and the manufacturer's recommendations.
- 8.c. Ground the equipment in accordance with the U.S. National Electrical Code and the manufacturer's recommendations.

**Refer to**  
**<http://www.lincolnelectric.com/safety>**  
**for additional safety information.**

## Electromagnetic Compatibility (EMC)

### Conformance

Products displaying the CE mark are in conformity with European Community Council Directive of 15 Dec 2004 on the approximation of the laws of the Member States relating to electromagnetic compatibility, 2004/108/EC. It was manufactured in conformity with a national standard that implements a harmonized standard: EN 60974-10 Electromagnetic Compatibility (EMC) Product Standard for Arc Welding Equipment. It is for use with other Lincoln Electric equipment. It is designed for industrial and professional use.

### Introduction

All electrical equipment generates small amounts of electromagnetic emission. Electrical emission may be transmitted through power lines or radiated through space, similar to a radio transmitter. When emissions are received by other equipment, electrical interference may result. Electrical emissions may affect many kinds of electrical equipment; other nearby welding equipment, radio and TV reception, numerical controlled machines, telephone systems, computers, etc. Be aware that interference may result and extra precautions may be required when a welding power source is used in a domestic establishment.

### Installation and Use

The user is responsible for installing and using the welding equipment according to the manufacturer's instructions. If electromagnetic disturbances are detected then it shall be the responsibility of the user of the welding equipment to resolve the situation with the technical assistance of the manufacturer. In some cases this remedial action may be as simple as earthing (grounding) the welding circuit, see Note. In other cases it could involve construction of an electromagnetic screen enclosing the power source and the work complete with associated input filters. In all cases electromagnetic disturbances must be reduced to the point where they are no longer troublesome.

Note: The welding circuit may or may not be earthed for safety reasons according to national codes. Changing the earthing arrangements should only be authorized by a person who is competent to access whether the changes will increase the risk of injury, e.g., by allowing parallel welding current return paths which may damage the earth circuits of other equipment.

### Assessment of Area

Before installing welding equipment the user shall make an assessment of potential electromagnetic problems in the surrounding area. The following shall be taken into account:

- a) other supply cables, control cables, signaling and telephone cables; above, below and adjacent to the welding equipment;
- b) radio and television transmitters and receivers;
- c) computer and other control equipment;
- d) safety critical equipment, e.g., guarding of industrial equipment;
- e) the health of the people around, e.g., the use of pacemakers and hearing aids;
- f) equipment used for calibration or measurement
- g) the immunity of other equipment in the environment. The user shall ensure that other equipment being used in the environment is compatible. This may require additional protection measures;
- h) the time of day that welding or other activities are to be carried out.

## Electromagnetic Compatibility (EMC)

The size of the surrounding area to be considered will depend on the structure of the building and other activities that are taking place. The surrounding area may extend beyond the boundaries of the premises.

### Methods of Reducing Emissions

#### Mains Supply

Welding equipment should be connected to the mains supply according to the manufacturer's recommendations. If interference occurs, it may be necessary to take additional precautions such as filtering of the mains supply. Consideration should be given to shielding the supply cable of permanently installed welding equipment, in metallic conduit or equivalent. Shielding should be electrically continuous throughout its length. The shielding should be connected to the welding power source so that good electrical contact is maintained between the conduit and the welding power source enclosure.

#### Maintenance of the Welding Equipment

The welding equipment should be routinely maintained according to the manufacturer's recommendations. All access and service doors and covers should be closed and properly fastened when the welding equipment is in operation. The welding equipment should not be modified in any way except for those changes and adjustments covered in the manufacturer's instructions. In particular, the spark gaps of arc striking and stabilizing devices should be adjusted and maintained according to the manufacturer's recommendations.

#### Welding Cables

The welding cables should be kept as short as possible and should be positioned close together, running at or close to floor level.

#### Equipotential Bonding

Bonding of all metallic components in the welding installation and adjacent to it should be considered. However, metallic components bonded to the work piece will increase the risk that the operator could receive a shock by touching these metallic components and the electrode at the same time. The operator should be insulated from all such bonded metallic components.

#### Earthing of the Workpiece

Where the workpiece is not bonded to earth for electrical safety, not connected to earth because of its size and position, e.g., ships hull or building steelwork, a connection bonding the workpiece to earth may reduce emissions in some, but not all instances. Care should be taken to prevent the earthing of the workpiece increasing the risk of injury to users, or damage to other electrical equipment. Where necessary, the connection of the workpiece to earth should be made by a direct connection to the workpiece, but in some countries where direct connection is not permitted, the bonding should be achieved by suitable capacitance, selected according to national regulations.

#### Screening and Shielding

Selective screening and shielding of other cables and equipment in the surrounding area may alleviate problems of interference. Screening of the entire welding installation may be considered for special applications<sup>1</sup>.

---

<sup>1</sup> Portions of the preceding text are contained in EN 60974-10: "Electromagnetic Compatibility (EMC) product standard for arc welding equipment."

<b>INSTALLATION</b> .....	<b>SECTION A</b>
GRAPHIC SYMBOLS .....	A-1
TECHNICAL SPECIFICATIONS - DUAL MAVERICK® 200/200X (K4382-1) .....	A-2
SAFETY PRECAUTIONS .....	A-3
VRD (VOLTAGE REDUCTION DEVICE) .....	A-3
LOCATION AND VENTILATION .....	A-4
STORING .....	A-4
STACKING .....	A-4
ANGLE OF OPERATION .....	A-4
LIFTING .....	A-4
HIGH ALTITUDE OPERATION .....	A-5
HIGH TEMPERATURE OPERATION .....	A-5
TOWING .....	A-5
VEHICLE MOUNTING .....	A-5
PRE-OPERATION ENGINE SERVICE .....	A-5
OIL .....	A-5
FUEL - USE DIESEL FUEL ONLY .....	A-6
ENGINE COOLANT .....	A-6
BATTERY CONNECTION .....	A-6
MUFFLER OUTLET PIPE .....	A-6
SPARK ARRESTOR .....	A-6
CASE FRONT CONTROLS .....	A-7
WELDING TERMINALS .....	A-9
WELDING OUTPUT CABLES .....	A-9
MACHINE GROUNDING .....	A-9
REMOTE CONTROL .....	A-10
STANDBY POWER CONNECTIONS .....	A-10
CABLE INDUCTANCE AND ITS EFFECTS ON WELDING .....	A-10
WIRE WELDING SET-UP, SPOOL GUN .....	A-11
CONNECTION OF WIRE FEEDERS WITH CONTROL CABLE (14 PIN) .....	A-12
AUXILIARY POWER RECEPTACLES .....	A-12
AUXILIARY POWER .....	A-12
CONNECTION OF ACROSS THE ARC WIRE FEEDERS TO THE DUAL MAVERICK® 200/200X .....	A-13
 <b>OPERATION</b> .....	 <b>SECTION B</b>
SAFETY PRECAUTIONS .....	B-1
GENERAL DESCRIPTION .....	B-1
FOR AUXILIARY POWER .....	B-1
ENGINE OPERATION .....	B-1
ADD FUEL .....	B-1
HAND PRIMER .....	B-1
RECOMMENDED APPLICATIONS .....	B-2
GENERATOR .....	B-2
AUTO-START INSTRUCTION .....	B-2
BREAK-IN PERIOD .....	B-2
ENGINE OPERATION .....	B-3
TYPICAL FUEL CONSUMPTION .....	B-3
WELDER OPERATION .....	B-4
PARALLELING .....	B-6
AUXILIARY POWER OPERATION .....	B-7
DISPLAY OPERATION .....	B-9
HOME SCREEN .....	B-9
STICK WELDING .....	B-10
MIG/FCAW WELDING .....	B-12
CROSSLINC .....	B-13
SPOOL GUN .....	B-14
SPOOL GUN SYNERGIC CONTROL MODE .....	B-15
PULSE MODE .....	B-16
SPOT TIME MODE .....	B-16
ENGINE STATUS SCREEN .....	B-17
ENGINE INFO .....	B-18



SET-UP .....	B-19
MACHINE SELECT .....	B-23
CROSSLINC: ON/OFF .....	B-23
SPOOL GUN CALIBRATION .....	B-24
ENGINE SERVICE KIT .....	B-24
PRODUCTIVITY METRICS .....	B-25

**ACCESSORIES .....SECTION C**

**MAINTENANCE.....SECTION D**

SAFETY PRECAUTIONS .....	D-1
ROUTINE AND PERIODIC MAINTENANCE .....	D-1
ENGINE MAINTENANCE .....	D-1
AIR FILTER .....	D-1
FUEL FILTERS .....	D-3
COOLING SYSTEM .....	D-3
NAMEPLATES / WARNING DECALS MAINTENANCE .....	D-3
WELDER / GENERATOR MAINTENANCE .....	D-3
FAN BELT CHANGE.....	D-3
OIL CHANGE.....	D-3
BATTERY HANDLING .....	D-4
PREVENTING ELECTRICAL DAMAGE.....	D-4
PREVENTING BATTERY DISCHARGE .....	D-4
PREVENTING BATTERY BUCKLING .....	D-4
CHARGING THE BATTERY .....	D-4

**Theory of Operations.....SECTION E**

**Troubleshooting Guide.....SECTION F**

**Wiring, Connection Diagrams and Dimension Prints.....SECTION G**

**Glossary.....APPENDIX A**

**Parts List.....PARTS.LINCOLNELECTRIC.COM**

CONTENT/DETAILS MAY BE CHANGED OR UPDATED WITHOUT NOTICE. FOR MOST CURRENT INSTRUCTION MANUALS, GO TO PARTS.LINCOLNELECTRIC.COM.

**GRAPHIC SYMBOLS**

The following graphics appear in the Maverick or in the manual.

	Warning or Caution		Hot Surface		Earth Ground
	Instructions		Fire or explosion		Circuit Breaker
	Fumes and Gases		Battery explosion		Welding Amperage
	Explosion		Battery acid		Welding Voltage
	Arc Rays		System Factory Reset		Wire Feed Speed
	Moving Parts		Temperature		Arc Length
	Falling Equipment		Positive Output		3 Phase Generator
	Electric Shock		Negative Output		Direct Current
	Open Circuit Voltage		SMAW welding		Choke
	Output Current		GMAW/FCAW welding		Stop
	Output Voltage		GTAW welding		Auto Idle
	Duty Cycle		Spool Gun		High Idle
	Home		Carbon Arc Gouging		Start
	Remote		Downhill Pipe welding		Select
	Help		Engine		Scroll
	Back		Set-up		Fuel
	Oil		Hot Start		CrossLinc
	Air Filter		Arc Force		Units
	Spark Plug		Pulse		Locked
	Fuel Filter		Spot Time		Unlocked
	Brushes		Pinch		Time
	Battery				Brightness

# INSTALLATION

## TECHNICAL SPECIFICATIONS - DUAL MAVERICK® 200/200X (K4382-1)

INPUT - DIESEL ENGINE					
MAKE/MODEL	DESCRIPTION	SPEED (RPM)	DISPLACEMENT CU. IN. (LTRS.)	STARTING SYSTEM	DRY CAPACITIES
Kubota D902 T4F	3 CYLINDER 24.8 HP (18.5 kW) 3600 RPM DIESEL ENGINE	HIGH IDLE 3600 FULL LOAD 3600 LOW IDLE 2500	54.80 (0.898)	12 VDC BATTERY & STARTER	FUEL: 20 GAL. (75.7 L) OIL: .97 GAL. (3.7 L) RADIATOR COOLANT: 0.9 GAL. (3.3 L) WET: 0.73 GAL. (2.8 L)
			BORE X STROKE INCH (MM) 2.83 X 2.90 (72 X 73.6)		
RATED OUTPUT @ 104°F(40°C) - WELDER					
SINGLE MODE			DUAL MODE		
DUTY CYCLE	WELDING OUTPUT	VOLTS AT RATED AMPS	DUTY CYCLE	WELDING OUTPUT	VOLTS AT RATED AMPS
60% <sup>(2)</sup>	450 A	24.5 VOLTS	60% <sup>(2)</sup>	225 A	24.5 VOLTS
60% <sup>(2)</sup>	335 A	33.4 VOLTS	60% <sup>(2)</sup>	200 A	28 VOLTS
100%	290 A	31.6 VOLTS	100%	170 A	26.8 VOLTS
OUTPUT @ 104°F (40°C) – WELDER AND GENERATOR					
SINGLE MODE			DUAL MODE		
<b>WELDING RANGE</b> 50 A - 450 AMPS CC 30 A - 370 AMPS CV 20 A - 255 AMPS TIG			<b>WELDING RANGE</b> 30 A - 225 AMPS CC 30 A - 220 AMPS CV 20 A - 255 AMPS TIG		
<b>OPEN CIRCUIT VOLTAGE</b> 80 MAX OCV @ 3600 RPM			<b>OPEN CIRCUIT VOLTAGE</b> 80 MAX OCV @ 3600 RPM		
<b>AUXILIARY POWER</b> 120 VAC (2) X 2400 WATTS, 60 Hz, SINGLE PHASE 240 VAC X 10000 WATTS, 60 Hz, SINGLE PHASE			<b>AUXILIARY POWER</b> 120 VAC (2) X 2400 WATTS, 60 Hz, SINGLE PHASE 240 VAC X 10000 WATTS, 60 Hz, SINGLE PHASE		
PHYSICAL DIMENSIONS					
HEIGHT	WIDTH	DEPTH	WEIGHT		
36.1 IN. (917 MM)	27.0 IN. (686 MM)	65.0 IN. (1651 MM)	1160 LBS. (526 KG.)		

Lift Bail weight rating 2130 lbs. (966 kg.) Maximum.

- (1) Output rating in watts is equivalent to volt-amperes at unity power factor. Output voltage is within +/- 10% at all loads up to rated capacity. When welding, available auxiliary power will be reduced.
- (2) Rated for 60% when above 91° F (33° C). When below, the machine can be run at 100% duty cycle.

## SAFETY PRECAUTIONS

Only qualified personnel should install, use, or service this equipment.

### WARNING

Do not attempt to use this equipment until you have thoroughly read the engine manufacturer's manual supplied with your welder. It includes important safety precautions, detailed engine starting, operating and maintenance instructions, and parts lists.

#### ELECTRIC SHOCK can kill.

- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.



#### ENGINE EXHAUST can kill.

- Use in open, well ventilated areas or vent exhaust outside.



#### MOVING PARTS can injure.

- Do not operate with doors open or guards off.
- Stop engine before servicing.
- Keep away from moving parts.



See additional warning information at front of this operator's manual.

### VRD (VOLTAGE REDUCTION DEVICE)

The VRD feature provides additional safety in the Stick, Pipe, Tig and Gouge modes especially in an environment with a higher risk of electric shock such as wet areas and hot humid sweaty conditions.

The VRD reduces the OCV (Open Circuit Voltage) at the welding output terminals while not welding to less than 13V DC when the resistance of the output circuit is above 200Ω (ohms).


The VRD requires that the welding cable connections be kept in good electrical condition because poor connections will contribute to poor starting. Having good electrical connections also limits the possibility of other safety issues such as heat-generated damage, burns and fires.

While VRD is active, no crossline devices or across the arc feeders are to be used. Both VRD and crossline/across the arc feeders are mutually exclusive features.

The machine is shipped with the VRD switch in the "OFF" position. To turn it "ON" or "OFF":


1. Switch the High Idle/Run - Stop switch to the Stop position.
2. Disconnect the negative battery cable.
3. Remove the 8 screws on the upper panel (Fig A.1). Pull out the panel to have access to the PC control boards (Fig A.1).

FIGURE A.1



4. Locate VRD switches (as marked in Fig A.2) on both PC control boards. Left position on each switch indicates "OFF" state; right position on each switch indicates "ON" state. PC Control Board on the left is for settings for the left user. PC Control board on the right is for settings for the right user.

FIGURE A.2



5. Set VRD switches as desired. Toggle left for "OFF". Toggle right for "ON"
6. Reinstall the upper panel with screws from Step 3. Turn on the High Idle/Run switch. Confirm VRD status on the LCD screen display related to that PC board.

When the VRD switch is in the "ON" position. The display will show a green tab with "VOLTS<30". If the VRD switch is in the "ON" position and stud voltage is above 30 volts or while welding, the display will show a red tab with "VOLTS>30".

### LOCATION AND VENTILATION

The welder should be located to provide an unrestricted flow of clean, cool air to the cooling air inlets and to avoid restricting the cooling air outlets. Locate the welder so that the engine exhaust fumes are properly vented to an outside area.

## CAUTION

### DO NOT MOUNT OVER COMBUSTIBLE SURFACES

Where there is a combustible surface directly under stationary or fixed electrical equipment, that surface should be covered with a steel plate at least .06"(1.6mm) thick, which should extend not less than 5.90"(150mm) beyond the equipment on all sides.

### STORING

1. Store the machine in a cool, dry place when it is not in use. Protect it from dust and dirt. Keep it where it can't be accidentally damaged from construction activities, moving vehicles, and other hazards.
2. Drain the engine oil and refill with fresh 10W30 oil. Run the engine for about five minutes to circulate oil to all the parts. See the MAINTENANCE section of this manual for details on changing oil.
3. Remove the battery, recharge it, and adjust the electrolyte level. Store the battery in a dry, dark place.

### STACKING

Dual Maverick® 200/200X machines cannot be stacked.

### ANGLE OF OPERATION

To achieve optimum engine performance the Dual Maverick® 200/200X should be run in a level position.

The maximum angle of operation for the machine is 35 degrees continuous in all directions.

When operating the welder at an angle, provisions must be made for checking and maintaining the oil level at the normal (FULL) oil capacity. The effective fuel capacity will be slightly less than the specified 20 gal.(75.7 ltrs.).

### LIFTING

The Dual Maverick® 200/200X weighs approximately 1300 lbs.(590 kg) with a full tank of fuel, 1160 lbs. (525 kg) without fuel. A lift bail and fork pockets are installed on the machine. Lift welder ONLY using the lift bail or fork pockets.

## WARNING

**FALLING EQUIPMENT can cause injury.**

- Lift only with equipment of adequate lifting capacity.
- Be sure machine is stable when lifting.
- Do not lift this machine using lift bail if it is equipped with a heavy accessory such as trailer or gas cylinder.
- Do not lift machine if lift bail is damaged.
- Do not operate machine while suspended from lift bail.
- **DO NOT EXCEED MAXIMUM LIFT BAIL WEIGHT RATING.**

( SEE TECHNICAL SPECIFICATIONS PAGE)



**HIGH ALTITUDE OPERATION**

The naturally aspirated engine will run correctly up to an altitude of 600 m (2000 ft.) If the engine is to operate at an altitude above this, an increase in smoke may be seen. This is normal for a naturally aspirated engine. Below is a table showing the power output loss as the altitude increases. All values in the table are with respect to an ambient temperature of 104°F (40°C).

**TABLE A.1 - ALTITUDE POWER LOSS (%)**

ALTITUDE FT (M)	POWER OUTPUT LOSS
0 (0)	0%
1640 (500)	5%
3280 (1000)	10%
4920 (1500)	14%
6560 (2000)	18%
8200 (2500)	22%
9840 (3000)	26%
11480 (3500)	30%

**HIGH TEMPERATURE OPERATION**

At temperatures above 40°C (104°F), output voltage derating may be necessary. While operating the Dual Maverick 200/200X continuously (100% Duty Cycle) at an ambient temperature of 40°C, a weld output of 9.2 KW should not be exceeded.

**TOWING**

The recommended trailer for use with this equipment for road, in-plant and yard towing by a vehicle (1) is Lincoln's K2636-1. If the user adapts a non-Lincoln trailer, he must assume responsibility that the method of attachment and usage does not result in a safety hazard nor damage the welding equipment. Some of the factors to be considered are as follows:

1. Design capacity of trailer vs. weight of Lincoln equipment and likely additional attachments.
2. Proper support of, and attachment to, the base of the welding equipment so that there will be no undue stress to the trailer's framework.
3. Proper placement of the equipment on the trailer to insure stability side to side and front to back when being moved and when standing by itself.
4. Typical conditions of use, such as travel speed, roughness of surface on which the trailer will be operated, and environmental conditions.
5. Proper preventative maintenance of trailer.
6. Conformance with federal, state and local laws(1).

(1) Consult applicable federal, state and local laws regarding specific requirements for use on public highways.

**VEHICLE MOUNTING**

 **WARNING**


Improperly mounted concentrated loads may cause unstable vehicle handling and tires or other components to fail.

- Only transport this Equipment on serviceable vehicles which are rated and designed for such loads.
- Distribute, balance and secure loads so vehicle is stable under conditions of use.
- Do not exceed maximum rated loads for components such as suspension, axles and tires.
- Mount equipment base to metal bed or frame of vehicle.
- Follow vehicle manufacture's instructions.


**PRE-OPERATION ENGINE SERVICE**

READ the engine operating and maintenance instructions supplied with this machine.

 **WARNING**

- Keep hands away from the engine muffler or HOT engine parts. 
- Stop engine and allow to cool before fuelling.
- Do not smoke when fuelling.
- Fill fuel tank at a moderate rate and do not over-fill.
- Wipe up spilled fuel and allow fumes to clear before starting engine.
- Keep sparks and flame away from tank.

**OIL**

The Dual Maverick® 200/200X is shipped with the engine crankcase filled with high quality SAE 10W-30 oil (API class CD or better). Check the engine oil levels before starting the engine. If it is not up to the full mark on the dip stick, add oil as required. Check the oil level every four hours of running time during the first 50 running hours. DO NOT operate with oil below low mark on dipstick. DO NOT fill above full mark on dipstick. Refer to the engine Operator's Manuals for specific oil recommendations and break-in information. The oil change interval is dependent on the quality of the oil and the operating environment. Refer to the engine Operator's Manuals for the proper service and maintenance intervals. 

**FUEL - USE DIESEL FUEL ONLY****Low sulphur or ultra low sulphur fuel in US & Canada.**

Fill the fuel tank with clean, fresh diesel fuel. The capacity of the fuel tank is approximately 20 gallons (75.7 liters). See engine Operator's Manual for specific fuel recommendations. Running out of fuel may require bleeding the fuel injection pump.



NOTE: Before starting the engine, open the fuel shutoff valve on the fuel filter located on the lift bale.

**ENGINE COOLANT**
 **WARNING**
**HOT COOLANT can burn skin.**

Do not remove cap if radiator is hot.

The welder is shipped with the engine and radiator filled with a 50% mixture of ethylene glycol and water. See the MAINTENANCE section and the engine Operator's Manual for more information on coolant.

**BATTERY CONNECTION**
 **WARNING**
**GASES FROM BATTERY can explode.**

Keep sparks, flame and cigarettes away from battery.



To prevent **EXPLOSION** when:

- **INSTALLING A NEW BATTERY** — disconnect negative cable from old battery first and connect to new battery last.
- **CONNECTING A BATTERY CHARGER** — remove battery from welder by disconnecting negative cable first, then positive cable and battery clamp. When reinstalling, connect negative cable last. Keep well ventilated.
- **USING A BOOSTER** — connect positive lead to battery first then connect negative lead to negative battery lead at engine foot.

**BATTERY ACID can burn eyes and skin.**

- Wear gloves and eye protection and be careful when working near battery.
- Follow instructions printed on battery.



**IMPORTANT:** To prevent **ELECTRICAL DAMAGE** WHEN:

- Installing new battery.
- Using a booster.

Use correct polarity — **NEGATIVE GROUND.**

The Dual Maverick® 200/200X is shipped with the negative battery cable disconnected. Before you operate the machine, make sure the High Idle / Run - Stop switch is in the STOP position and attach the disconnected cable securely to the negative (-) battery terminal.

Remove the insulating cap from the negative battery terminal. Replace and tighten negative battery cable terminal. NOTE: This machine is furnished with a wet charged battery; if unused for several months, the battery may require a booster charge. Be sure to use the correct polarity when charging the battery.

**MUFFLER OUTLET PIPE**

Remove the plastic plug covering the muffler outlet tube. Using the clamp provided secure the outlet pipe to the outlet tube with the pipe positioned such that it will direct the exhaust in the desired position.


**SPARK ARRESTOR**

Some federal, state or local laws may require that petrol or diesel engines be equipped with exhaust spark arrestors when they are operated in certain locations where unarrested sparks may present a fire hazard. When required by local regulations, a suitable spark arrestor, must be installed and properly maintained.

 **CAUTION**

An incorrect arrestor may lead to damage to the engine or adversely affect performance.

FIGURE A.3 - CASE FRONT CONTROLS



**CASE FRONT CONTROLS**

1. **LCD SCREEN, IP67 RATED OPERATOR A** - The LCD screen displays information about welding mode, output voltage or current, engine status and machine settings. It allows operator to select welding mode and read the output voltage or current when presetting using the output control knob. During welding, the screen displays the actual output voltage (VOLTS) and current (AMPS). A memory feature holds the screens on for 5 seconds after welding is stopped. This allows the operator to read the actual current and voltage just prior to when welding was ceased. In engine status section, information about engine hours, filter condition, engine oil and other service items are displayed.
2. **OUTPUT CONTROL OPERATOR A** - The OUTPUT KNOB is used to preset the output voltage or current as displayed on the LCD screen for the six welding modes. When in the ARC GOUGING or CV-WIRE modes and when a remote control is connected to the 6-Pin or 14-Pin Connector, the auto-sensing circuit automatically switches the OUTPUT CONTROL from control at the welder to the remote control. When in

DOWNHILL PIPE and CC-STICK modes if a remote control is connected to the 6-Pin or 14 Pin Connectors, the output is controlled by the remote and the output control on the machine is used to set the maximum current range for the remote.

3. **SINGLE/DUAL OPERATOR MODE SWITCH** - The switch allows the user to choose between Single Operator and Dual Operator weld modes. Single Operator mode is when the switch is in the “Left” position. Dual Operator mode is when the switch is in the “Right” position.
4. **14-PIN WIRE FEEDER CONNECTION OPERATOR A** - For attaching wire feeder control cables. Includes contactor closure circuit, auto-sensing remote control circuit, and 42V power. The remote control circuit operates the same as the 6 Pin Amphenol. NOTE: That 115V is not available.
5. **WIRE FEEDER POLARITY SWITCH** - Matches the polarity of the wire feeder voltmeter to the polarity of the electrode.
6. **6-PIN REMOTE CONTROL CONNECTOR OPERATOR A** - For attaching optional remote control equipment. Includes auto-sensing remote control circuit.





7. **20 AMP CIRCUIT BREAKER** - Protects the 120V, single phase receptacle.
8. **20 AMP CIRCUIT BREAKER** - Protects the 120V, single phase receptacle.
9. **50 AMP CIRCUIT BREAKER** - Protects the 240V, single phase receptacle.
10. **120VAC SINGLE PHASE AC DOMESTIC PLUGS**
11. **240VAC SINGLE PHASE**
12. **POSITIVE AND NEGATIVE WELD TERMINAL OPERATOR A** - Provides a connection point for the electrode and work cables.
13. **GLOW PLUG PUSH BUTTON** - When pushed activates the glow plugs. Glow plug should not be activated for more than 20 seconds continuously.
14. **RUN / STOP SWITCH** - RUN position energizes the engine prior to starting. STOP position stops the engine. The oil pressure interlock switch prevents battery drain if the switch is left in the RUN position and the engine is not operating.
15. **START PUSH BUTTON**- Energizes the starter motor to crank the engine.
16. **BATTERY BREAKER** - For protection of Battery Charging Circuit.
17. **LCD SCREEN, IP67 RATED OPERATOR B**
18. **OUTPUT CONTROL OPERATOR B**
19. **6-PIN REMOTE CONTROL CONNECTION OPERATOR B**
20. **WIRE FEEDER POLARITY SWITCH OPERATOR B**
21. **14-PIN WIRE FEEDER CONNECTION OPERATOR B**
22. **GFCI** – protection is required for 120V outlet receptacles.
23. **WIRE FEEDER CIRCUIT BREAKER**- 42V WIRE FEEDER BREAKERS.
24. **POSITIVE AND NEGATIVE WELD TERMINAL OPERATOR B**
25. **7-PIN SPOOL GUN CONNECTION OPERATOR A** - For attaching optional spool gun equipment. Includes contactor closure circuit and auto-sensing remote control circuit.
26. **7-PIN SPOOL GUN CONNECTION OPERATOR B** - For attaching optional spool gun equipment. Includes contactor closure circuit and auto-sensing remote control circuit.

**WELDING TERMINALS**

From the main screen select MIG / FCAW / TIG / ROOT WAVE welding. Press knob to select screen that shows Weld Output Override. (Figure A.4)

Press knob to select either OFF - output controlled by welding gun switch or ON - output always ON (electrode always hot).

**FIGURE A.4**



**WELDING OUTPUT CABLES**

With the engine off, connect the electrode and work cables to the terminals provided. These connections should be checked periodically and tightened if necessary.

Listed in Table A.2 are copper cable sizes recommended for the rated current and duty cycle. Lengths stipulated are the distance from the welder to work and back to the welder again. Cable sizes are increased for greater lengths primarily for the purpose of minimizing cable voltage drop.

**TABLE A.2 TOTAL COMBINED LENGTH OF ELECTRODE AND WORK CABLES**

Cable Length	Cable Size for 400 Amps 60% Duty Cycle	Cable Size for 300 AMPS 60% Duty Cycle
Lengths up to 100 ft. (30m)	2/0 AWG	1/0 AWG
100 ft. (30m) to 150 ft. (61m)	2/0 AWG	1/0 AWG
150 ft. (46m) to 200 ft. (61m)	3/0 AWG	2/0

**MACHINE GROUNDING**

Because this portable engine driven welder creates its own power, it is not necessary to connect its frame to an earth ground, unless the machine is connected to premises wiring (home, shop, etc.).

**⚠ WARNING**

To prevent dangerous electric shock, other equipment to which this engine driven welder supplies power must:

- Be grounded to the frame of the welder using a grounded type plug or be double insulated.
- Do not ground the machine to a pipe that carries explosive or combustible material.

When this welder is mounted on a truck or trailer, its frame must be securely connected to the metal frame of the vehicle. When this engine driven welder is connected to premises wiring such as that in a home or shop, its frame must be connected to the system earth ground. See further connection instructions in the section entitled "Standby Power Connections" as well as the article on grounding in the latest National Electrical Code and the local codes.

In general, if the machine is to be grounded, it should be connected with a #8 or larger copper wire to a solid earth ground such as a metal ground stake going into the ground for at least 10 Feet or to the metal framework of a building which has been effectively grounded.

The National Electric Code lists a number of alternate means of grounding electrical equipment. A machine grounding stud marked with the symbol Ⓧ is provided on the front of the welder.

**REMOTE CONTROL**

The Dual Maverick® 200/200X is equipped with a 6-pin and a 14-pin connector. The 6-pin connector is for connecting the K857 or K857-1 Remote Control or for TIG welding, the K870 foot Amptrol or the K963-3 hand Amptrol. When in the CC-STICK, ARC GOUGING, TIG or CV-WIRE modes and when a remote control is connected to the 6-pin Connector, the auto-sensing circuit automatically switches the OUTPUT control from control at the welder to remote control.

The 14-pin connector is used to directly connect a wire feeder control cable. In the CV-WIRE mode, when the control cable is connected to the 14-pin connector, the auto-sensing circuit automatically makes the Output Control inactive and the wire feeder voltage control active.

NOTE: Wire feeders should NOT be used while in TIG mode.

In each case, once connected control maybe optionally changed back to the control panel using the display remote button. The maximum and minimum current range can be setup / modified in display.

**⚠ WARNING**

NOTE: When a wire feeder with a built in welding voltage control is connected to the 14-pin connector, do not connect anything to the 6-pin connector.

**STANDBY POWER CONNECTIONS**

The Dual Maverick® 200/200X is suitable for temporary, standby or emergency power using the engine manufacturer’s recommended maintenance schedule.

The Dual Maverick® 200/200X can be permanently installed as a standby power unit for 240 VAC, single phase, 42 amp service.

Connections must be made by a licensed electrician who can determine how the power can be adapted to the particular installation and comply with all applicable electrical codes.

Take necessary steps to assure load is limited to the capacity of the Dual Maverick® 200/200X.


**CABLE INDUCTANCE AND ITS EFFECTS ON WELDING**

Excessive cable inductance will cause the welding performance to degrade. There are several factors that contribute to the overall inductance of the cabling system including cable size, length, and number of loops. To reduce cable inductance do not loop welding cables see Figure A.5, especially consistently in one direction. If there are loops separate them as much as possible and make the loop as large as possible. A straight or zig-zag pattern between the machine and work is recommended see Figure A.5.

If a spooling mechanism is used to store the welding cables, unspool the cables. Avoid leaving more than 30 feet of cable on each storage spool. For best performance completely unspool the welding cables.

For optimal performance when welding with two operators maintain some distance between the left and right sets of welding cables and use individual work piece cables.


**FIGURE A.5**



WIRE WELDING SET-UP, SPOOL GUN

Electrode Positive (+) shown

FIGURE A.6



In the spool gun mode, the weld output is controlled by the trigger of the spool gun. The knob on the Dual Maverick display sets voltage and the spool gun knob sets wire feed speed. Rotating the knob on the spool gun adjusts the work point (wire feed speed). Spool gun modes have the option of being “synergic” (when the wire feed speed is changed, the voltage is automatically modified up or down to maintain a similar arc length).


Spool guns are also compatible with other wire feed modes, such as MIG, FCAW and ROOT WAVE. When in a wire feed mode and the spool gun is connected, the wire feed speed will adjust to match the potentiometer located on the spool gun, as long as the wire feed speed is above 70. The wire feed speed may be adjusted for a separate wire feeder while the spool gun is connected. If the spool gun’s potentiometer is changed to 0 (the

spool gun pot being adusted all the way to CCW) the user may manually adjust the wire feed speed.

If desired, a remote can be plugged into the 6 pin connector for setting the voltage away from the Dual Maverick.

The best spool gun operation is obtained with the Magnum Pro LX GT spool gun with mechanical gas flow trigger and Magnum Pro consumables. The standard Magnum PRO 250 LX gun is also supported but requires an external gas control. The Magnum SG spool gun and Magnum PRO 100 SG spool gun are not supported.

FIGURE A.7



**CONNECTION OF WIRE FEEDERS WITH CONTROL CABLE (14 PIN)**

**⚠ WARNING**

Shut off welder before making any electrical connections.

**CONNECTION OF LF-72, LF-74, FLEX FEED 74 HT, FLEX FEED 84, LN-25 PRO DUAL POWER TO THE DUAL MAVERICK® 200/200X**

**NOTE:** The Dual Maverick 200/200X can operate two different wire feeders at the same time.

- Shut the welder off.
- Set the "WIRE FEEDER VOLTMETER" switch to either "+" or "-" as required by the electrode being used.
- For electrode Positive, connect the electrode cable to the "+" terminal of the welder and work cable to the "-" terminal of the welder. For electrode Negative, connect the electrode cable "-" terminal of the welder and work cable to the "+" terminal of the welder.
- Using the display Set "MODE" to MIG/FCAW/ROOT WAVE.
- Adjust the "PINCH" setting to desired Crispness. SOFT for MIG and CRISP for Innershield.
- Set the "Weld Output Override" to the desired settings using the display.
- Connect the 14 pin control cable from the wire feeder to the engine drive (See Figure A.8).
- This procedure can be done for both "Single" and "Dual" operator modes.

**AUXILIARY POWER RECEPTACLES**

For heavy loads switch the "HIGH IDLE/RUN-STOP" control switch to the "High Idle" mode and set weld output at max.

The auxiliary power capacity is 2400 Watts continuous of 120 VAC 60 Hz single phase power for each of the 2 receptacles and 10,000 Watts continuous of 240VAC 60 Hz single phase power.

**AUXILIARY POWER**

**⚠ CAUTION**

**An electric shock can result in serious injury or death.**


- Always perform the GFCI test before using the generator. If the GFCI system fails the test, the machine must be repaired by an authorized service center.
- Due to the risk of power interruption, do not power life support equipment from this machine.
- Unplug accessories and tools before attempting service.
- Close the front service doors protecting the receptacles when operating the machine.
- Do not test or reset the GFCI while at idle speed.
- If the LED blinks, stop using the GFCI receptacle and have it replaced by an authorized service center.
- Long extension cords or cords with poor insulation may allow enough leakage current to trip the GFCI.
- If LED does not light up while machine is in HIGH idle, and resetting does not work, stop using the GFCI receptacle and have it replaced by an authorized service center.

When set to high idle, the output frequency is controlled to 57 to 63 Hz under steady state conditions. If the machine is set to AUTO, the output frequency may drop to 42 Hz with a lower voltage. Verify equipment connected to the Dual Maverick is compatible with the frequency and voltage.

For equipment affected by momentary voltage fluctuations, install a plug-in surge suppressor on the receptacles feeding the equipment.

**The Lincoln Electric Company is not responsible for any damage to electrical components improperly connected to this product.**

**FIGURE A.8  
(14 PIN AMPHENOL WIRE FEEDER)**




**CONNECTION OF ACROSS THE ARC WIRE FEEDERS TO THE DUAL MAVERICK® 200/200X**


These connections instructions apply to both the LN-25X Pro, Activ8X and CrossLinc models.

- Shut the welder off.
- For electrode Positive, connect the electrode cable to the "+" terminal of the welder and work cable to the "-" terminal of the welder. For electrode Negative, connect the electrode cable to the "-" terminal of the welder and work cable to the "+" terminal of the welder.
- Attach the single lead from the front of the feeder to work using the spring clip at the end of the lead. This is a control lead to supply current to the wire feeder motor; it does not carry welding current (See Figure A.9).
- For the CrossLinc Remote, connect the remote in series with the wire feeder and/or electrode and the weld cable of the desired polarity (See Figure A.10).

**FIGURE A.9  
(CROSSLINC WIRE FEEDER)**



**FIGURE A.10  
(CROSSLINC REMOTE)**



**⚠ CAUTION**

Certain electrical devices cannot be powered by this product. See Table A.3

**TABLE A.3  
ELECTRICAL DEVICE USE WITH THIS PRODUCT**

Type	Common Electrical Devices	Possible Concerns
Resistive	Heaters, toasters, incandescent light bulbs, electric range, hot pan, skillet, coffee maker.	NONE
Capacitive	TV sets, radios, microwaves, appliances with electrical control.	Voltage spikes or high voltage regulation can cause the capacitive elements to fail. Surge protection, transient protection, and additional loading is recommended for 100% fail-safe operation. <b>DO NOT RUN THESE DEVICES WITHOUT ADDITIONAL RESISTIVE TYPE LOADS.</b>
Inductive	Single-phase induction motors, drills, well pumps, grinders, small refrigerators, weed and hedge trimmers.	These devices require large current inrush for starting. Some synchronous motors may be frequency sensitive to attain maximum output torque, but they <b>SHOULD BE SAFE</b> from any frequency induced failures.
Capacitive / Inductive	Computers, high resolution TV sets, complicated electrical equipment.	An inductive type line conditioner along with transient and surge protection is required, and liabilities still exist. <b>DO NOT USE THESE DEVICES WITH THIS PRODUCT.</b>

**The Lincoln Electric Company is not responsible for any damage to electrical components improperly connected to this product.**

# OPERATION

## SAFETY PRECAUTIONS

Read and understand this entire section before operating your Dual Maverick® 200/200X.

### WARNING

- Do not attempt to use this equipment until you have thoroughly read the engine manufacturer's manual supplied with your welder. It includes important safety precautions, detailed engine starting, operating and maintenance instructions, and parts lists.

#### ELECTRIC SHOCK can kill.

- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.



#### ENGINE EXHAUST can kill.

- Use in open, well ventilated areas or vent exhaust outside.
- Do not stack anything near the engine.



#### MOVING PARTS can injure.

- Do not operate with doors open or guards off.
- Stop engine before servicing.
- Keep away from moving parts.



- Only qualified personnel should operate this equipment.
- Always operate the welder with the door closed and the side panels in place as these provide maximum protection from moving parts and insure proper cooling air flow.

## GENERAL DESCRIPTION

The Dual Maverick® 200/200X is a dual-operator multi-purpose diesel engine-driven welding power source. The machine uses a brushless alternator / generator for DC multipurpose welding, for 120 VAC single phase, 240 VAC single phase. The DC welding control system uses state of the art Chopper Technology for superior welding performance.

The Dual Maverick® 200/200X is fitted with a selectable VRD (Voltage Reduction Device). The VRD operates in the Stick, TIG, PIPE and GOUGE modes reducing the OCV to <13 volts, increasing operator safety when welding is performed in environments with increased hazard of electric shock such as wet areas and hot, humid sweaty conditions.

## FOR AUXILIARY POWER

Start the engine and set the IDLER control switch to the desired operating mode. Full power is available regardless of the welding control settings providing no welding current is being drawn.

## ENGINE OPERATION

Before Starting the Engine:

- Be sure the machine is on a level surface.
- Open side engine door and remove the engine oil dipstick and wipe it with a clean cloth. Reinsert the dipstick and check the level on the dipstick.
- Add oil (if necessary) to bring the level up to the full mark. Do not overfill. Close engine door.
- DO NOT operate with oil below low mark on dipstick.
- DO NOT fill above full mark on dipstick.
- Check radiator for proper coolant level. (Fill if necessary).
- See Engine Owner's Manual for specific oil and coolant recommendations.



## ADD FUEL

### WARNING

#### DIESEL FUEL can cause fire.

- Stop engine while fueling.
- Do not smoke when fueling.
- Keep sparks and flame away from tank.
- Do not leave unattended while fueling.
- Wipe up spilled fuel and allow fumes to clear before starting engine.
- Do not overfill tank, fuel expansion may cause overflow.



#### DIESEL FUEL ONLY- Low sulfur fuel or ultra low sulphur fuel in U.S.A. and Canada.



- Remove the fuel tank cap.
- Fill the tank. DO NOT FILL THE TANK TO THE POINT OF OVERFLOW.
- Replace the fuel cap and tighten securely.
- See Engine Owner's Manual for specific fuel recommendations.

## HAND PRIMER


Air in the fuel system will cause the following engine problems:

- Hard to start
- Run rough
- Misfire
- Fuel knock

For faster air purge, a small amount of air can be vented from the system by pumping the hand primer (See Figure B.1, Engine Service Side View)



FIGURE B.1 Engine Service Side View



## RECOMMENDED APPLICATIONS

The Dual Maverick® 200/200X provides excellent constant current DC welding output for stick (SMAW) and TIG welding. The Dual Maverick® 200/200X also provides excellent constant voltage DC welding output for MIG (GMAW), Innershield (FCAW), Outershield (FCAW-G) and Metal Core welding. In addition the Dual Maverick® 200/200X can be used for Arc Gouging with carbons up to 3/8" (10mm) in diameter.

The Dual Maverick® 200/200X is not recommended for pipe thawing.

## GENERATOR

The Dual Maverick® 200/200X provides smooth 120 VAC single phase and 240 VAC single phase, 60Hz output for auxiliary power and emergency standby power.

## AUTO-START INSTRUCTION

- To make Auto Start active, press home button for the main menu. Rotate knob to select "Setup" icon and press knob.
  - Auto-Start On/Off: Determines On/Off states for Auto-start feature.
    - Rotate knob to select "Auto-Start On/Off" and press knob to confirm.
    - Rotate knob to select "On" or "Off" and press knob to confirm.
  - Auto-Start No Load Period: Determines when no load is on, how long the welder will be on before auto shutdown. This period will be reset to the setting value when load appears.
    - Rotate knob to select "Auto-Start No Load Period" and press knob to confirm.
    - Rotate knob to change the period from 15 min to 120 min and press knob to confirm.
  - Tap-Start Active Period: Determines how long tap start will be active.
    - Rotate knob to select "Tap-Start Active Period" and press knob to confirm.
    - Rotate knob to change the period from 15 min to 120 min and press knob to confirm.
  - Press home button to go to the main menu. Select welding mode. Confirm Auto Start settings on the display.
- When Auto-Start feature is turned "ON" and a remote is plugged in the engine can be remotely turned off by completing the following pattern on the remote knob:
    - Remote Knob to Min.
    - Remote knob to Max.
    - Remote Knob to Middle.
    - Remote knob to Max.
    - Remote knob to Min.
 Each step should be completed within 3 seconds.
  - Auto start does not work when small loads such as across the arc wire feeders are connected. In this case turn Auto Start off.
  - To restart engine, firmly tap and hold electrode to work for 0.1 to 1 sec. Ensure there is direct contact between metal part of the electrode and work.
  - Pull electrode away from work and wait a few seconds for engine to come up to speed.
- NOTE:** Small loads across the output terminals such as an across the arc wire feeder may cause the auto start count to restart without shutting down the engine. Remove any such small loads. Or turn Auto start off.

## BREAK-IN PERIOD

Lincoln Electric selects high quality, heavy-duty industrial engines for the portable welding machines we offer. While it is normal to see a small amount of crankcase oil consumption during initial operation, excessive oil use, wetstacking (oil or tar like substance at the exhaust port), or excessive smoke is not normal.

Larger machines with a capacity of 350 amperes and higher, which are operated at low or no-load conditions for extended periods of time are especially susceptible to the conditions described above. To accomplish successful engine break-in, most diesel-powered equipment needs only to be run at a reasonably heavy load within the rating of the welder for some period of time during the engine's early life. However, if the welder is subjected to extensive light loading, occasional moderate to heavy loading of the engine may sometimes be necessary. Caution must be observed in correctly loading a diesel/generator unit.

- Connect the welder output studs to a suitable resistive load bank. Note that any attempt to short the output studs by connecting the welding leads together, direct shorting of the output studs, or connecting the output leads to a length of steel will result in catastrophic damage to the generator and voids the warranty.
- Set the welder controls for an output current and voltage within the welder rating and duty cycle. Note that any attempt to exceed the welder rating or duty cycle for any period of time will result in catastrophic damage to the generator and voids the warranty.
- Periodically shut off the engine and check the crankcase oil level.

## CAUTION

**During break-in, subject the Welder to moderate loads. Avoid long periods running at idle. Before stopping the engine, remove all loads and allow the engine to cool several minutes.**

**ENGINE OPERATION**

**STARTING THE ENGINE**

1. Open the engine service compartment door and check that the fuel shutoff valve on the fuel filter separator located on the lift bale is in the open position.
2. Check for proper oil level and coolant level. Close engine service compartment door.
3. Remove heavy auxiliary loads from the AC power receptacles.
4. Firmly set the Operator Selector Switch to Single or Dual. The Operator Selector Switch can be set to Single or Dual mode and must be securely in one of the two positions.
5. Set the RUN/IDLE/STOP switch to "AUTO IDLE".
6. For cold weather starting, press Glow Plug Button and hold 5 to 10 seconds.
7. Press START button until the engine starts or for up to 10 seconds.
8. Release the engine START button when the engine starts.
9. Allow the engine to warm up at low idle speed for several minutes before applying a load and/or switching to high idle. Allow a longer warm up time in cold weather.

**COLD WEATHER STARTING**

With a fully charged battery and the proper weight oil, the engine should start satisfactorily even down to about -5°C (23°F) below this it may be desirable to use the included block heater.

NOTE: Extreme cold weather starting may require longer glow plug operations.

**STOPPING THE ENGINE**

Switch the RUN/IDLE/STOP switch to "STOP". This turns off the voltage supplied to the shutdown solenoid. A backup shutdown can be accomplished by shutting off the fuel valve located on the fuel pre-filter located on the lift bale.

**TYPICAL FUEL CONSUMPTION**

Refer to Table B.1 for typical fuel consumption of the Dual Maverick® 200/200X Engine for various operating settings.

**TABLE B.1**

TYPICAL DUAL MAVERICK 200/200X FUEL CONSUMPTION		
Load	KUBOTA D902 T4F gal./hr (liters/hr)	Operating Time for 20 gallons (75.7 L) (Hours)
Low Idle No Load	0.290 (1.12)	67.55
2500 RPM		
STICK WELD OUTPUT	0.377 (1.42)	53.30
50A @ 22V		
STICK WELD OUTPUT	0.500 (1.85)	40.86
100A @ 24V		
STICK WELD OUTPUT	0.594 (2.30)	32.94
150A @ 26V		
STICK WELD OUTPUT	0.671 (2.60)	29.07
200A @ 28V		
STICK WELD OUTPUT	1.21 (4.58)	16.53
300A @ 32V		
STICK WELD OUTPUT	1.44 (5.40)	14.01
335A @ 33.4V		
STICK WELD OUTPUT	1.47 (5.64)	13.85
450A @ 24.5V		
240V AUXILLARY	0.993 (3.85)	19.64
Aux. 5000W		
240V AUXILLARY	1.16 (4.29)	17.64
Aux. 8000W		
240V AUXILLARY	1.24 (4.71)	16.07
Aux. 10000W		

NOTE: This data is for reference only. Fuel consumption is approximate and can be influenced by many factors, including engine maintenance, environmental conditions and fuel quality.

## WELDER OPERATION

### DUTY CYCLE

Duty Cycle is the percentage of time the load is being applied in a 10 minute period. For example a 60% duty cycle, represents 6 minutes of load and 4 minutes of no load in a 10 minute period.

### ELECTRODE INFORMATION

For any electrode the procedures should be kept within the rating of the machine. For information on electrodes and their proper application see ([www.lincolnelectric.com](http://www.lincolnelectric.com)) or the appropriate Lincoln publication.

The Dual Maverick® 200/200X can be used with a broad range of DC stick electrodes. The MODE switch provides two stick welding settings as follows:

### Constant Current (CC-STICK) Welding

Stick "Mode" is designed for horizontal and vertical-up welding with all types of electrodes, especially low hydrogen.

The ARC Force setting on the mode screen controls the short circuit current (arc-force) during stick welding to adjust for a soft or crisp arc. Increasing the number from -10(soft) to +10(crisp) increases the short circuit current and prevents sticking of the electrode to the plate while welding. This can also increase spatter. It is recommended that the ARC CONTROL be set to the minimum number without electrode sticking. Start with the dial set at 0 (OFF).

NOTE: Due to the low OCV with the VRD on, a very slight delay during striking of the electrodes may occur. Due to the requirement of the resistance in the circuit to be low for a VRD to operate, a good metal-to-metal contact must be made between the metal core of the electrode and the job. A poor connection anywhere in the welding output circuit may limit the operation of the VRD. This includes a good connection of the work clamp to the job. The work clamp should be connected as close as practical to where the welding will be performed.

#### For Re-Striking Electrodes

Some electrodes form a cone at the end of the electrode after the welding arc has been broken, particularly iron powder and low hydrogen electrodes. This cone will need to be broken off in order to have the metal core of the electrode make contact.

E6010 - To begin welding with VRD active.

E7018, E7024 - Tap, slide and lift in one motion.

Once the arc is started, normal welding technique for the application is then used.

For other electrodes the above techniques should be tried first and varied as needed to suit operator preference. The goal for successful starting is good metal to metal contact.

### DOWNHILL PIPE Welding


This slope controlled mode is intended for "out-of-position" and "down hill" pipe welding where the operator would like to control the current level by changing the arc length.

The ARC FORCE setting sets the short circuit current (arc-force) during stick welding to adjust for a soft or more forceful digging arc (crisp). Increasing the number from -10(soft) to +10(crisp) increases the short circuit current which results in a more forceful digging arc.

Typically a forceful digging arc is preferred for root and hot passes. A softer arc is preferred for fill and cap passes where weld puddle control and deposition ("stacking" of iron) are key to fast travel speeds. This can also increase spatter.

It is recommended that the ARC FORCE be set to the minimum number without electrode sticking. Start with the setting at 0.

NOTE: With the VRD set to the "ON" position (See **Figure A.2** for location) there is no output in the downhill pipe mode.



**TIG Welding**

The TOUCH START TIG is for DC TIG (Tungsten Inert Gas) welding. To initiate a weld, the selector knob is used to set to the desired current and the tungsten is touched to the work. During the time the tungsten is touching the work there is very little voltage or current and, in general, no tungsten contamination. Then, the tungsten is gently lifted off the work in a rocking motion, which establishes the arc.

When in the touch start TIG mode and when a Amptrol is connected to the 6-Pin connector the selector knob is used to set the maximum current range of the current control of the Amptrol.

The ARC FORCE is not active in the TIG mode. To STOP a weld, simply pull the TIG torch away from the work.

When the arc voltage reaches approximately 30 Volts the arc will go out and the machine will reset the current to the Touch Start level.

To reinitiate the arc, retouch the tungsten to the work and lift. Alternatively, the weld can be stopped by releasing the Amptrol or arc start switch.

The Dual Maverick® 200/200X can be used in a wide variety of DC TIG welding applications. In general the 'Touch Start' feature allows contamination free starting without the use of a Hi-frequency unit.

If desired, the K930-2 TIG Module can be used with the Dual Maverick® 200/200X. The settings are for reference.

Dual Maverick® 200/200X settings when using the K930-2 TIG Module with an Amptrol or Arc Start Switch:

- Set the MODE to the TOUCH START TIG setting.
- Set the "IDLER" Switch to the "AUTO/IDLE/RUN" position.
- Set the "Weld Output Override" to the "REMOTELY CONTROLLED" position.

This will keep the "Solid State" contactor open and provide a "cold" electrode until the Amptrol or Arc Start Switch is pressed.

When using the TIG Module, the selector knob on the Dual Maverick® 200/200X is used to set the maximum range of the CURRENT CONTROL on the TIG Module or an Amptrol if connected to the TIG Module.

NOTE: The TIG process is to receive a low voltage welding process. There is no difference in operation with the VRD "ON" or "OFF" for this mode.




TABLE B.2

TYPICAL CURRENT RANGES <sup>(1)</sup> FOR TUNGSTEN ELECTRODES <sup>(2)</sup>						
Tungsten Electrode Diameter in. (mm)	DCEN (-)	DCEP (+)	Approximate Argon Gas Flow Flow Rate C.F.H. ( l /min.)		TIG TORCH Nozzle Size (4), (5)	
	1%, 2% Thoriated Tungsten	1%, 2% Thoriated Tungsten	Aluminum	Stainless Steel		
.010 (.25)	2-15	(3)	3-8 (2-4)	3-8 (2-4)	#4, #5, #6	
0.020 (.50)	5-20	(3)	5-10 (3-5)	5-10 (3-5)		
0.040 (1.0)	15-80	(3)	5-10 (3-5)	5-10 (3-5)		
1/16 (1.6)	70-150	10-20	5-10 (3-5)	9-13 (4-6)	#5, #6	
3/32 (2.4)	150-250	15-30	13-17 (6-8)	11-15 (5-7)	#6, #7, #8	
1/8 (3.2)	250-400	25-40	15-23 (7-11)	11-15 (5-7)		
5/32 (4.0)	400-500	40-55	21-25 (10-12)	13-17 (6-8)	#8, #10	

(1) When used with argon gas. The current ranges shown must be reduced when using argon/helium or pure helium shielding gases.

(2) Tungsten electrodes are classified as follows by the American Welding Society (AWS):

- Pure EWP
- 1% Thoriated EWTh-1
- 2% Thoriated EWTh-2

Though not yet recognized by the AWS, Ceriated Tungsten is now widely accepted as a substitute for 2% Thoriated Tungsten in AC and DC applications.

(3) DCEP is not commonly used in these sizes.

(4) TIG torch nozzle "sizes" are in multiples of 1/16ths of an inch:

- # 4 = 1/4 in. (6 mm)
- # 5 = 5/16 in. (8 mm)
- # 6 = 3/8 in. (10 mm)
- # 7 = 7/16 in. (11 mm)
- # 8 = 1/2 in. (12.5 mm)
- #10 = 5/8 in. (16 mm)

(5) TIG torch nozzles are typically made from alumina ceramic. Special applications may require lava nozzles, which are less prone to breakage, but cannot withstand high temperatures and high duty cycles.

**WIRE WELDING-CV**

Connect a wire feeder to the Dual Maverick® 200/200X according to the instructions in INSTALLATION INSTRUCTIONS Section.

The Dual Maverick® 200/200X in the CV-WIRE mode, permits it to be used with a broad range of flux cored wire (Innershield and Outershield) electrodes and solid wires for MIG welding (gas metal arc welding). Welding can be finely tuned using the PINCH from -10 (soft) to +10 (crisp) changes the arc from soft and washed-in to crisp and narrow. It acts as an inductance/pinch control. The proper setting depends on the procedure and operator preference. Start with the setting at 0 (OFF).

If the engine bogs while wire welding check that the power required for the process does not exceed the rated power of the machine. For unusually high wire feed speeds and low voltage combinations it may be necessary to disable the variable speed feature(see "SET-UP" section) and set the ignition switch to high idle.

**ARC GOUGING**

Dual Maverick® 200/200X can be used for Arc Gouging with carbons up to 3/8" (10mm) in diameter.

Use the selector knob to adjust output current to the desired level for the gouging electrode being used.

The ARC FORCE is not active in the ARC GOUGING Mode. The ARC FORCE is automatically set to maximum when the ARC GOUGING mode is selected which provides the best ARC GOUGING performanc.

**PARALLELING**

When paralleling machines in order to combine their outputs, all units must be operated in the CC-STICK mode only at the same output settings. Use the selector knob to choose stick mode from the home screen. Set each machine to half the desired current. Operation in other modes may produce erratic outputs, and large output imbalances between the units.

**AUXILIARY POWER OPERATION**

Start the engine and set the IDLER control switch to the desired operating mode. Full power is available regardless of the welding control settings, if no welding current is being drawn.

For heavy loads set to HIGH IDLE and maximum weld output for maximum starting power.

**SIMULTANEOUS WELDING AND AUXILIARY POWER LOADS**

It must be noted that the specified auxiliary power ratings are with no welding load.

Simultaneous welding and power loads are specified in Table B.3.

**TABLE B.3 DUAL MAVERICK® 200/200X SIMULTANEOUS WELDING AND POWER LOADS**

Simultaneous Welding and Power Loads (120/240V AUX)			
Simultaneous Each Side Dual Current	Single Current	Aux Power	Single Phase Amps (240V)
23.9	45.8	10000	41.7
54.1	100	8600	35.8
114	200	5400	22.5
145.3	250	3500	14.6
177.2	300	1400	5.8
196.6	330	0	0
200	400	0	0
225	450	0	0

Simultaneous Welding and Power Loads (120V AUX)			
Simultaneous Each Side Dual Current	Single Current	Aux Power	Single Phase Amps (120V)
23.9	45.8	2400	20 + 20
54.1	100	2400	20 + 20
114	200	2400	20 + 20
145.3	250	2400	20 + 9.2
177.2	300	1400	11.67 + 0
196.6	330	0	0 + 0
200	400	0	0 + 0
225	450	0	0 + 0

GFCI MODULE


**! WARNING**

- An electric shock can result in serious injury or death.
- Always perform the GFCI test before using the generator. If the GFCI system fails the test, the machine must be repaired by an authorized service center.
- If the GFCI fails to trip when the test button is pressed (“ON” light does not go off or "STATUS light is RED) or fails to reset (“ON” light does not go on or "STATUS light is blinking) the device is inoperative and should be replaced immediately.
- If the GFCI tests properly without any appliance connected to it but trips each time an appliance is connected to it, the appliance has a ground fault and needs to be repaired or replaced. **DO NOT USE THE APPLIANCE IF THIS CONDITION OCCURS: A REAL SHOCK HAZARD MAY EXIST.**
- Due to the risk of power interruption, do not power life support equipment from this machine.
- GFCI’s do not protect against short circuits or overloads.
- Unplug accessories and tools before attempting service.
- Close the front service doors protecting the receptacles when operating the machine.
- Do not test or reset the GFCI while at idle speed.
- If the LED blinks, stop using the GFCI receptacle and have it replaced by an authorized service center.
- Long extension cords or cords with poor insulation may allow enough leakage current to trip the GFCI.

The GFCI module protects the (2) 120 VAC duplex receptacles. Two different types of modules are used in the machine.

Machines manufactured approximately September 2021 or earlier

The GFCI is an auto reset GFCI. It is identified by the “ON” LED located below the buttons.




- Auto Reset: Immediately supplies power to the load when power is applied to the line.
- “ON” LED illuminates red when the load has power.

To test this GFCI, press the "TEST" button. The "ON" red LED should turn off. Then press the "RESET" button. The "ON" red LED should turn on. If the "ON" red LED does not turn off and on as indicated, the GFCI failed the test and should be replaced.

Machines manufactured approximately October 2021 or later

The GFCI is an auto reset, self-testing GFCI. It is identified by the “STATUS” LED located above the buttons.



- Auto Reset: Immediately supplies power to the load when power is applied to the line.
- “STATUS” LED illuminates Green when the GFCI is functioning properly.
- “STATUS” LED illuminates Red when the GFCI has “tripped”. Press the reset button.
- “STATUS” LED illuminates flashing Red when the GFCI has failed and needs replaced.

While this GFCI has a self-testing feature, to manually test this GFCI, press the "TEST" button. The "STATUS" LED should turn red. Then press the "RESET" button. The "STATUS" LED should turn green. If the "STATUS" LED does not turn red and green as indicated, or flashes red, the GFCI failed the test and should be replaced.”


**DISPLAY OPERATION**

(See Figure B.2)

1. **HOME** - Brings up the home screen (main menu)
2. **REMOTE CONTROL** - Toggles the remote control ON / OFF
3. **HELP** - Displays additional information describing the function
4. **BACK** - Goes back to the previous screen
5. **SELECTOR KNOB** - rotate adjusts values, push confirms the selected value or choice


NOTE: When Dual Maverick 200/200X is first started, it will return to the screen that was shown when the machine was turned off.

FIGURE B.2



**HOME SCREEN**



Pressing the Home button displays the home menu. Rotate the knob to select the desired weld mode, or choose engine options or set-up menu. Push the selector knob to make the selection.






### STICK WELDING


Manual entry operates like a traditional welding machine. Simply set the desired preset amperage or voltage and begin to weld. The "Preset" screen appears when welding is not active. It shows the amount of fuel on the left hand side; the weld mode in the lower left hand corner; the preset value in the middle; and the weld output status in the upper right corner.




Stick Welding Basic OCV




Shows present current



Stick Welding Basic OCV w Remote




Shows present current




Shows Autostart status

Stick Welding Basic Arc is struck




Actual arc amps




Actual arc volts

Stick Welding Basic 5 seconds after arc goes out



Flashes


Stick Options




All weld modes support using a remote control like K857-1. Plug the remote into the 6 pin connector on the front of the machine.

Press the remote button on the display to toggle between control at the remote and control at the knob on the machine. The remote button does not function when welding is occurring.


When the remote is enabled, a bar will appear underneath the preset value showing the remote range. The standard range allows the remote to adjust from the minimum to the maximum value of the machine.




Stick Welding Remote Control




Bar adjusts as number changes



Max current value flashes









Min current value flashes





Bar adjusts as number changes

Stick Welding ARC FORCE





**MIG/FCAW WELDING**

Manual entry operates like a traditional welding machine. Simply set the desired preset amperage or voltage and begin to weld. The “Preset” screen appears when welding is not active. It shows the amount of fuel on the left hand side; the weld mode in the lower left hand corner; the preset value in the middle; and the weld output status in the upper right corner.





**MIG Welding Basic OCV**





Shows present voltage

**MIG Welding Basic OCV w Remote**





Shows present voltage

**Pinch Mode Info**





Press knob to continue

**MIG Options**





Press knob for select

**MIG Settings**





Press knob to select

**Pinch Mode**



Press knob to select




**Note:** Select the maximum wire feed speed (WFS) that will be used during the welding session to ensure power output to the wire feeder is sufficient.

### CROSSLINC



CrossLinc provides the benefits of remote control without a cable. The accessory or wire feeder talks to the power source by sending signal through the electrode cable.

To start CrossLinc, simply connect the weld cables and sense lead per the CrossLinc device's instructions. Select the desired weld mode with the Dual Maverick 200/200X. When the weld output is ON the CrossLinc device will automatically link to the Dual Maverick. The CrossLinc icon will appear on the screen to show active communication. When CrossLinc is active, the remote control is disabled.




### SPOOL GUN

Manual entry operates like a traditional welding machine. Simply set the desired preset amperage or voltage and begin to weld. The “Preset” screen appears when welding is not active. It shows the amount of fuel on the left hand side; the weld mode in the lower left hand corner; the preset value in the middle; and the weld output status in the upper right corner.





Spool Gun Welding Basic OCV





Shows present wire feed speed  
Shows present voltage

Spool Gun Welding Basic OCV w Remote




Spool Gun Options








### SPOOL GUN SYNERGIC CONTROL MODE

The spool gun may be either set in “normal” control or “synergic” control. Synergic mode automatically adjusts the voltage when the wire feed speed is changed.



#### Synergic Control Selection



#### Synergic Control Mode Info





NOTE: After selecting Synergic Control, the user is required to select their desired Wire Type and Wire Diameter. This allows the program to calculate the recommended range for their welding needs.



#### Spool Gun Synergic Control Selection

Recommended ranges


Green box appears when user is in the recommended range




**PULSE MODE**

Activating Spool Gun Pulse toggles both the voltage and wire feed speed between a peak and a low level. It is useful for lower heat input welding and creating the appearance of “stacked dimes” in aluminum.

Pulse Mode




Pulse Mode Info




**SPOT TIME MODE**

Spot Time is useful for making multiple welds of a similar size. Popular applications are when welding on thin material to control heat input, and to make consistent sized tack welds. When spot time is enabled, welding continues for the period of time chosen, as long as the trigger is pulled. Welding stops when the time is exceeded, even if the trigger remains pulled. Release the trigger and pull again to make another weld.

Spot Time Mode



Spot Time Mode Info



### ENGINE STATUS SCREEN

The Engine Status screen provides information about the engine servicing and operation.

Five parts of the engine are monitored for service: Oil, Coolant, Air Filter, Fan Belt and Fuel Filter. To view detailed information about an item, rotate the knob until the item is highlighted in red. The top of the screen displays the number of hours remaining until service is required for the selected item.





The red/yellow/green bars for each item indicate how much time is left.

Green = Normal operation

Yellow = Service is required soon

Red = Service is overdue


After service has been performed on an item, press and hold the knob for 5 seconds to reset the service interval timer.





### ENGINE INFO

While in Dual Mode, the user can bring up the Engine Information screen by pressing the “?” button while on the landing page in any welding mode. In order to exit the Engine Information screen, press the back button or the encoder knob. Furthermore, the user may press the home button to return to the weld mode selection.







**SET-UP**


The set-up allows for customization of the Maverick. Options available in the Set-up menu are:

- **AUTO-START: NO LOAD PERIOD** - When AUTO-START is enabled, the NO LOAD PERIOD is the period of time the machine can be running with no auxiliary or weld load before it automatically shuts down. The user can use this setting to set the amount of time for the NO LOAD PERIOD.
- **TAP START ACTIVE PERIOD** - The TAP START ACTIVE PERIOD is the period of time that the user can restart the welder after it is shut down due to the NO LOAD PERIOD when AUTO-START is enabled. In order to restart the welder, tap the electrode to the work piece. This setting is used to set the TAP START ACTIVE PERIOD time.
- **AUTO-START: ON/OFF** - AUTO-START shuts down the engine when it is not in use for a set period of time and allows the user to re-start the engine with a "tap" of their electrode onto their work piece without having to go back to their machine.
- **PIN** - PIN page is used to set and enable a mandatory Operator Pin when the machine is turned on and/or a Supervisor Pin for accessing the Setup page.
- **DISPLAY BRIGHTNESS**
- **DIAGNOSTIC INFORMATION** - Diagnostic information page can be used to get useful information about the welder. ECG FAULT CODE is the number of pulse detected from ECG fault lamp. The fault codes can be found in troubleshooting section (E-4).
- **NEW PCB CALIBRATION** - When new PCB(s) is installed on the machine, calibration is needed for both Single and Dual modes. On Single mode, only follow the instructions on the left display. On Dual mode, only follow the instructions on the right display. To ensure proper calibration ensure mode was in Stick at 150 amps set point before entering setup menu. Failure to do so will not allow welder to enter calibration mode.
- **VARIABLE SPEED ON/OFF** - Turn the variable speed function off when desired weld output is not reached. For example, in high altitude areas that have lower oxygen levels, the operator can turn off the variable speed function to increase weld output.
- **RESTORE FACTORY SETTINGS**
- **MACHINE SELECT** - When a new PCB(s) is installed on the machine, the PCB has to go through a "Machine Select" process. This setup option should only be used if the initial "Machine Select" process was not completed successfully. To enter this setup option use the following pass code: 3210. Ensure the correct K # and Code number is used for the machine. Failure to do so can permanently damage the welder.
- **CROSSLINC ON/OFF**
- **SPOOL GUN CALIBRATION** - When first connecting a spool gun to the machine, the engine power must be calibrated for the spool gun to have the wire feed speed be accurate.
- **ENGINE SERVICE KIT** - Provides useful information regarding replacement parts needed during the service of the Dual Maverick 200/200X.


- **PRODUCTIVITY METRICS** - Provides useful information and statistics regarding how the machine is being used.





### Auto-Start: No Load Period




Autostart  
time




### Display Brightness





### Tap Start Active Period





Tap Start  
time



### Restore Factory Settings



### Auto Start: ON/OFF



**PIN**


**DO NOT FORGET THE PIN!** The PIN may only be reset by a Lincoln Authorized Service Shop.

To turn on Operator security, rotate the knob until Operator PIN is highlighted and press the knob.


Rotate the knob to turn the PIN on or off. Press the knob to select.

Rotate the knob to adjust the value of the PIN. Press the knob to advance to the next number. Press the BACK button to go the previous number.


Entry of the Supervisor PIN is similar to the Operator PIN.




Variable Speed Setup




Diagnostic Info




New PCB Calibration - Right Side Display (Dual Mode)




New PCB Calibration - Left Side Display (Single Mode)





**MACHINE SELECT**



**CROSSLINC: ON/OFF**











Enter the correct K# and Code # for the welder the PCB is being installed on. K# and Code # can be found above the top name plate ("Machine Information Above"). Failure to enter the correct K# and Code # may result in permanent damage to the welder.





If correct k # and Code # entered. The Welder will be accepted.

SPOOL GUN CALIBRATION



ENGINE SERVICE KIT

Engine Service Kit



This screen will remain for approximately 5 seconds as the wire feeds. During this process, the wire coming out of the spool gun will grow longer as a visual representative.

**PRODUCTIVITY METRICS**

The Productivity Metrics screen provides information and statistics on how the machine is being utilized.

Five statistics of the machine are monitored: Arc Hours, Auxiliary Hours, Utilization Percent, Standby Hours and Fuel Saved w/ Auto-Start.

Arc Hours is the time spent using the machine for welding.

Auxilliary Hours is the time spent using the auxiliary power on the machine.

Utilization Percent represents how efficiently the machine is being used. It shows the percentage of time the machine is being loaded with respect to the total hours on the engine.





Standby Hours is the time the machine was running while not being loaded.

Fuel Saved w/ Auto-Start is the amount of fuel in US gallons that has been saved due to the Auto-Start feature.

To view information regarding one of the monitored parameters, rotate the knob until the desired item is highlighted in red. The bottom of the screen shows the value of the parameter on the longer left side portion, and located in the bottom right corner is the engine hours.

In order to reset any of these metrics, press and hold the knob on the selected parameter for 5 seconds.

**Productivity Metrics**





# ACCESSORIES

---

## OPTIONAL FIELD INSTALLED ACCESSORIES

**K2636-1** Medium Trailer

**K2639-1** Fender Kit

**K2640-1** Cable Rack

**K2641-2** Four Wheel Trailer

**K857** Remote Control

**K857-1** Remote Control

**K2613-5A1** Ln-25 PRO with K126 PRO Gun

**K126-12** K126 PRO Gun

**KP1696-068** Drive Roll Kit

**K12038-2** Invertec PC610 Plasma

**K12048-1** Tomahawk 1025 Plasma

# MAINTENANCE

## SAFETY PRECAUTIONS

### WARNING

- Have qualified personnel do all maintenance and troubleshooting work.
- Turn the engine off before working inside the machine or servicing the engine.
- Remove guards only when necessary to perform maintenance and replace them when the maintenance requiring their removal is complete. If guards are missing from the machine, obtain replacements from a Lincoln Distributor. (See Operating Manual Parts List.)

Read the Safety Precautions in the front of this manual and in the Engine Owner’s Manual before working on this machine.

Keep all equipment safety guards, covers, and devices in position and in good repair. Keep hands, hair, clothing, and tools away from the gears, fans, and all other moving parts when starting, operating, or repairing the equipment.

## ROUTINE AND PERIODIC MAINTENANCE

### DAILY

- Check the Engine oil levels.
- Refill the fuel tank to minimize moisture condensation in the tank.
- Open the water drain valve located on the bottom of the water separator element 1 or 2 turns and allow to drain into a container suitable for diesel fuel for 2 to 3 seconds. Repeat the above drainage procedure until diesel fuel is detected in the container.
- Check coolant level in the coolant recovery bottle. If full empty bottle.

### WEEKLY

Blow out the machine with low pressure air periodically. In particularly dirty locations, and the radiator, this may be required once a week.

## ENGINE MAINTENANCE

Refer to the “Periodic Checks” section of the Engine Operator’s Manual for the recommended maintenance schedule of the following:

- Engine Oil and Filter
- Air Cleaner
- Fuel Filter - and Delivery System
- Alternator Belt
- Battery
- Cooling System

Refer to Table D.1 at the end of this section for various engine maintenance components.

TABLE D.1

REPLACEMENT SERVICE ITEMS			
ITEM	MAKE	PART NUMBER	SERVICE INTERVAL
AIR CLEANER ELEMENT	KUBOTA	1G319-11212*	CLEAN EVERY 100 HOURS REPLACE EVERY YEAR OR EVERY 6 CLEANINGS
FAN BELT	KUBOTA	19805-72530 or BANDO 2345	REPLACE EVERY 500 HOURS
OIL FILTER	KUBOTA	HH150-32430*	REPLACE EVERY 200 HOURS
WATER SEPARATOR ELEMENT	KUBOTA	RD819-51280*	REPLACE/ CLEAN EVERY 400 HOURS
FUEL FILTER	KUBOTA	70000-43081*	REPLACE EVERY 400 HOURS
BATTERY	—	BCI GROUP 58	INSPECT EVERY 500 HOURS

\*ITEM INCLUDED IN K3599-4 ENGINE SERVICE KIT S33343 VM

## AIR FILTER

### CAUTION

Excessive air filter restriction will result in reduced engine life.

### WARNING

Never use gasoline or low flash point solvents for cleaning the air cleaner element. A fire or explosion could result.

### CAUTION

Never run the engine without the air cleaner. Rapid engine wear will result from contaminants, such as dust and dirt being drawn into the engine.

The diesel engine is equipped with a dry type air filter. Never apply oil to it. Service the air cleaner as follows:

Replace the element as indicated by the service indicator. (See Service Instructions and Installation Tips for Engine Air Filter.)

# Service Instructions


## Single- and Two-Stage Engine Air Cleaners

### 1 Remove the Filter



Rotate the filter while pulling straight out.


Unfasten or unlatch the service cover. Because the filter fits tightly over the outlet tube to create the critical seal, there will be some initial resistance, similar to breaking the seal on a jar. Gently move the end of the filter back and forth to break the seal then rotate while pulling straight out. Avoid knocking the filter against the housing.



If your air cleaner has a safety filter, replace it every third primary filter change. Remove the safety filter as you would the primary filter. Make sure you cover the air cleaner outlet tube to avoid any unfiltered contaminant dropping into the engine.


### 2 Clean Both Surfaces of the Outlet Tube and Check the Vacuator™ Valve

Use a clean cloth to wipe the filter sealing surface and the inside of the outlet tube. Contaminant on the sealing surface could hinder an effective seal and cause leakage. Make sure that all contaminant is removed before the new filter is inserted. Dirt accidentally transferred to the inside of the outlet tube will reach the engine and cause wear. Engine manufacturers say that it takes only a few grams of dirt to "dust" an engine! Be careful not to damage the sealing area on the tube.



Outer edge of the outlet tube

Wipe both sides of the outlet tube clean.




Inner edge of the outlet tube

If your air cleaner is equipped with a Vacuator Valve Visually check and physically squeeze to make sure the valve is flexible and not inverted, damaged or plugged.




### 3 Inspect the Old Filter for Leak Clues

Visually inspect the old filter for any signs of leaks. A streak of dust on the clean side of the filter is a telltale sign. Remove any cause of leaks before installing new filter.



### 4 Inspect the New Filter for Damage


Inspect the new filter carefully, paying attention to the inside of the open end, which is the sealing area. NEVER install a damaged filter. A new Donaldson radial seal filter may have a dry lubricant on the seal to aid installation.



### 5 Insert the New Radial Seal Filter Properly

If you're servicing the safety filter, this should be seated into position before installing the primary filter.

Insert the new filter carefully. Seat the filter by hand, making certain it is completely into the air cleaner housing before securing the cover in place.



The critical sealing area will stretch slightly, adjust itself and distribute the sealing pressure evenly. To complete a tight seal, apply pressure by hand at the outer rim of the filter, not the flexible center. (Avoid pushing on the center of the urethane end cap.) No cover pressure is required to hold the seal. NEVER use the service cover to push the filter into place! Using the cover to push the filter in could cause damage to the housing, cover fasteners and will void the warranty.

If the service cover hits the filter before it is fully in place, remove the cover and push the filter (by hand) further into the air cleaner and try again. The cover should go on with no extra force.

Once the filter is in place, secure the service cover.



### Caution

**NEVER use the service cover to push the filter into place! Using the cover to push the filter in could cause damage to the housing, cover fasteners and will void the warranty.**



### 6 Check Connectors for Tight Fit

Make sure that all mounting bands, clamps, bolts, and connections in the entire air cleaner system are tight. Check for holes in piping and repair if needed. Any leaks in your intake piping will send dust directly to the engine!

**FUEL FILTERS**

**! WARNING**

When working on the fuel system:

- Keep naked lights away, do not smoke!
- Do not spill fuel!



The Dual Maverick® 200/200X is equipped with a Fuel Filter located to left of air cleaner. The procedure for changing the filter is as follows.

1. Close the fuel shutoff valve located in front of the fuel filter.
2. Clean the area around the fuel filter head. Remove the filter. Clean the gasket surface of the filter head and replace the o-ring.
3. Fill the clean filter with clean fuel, and lubricate the o-ring seal with clean lubricating oil.
4. Install the filter as specified by the filter manufacturer.

**! WARNING**

Mechanical overtightening will distort the threads, filter element seal or filter can.

**COOLING SYSTEM**

The Dual Maverick® 200/200X is equipped with a pressure radiator. Keep the radiator cap tight to prevent loss of coolant. Clean and flush the coolant system periodically to prevent clogging the passage and over-heating the engine. When antifreeze is needed, always use the permanent type.

- Every 500 hours check radiator to ensure there is no fin blockage or leaks. Clean as necessary with an environmentally friendly degreaser and low pressure water.
- When draining the entire contents of the system, remove radiator cap. Pull drain hose through the battery access door in the base and open shut off valve until system is empty.
- When refilling, close shut off valve on drain hose.

**NAMEPLATES / WARNING DECALS MAINTENANCE**

Whenever routine maintenance is performed on this machine - or at least yearly - inspect all nameplates and labels for legibility. Replace those which are no longer clear. Refer to the parts list for the replacement item number.

**WELDER / GENERATOR MAINTENANCE STORAGE**

Store the Dual Maverick® 200/200X in clean, dry, protected areas.

**CLEANING**


Blow out the generator and controls periodically with low pressure air. Do this at least once a week in particularly dirty areas.

**FAN BELT CHANGE**

Ensure when changing the fan belt a Lincoln recommended fan belt is used or equivalent EPDM material, 877 mm datum length and XPZ profile (Width 10, Height 8 mm, Cogged) belt is used. Tension new belts to 120lbs, used belts to 80lbs, using a Burroughs guage. Refer to engine operator's manual for proper installation and tension.

**OIL CHANGE**

Remove battery cover (see below) and route oil drain hose through opening to change engine oil.



**BATTERY HANDLING****WARNING****GASES FROM BATTERY can explode.**

Keep sparks, flame and cigarettes away from battery.

**To prevent EXPLOSION when:**

- **INSTALLING A NEW BATTERY** - disconnect negative cable from old battery first and connect to new battery last.
- **CONNECTING A BATTERY CHARGER** - Remove battery from welder by disconnecting negative cable first, then positive cable and battery clamp. When reinstalling, connect negative cable last. Keep well ventilated.
- **USING A BOOSTER** - connect positive lead to battery first then connect negative lead to engine foot.

**BATTERY ACID CAN BURN EYES AND SKIN.**

- Wear gloves and eye protection and be careful when working near battery. Follow instructions printed on battery.

**PREVENTING ELECTRICAL DAMAGE**

1. When replacing, jumping, or otherwise connecting the battery to the battery cables, the proper polarity must be observed. Failure to observe the proper polarity could result in damage to the charging circuit. The positive (+) battery cable has a red terminal cover.
2. If the battery requires charging from an external charger, disconnect the negative battery cable first and then the positive battery cable before attaching the charger leads. Failure to do so can result in damage to the internal charger components. When reconnecting the cables, connect the positive cable first and the negative cable last.

**PREVENTING BATTERY DISCHARGE**

Turn the RUN/STOP switch to stop when engine is not running.

**PREVENTING BATTERY BUCKLING**

Tighten nuts on battery clamp until snug.

**CHARGING THE BATTERY**

When you charge, jump, replace, or otherwise connect battery cables to the battery, be sure the polarity is correct. Improper polarity can damage the charging circuit. The Dual Maverick® 200/200X positive (+) battery terminal has a red terminal cover.

If you need to charge the battery with an external charger, disconnect the negative cable first, then the positive cable before you attach the charger leads.

After the battery is charged, reconnect the positive battery cable first and the negative cable last. Failure to do so can result in damage to the internal charger components.

Follow the instructions of the battery charger manufacturer for proper charger settings and charging time.

TABLE OF CONTENTS

<b>THEORY OF OPERATIONS.....</b>	<b>SECTION E</b>
FUNCTIONAL DESCRIPTION .....	E1
POWER UP .....	E2
CONTROLS .....	E3
ENGINE COMPONENTS.....	E4
WELDING OUTPUT AND CONTROL.....	E5
MACHINE PROTECTION.....	E6
TYPICAL IGBT OUTPUTS.....	E7
IGBT OPERATION.....	E8
CHOPPER TECHNOLOGY.....	E9
BRUSHLESS ALTERNATOR.....	E10

## FUNCTIONAL DESCRIPTION

The Dual Maverick 200/200X is a diesel engine-driven welding power source capable of producing 450 amps at 24.5VDC at a 60% duty cycle when being used in a single side mode. If being used in a dual mode (both sides at same time) the maximum output per side is 225 amps at 24.5VDC at a 60% duty cycle. The engine is coupled to a brushless alternator. See Brushless Alternator in this section. The welding AC output of the brushless alternator is rectified and then controlled by Chopper Technology to produce DC current for multi-purpose welding applications. The Dual Maverick 200/200X is also capable of producing 10,000 watts of AC single phase (120VAC/240VAC) auxiliary power at 100% duty cycle.

The machine is equipped with Crossline® Technology that enables communication between a compatible wirefeeder and the Dual Maverick 200/200X for weld voltage control at the arc without the need for a control cable.

The Dual Maverick 200/200X is made up of eight main circuits/components. They are the following:

- The Engine
- Engine Components, Sensors, Engine Control Unit (ECU), Relays, and Switches
- The Stator/Rotor and Circuitry (Brushless Alternator)
- Auxiliary Power Circuitry and Protection
- Output Rectifiers
- Chopper Boards and Control PC Boards
- LCD Display Boards and Controls
- Automatic Voltage Regulator (AVR)




Figure E.1

## POWER UP

### BATTERY, ENGINE, ROTOR/STATOR (Brushless Alternator Assembly)

The 12VDC Battery supplies voltage to the Glow Plug Switch, the Start Button, the CR1 Start Relay, the Engine Control Unit (ECU), and to the On/Off Idler Switch. When the On/Off Idler Switch is in the “ON” position 12VDC is sent to the Left and Right Side Control Boards and via the Control Boards to the two Display Boards. When the Start Button is pressed a 12VDC signal is sent to the Left Side Control Board and through a 5 amp fuse to the Engine Control Unit. The Left Side Control Board then activates the CR1 Relay. The CR1 Relay then energizes the Starter Motor Assembly on the Engine and the Engine Control Unit allows fuel to flow into the engine.

When the Engine, which is mechanically coupled to the Rotor that is located within the Brushless Alternator Assembly, is started up and running the Automatic Voltage Regulator (AVR) controls the voltage in the stationary exciter field windings. The AC output of the excitation rotor windings is rectified and the resultant DC voltage is applied to the main rotor windings. This rotating field induces AC voltages on the stationary windings housed in the stator frame.

The stator houses two separate three-phase windings for welding, and 120/240VAC single phase windings for auxiliary power. The three-phase welding windings are connected to the left and right side output rectifiers. Also, there is a 42VAC winding that is rectified by the D3 Diode Bridge, and applied to the left and right side control boards. Additionally the 42VAC is connected to the two 14 pin remote amphenols for wire feeder power.




Figure E.2



# CONTROLS

## LCD DISPLAY / USER INTERFACE / ENCODERS

The displays will turn on when the ON/OFF IDLER switch is placed into an ON position. Through the display and encoder the operator can access and control the following within the machine:

The listing below are only some of the options and settings available through the Display/User Interface Boards and Encoder.

- Add/Remove a PIN to control access to the machine
- Select weld mode and specific welding settings related to the weld mode such as remote control range, hot start, arc force, pinch, etc.
- Check engine status – Includes engine hours, battery voltage, and remaining life for maintenance items
- Select machine settings such as units of measure, PIN options, hide/show weld modes and settings, set engine alerts, clock, language, etc.

- Enable/Disable auto-stop/start and adjust settings – Set No Load Period and Standby Period
- Diagnostics information – Lists machine serial number, engine serial number, code number, etc
- CC and CV test modes
- Home Button – Returns user to Menu Screen
- Remote Control Button – Deactivates or Reactivates the remote control when connected
- Question Mark Button – Describes an option or brings up engine information
- Main Menu – Allows the user to select the desired weld mode
- Encoder – Allows the user to navigate through the selections
- Auto-Shutdown – Set shutdown timer




Figure E.3

# ENGINE COMPONENTS

## SENSORS, RELAYS AND CONTROLS

The Engine's Alternator supplies charging current for the Battery Circuit. The Engine's sensors will shut the engine off in the event of low oil pressure, or engine over temperature. The Engine Governor Unit (ECU) controls the engine speed (low, high, or variable RPM) dependent upon the signal from the CR2 Idler Relay and the Digital (CAN) signals from the Left Side Control and Display Boards. A Fuel Actuator and a Magnetic Pickup are also parts of the Sensors and Controls.

If no welding or auxiliary current is being drawn, and the On/Off/Idler Switch is in the Auto position, the Left Side Control Board will activate the Idler Relay and the Engine Governor will take the Engine to low idle speed (2500RPM). When output is sensed, either weld or auxiliary, the Left Side Control Board deactivates the Idler Relay and the Engine Governor will take the Engine to a high idle state (3600RPM).




Figure E.4

## WELDING OUTPUT AND CONTROL

### THREE PHASE OUTPUT RECTIFIERS, CHOPPER BOARDS, CHOPPER CONTROL BOARDS, D3 RECTIFIER BRIDGE, FEEDBACK, OUTPUT SWITCH, AND OUTPUT CHOKES

The two three phase stator windings are connected to two separate three phase rectifier bridges (left and right). The resultant DC voltages are applied to the capacitor/chopper circuitry that is incorporated within the two Chopper Boards. The capacitors function as filters and also power supplies for the chopper IGBTs. See IGBT Operation in this section. The IGBTs are high speed switches operating at 20KHZ. These devices are switched on and off by the signals generated within the Left and Right Chopper Control Boards. See Pulse Width Modulation in this section. These “chopped” DC outputs are applied to the output terminals (left and right) through Chokes and Current Sensors that are incorporated within the left and right side Control Boards. If only the left side is being used the Output Switch configures the two sides in parallel. If both sides are being used the Output Switch takes the two sides out of a parallel configuration. The Auxiliary Contacts, that are part of the Output Switch, signal the Right Side Control Board when not in a parallel configuration. The Chokes

function as current filters. Free-wheeling diodes are incorporated in the Chopper Board circuitry to provide a current path for the stored energy in the Chokes when the IGBTs are in the off state. See Chopper Technology in this section. Output voltage and current feedback is sent to the Control Boards for processing and control.

The Control Left Side Board has many functions as follows:

- Receives voltage from the Three Phase Rectifier Bridges. (both control boards)
- Applies 12VDC battery voltage to various components/circuits when required.
- Activates the CR3 Power Relay
- Controls the CR1 (starter relay) and the CR2 (idle relay) relays.
- Interfaces with the remote receptacles (both control boards)
- Supplies power to the LCD Display/User Interface and communicates through CAN (both control boards).
- Monitors both left side welding current and auxiliary current (Toroid).
- Determines how the welding output should be controlled based on user commands (from the LCD Display/User Interface and voltage/current feedback) to optimize the welding results. (both control boards)
- Interfaces with the Engine Control Unit (ECU)




Figure E.5

---

## **MACHINE PROTECTION**

### **AUXILIARY POWER**

The auxiliary power supplies are protected from over current conditions by the following circuit breakers. The 240VAC supply is protected from over-current by CB1 a two pole 50 amp circuit breaker. The two 120VAC receptacles are protected from over-current by CB2 and CB3, both are 20 amp circuit breakers. The 120VAC supplies are also protected from ground faults by two separate GFCI (Ground Fault Circuit Interrupters).



### **WELDING CURRENT**

Based on the feedback from the current transducers, located within the Control Boards, the welding current will be limited to a maximum output.

### **ENGINE PROTECTION**

In the case of low oil pressure, or high coolant temperature, the engine will shut down. The engine is also protected from excessive low or high RPM.

TYPICAL IGBT OUTPUTS



**PULSE WIDTH MODULATION**

The term PULSE WIDTH MODULATION is used to describe how much time is devoted to conduction in the cycle. Changing the pulse width is known as MODULATION. Pulse Width Modulation (PWM) is the varying of the pulse width over the allowed range of a cycle to affect the output of the machine.

**MINIMUM OUTPUT**


By controlling the duration of the gate signal, the IGBT is turned on and off for different durations during a cycle. The top drawing shows the minimum output signal possible over a 25-microsecond time period.

The positive portion of the signal represents one IGBT group conducting for 2 microseconds. The dwell time (off time) is 23 microseconds. Since only 2 microseconds of the 25-microsecond time period is devoted to conducting, the output power is minimized.

**MAXIMUM OUTPUT**

By holding the gate signals on for 23 microseconds and allowing only 2 microseconds of dwell time (off time) during the 25-microsecond cycle, the output is maximized. The darkened area under the top curve can be compared to the area under the bottom curve. The more darkened area under the curve, the more power is present.

IGBT OPERATION



**INSULATED GATE BIPOLAR TRANSISTOR (IGBT) OPERATION**

An IGBT is a type of transistor. IGBTs are semiconductors well suited for high frequency switching and high current applications.


Drawing A shows an IGBT in a passive mode. There is no gate signal, (zero volts relative to the source) and therefore, no current flow. The drain terminal of the IGBT may be connected to a voltage supply; but since there is no conduction the circuit will not supply current to components connected to the source. The circuit is turned off like a light switch in the OFF position.

Drawing B shows the IGBT in an active mode. When the gate signal, a positive DC voltage relative to the source, is applied to the gate terminal of the IGBT, it is capable of conducting current. A voltage supply connected to the drain terminal will allow the IGBT to conduct and supply current to circuit components coupled to the source. Current will flow through the conducting IGBT to downstream components as long as the positive gate signal is present. This is similar to turning ON a light switch.

# CHOPPER TECHNOLOGY FUNDAMENTALS


The new era of welding machines such as the Frontier 400X, employ a technology whereby a DC source is turned on and off (chopped up) at high speed, then smoothed through an inductor to control an arc.

Hence the name “Chopper.” The biggest advantage of chopper technology is the high-speed control of the arc, similar to the inverter machines. A block diagram for this is as follows:



In this system, the engine drives a three-phase alternator, which generates power that is rectified and filtered to produce approximately 90-100VDC. The current is applied through a solid state switch to an

inductor. By turning the switch on and off, current in the inductor and the arc can be controlled. The following diagram depicts the current flow in the system when the switch is open and closed.



When the switch is closed, current is applied through the inductor to the arc. When the switch opens, current stored in the inductor sustains flow in the arc and through the diode. The repetition rate of switch closure is 40Khz, which allows ultra-fast control of

the arc. By varying the ratio of on time versus off time of the switch (Duty Cycle), the current applied to the arc is controlled. This is the basis for Chopper Technology: Controlling the switch in such a way as to produce superior welding.

# Brushless Alternator







TABLE OF CONTENTS

<b>TROUBLE SHOOTING .....</b>	<b>SECTION F</b>
TROUBLESHOOTING GUIDE .....	F1
ENGINE FAULT FLASH CODES .....	F5
TEST PROCEDURES .....	F6
ALTERNATOR .....	F7
AUXILIARY RECEPTACLES .....	F9
AUTOMATIC VOLTAGE REGULATOR .....	F11
CB1 .....	F13
CB2 .....	F15
CB3 .....	F17
CB4 .....	F19
CB5 .....	F21
CHOPPER PCB3 .....	F23
CHOPPER PCB4 .....	F26
CR1 .....	F29
CR2 .....	F32
CR3 .....	F35
D1 .....	F38
D2 .....	F41
D3 .....	F44
ECU .....	F47
GLOW PLUG SWITCH .....	F50
L1 CHOKE .....	F53
L2 CHOKE .....	F55
ON, IDLE, STOP SWITCH.....	F57
START SWITCH .....	F60
STARTER .....	F63
STATOR .....	F65
<b>COMPONENT REMOVAL PROCEDURES .....</b>	<b>SECTION F</b>
RETEST AFTER REPAIR .....	F72

# TROUBLESHOOTING

## How to Use Troubleshooting Guide

### **WARNING**

Service and Repair should only be performed by Lincoln Electric Factory Trained Personnel. Unauthorized repairs performed on this equipment may result in danger to the technician and machine operator and will invalidate your factory warranty. For your safety and to avoid Electrical Shock, please observe all safety notes and precautions detailed throughout this manual.



This Troubleshooting Guide is provided to help you locate and repair possible machine malfunctions. Simply follow the three-step procedure listed below.

### Step 1. LOCATE PROBLEM (SYMPTOM).

Look under the column labeled “PROBLEM (SYMPTOMS).” This column describes possible symptoms that the machine may exhibit. Find the listing that best describes the symptom that the machine is exhibiting.

### Step 2. POSSIBLE CAUSE.

The second column labeled “POSSIBLE CAUSE” lists the obvious external possibilities that may contribute to the machine symptom.

### Step 3. RECOMMENDED COURSE OF ACTION.

This column provides a course of action for the Possible Cause, generally it states to contact your local Lincoln Authorized Field Service Facility.

If you do not understand or are unable to perform the Recommended Course of Action safely, contact your local Lincoln Authorized Field Service Facility.

### **WARNING**

#### **ELECTRIC SHOCK can kill.**

- Turn off machine at the disconnect switch on the rear of the machine and remove main power supply connections before doing any troubleshooting.



If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your Lincoln Authorized Service Facility for technical troubleshooting assistance before you proceed.

**[WWW.LINCOLNELECTRIC.COM/LOCATOR](http://WWW.LINCOLNELECTRIC.COM/LOCATOR)**

PROBLEMS (SYMPTOMS)	POSSIBLE CAUSE	RECOMMENDED COURSE OF ACTION
<b>OUTPUT PROBLEMS</b>		
Major mechanical or electrical damage is evident.	1. Contact your local Lincoln Authorized Field Service Facility.	1. Contact the Lincoln Electric Service Department at 1-888-935-3877.
There is no welding from either the left or right side. Also, there is no auxiliary voltage output. The engine is operating normally.	1. Check Circuit Breaker CB5.	1. Perform the <b>CR3 Power Relay Test</b> . 2. Perform the <b>Automatic Voltage Regulator Test (AVR)</b> . 3. Perform the <b>Stator Test</b> . 4. The Left Side Control Board may be faulty.
There is no welding output from either the left or right side. The auxiliary output voltage is normal. The engine is operating normally.	1. Check the Output Switch (S1) for normal operation. See the Wiring Diagram. 2. If welding in a Constant Voltage (CV) mode make sure the output is triggered ON.	1. Perform the <b>Chopper Board Tests</b> . 2. Perform the <b>Left Side Output Rectifier (D1) and the Right Side Output Rectifier (D2) Tests</b> . 3. Perform the <b>Stator Test</b> . 4. Perform the <b>D3 Rectifier Test</b> .
There is no welding output from the left side. The right side is operating normally. The auxiliary output voltage is normal. The engine is operating normally.	1. If welding in a Constant Voltage (CV) mode make sure the left side output is triggered ON.	1. Perform the <b>Left Side Output Rectifier Test</b> . Perform the <b>Left Side Chopper Board Test</b> . 2. Perform the <b>Left Side Output Choke Test</b> . 3. Perform the <b>Stator Test</b> . 4. The Left Side Control Board may be faulty.
There is no welding output from the right side. The left side is operating normally. The auxiliary output voltage is normal. The engine is operating normally.	1. If welding in a Constant Voltage (CV) mode make sure the right side output is triggered ON. 2. Make sure the Output Switch (S1) is in the correct position. See the Wiring Diagram	1. Perform the <b>SW1 Output Selector Switch Test</b> . 2. Perform the <b>Right Side Output Rectifier Test</b> . 3. Perform the <b>Right Side Chopper Board Test</b> . 4. Perform the <b>Right Side Output Choke Test</b> . 5. Perform the <b>Stator Test</b> . 6. The Right Side Control Board may be Faulty
Both welding sides are functioning normally but there is no auxiliary voltage output.	1. Check the circuit breakers (CB1, CB2, and CB3) for proper operation. 2. Check the GFCI for proper operation. See the wiring diagram.	1. Perform the <b>Stator Test</b> .



If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your Lincoln Authorized Service Facility for technical troubleshooting assistance before you proceed.

[WWW.LINCOLNELECTRIC.COM/LOCATOR](http://WWW.LINCOLNELECTRIC.COM/LOCATOR)

PROBLEMS (SYMPTOMS)	POSSIBLE CAUSE	RECOMMENDED COURSE OF ACTION
<b>OUTPUT PROBLEMS (CONT)</b>		
The machine has low welding voltage output (on both sides) and low auxiliary voltage output. The engine operates normally.	1. N/A	1. Perform the <b>Automatic Voltage Regulator Test (AVR)</b> . 2. Perform the <b>CR3 Power Relay Test</b> . 3. Perform the <b>Stator Test</b> . 4. The Left Side Control Board may be faulty.
The welding output cannot be controlled on either side. Auxiliary voltage output is normal and the engine operates normally.	1. If a remote control unit or wire feeder is connected to the machine remove and see if problem is resolved. 2. Check the welding and work cables for loose or faulty connections.	1. Check the voltage feedback leads for loose or faulty connections. See the wiring diagram. 2. The encoders and or User Interface boards may be faulty.
<b>ENGINE PROBLEMS</b>		
Engine will not crank when start switch is pushed.	1. Make sure the On/Idler switch is set to On. 2. Check the battery connections.	1. Perform the <b>On/Idler Switch Test</b> . 2. Perform the <b>Start Switch Test</b> . 3. Perform the <b>CR1 Start Relay Test</b> . 4. The Left Side Control Board may be faulty.
The Engine will crank but not start when the start button is pressed.	1. Make sure the glow Plug Button is pressed. 2. Make sure there is adequate fuel in the tank. 3. If the engine is cranking slow the battery may need charged. 4. Make sure the fuel shut off is in the open position. 5. Check the 5AMP fuse. See the Wiring Diagram.	1. Perform <b>the Glow Button Test</b> . 2. Perform the <b>CR2 Relay Test</b> . 3. Perform the <b>Engine Control Unit (ECU) Test</b> . 4. The Left Side Control Board may be faulty.
The Engine starts but shuts down shortly after starting.	1. Check to make sure there is sufficient oil in the engine. 2. The engine coolant temperature may be too high. 3. Make sure there is sufficient fuel in the tank.	1. Perform the <b>Engine Control Unit (ECU) Test</b> .
The Engine will not shut off.	1. Make sure the On/Idler Switch is set to OFF.	1. Perform the <b>On/Idler Switch Test</b> . 2. Perform the <b>CR2 Relay Test</b> . 3. Perform the <b>Engine Control Unit (ECU) Test</b> . 4. The Left Side Control Board may be faulty.



If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your Lincoln Authorized Service Facility for technical troubleshooting assistance before you proceed.

[WWW.LINCOLNELECTRIC.COM/LOCATOR](http://WWW.LINCOLNELECTRIC.COM/LOCATOR)

PROBLEMS (SYMPTOMS)	POSSIBLE CAUSE	RECOMMENDED COURSE OF ACTION
<b>ENGINE PROBLEMS (CONT)</b>		
The Engine will not go to low idle.	<ol style="list-style-type: none"> <li>1. Make sure the ON/Idler Switch is in the Auto Position</li> <li>2. Make sure there is not a load on the Auxiliary Receptacles or the Welding Output Terminals.</li> </ol>	<ol style="list-style-type: none"> <li>1. Perform the <i>On/Idler Switch Test</i>.</li> <li>2. Perform the <i>CR2 Relay Test</i>.</li> <li>3. Perform the <i>Engine Control Unit (ECU) Test</i>.</li> <li>4. The Auxiliary Toroid Sensor may be faulty.</li> <li>5. The Left or Right Side Control Board may be faulty.</li> <li>6. The Left Side User Interface may be faulty.</li> </ol>
The Engine will not go to full power (high speed) when a load is applied to the Auxiliary Receptacles.	<ol style="list-style-type: none"> <li>1. Make sure the load is above 100 Watts.</li> <li>2. Make sure the ON/Idler Switch is in the Auto Position.</li> </ol>	<ol style="list-style-type: none"> <li>1. Perform the <i>On/Idler Switch Test</i>.</li> <li>2. Perform the <i>CR2 Relay Test</i>.</li> <li>3. Perform the <i>Engine Control Unit (ECU) Test</i>.</li> <li>4. The Auxiliary Toroid Sensor may be faulty.</li> </ol>
The Engine will not go to full power (high speed) when a load is applied to the Left Side Welding Terminals.	<ol style="list-style-type: none"> <li>1. Make sure the ON/Idler Switch is in the Auto Position.</li> </ol>	<ol style="list-style-type: none"> <li>1. Perform the <i>On/Idler Switch Test</i>.</li> <li>2. Perform the <i>CR2 Relay Test</i>.</li> <li>3. Perform the <i>Engine Control Unit (ECU) Test</i>.</li> <li>4. The Left Side Control Board may be faulty.</li> </ol>
The Engine will not go to full power (high speed) when a load is applied to the Right Side Welding Terminals.	<ol style="list-style-type: none"> <li>1. Make sure the ON/Idler Switch is in the Auto Position.</li> <li>2. Make sure the Output Switch (S1) is in the DUAL position. See the Wiring Diagram</li> </ol>	<ol style="list-style-type: none"> <li>1. Perform the <i>On/Idler Switch Test</i>.</li> <li>2. Perform the <i>CR2 Relay Test</i>.</li> <li>3. Perform the <i>Engine Control Unit (ECU) Test</i>.</li> <li>4. Check the wire connections between the Left Side Control Board and the Right Side Control Board. See the wiring diagram.</li> <li>5. The Right Side Control Board may be faulty.</li> </ol>
<b>FUNCTION PROBLEMS</b>		
The battery does not stay charged.	<ol style="list-style-type: none"> <li>1. Check for loose or faulty connections at the battery terminals and charging circuit.</li> <li>2. The battery may be faulty.</li> <li>3. The fan belt may be loose.</li> </ol>	<ol style="list-style-type: none"> <li>1. Perform <i>the Engine Alternator Test</i>.</li> </ol>
There is no control of output at the front panel.	<ol style="list-style-type: none"> <li>1. Verify the remote control is not turned ON. "Remote ON" appears on the bottom left of the screen whenever a remote control device is installed.</li> </ol>	<ol style="list-style-type: none"> <li>1. The encoders and or User Interface Board(s) may be faulty.</li> </ol>
The welding output is limited when using a remote control device. The welding output is normal when in machine/local control.	<ol style="list-style-type: none"> <li>1. The machine may be in the TIG welding mode. If so, this is normal.</li> </ol>	<ol style="list-style-type: none"> <li>1. While in the weld mode go to the remote screen and change the scaling of the remote.</li> </ol>



If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your Lincoln Authorized Service Facility for technical troubleshooting assistance before you proceed.

[WWW.LINCOLNELECTRIC.COM/LOCATOR](http://WWW.LINCOLNELECTRIC.COM/LOCATOR)

## ENGINE FAULT FLASH CODES ON ECG

J1939-73		FAULT	WILL ENGINE SHUTDOWN?	CORRECTIVE ACTION
SPN	FMI			
100	1	Oil pressure error	Yes	Turn off the machine. Disconnect the negative on the battery. Check lead 234, connected to the oil pressure switch, located on the left side of the engine below the alternator. Check ECU wiring.
110	0	Engine overheat	Yes	Check to see if the load is above the rated output of the machine. Check the fan belt. Check the fan blade. Check oil level. Inspect inside machine to see if any debris is preventing proper airflow from being provided to the engine and radiator. Open the engine service door and allow the coolant temperature to cool down to ambient. Once the engine is cooled, check the coolant level. Ensure the coolant level is always above the fins of the radiator and at the neck. If the cause is electrical, turn off the machine, disconnect the negative, and check leads 241 and GND-S, as well as the connector connected to the coolant sensor located on the left side of the engine, above the alternator.
110	3	Water temperature sensor: High	Yes	Turn off the machine. Disconnect the negative on the battery. Check leads 241 and GND-S, as well as the connector connected to the coolant sensor located on the left side of the engine, above the alternator.
110	4	Water temperature sensor: Low	Yes	
158	3	Factory calibration lost	Yes	Turn off the machine. Disconnect the negative on the battery. Confirm the battery voltage with a multimeter. If incorrect the ECU requires a recalibration. If the voltage is correct, turn the machine on but, do not start the engine. This will allow the battery to discharge.
190	0	Engine overrun	Yes	Turn off the machine. Disconnect the negative on the battery. Check speed sensor connector, located on the right side of the engine, above the oil filter, to ensure it is properly connected. Moreover, inspect leads 57, 57N, and 57P to ensure they are properly connected to the connector and have no rips or tears in the leads or sleeving. If the speed of the engine is exceeding 4100 rpm and the problem is not electrical, please call your Lincoln service provider.
523771	2	Actuator abnormal	Yes	Turn off the machine. Disconnect the negative on the battery. Ensure leads 58 and 58N are both connected securely to the actuator connector, located on the right side of the engine towards the fan. Inspect both leads for rips and tears in sleeving.
523772	2	Engine speed sensor abnormal	Yes	Turn off the machine. Disconnect the negative on the battery. Check speed sensor connector, located on the right side of the engine, above the oil filter, to ensure it is properly connected. Moreover, inspect leads 57, 57N, and 57P to ensure they are properly connected to the connector and have no rips or tears in the leads or sleeving.
523736	2	Starter error	Yes	Turn off the machine. Disconnect the negative on the battery. Check the battery voltage. Check leads CAN H and CAN L, located on the left side of the machine coming out of the ECU harness and the PCB harness. Inspect the alternator including all leads going into the unit.
523737	2	Alternator L terminal abnormal	Yes	Turn off the machine. Disconnect the negative on the battery. Inspect the L terminal connected to the alternator. Ensure it is connected correctly. Furthermore, check leads 233A and 100 coming out of the L connector for rips and tears in the leads.
523738	2	Charging failure	Yes	



If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your Lincoln Authorized Service Facility for technical troubleshooting assistance before you proceed.

[WWW.LINCOLNELECTRIC.COM/LOCATOR](http://WWW.LINCOLNELECTRIC.COM/LOCATOR)

# TEST PROCEDURES

## HOW TO USE THE TEST REFERENCE CHART



### WARNING

Service and Repair should only be performed by Lincoln Electric Factory Trained Personnel. Unauthorized repairs performed on this equipment may result in danger to the technician and machine operator and will invalidate your factory warranty. For your safety and to avoid Electrical Shock, please observe all safety notes and precautions detailed throughout this manual.

The Test Reference Chart is a nonspecific, operations based troubleshooting aide intended to identify components involved in a particular machine function. The left side of the chart consists of a listing of all major components in the machine. Across the top of the chart the three main machine functions are listed. This chart is provided to help you quickly identify possible faulty components, simply identify the particular function and refer to its specified column for a list of its related components. Simply follow the steps below.

### Step 1. IDENTIFY MACHINE FUNCTION

There will be three columns with a "MACHINE FUNCTION" listed at the top. You can choose from "POWER UP", "PRIMARY OUTPUT" or 'AUXILIARY OUTPUT". Choose the column that best describes the symptom that the machine is exhibiting a problem with. Examples are as follows:

- POWER UP - machine wont turn on, blows fuses, no display
- WELDING OUTPUT - no welding output, no wire feed, cannot control output, poor welding characteristics
- AUXILIARY OUTPUT - does not power feeder, no power from 120V receptacle,

### Step 2. IDENTIFY RELATED COMPONENTS

If a component is used in a particular "MACHINE FUNCTION" it will be marked in the corresponding column. These components serve a purpose for the identified "MACHINE FUNCTION" and could be related to the symptom identified as a possible faulty component.

RELATED COMPONENT LIST	MACHINE FUNCTION DUAL MAVERICK® 200/200X		
	POWER UP	WELDING OUTPUT	AUXILIARY OUTPUT
Auxiliary Receptacles			X
AVR	X	X	X
CB1			X
CB2			X
CB3			X
CB4	X		
CB5			X
Chopper PCB3		X	
Chopper PCB4		X	
CR1	X		
CR2	X		
CR3	X		X
D1		X	
D2		X	
D3			
ECU	X	X	
L1 Choke		X	
L2 Choke		X	
Stator		X	
GFCI			X
Engine Starter	X		
Engine Alternator	X		
Glow Plug Switch	X		
Start Switch	X		
Run/Stop/Idle Switch	X		



If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your Lincoln Authorized Service Facility for technical troubleshooting assistance before you proceed.

[WWW.LINCOLNELECTRIC.COM/LOCATOR](http://WWW.LINCOLNELECTRIC.COM/LOCATOR)

Refer to Safety pages for explanation of hazards:



## ALTERNATOR TEST PROCEDURE

### TEST DESCRIPTION:

This procedure will determine the proper function of the Alternator using Active tests.

### MATERIALS NEEDED:

1/2" Nut Driver  
Miscellaneous Hand Tools  
Digital Multi-Meter  
Wiring Diagram  
Machine Schematic  
Required P.P.E.

### TEST PROCEDURE:

1. For location of the Alternator refer to Figure F.1.





Figure F.1

2. Perform the "Case Cover Removal" to gain access for testing.
3. Perform the Active Testing.



**A. ACTIVE TESTING**

- A.1. Ensure the engine and On/Idle/Stop switch are set as per the conditions listed in Test Table 1.
- A.2. Perform the measurements identified in Test Table 1 below, refer to Figure F.2 for test point locations.



**Figure F.2**

Alternator Active Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
Battery Voltage	Engine not running	Positive Battery Terminal	Negative Battery Terminal	~12.6VDC
Alternator Flashing	Engine not running, On/Idle/Stop Switch Set to HIGH	Lead 233A	Chassis Ground (Terminal Block T4)	~12.6VDC
Alternator Charging		Positive Battery Terminal	Negative Battery Terminal	13.7VDC - 14.2VDC
Alternator Charging		Lead 238	Chassis Ground (Terminal Block T4)	13.7VDC - 14.2VDC
Alternator Feedback to ECU		Lead 100	Chassis Ground (Terminal Block T4)	13.7VDC - 14.2VDC

**Table 1**

- A.3. If the measurements are not correct this component may be faulty.
4. If problems with the machine persist, refer to the “Test Reference” chart for other possible faulty components. Reconnect anything disconnected in previous steps.

Refer to Safety pages for explanation of hazards:



### AUXILIARY RECEPTACLES TEST PROCEDURE

#### TEST DESCRIPTION:

This procedure will determine the proper function of the Auxiliary Receptacles using Active tests.

#### MATERIALS NEEDED:

8mm Nut Driver  
Miscellaneous Hand Tools  
Digital Multi-Meter  
Wiring Diagram  
Machine Schematic  
Required P.P.E.

#### TEST PROCEDURE:

1. For location of the Auxiliary Receptacles refer to Figure F.1.





Figure F.1

2. Perform the “Case Cover Removal” to gain access for testing.
3. Perform the Active Testing.

**A. ACTIVE TESTING**

- A.1. Ensure the engine is running and On/Idle/Stop switch set to HIGH.
- A.2. Perform the measurements identified in Test Table 1 below, refer to Figure F.2 for test point locations.



**Figure F.2**

Auxiliary Receptacles Active Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
120 / 240 VAC Single Phase Receptacle (J100)	Engine running on HIGH	TP1	TP2	~240VAC
		TP1	TP3	~120VAC
		TP2	TP3	~120VAC
120VAC Receptacle Left Side (J102)		TP4	TP5	~120VAC
120VAC Receptacle Right Side (J102)		TP6	TP7	~120VAC

**Table 1**

- A.3. If the output measurements are not correct this component may be faulty.
- 4. If problems with the machine persist, refer to the “Test Reference” chart for other possible faulty components. Reconnect anything disconnected in previous steps.

Refer to Safety pages for explanation of hazards:



### AUTOMATIC VOLTAGE REGULATOR TEST PROCEDURE

#### TEST DESCRIPTION:

This procedure will determine the proper function of the Automatic Voltage Regulator (AVR) using Active tests.

#### MATERIALS NEEDED:

1/2" Nut Driver  
Miscellaneous Hand Tools  
Digital Multi-Meter  
Wiring Diagram  
Machine Schematic  
Required P.P.E.

#### TEST PROCEDURE:

1. For location of the AVR refer to Figure F.1.





Figure F.1

2. Perform the "Case Cover Removal" to gain access for testing.
3. Perform the Active Testing.

**A. ACTIVE TESTING**

A.1. Ensure all AVR dip switches are ON, the jumper is present on the “EXT POT” tabs, the engine is running and On/Idle/Stop switch set to HIGH.

A.2. Perform the measurements identified in Test Table 1 below, refer to Figure F.2 for test point locations.



**Figure F.2**

AVR Active Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
AVR Voltage	Engine Running, On/Idle/Stop switch set to HIGH, Unit set to Single or Dual Mode	AUXL	AUXN	~120VAC
AVR Sensing Voltage	Engine Running, On/Idle/Stop switch set to HIGH, Unit set to Single or Dual Mode	230	AUXL	~240VAC
AVR Rotor Exciter Voltage	Engine Running, On/Idle/Stop switch set to HIGH	+EX	-EX	~5.5VDC

**Table 1**

A.3. If the output measurements are not correct this component may be faulty.

4. If problems with the machine persist, refer to the “Test Reference” chart for other possible faulty components. Reconnect anything disconnected in previous steps.

Refer to Safety pages for explanation of hazards:



**CB1 TEST PROCEDURE**

**TEST DESCRIPTION:**

This procedure will determine the proper function of the CB1 using Static tests.

**MATERIALS NEEDED:**

- 3/8” Nut Driver
- Miscellaneous Hand Tools
- Digital Multi-Meter
- Wiring Diagram
- Machine Schematic
- Required P.P.E.

**TEST PROCEDURE:**

1. For location of the CB1 refer to Figure F.1.




**Figure F.1**

2. Perform the “Case Cover Removal” to gain access for testing.
3. Perform the Static Testing.

**A. STATIC TESTING**


A.1. Ensure the machine is off and the On/Idle/Stop switch is in the STOP position.

A.2. Label and disconnect the following connections, refer to Figure F.2.



**Figure F.2**

A.3. Perform the static measurements in Test Table 1, refer to Figure F.3 for test point locations. NOTE: Leads are disconnected for these measurements.



**Figure F.3**

CB1 Static Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
CB1	Engine not running, CB1 not tripped	Terminal 3A	Terminal A	0Ω
		Terminal 6D	Terminal C	0Ω

**Table 1**

A.3. Any failed measurement indicates a defective component.

4. If problems with the machine persist, refer to the “Test Reference” chart for other possible faulty components. Reconnect anything disconnected in previous steps.

Refer to Safety pages for explanation of hazards:



## CB2 TEST PROCEDURE

### TEST DESCRIPTION:

This procedure will determine the proper function of the CB2 using Static tests.

### MATERIALS NEEDED:

3/8" Nut Driver  
Miscellaneous Hand Tools  
Digital Multi-Meter  
Wiring Diagram  
Machine Schematic  
Required P.P.E.

### TEST PROCEDURE:

1. For location of the CB2 refer to Figure F.1.



Figure F.1


2. Perform the "Case Cover Removal" to gain access for testing.
3. Perform the Static Testing.



**A. STATIC TESTING**


A.1. Ensure the machine is off and the On/Idle/Stop switch is in the STOP position.

A.2. Label and disconnect the following connections, refer to Figure F.2.



**Figure F.2**

A.3. Perform the static measurements in Test Table 1, refer to Figure F.3 for test point locations. NOTE: Leads are disconnected for these measurements.



**Figure F.3**

CB2 Static Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
CB2	Engine not running, CB2 not tripped	Terminal 3A	Terminal 8B	0Ω

**Table 1**

A.3. Any failed measurement indicates a defective component.

4. If problems with the machine persist, refer to the “Test Reference” chart for other possible faulty components. Reconnect anything disconnected in previous steps.

Refer to Safety pages for explanation of hazards:



### CB3 TEST PROCEDURE

#### TEST DESCRIPTION:

This procedure will determine the proper function of the CB3 using Static tests.

#### MATERIALS NEEDED:

3/8" Nut Driver  
Miscellaneous Hand Tools  
Digital Multi-Meter  
Wiring Diagram  
Machine Schematic  
Required P.P.E.

#### TEST PROCEDURE:

1. For location of the CB3 refer to Figure F.1.




Figure F.1

2. Perform the "Case Cover Removal" to gain access for testing.
3. Perform the Static Testing.

**A. STATIC TESTING**


A.1. Ensure the machine is off and the On/Idle/Stop switch is in the STOP position.

A.2. Label and disconnect the following connections, refer to Figure F.2.



**Figure F.2**

A.3. Perform the static measurements in Test Table 1, refer to Figure F.3 for test point locations. NOTE: Leads are disconnected for these measurements.



**Figure F.3**

CB3 Static Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
CB3	Engine not running, CB3 not tripped	Terminal 6B	Terminal 8B	0Ω

**Table 1**

A.3. Any failed measurement indicates a defective component.

4. If problems with the machine persist, refer to the “Test Reference” chart for other possible faulty components. Reconnect anything disconnected in previous steps.

Refer to Safety pages for explanation of hazards:



### CB4 TEST PROCEDURE

#### TEST DESCRIPTION:

This procedure will determine the proper function of the CB4 using Static tests.

#### MATERIALS NEEDED:

3/8" Nut Driver  
Miscellaneous Hand Tools  
Digital Multi-Meter  
Wiring Diagram  
Machine Schematic  
Required P.P.E.

#### TEST PROCEDURE:

1. For location of the CB4 refer to Figure F.1.




Figure F.1

2. Perform the "Case Cover Removal" to gain access for testing.
3. Perform the Static Testing.

**A. STATIC TESTING**


A.1. Ensure the machine is off and the On/Idle/Stop switch is in the STOP position.

A.2. Label and disconnect the following connections, refer to Figure F.2.



**Figure F.2**

A.3. Perform the static measurements in Test Table 1, refer to Figure F.3 for test point locations. NOTE: Leads are disconnected for these measurements.



**Figure F.3**

CB4 Static Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
CB4	Engine not running, CB4 not tripped	Terminal 236	Terminal 238D	0Ω

**Table 1**

A.3. Any failed measurement indicates a defective component.

4. If problems with the machine persist, refer to the “Test Reference” chart for other possible faulty components. Reconnect anything disconnected in previous steps.

Refer to Safety pages for explanation of hazards:



### CB5 TEST PROCEDURE

#### TEST DESCRIPTION:

This procedure will determine the proper function of the CB5 using Static tests.

#### MATERIALS NEEDED:

3/8" Nut Driver  
Miscellaneous Hand Tools  
Digital Multi-Meter  
Wiring Diagram  
Machine Schematic  
Required P.P.E.

#### TEST PROCEDURE:

1. For location of the CB5 refer to Figure F.1.




Figure F.1

2. Perform the "Case Cover Removal" to gain access for testing.
3. Perform the Static Testing.

**A. STATIC TESTING**


A.1. Ensure the machine is off and the On/Idle/Stop switch is in the STOP position.

A.2. Label and disconnect the following connections, refer to Figure F.2.



**Figure F.2**

A.3. Perform the static measurements in Test Table 1, refer to Figure F.3 for test point locations. NOTE: Leads are disconnected for these measurements.



**Figure F.3**

CB5 Static Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
CB5	Engine not running, CB5 not tripped	Terminal 43	Terminal 42D	0Ω

**Table 1**

A.3. Any failed measurement indicates a defective component.

4. If problems with the machine persist, refer to the “Test Reference” chart for other possible faulty components. Reconnect anything disconnected in previous steps.

Refer to Safety pages for explanation of hazards:



### CHOPPER PCB3 TEST PROCEDURE

#### TEST DESCRIPTION:

This procedure will determine the proper function of the Chopper PCB3 using Static and Active tests.

#### MATERIALS NEEDED:

1/2" nut driver  
7/16" nut driver  
Digital Multi-Meter  
Wiring Diagram  
Machine Schematic  
Required P.P.E.

#### TEST PROCEDURE:

1. For location of the Chopper PCB3 refer to Figure F.1.




Figure F.1


2. Perform the "Case Cover Removal" to gain access for testing.
3. Perform the Static Testing.



**A. STATIC TESTING**


A.1. Ensure the machine is off and the On/Idle/Stop switch is in the STOP position.

A.2. Label and disconnect the following connections, refer to Figure F.2.



**Figure F.2**

A.3. Perform the static measurements in Test Table 1, refer to Figure F.3 for test point locations.



**Figure F.3**

CHOPPER PCB3 Static Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
Chopper Board PCB3	Engine not running, On/Idle/Stopswitch set to STOP, Meter set to Diode Mode	Terminal B3	Terminal B2	~0.334VDC
		Terminal B1	Terminal B3	~0.334 VDC
		Terminal B6	Terminal B5	~0.334 VDC
		Terminal B4	Terminal B6	OL

**Table 1**


A.4. If measurements are correct reconnect anything disconnected in previous steps and proceed to “B. ACTIVE TESTING”.

A.5. Any failed measurement indicates a defective component.

**B. ACTIVE TESTING**

B.1. Ensure the engine is running at High Idle, On/Idle/Stop switch set to HIGH and set to CC-Stick Mode Dual Operation.

B.2. Perform the measurements in Test Table 2 below, refer to Figure F.4 for test point locations.



**Figure F.4**

CHOPPER PCB3 Active Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
Chopper Board PCB3 Input	Engine running at High Idle, On/Idle/Stop switch set to HIGH, CC-Stick Mode Dual Operation	Terminal B2	Terminal B1	~104VDC
		Terminal B5	Terminal B4	~104VDC
Terminal B2		Terminal B3	~57VDC	
Terminal B5		Terminal B6	~57VDC	
Chopper Board PCB3 Output				

**Table 2**

B.3. If the input measurements are correct and the output measurements are not correct this component may be faulty.

4. If problems with the machine persist, refer to the “Test Reference” chart for other possible faulty components. Reconnect anything disconnected in previous steps.

Refer to Safety pages for explanation of hazards:



### CHOPPER PCB4 TEST PROCEDURE

#### TEST DESCRIPTION:

This procedure will determine the proper function of the Chopper PCB4 using Static and Active tests.

#### MATERIALS NEEDED:

1/2" nut driver  
7/16" nut driver  
Digital Multi-Meter  
Wiring Diagram  
Machine Schematic  
Required P.P.E.

#### TEST PROCEDURE:

1. For location of the Chopper PCB4 refer to Figure F.1.





Figure F.1

2. Perform the "Case Cover Removal" to gain access for testing.
3. Perform the Static Testing.

**A. STATIC TESTING**


A.1. Ensure the machine is off and the On/Idle/Stop switch is in the STOP position.

A.2. Label and disconnect the following connections, refer to Figure F.2.



**Figure F.2**

A.3. Perform the static measurements in Test Table 1, refer to Figure F.3 for test point locations.



**Figure F.3**

CHOPPER PCB4 Static Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
Chopper Board PCB4	Engine not running, On/Idle/Stop switch set to STOP, Meter set to Diode Mode	Terminal B3	Terminal B2	~0.334VDC
		Terminal B1	Terminal B3	~0.334 VDC
		Terminal B6	Terminal B5	~0.334 VDC
		Terminal B4	Terminal B6	OL

**Table 1**


A.4 If measurements are correct reconnect anything disconnected in previous steps and proceed to “B. ACTIVE TESTING”.

A.5. Any failed measurement indicates a defective component.

**B. ACTIVE TESTING**

B.1. Ensure the engine is running at High Idle, On/Idle/Stop switch set to HIGH and set to CC-Stick Mode Dual Operation.

B.2. Perform the measurements in Test Table 2 below, refer to Figure F.4 for test point locations.



**Figure F.4**

CHOPPER PCB4 Active Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
Chopper Board PCB4 Input	Engine running at High Idle, On/Idle/Stop switch set to HIGH, CC-Stick Mode Dual Operation	Terminal B2	Terminal B1	~104VDC
		Terminal B5	Terminal B4	~104VDC
Terminal B2		Terminal B3	~57VDC	
Terminal B5		Terminal B6	~57VDC	

**Table 2**

B.3. If the input measurements are correct and the output measurements are not correct this component may be faulty.

4. If problems with the machine persist, refer to the “Test Reference” chart for other possible faulty components. Reconnect anything disconnected in previous steps.

Refer to Safety pages for explanation of hazards:



### CR1 TEST PROCEDURE

#### TEST DESCRIPTION:

This procedure will determine the proper function of the CR1 using Static and Active tests.

#### MATERIALS NEEDED:

1/2" nut driver  
Needle nose pliers  
Digital Multi-Meter  
Wiring Diagram  
Machine Schematic  
Required P.P.E.

#### TEST PROCEDURE:

1. For location of the Chopper CR1 refer to Figure F.1.





Figure F.1

2. Perform the "Case Cover Removal" to gain access for testing.
3. Perform the Static Testing.

**A. STATIC TESTING**

- A.1. Ensure the machine is off and the On/Idle/Stop switch is in the STOP position.
- A.2. Label and disconnect CR1 from its socket.
- A.3. Perform the static measurements in Test Table 1, refer to Figure F.2 for test point locations



**Figure F.2**

CR1 Static Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
CR1 coil	Engine not running, On/Idle/Stop switch set to STOP, Relay removed from socket	Terminal 86	Terminal 85	~90Ω
CR1 contacts		Terminal 30	Terminal 87	OL

**Table 1**


A.4 If measurements are correct reconnect anything disconnected in previous steps and proceed to “B. ACTIVE TESTING”.

A.5. Any failed measurement indicates a defective component.

**B. ACTIVE TESTING**

B.1. Ensure CR1 is re-installed, the “On/Idle/Stop” switch set to AUTO and Start button is DEPRESSED.

B.2. Perform the measurements in Test Table 2 below, refer to Figure F.3 for test point locations. NOTE: Measurements are taken from the leads beneath the relay socket.



**Figure F.3**

CR1 Active Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
CR1 coil input	On/Idle/Stop switch set to AUTO, Start button DEPRESSED	Lead 232Z, Terminal 86	Lead 285, Terminal 85	~12VDC
CR1 output		Lead 238C, Terminal 30	Lead 231A, Terminal 87	>1VDC

**Table 2**

B.3. If the input measurements are correct and the output measurements are not correct this component may be faulty.

4. If problems with the machine persist, refer to the “Test Reference” chart for other possible faulty components. Reconnect anything disconnected in previous steps.



Refer to Safety pages for explanation of hazards:



## CR2 TEST PROCEDURE

### TEST DESCRIPTION:

This procedure will determine the proper function of the CR2 using Static and Active tests.

### MATERIALS NEEDED:

1/2" nut driver  
Needle nose pliers  
Digital Multi-Meter  
Wiring Diagram  
Machine Schematic  
Required P.P.E.

### TEST PROCEDURE:

1. For location of the Chopper CR2 refer to Figure F.1.





Figure F.1

2. Perform the "Case Cover Removal" to gain access for testing.
3. Perform the Static Testing.

**A. STATIC TESTING**

- A.1. Ensure the machine is off and the On/Idle/Stop switch is in the STOP position.
- A.2. Label and disconnect CR2 from its socket.
- A.3. Perform the static measurements in Test Table 1, refer to Figure F.2 for test point locations



**Figure F.2**

CR2 Static Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
CR2 coil	Engine not running, On/Idle/Stop switch set to STOP, Relay removed from socket	Terminal 86	Terminal 85	~90Ω
CR2 contacts		Terminal 30	Terminal 87	OL


**Table 1**

- A.4 If measurements are correct reconnect anything disconnected in previous steps and proceed to “B. ACTIVE TESTING”.
- A.5. Any failed measurement indicates a defective component.

**B. ACTIVE TESTING**

B.1. Ensure CR2 is re-installed, the 'On/Idle/Stop" switch set to AUTO and Start button is DEPRESSED.

B.2. Perform the measurements in Test Table 2 below, refer to Figure F.3 for test point locations. NOTE: MEASUREMENTS ARE TAKEN FROM THE LEADS BENEATH THE RELAY SOCKET.



**Figure F.3**

CR2 Active Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
CR2 input	On/Idle/Stop switch set to AUTO, Start button DEPRESSED	Lead 232, Terminal 86	Lead 377, Terminal 85	~12VDC
CR2 output		Lead 236A, Terminal 30	Lead 233A, Terminal 87	>1VDC

**Table 2**

B.3. If the input measurements are correct and the output measurements are not correct this component may be faulty.

4. If problems with the machine persist, refer to the "Test Reference" chart for other possible faulty components. Reconnect anything disconnected in previous steps.

Refer to Safety pages for explanation of hazards:



### CR3 TEST PROCEDURE

#### TEST DESCRIPTION:

This procedure will determine the proper function of the CR3 using Static and Active tests.

#### MATERIALS NEEDED:

1/2" nut driver  
Needle nose pliers  
Digital Multi-Meter  
Wiring Diagram  
Machine Schematic  
Required P.P.E.

#### TEST PROCEDURE:

1. For location of the Chopper CR3 refer to Figure F.1.





Figure F.1

2. Perform the "Case Cover Removal" to gain access for testing.
3. Perform the Static Testing.

**A. STATIC TESTING**


A.1. Ensure the machine is off and the On/Idle/Stop switch is in the STOP position.

A.2. Label and disconnect the following leads, refer to Figure F.2 below.



**Figure F.2**

A.3. Perform the static measurements in Test Table 1, refer to Figure F.3 for test point locations



**Figure F.3**

CR3 Static Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
CR3 coil	Engine not running, On/Idle/Stop switch set to STOP	Terminal 232T	Terminal 832	~90Ω
CR3 contacts		Terminal 200A	Terminal 200	OL

**Table 1**


A.4. If measurements are correct reconnect anything disconnected in previous steps and proceed to “B. ACTIVE TESTING”.

A.5. Any failed measurement indicates a defective component.

**B. ACTIVE TESTING**

B.1. Ensure CR3 leads are re-installed, the On/Idle/Stop switch set to AUTO and the engine is NOT running.

B.2. Perform the measurements in Test Table 2 below, refer to Figure F.3 for test point locations. NOTE: MEASUREMENTS ARE TAKEN WITH THE LEADS INSTALLED.



**Figure F.3**

CR3 Active Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
CR3 coil input	Engine NOT running, On/Idle/Stop switch set to AUTO	Lead 232T	Lead 832	~12VDC
CR3 output		Lead 200A	Lead 200	>1VDC

**Table 2**

B.3. If the input measurements are correct and the output measurements are not correct this component may be faulty.

4. If problems with the machine persist, refer to the “Test Reference” chart for other possible faulty components. Reconnect anything disconnected in previous steps.

Refer to Safety pages for explanation of hazards:



## D1 TEST PROCEDURE

### TEST DESCRIPTION:

This procedure will determine the proper function of D1 using Static and Active tests.

### MATERIALS NEEDED:

1/2" nut driver  
7/16" nut driver  
Digital Multi-Meter  
Wiring Diagram  
Machine Schematic  
Required P.P.E.

### TEST PROCEDURE:

1. For location of the D1 refer to Figure F.1.





Figure F.1

2. Perform the "Case Cover Removal" to gain access for testing.
3. Perform the Static Testing.

**A. STATIC TESTING**


A.1. Ensure the machine is off and the On/Idle/Stop switch is in the STOP position.

A.2. Label and disconnect the following leads, refer to Figure F.2 below.



**Figure F.2**

A.3. Perform the static measurements in Test Table 1, refer to Figure F.3 for test point locations.



**Figure F.3**

D1 Static Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
D1	Engine not running, On/Idle/Stop switch set to STOP, Meter set to DIODE mode	Terminal X2	POS Terminal	.3-.7VDC
		Terminal X1	POS Terminal	.3-.7VDC
		Terminal X3	POS Terminal	.3-.7VDC
		NEG Terminal	Terminal X2	.3-.7VDC
		NEG Terminal	Terminal X1	.3-.7VDC
		NEG Terminal	Terminal X3	.3-.7VDC

**Table 1**




A.4 If measurements are correct reconnect anything disconnected in previous steps and proceed to “B. ACTIVE TESTING”.

A.5. Any failed measurement indicates a defective component.

**B. ACTIVE TESTING**

B.1. Ensure D1 leads are re-installed, the On/Idle/Stop switch set to HIGH, Single/Dual switch set to DUAL and the engine is at High Idle.

B.2. Perform the measurements in Test Table 2 below, refer to Figure F.3 for test point locations. NOTE: MEASUREMENTS ARE TAKEN WITH THE LEADS INSTALLED.



**Figure F.3**

D1 Active Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
Phase 1 AC Input	Engine running, On/Idle/Stop switch set to HIGH, Single/Dual switch set to DUAL	Lead X2	Lead X1	~72VAC
Phase 2 AC Input		Lead X3	Lead X1	~72VAC
Phase 3 AC Input		Lead X2	Lead X3	~72VAC
Rectified Output		Lead POS	Lead NEG	~104VDC

**Table 2**

B.3. If the input measurements are correct and the output measurements are not correct this component may be faulty.

4. If problems with the machine persist, refer to the “Test Reference” chart for other possible faulty components. Reconnect anything disconnected in previous steps.

Refer to Safety pages for explanation of hazards:



## D2 TEST PROCEDURE

### TEST DESCRIPTION:

This procedure will determine the proper function of the D2 using Static and Active tests.

### MATERIALS NEEDED:

1/2" nut driver  
7/16" nut driver  
Digital Multi-Meter  
Wiring Diagram  
Machine Schematic  
Required P.P.E.

### TEST PROCEDURE:

1. For location of the D2 refer to Figure F.1.




Figure F.1

2. Perform the "Case Cover Removal" to gain access for testing.
3. Perform the Static Testing.

**A. STATIC TESTING**


A.1. Ensure the machine is off and the “Run/Stop/Idle” switch is in the STOP position.

A.2. Label and disconnect the following leads, refer to Figure F.2 below.



**Figure F.2**

A.3. Perform the static measurements in Test Table 1, refer to Figure F.3 for test point locations. NOTE: MEASUREMENTS ARE TAKEN WITH LEADS REMOVED.



**Figure F.3**

D2 Static Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
D2	Engine not running, Run/Stop/Idle switch set to STOP, Meter set to DIODE mode	Terminal Y2	POS Terminal	.3-.7VDC
		Terminal Y1	POS Terminal	.3-.7VDC
		Terminal Y3	POS Terminal	.3-.7VDC
		NEG Terminal	Terminal Y2	.3-.7VDC
		NEG Terminal	Terminal Y1	.3-.7VDC
		NEG Terminal	Terminal Y3	.3-.7VDC

**Table 1**


A.4 If measurements are correct reconnect anything disconnected in previous steps and proceed to “B. ACTIVE TESTING”.

A.5. Any failed measurement indicates a defective component.

**B. ACTIVE TESTING**

B.1. Ensure D2 leads are re-installed, the Run/Stop/Idle switch set to HIGH, Single/Dual switch set to DUAL and the engine is at High Idle.

B.2. Perform the measurements in Test Table 2 below, refer to Figure F.3 for test point locations. NOTE: MEASUREMENTS ARE TAKEN WITH THE LEADS INSTALLED.



**Figure F.3**

D2 Active Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
Phase 1 AC Input	Engine running, Run/Stop/Idle switch set to HIGH, Single/Dual switch set to DUAL	Lead Y2	Lead Y1	~72VAC
Phase 2 AC Input		Lead Y3	Lead Y1	~72VAC
Phase 3 AC Input		Lead Y2	Lead Y3	~72VAC
Rectified Output		Lead POS	Lead NEG	~104VDC

**Table 2**

B.3. If the input measurements are correct and the output measurements are not correct this component may be faulty.

4. If problems with the machine persist, refer to the “Test Reference” chart for other possible faulty components. Reconnect anything disconnected in previous steps.

Refer to Safety pages for explanation of hazards:



### D3 TEST PROCEDURE

#### TEST DESCRIPTION:

This procedure will determine the proper function of the D3 using Static and Active tests.

#### MATERIALS NEEDED:

1/2" nut driver  
7/16" nut driver  
Digital Multi-Meter  
Wiring Diagram  
Machine Schematic  
Required P.P.E.

#### TEST PROCEDURE:

1. For location of the D3 refer to Figure F.1.





Figure F.1

2. Perform the "Case Cover Removal" to gain access for testing.
3. Perform the Static Testing.

**A. STATIC TESTING**


A.1. Ensure the machine is off and the “Run/Stop/Idle” switch is in the STOP position.

A.2. Label and disconnect the following leads, refer to Figure F.2 below.



**Figure F.2**

A.3. Perform the static measurements in Test Table 1, refer to Figure F.3 for test point locations.



**Figure F.3**

D3 Static Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
D3	Engine not running, Run/Stop/Idle switch set to STOP, Meter set to DIODE mode	Terminal 43	Terminal 311	.3-.7VDC
		Terminal 41C	Terminal 311	.3-.7VDC
		Terminal 310	Terminal 43	.3-.7VDC
		Terminal 310	Terminal 41C	.3-.7VDC

**Table 1**


A.4. If measurements are correct reconnect anything disconnected in previous steps and proceed to “B. ACTIVE TESTING”.

A.5. Any failed measurement indicates a defective component.

**B. ACTIVE TESTING**

B.1. Ensure D3 leads are re-installed, the Run/Stop/Idle switch set to HIGH, Single/Dual switch set to DUAL and the engine is at High Idle.

B.2. Perform the measurements in Test Table 2 below, refer to Figure F.3 for test point locations.



**Figure F.3**

D3 Active Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
D3 Input	Engine running, Run/Stop/Idle switch set to AUTO	Lead 41C	Lead 43	~43VAC
D3 Output		Lead 311	Lead 310	~41VDC

**Table 2**

B.3. If the input measurements are correct and the output measurements are not correct this component may be faulty.

4. If problems with the machine persist, refer to the “Test Reference” chart for other possible faulty components. Reconnect anything disconnected in previous steps.

Refer to Safety pages for explanation of hazards:



## ENGINE CONTROL UNIT (ECU) TEST PROCEDURE

### TEST DESCRIPTION:

This procedure will determine the proper function of the ECU using Active tests.

### MATERIALS NEEDED:

1/2" Nut Driver  
Miscellaneous Hand Tools  
Digital Multi-Meter  
Wiring Diagram  
Machine Schematic  
Required P.P.E.

### TEST PROCEDURE:

1. For location of the ECU refer to Figure F.1.




Figure F.1

2. Perform the "Case Cover Removal" to gain access for testing.
3. Perform the Active Testing.



A. ACTIVE TESTING

- A.1. Ensure the engine is NOT running and On/Idle/Stop switch set as directed.
- A.2. Label and disconnect the following connectors, refer to Figure F.2 below.




Figure F.2

- A.3. Perform the active measurements in Test Table 1, refer to Figure F.3 for test point locations. NOTE: AFTER 45 SECONDS THE ECU WILL TIME OUT, CYCLE TIMER MOVING THE ON/IDLE/STOP SWITCH TO STOP THEN HIGH OR AUTO.




Figure F.3

ECU Active Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
ECU Low Power	On/Idle/Stop switch set to OFF	CB4 Lead 236B	T4 Terminal Block	~12VDC
ECU Speed Power	On/Idle/Stop switch set to Auto or High idle	Lead 57P	Lead 57N	~10.6VDC
ECU Engine Start Signal	On/Idle/Stop switch set to HIGH, Start Button Pressed	Lead 52C	T4 Terminal block	~12.2VDC
ECU Power	On/Idle/Stop switch set to Auto	Lead 233	T4 Terminal Block	~12VDC
ECU Oil Pressure Sensor Signal	On/Idle/Stop switch set to HIGH	Lead 234	Chassis Ground	~10.6VDC
ECU Actuator Power	On/Idle/Stop switch set to HIGH	Lead 58	Lead 58N	~12.4VDC

**Table 1**

A.4. If the measurements are not correct this component may be faulty.

4. If problems with the machine persist, refer to the “Test Reference” chart for other possible faulty components. Reconnect anything disconnected in previous steps.

Refer to Safety pages for explanation of hazards:



### GLOW PLUG SWITCH TEST PROCEDURE

#### TEST DESCRIPTION:

This procedure will determine the proper function of the Glow Plug Switch using Static and Active tests.

#### MATERIALS NEEDED:

1/2" nut driver  
7/16" nut driver  
Digital Multi-Meter  
Wiring Diagram  
Machine Schematic  
Required P.P.E.

#### TEST PROCEDURE:

1. For location of the Glow Plug Switch refer to Figure F.1.





Figure F.1

2. Perform the "Case Cover Removal" to gain access for testing.
3. Perform the Static Testing.

**A. STATIC TESTING**

A.1. Ensure the machine is off and the On/Idle/Stop switch is in the STOP position and the Battery is NOT connected.

A.2. Perform the static measurements in Test Table 1, refer to Figure F.2 for test point locations.



**Figure F.2**

Glow Plug Switch Static Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
Glow Plug Switch	Battery disconnected, Glow Plug button depressed.	Lead 238B	Lead 239	<1Ω
	Battery disconnected, Glow Plug button NOT depressed.	Lead 238B	Lead 239	OL

**Table 1**


A.3 If measurements are correct reconnect anything disconnected in previous steps and proceed to “B. ACTIVE TESTING”.

A.4. Any failed measurement indicates a defective component.

**B. ACTIVE TESTING**

B.1. Ensure the engine is NOT running, On/Idle/Stop switch set to HIGH and the Glow Plug button is depressed when directed as per Test Table 2 below.

B.2. Perform the measurements in Test Table 2 below, refer to Figure F.4 for test point locations.



**Figure F.3**

Glow Plug Switch Active Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
Glow Plug Switch Input	Glow Plug button NOT depressed	Lead 238B	Lead 239	~12VDC
Glow Plug Switch Output	Glow Plug button depressed	Lead 238B	Lead 239	<1VDC

**Table 2**

B.3. If the input measurements are correct and the output measurements are not correct this component may be faulty.

4. If problems with the machine persist, refer to the “Test Reference” chart for other possible faulty components. Reconnect anything disconnected in previous steps.

Refer to Safety pages for explanation of hazards:



### L1 CHOKE TEST PROCEDURE

#### TEST DESCRIPTION:

This procedure will determine the proper function of the L1 Choke using Static tests.

#### MATERIALS NEEDED:

1/2" Nut Driver  
Miscellaneous Hand Tools  
Digital Multi-Meter  
Wiring Diagram  
Machine Schematic  
Required P.P.E.

#### TEST PROCEDURE:

1. For location of the L1 Choke refer to Figure F.1.





Figure F.1

2. Perform the "Case Cover Removal" to gain access for testing.
3. Perform the Static Testing.

**A. STATIC TESTING**


A.1. Ensure the machine is off and the On/Idle/Stop switch is in the STOP position.

A.2. Label and disconnect the following connections, refer to Figure F.2.



**Figure F.2**

A.3. Perform the static measurements in Test Table 1, refer to Figure F.3 for test point locations. NOTE: LEAD NEG IS DISCONNECTED FOR THESE MEASUREMENTS.



**Figure F.3**

L1 CHOKE Static Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
L1 Choke	On/Idle/Stop switch set to STOP	Terminal B3	Terminal NEG	< 1 Ohms
		Terminal B3	Chassis Ground	OL Ohms

**Table 1**

A.3. Any failed measurement indicates a defective component.

4. If problems with the machine persist, refer to the “Test Reference” chart for other possible faulty components. Reconnect anything disconnected in previous steps.

Refer to Safety pages for explanation of hazards:



## L2 CHOKE TEST PROCEDURE

### TEST DESCRIPTION:

This procedure will determine the proper function of the L2 Choke using Static tests.

### MATERIALS NEEDED:

1/2" Nut Driver  
Miscellaneous Hand Tools  
Digital Multi-Meter  
Wiring Diagram  
Machine Schematic  
Required P.P.E.

### TEST PROCEDURE:

1. For location of the L2 Choke refer to Figure F.1.




Figure F.1


2. Perform the "Case Cover Removal" to gain access for testing.
3. Perform the Static Testing.



**A. STATIC TESTING**


A.1. Ensure the machine is off and the On/Idle/Stop switch is in the STOP position.

A.2. Label and disconnect the following connections, refer to Figure F.2.



**Figure F.2**

A.3. Perform the static measurements in Test Table 1, refer to Figure F.3 for test point locations. NOTE: LEAD NEG IS DISCONNECTED FOR THESE MEASUREMENTS.



**Figure F.3**

L2 CHOKE Static Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
L2 Choke	On/Idle/Stop switch set to STOP	Terminal B3	Terminal NEG	< 1 Ohms
		Terminal B3	Chassis Ground	OL Ohms

**Table 1**

A.3. Any failed measurement indicates a defective component.

4. If problems with the machine persist, refer to the “Test Reference” chart for other possible faulty components. Reconnect anything disconnected in previous steps.

Refer to Safety pages for explanation of hazards:



### ON/IDLE/STOP SWITCH TEST PROCEDURE

#### TEST DESCRIPTION:

This procedure will determine the proper function of the On/Idle/Stop Switch using Static and Active tests.

#### MATERIALS NEEDED:

1/2" nut driver  
3/8" nut driver  
Digital Multi-Meter  
Wiring Diagram  
Machine Schematic  
Required P.P.E.

#### TEST PROCEDURE:

1. For location of the On/Idle/Stop Switch refer to Figure F.1.




Figure F.1

2. Perform the "Case Cover Removal" to gain access for testing.
3. Perform the Static Testing.

**A. STATIC TESTING**

A.1. Ensure the machine is off and the “On/Idle/Stop” switch is in the STOP position and the Battery is NOT connected.

A.2. Perform the static measurements in Test Table 1, refer to Figure F.2 for test point locations. NOTE: ENSURE THE BATTERY IS NOT CONNECTED BEFORE TAKING ANY MEASUREMENTS.



**Figure F.2**

On/Idle/Stop Switch Static Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
On/Idle/Stop Switch	On/Idle/Stop Switch in High Idle (POS. 1)	Lead 236 (Terminal 2)	Lead 232L (Terminal 3)	<1Ω
	On/Idle/Stop Switch in Auto (POS. 2)	Lead 236 (Terminal 2)	Lead 232L (Terminal 3)	<1Ω
	On/Idle/Stop Switch in High Idle (POS. 1)	Lead 844 (Terminal 6)	Lead GND-W (Terminal 5)	<1Ω
	On/Idle/Stop Switch in High Idle (POS. 2)	Lead 844 (Terminal 6)	Lead GND-W (Terminal 5)	OL
	On/Idle/Stop Switch in Stop (POS. 3)	Lead 236 (Terminal 2)	Lead 232L (Terminal 3)	OL
	On/Idle/Stop Switch in Stop (POS. 3)	Lead 844 (Terminal 6)	Lead GND-W (Terminal 5)	OL

**Table 1**

A.3 If measurements are correct reconnect anything disconnected in previous steps and proceed to “B. ACTIVE TESTING”.

A.4. Any failed measurement indicates a defective component.


**B. ACTIVE TESTING**

B.1. Ensure the engine is NOT running, On/Idle/Stop switch set as directed per Test Table 2 below.

B.2. Perform the measurements in Test Table 2 below, refer to Figure F.3 for test point locations.

SWITCH FUNCTION

POS. 1	POS. 2	POS. 3
ON	ON	OFF
2 TO 3	2 TO 3	
5 TO 6		



**Figure F.3**

On/Idle/Stop Switch Active Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
On/Idle/Stop Switch	On/Idle/Stop Switch set to HIGH (POS. 1)	Lead 236 (Terminal 2)	Lead 232L (Terminal 3)	<1VDC
	On/Idle/Stop Switch set to AUTO (POS. 2)	Lead 236 (Terminal 2)	Lead 232L (Terminal 3)	<1VDC
	On/Idle/Stop Switch set to HIGH (POS. 1)	Lead 844 (Terminal 6)	Lead GND-W (Terminal 5)	<1VDC
	On/Idle/Stop Switch set to AUTO (POS. 2)	Lead 844 (Terminal 6)	Lead GND-W (Terminal 5)	~12VDC
	On/Idle/Stop Switch set to STOP (POS. 3)	Lead 236 (Terminal 2)	Lead 232L (Terminal 3)	~12VDC
	On/Idle/Stop Switch set to STOP (POS. 3)	Lead 844 (Terminal 6)	Lead GND-W (Terminal 5)	~12VDC

**Table 2**

B.3. If the measurements are not correct this component may be faulty.

4. If problems with the machine persist, refer to the “Test Reference” chart for other possible faulty components. Reconnect anything disconnected in previous steps.

Refer to Safety pages for explanation of hazards:



### START SWITCH TEST PROCEDURE

#### TEST DESCRIPTION:

This procedure will determine the proper function of the Start Switch using Static and Active tests.

#### MATERIALS NEEDED:

1/2" nut driver  
3/8" nut driver  
Digital Multi-Meter  
Wiring Diagram  
Machine Schematic  
Required P.P.E.

#### TEST PROCEDURE:

1. For location of the Start Switch refer to Figure F.1.





Figure F.1

2. Perform the "Case Cover Removal" to gain access for testing.
3. Perform the Static Testing.

**A. STATIC TESTING**

A.1. Ensure the machine is off and the On/Idle/Stop switch is in the STOP position and the Battery is NOT connected.

A.2. Perform the static measurements in Test Table 1, refer to Figure F.2 for test point locations. NOTE: ENSURE THE BATTERY IS NOT CONNECTED BEFORE TAKING ANY MEASUREMENTS.



**Figure F.2**

Start Switch Static Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
Start Switch	Start button depressed	Lead 238A	Lead 52A	<1Ω
	Start button not depressed	Lead 238A	Lead 52A	OL


**Table 1**

A.3 If measurements are correct reconnect anything disconnected in previous steps and proceed to “B. ACTIVE TESTING”.

A.4. Any failed measurement indicates a defective component.

**B. ACTIVE TESTING**

- B.1. Ensure the engine is NOT running, On/Idle/Stop switch set to HIGH.
- B.2. Perform the measurements in Test Table 2 below, refer to Figure F.3 for test point locations.



**Figure F.3**

Start Switch Active Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
Start Switch input	Battery Connected, Start button NOT depressed	Lead 238A	Lead 52A	12VDC
Start Switch output	Battery Connected, Start button depressed	Lead 238A	Lead 52A	<1VDC

**Table 2**

- B.3. If the measurements are not correct this component may be faulty.
- 4. If problems with the machine persist, refer to the “Test Reference” chart for other possible faulty components. Reconnect anything disconnected in previous steps.

Refer to Safety pages for explanation of hazards:



## STARTER TEST PROCEDURE

### TEST DESCRIPTION:

This procedure will determine the proper function of the Starter using Active tests.

### MATERIALS NEEDED:

1/2" Nut Driver  
Miscellaneous Hand Tools  
Digital Multi-Meter  
Wiring Diagram  
Machine Schematic  
Required P.P.E.

### TEST PROCEDURE:

1. For location of the Starter refer to Figure F.1.





Figure F.1

2. Perform the "Case Cover Removal" to gain access for testing.
3. Perform the Active Testing.



**A. ACTIVE TESTING**

- A.1. Ensure the engine and On/Idle/Stop switch are set as per the conditions listed in Test Table 1.
- A.2. Perform the measurements identified in Test Table 1 below, refer to Figure F.2 for test point locations.



**Figure F.2**

Starter Active Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
Input from Battery	Engine not running	Lead 238	Chassis Ground	~12.6VDC
Input From Relay	On/Idle/Stop switch Set to HIGH, Lead 231 disconnected, Start Button depressed	Lead 231	Chassis Ground	~12.6VDC
Output to Starter Motor	On/Idle/Stop switch Set to HIGH, Start Button depressed	Lead S	Chassis Ground	~12.6VDC

**Table 1**

- A.3. If the input measurements are correct and the output measurements are not this component may be faulty.
- 4. If problems with the machine persist, refer to the “Test Reference” chart for other possible faulty components. Reconnect anything disconnected in previous steps.

Refer to Safety pages for explanation of hazards:



## STATOR TEST PROCEDURE

### TEST DESCRIPTION:

This procedure will determine the proper function of the Stator using Static and Active tests.

### MATERIALS NEEDED:

1/2" Nut Driver  
Digital Multi-Meter  
Wiring Diagram  
Machine Schematic  
Required P.P.E.

### TEST PROCEDURE:

1. For location of the Stator refer to Figure F.1.





Figure F.1

2. Perform the "Case Cover Removal" to gain access for testing.
3. Perform the Static Testing.

**A. STATIC TESTING**

A.1. Ensure the machine is off and the On/Idle/Stop switch is in the STOP position.

A.2. Label and disconnect the following leads, refer to Figure F.2 below.



**Figure F.2**

A.3. Perform the static measurements in Test Table 1, refer to Figure F.2 for test point locations. NOTE: MEASUREMENTS ARE MADE ON THE DISCONNECTED LEADS.

Stator Static Test (left side)				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
Stator Weld Windings	Engine not running, On/Idle/Stop switch set to STOP	Lead X1	Lead X2	< 1 Ohms
		Lead X1	Lead X3	< 1 Ohms
		Lead X2	Lead X3	< 1 Ohms
		Lead X1	Chassis Ground	OL Ohms
		Lead X2	Chassis Ground	OL Ohms
		Lead X3	Chassis Ground	OL Ohms

**Table 1**

A.4. Ensure the machine is off and the On/Idle/Stop switch is in the STOP position.

A.5. Label and disconnect the following leads, refer to Figure F.3 below.




Figure F.3

A.6. Perform the static measurements in Test Table 2, refer to Figure F.3 for test point locations. NOTE: MEASUREMENTS ARE MADE ON THE DISCONNECTED LEADS.

Stator Static Test (right side)				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
Stator Weld Windings	Engine not running, Run/Stop/Idle switch set to STOP	Lead Y1	Lead Y2	< 1 Ohms
		Lead Y1	Lead Y3	< 1 Ohms
		Lead Y2	Lead Y3	< 1 Ohms
		Lead Y1	Chassis Ground	OL Ohms
		Lead Y2	Chassis Ground	OL Ohms
		Lead Y3	Chassis Ground	OL Ohms

Table 2

A.7. Ensure the machine is off and the On/Idle/Stop switch is in the STOP position.

A.8. Label and disconnect the following leads, refer to Figure F.4 below.




Figure F.4

A.9. Perform the static measurements in Test Table 3, refer to Figure F.4 for test point locations. NOTE: MEASUREMENTS ARE MADE ON THE DISCONNECTED LEADS.

Stator Static Test (right side)				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
Stator Auxiliary Windings	Engine not running, Run/Stop/Idle switch set to STOP	Lead V1	Lead V2	< 1 Ohms
		Lead V3	Lead V4	< 1 Ohms
		Lead W1	Lead W2	< 1 Ohms
		Lead W3	Lead W4	< 1 Ohms
		Lead U1	Lead U2	< 1 Ohms
		Lead U3	Lead U4	< 1 Ohms
		Lead 41C	Lead 42C	< 1 Ohms
		Lead V1	Ground	OL Ohms
		Lead V3	Ground	OL Ohms
		Lead W1	Ground	OL Ohms
		Lead W3	Ground	OL Ohms
		Lead U1	Ground	OL Ohms
		Lead U3	Ground	OL Ohms
		Lead 41C	Ground	OL Ohms

**Table 3**


A.10 If measurements are correct reconnect anything disconnected in previous steps and proceed to “B. ACTIVE TESTING”.

A.11. Any failed measurement indicates a defective component.

**B. ACTIVE TESTING**

B.1. Ensure Stator leads are re-installed, the Run/Stop/Idle switch set to HIGH, Single/Dual switch set to DUAL and the engine is at High Idle.

B.2. Perform the measurements in Test Table 4 below, refer to Figure F.3 for test point locations. NOTE: MEASUREMENTS ARE TAKEN WITH THE LEADS INSTALLED.



**Figure F.3**

Stator Active Test				
Component/Circuit Tested	Condition(s)	+Meter Lead	-Meter Lead	Expected Value
Stator Weld Windings	Engine running, Run/Stop/Idle switch set to HIGH, Single/Dual switch set to DUAL	Terminal Y1	Terminal Y2	~72VAC
		Terminal Y1	Terminal Y3	~72VAC
		Terminal Y2	Terminal Y3	~72VAC
Stator Weld Windings		Terminal X1	Terminal X2	~72VAC
		Terminal X1	Terminal X3	~72VAC
		Terminal X2	Terminal X3	~72VAC
Stator Auxiliary Windings		Lead V1 & V3	Lead W2 & W4	~120VAC
		Lead U2 & U4	Lead U1 & U3	~120VAC
		Lead V1 & V3	Lead U1 & U3	~240VAC
	Lead 41C	Lead 42C	~42VAC	

**Table 4**

B.3. If the measurements are not correct this component may be faulty.

4. If problems with the machine persist, refer to the “Test Reference” chart for other possible faulty components. Reconnect anything disconnected in previous steps.



## DUAL MAVERICK 200/200X

### RETEST AFTER REPAIR

Retest a machine:

- If it is rejected under test for any reason that requires you to remove any mechanical part which could affect the machine’s electrical characteristics.  
OR
- If you repair or replace any electrical components.

### ENGINE OUTPUT

Engine Mode	No Load RPM	Load RPM
Low Idle	2500 RPM	N/A
High Idle	3600 RPM	3600 RPM

### WELDER RATED OUTPUT


Weld Mode	Output Control	Maximum Open Circuit Voltage	Load Voltage	Load Amps
Single Mode	Maximum	80 VDC	24.5 VDC	450 Amps
Dual Mode	Maximum	80 VDC	24.5 VDC	225 Amps

### WELDER OUTPUT RANGES


Weld Mode	Output Control	Current Range	Process
Single Mode	Variable	50 – 450 Amps	Constant Current
Single Mode	Variable	30 – 370 Amps	Constant Voltage
Single Mode	Variable	20 – 255 Amps	TIG CC
Dual Mode	Variable	30 – 225 Amps	Constant Current
Dual Mode	Variable	30 – 220 Amps	Constant Voltage
Dual Mode	Variable	20 – 255 Amps	TIG CC

### AUXILIARY POWER OUTPUT






Open Circuit Voltage	Load Amps	Watts (Continuous)
240 VAC 1-Phase	50 Amps	10,000 Watts
120 VAC 1-Phase	20 Amps	2400 Watts



**NOTE:** This diagram is for reference only. It may not be accurate for all machines covered by this manual. The specific diagram for a particular code is included with the machine. If the diagram is illegible, write to the Service Department for a replacement. Give the equipment code number.



NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual. The specific diagram for a particular code is included with the machine. If the diagram is illegible, write to the Service Department for a replacement. Give the equipment code number.



This page intentionally left blank

**2 Step** – When the gun trigger is pulled, the welding system cycles through the arc starting sequence and into the main welding parameters. The welding system will continue to weld as long as the gun trigger is activated. Once the trigger is released, the welding system cycles through the arc ending steps.

**3 Phase voltage** – Three AC voltage sources that are phase shifted 120° with respect to each other.

**4 Step** – The 4 step trigger adds to the welder's comfort when making long welds by allowing the trigger to be released after an initial trigger pull. When the gun trigger is pulled, the welding system cycles through the arc starting sequence and into the main welding parameters. Welding stops when the trigger is pulled a second time and then released and the welding system cycles through the arc ending steps.

**A-lead** – The single wire used to configure the machine reconnect for various input Voltages.

**AC (Alternating Current)** – Voltage or current that changes polarity or direction, respectively, over time.

**Active Condition** – The machine is energized either by connection to a power source or has some kind of mechanical motion within the unit.

**Alternator** – An electric generator that produces alternating current. The main function of this device is to change mechanical energy into electrical energy. The mechanical energy can be supplied by either a motor or engine.

**Ampere (Amp)** – The standard measurement unit of current flow. Symbol: A

**Anode** – The positively charged electrode of a device.

**Arc Control (Pinch)** – Adjusts how quickly the current will rise when the wire is shorted to the work resulting in a soft or crisp arc.

**Arc Force** – A temporary increase of the output current during SMAW welding when the arc is too short.

**Arc Length** – The physical gap between the end of the electrode and the weld puddle.

**Across the Arc** – The device is electrically connected to the welding terminals. This device is powered by the same voltage that is used for welding.

**Arc-link cable** – Used between the power source and wire feeder in a bench system and between the power source, control box and wire drive in a boom system. This 5 pin cable supplies voltage from the power source to power the feeder and also transmits digital signals between the two.

**Armature** – The part of an electric device that includes the main current-carrying winding and in which the electromotive force is induced.

**Armature Reaction** – A force set up by the current induced in the armature of a generator that results in altering as to both magnitude and direction the flux due to the field magnet.

**Asynchronous Welder Generator** – An alternator that utilizes an air-gap rotating magnetic-field between a stator and a rotor to interact with an induced current in a rotor winding. It is sometimes called an induction generator.

**Auxiliary Windings** – Stator winding used to power the auxiliary connections.

**Battery** – A combination of two or more cells electrically connected to work together to produce electric energy.

**Block Diagram** – visual representation of a machine that utilizes simplified blocks to represent the principal parts or functions of the machine.

**Boost Converter** – The boost converter increases applied voltage to a higher level. This circuitry only applies to DC voltage and is only active if the applied voltage is below a predetermined value.

**Bridge Rectifier** – A type of full wave rectifier which uses four or more diodes in a bridge circuit configuration to efficiently convert the Alternating Current (AC) into Direct Current (DC).

**Brushes** – An electrical contact which conducts current between stationary wires and moving parts, most commonly in a rotating shaft.

**Buck Converter** – The buck converter decreases applied voltage to a lower level. This circuitry only applies to DC voltage and is only active if the applied voltage is above a predetermined value.

**Buck/Boost Converter** – The combined buck/boost circuitry is utilized to increase or decrease an applied voltage to a predetermined value.

**CAN communication** – Controller Area Network (CAN bus) is a robust vehicle bus standard designed to allow microcontrollers and devices to communicate with each other's applications without a host computer. It broadcasts messages to the nodes presented in a network.

**Cathode** – The negatively charged electrode of a device.

**Capacitance** – The ability of a body to store an electrical charge.

**Capacitor** – A device used to store an electric charge, consisting of one or more pairs of conductors separated by an insulator. Capacitance is measured in Farad's (F) and some capacitors are polarity sensitive which is typically noted on the device as such.

**Circuit Breaker** – A device to prevent excessive current flow in a circuit that may be caused by a short circuit or heavy loads. The circuit breaker will stop the flow of current (open) if such a situation occurs.

**Collector** – The positively charged electrode of a transistor device.

**Commutator** – A cylindrical ring or disk assembly of conducting members, individually insulated in a supporting structure with an exposed surface for contact with current-collecting brushes and mounted on the armature shaft, for changing the frequency or direction of the current in the armature windings.

**Conductor** – A type of material that allows the flow of charge (**electrical** current) in one or more directions

**Connectors** – Various devices for connecting one object to another.

**Constant Current** – A process where the power source keeps the current as constant as possible even when the operator varies the arc length. The voltage varies, formerly known as "variable voltage". Mainly used for Stick and TIG welding.

**Constant Voltage** – A process where the power source keeps the voltage as constant as possible and allows amperage to vary considerably. Mainly used for MIG and Flux core welding using wire feeders.

**Contact**or – A mechanically or electrically operated switch used in high current applications.

**Control cable** – A multistrand cable used for transmission of power, command and feedback information.

**Crosslinc** – A welding system communication technology. When using a Crosslinc enabled power source and wire feeder, welding voltage can be controlled remotely, through the welding cable without the use of an additional control cable.

**Current** – The flow of electrons through a conductor.

**Current Transducer** – A device used to detect DC current flow.

**Cycle** – One complete wave of alternating current or voltage.

**DC (Direct Current)** – A voltage or current that never crosses zero and maintains current flow in one direction.

**Diode** – A device used in a circuit that allows current to flow in one direction only. Typically current flow will occur if the diode's anode is more positive than its cathode. Typical configurations used can be: blocking, flashing, free-wheeling, full wave bridge rectifier, half wave rectifier.

**Display** – An electronic device with a screen used for displaying information.

**Duty Cycle** – The percentage of a ten (10) minute period that a power source can operate its rated load before exceeding its thermal limit.

**Efficiency** – The ratio of the output power divided by the input power.

**Electrical Interference (noise)** – Unwanted noise or other effects from electromagnetic radiation.

**Electricity** – The flow of electrons through a conductor from the source to a ground.

**Electrode Negative** – When the electrode is connected to the negative output terminal.

**Electrode Positive** – When the electrode is connected to the positive output terminal.

**Electromagnetism** – Magnetism developed by a current of electricity.

**Emitter** – The negatively charged electrode of a transistor device.

**Encoder** – An electro-mechanical device that converts the angular position or motion of a shaft or axle to digital output signals.

**Excitation** – The process of generating a magnetic field by means of an electric current. The source of this can be from a magnet or an external voltage source.

**Excitation Windings** – Stator winding that powers the excitation process in an alternator or generator.

**Farads** – The standard measurement unit of capacitance. Symbol: f

**Feedback** – To provide actual output information to a control circuit so as to maintain a constant output.

**Feeder Winding** – Stator winding that powers the wire feeders.

**Field Windings** – The stationary windings of a generator.



**Field Current** – The current flow through the Field Windings

**Light Emitting Diode (LED)** – A semiconductor device that emits light when an electric current passes through it.

**Flashing** – A generic term referring to the initial excitation of an electrical magnetic field.

**Forward Biased** – When voltage is applied to a semiconductor device in the direction that allows current to flow.

**Frequency** – The number of occurrences of a repeating event (cycles) per unit of Time.

**Full Wave** – A rectifier that converts alternating current into continuous current and that utilizes both halves of each cycle of the alternating current.

**Fuse** – An electrical safety device that operates to provide overcurrent protection of an electrical circuit. Its essential component is a metal wire or strip that melts when too much current flows through it, thereby interrupting current flow.

**Gate** – Is the control terminal in a semiconductor device. Typically a small voltage is applied to the Gate to trigger or latch the device.

**Generator** – An electric generator that produces direct current. The main function of this device is to change mechanical energy into electrical energy. The mechanical energy can be supplied by either a motor or engine.

**GFCI (Ground Fault Circuit Interrupter)** – A device which interrupts current flow when it senses an imbalance between the outgoing and incoming current.

**Ground Connection** – A safety connection from a welding machine frame to an earth ground.

**Half Wave** - A rectifier that utilizes one half cycle of alternating current and suppresses the other.

**Henry** – The standard measurement unit of inductance. Symbol: H

**Hertz** – The standard measurement unit of electrical frequency. Symbol: Hz

**High Frequency** – A high frequency used for arc ignition and stabilization when TIG welding.

**Hot Start** – Increases the output amperage for a designated amount of time at the start of a weld.

**Insulated Gate Bipolar Transistor (IGBT)** – A high speed solid state switching device that can be turned on by applying a voltage signal to the gate. When the gate signal is removed the IGBT will turn off. An IGBT will operate on DC voltage only.

**Inductance** – The tendency of an electrical conductor to oppose a change in the electric current flowing through it.

**Inductor** – A passive component which stores the electrical energy in a magnetic field when the electric current passes through it.

**Interpole Coils** – Utilized in generators. They counteract the effects of armature reaction.

**Inverter** – circuitry that changes direct current (DC) to alternating current (AC).

**Life Cycle** – The length of time a product is introduced to consumers until it's removal from the shelves.

**Motor** – An electrical device that converts electrical energy into mechanical energy.

**Magnetic Field** – The area around a magnet or coil in which there is magnetic force.

**Magnetic Flux** – The measurement of the total magnetic field lines that pass through a given surface area.

**Magnetism** – The force that arises from the motion of electric charges.

**MOLEX** – Is the vernacular term for a two-piece pin and socket interconnection that was pioneered by Molex Connector Company.

**Negative Temperature Co-efficient (NTC)** – A type of thermistor in which the resistance decreases in relation to a rise in temperature.

**OCV (Open Circuit Voltage)** –The potential voltage in the welding circuit before the arc is initiated or a load applied; measured in volts.

**Ohms** – The standard measurement unit of electrical resistance. Symbol:  $\Omega$

**Ohm's Law** – current passing through a conductor is proportional to the voltage over the resistance.  $I = V / R$ .

**Parallel Circuit** – a circuit that has multiple current paths.

**Peak Value** – The maximum value attained by the current during one cycle. There is a positive and negative peak.

**Peak to Peak Value** – The maximum value attained by both peaks during one cycle.

**Phase** – A relative variation or change of state or a cycle.

**Phaseback (foldback)** – A current limiting feature (a type of overload protection).

**Pilot Arc** – The electrical pathway between the torch nozzle and electrode tip. This function aids in the transfer of current from the electrode tip to the work piece.

**Polarity** – The polarity of the electrode as compared to the polarity of the work piece.

**Positive Temperature Co-efficient (PTC)** – A type of thermistor in which the resistance increases in relation to a rise in temperature.

**Potentiometer** – It is a variable resistor with three terminals. The middle terminal is adjustable. The potential at the third terminal can be adjusted to give any fraction of the potential voltage across the two outer terminals.

**Power** – The rate, over time, in which electrical energy is transferred within an electrical circuit.

**Power Factor** – The ratio of the real power that is used to do work to the apparent power that is supplied to the circuit.

**Printed Circuit Boards** – A physical device that houses one or more electrical circuits.

**Pulsating DC** – A periodic current which changes in value but never changes direction.

**Rated Load** – The average amperage and voltage the power source is designed to produce for a given specific duty cycle time period. For example, 400 amps, 36 load volts, at 60 percent duty cycle.

**RCBO (Residual Current Breaker with Over-current)** – A combination of a RCD and Circuit Breaker.

**RCD (Residual Current Device)** – Detects imbalance in the currents of the supply and return conductors of a circuit. Does not protect against shorts.

**Reactor** – An electrical magnetic component used to maintain current at constant levels by resisting any changes in the current.

**Reconnect Panel** – Used to configure the machine's internal components for various input power voltages

**Rectification** – The process of converting alternating current to direct current.

**Relay** – An electrically operated switch used in low current applications.

**Resistance** – The opposition to the passage of an electric current through a conductor. Measured in Ohms ( $\Omega$ ) and is not polarity sensitive.

**Resistor** – Used to regulate voltage and current levels in a circuit.

**Reverse Biased** – When voltage is applied to a semiconductor device in the direction that does not allow current to flow.

**Rheostat** – A two terminal adjustable resistor that may have its resistance value changed without opening the circuit in which it is connected, thereby controlling the current through the circuit.

**Ripple** – The residual periodic variation of the DC voltage within a power supply which has been derived from an alternating current source.

**RMS (Root Means Squared)** – The same amount of heat dissipation across a resistor as Direct Current.

**Rotor** – A rotating component of an electromagnetic system in an electric motor, or alternator.

**RPM (Revolutions per minute)** – A unit of rotational speed or the frequency of rotation around a fixed axis.

**Saturation** – The state reached when an increase in applied external magnetic field cannot increase the magnetization of the material further.

**Saw Tooth Wave Form** – A non-sinusoidal waveform. It is so named based on its resemblance to the teeth of a plain-toothed saw.

**Schematic Diagram** – A representation of the electronic components of a machine utilizing graphic symbols rather than realistic pictures.

**Schematic Symbols** – A standardized pictogram used to represent various electrical and electronic devices or function.

**Series Circuit** – a circuit that has only one current path.

**Series - Parallel Circuit** – a circuit that has both a single current path and multiple current paths.

**Silicon Controlled Rectifier (SCR)** – Very similar to a Diode in which it allows current to flow when the anode is more positive than the cathode. However, current flow will occur only if a small signal is applied to its Gate and will stop flowing when the voltage drops to zero or goes negative.

**Shunt** – A type of low value resistance used to detect circuit current.

**Sinusoidal Wave Form** – A curve that describes a smooth repetitive oscillation of a waveform.

**Slip Rings** – An electromechanical device that allows the transmission of electrical power from a stationary to a rotating structure. Normally a copper or brass circular device attached to a rotating member.

**Solenoid** – An electromechanical device that when energized acts like a magnet so that a movable core is drawn into the coil when a current flows and that is used especially as a switch or control for a mechanical device (such as a valve).

**Source** – Provides the electrical potential that is required for electricity to flow.

**Spark Gap Generator** – Used to initiate and maintain the arc in a TIG machine.

**Square Wave Form** – A type of waveform where the signal has only two levels. The signal transitions between these levels at regular intervals and the switching time is very rapid.

**Standard Units of Measurement** – Is a quantifiable language that helps everyone understand the association of the object with the measurement.

**Static Condition** – The machine is not connection to a power source and has no mechanical motion.

**Stator** – The stationary part of a rotary system, found in electric alternators, generators and electric motors.

**Switch** – A mechanical device used to interrupt the flow of current in a circuit. Switches are essentially binary devices: they are either completely on (closed) or completely off (open).

**Tachometer** – A device or circuit used to measure the rotations of a mechanical device.

**Thermistor** – A type of resistor in which resistance changes due to temperature, two main types: Positive Temperature Co-efficient (PTC), Negative Temperature Co-efficient (NTC).

**Thermostat** – A mechanical device that interrupts or closes a circuit when a pre-determined temperature limit is reached.

**Toroid** – A device used to filter unwanted electrical noise.

**Trigger Interlock** – The gun trigger will stay closed (activated) as long as welding current is flowing and will open (deactivate) when welding current stops.

**Transformer** – A device with a group of mutually-inductive coils used to magnetically induce AC power from one coil to the other. Typical examples are as follows:

***Isolation Transformer*** – A transformer usually used for circuit protection.

***Step Down Transformer*** – A transformer where the secondary voltage is lower than the primary voltage.

***Step Up Transformer*** – A transformer where the secondary voltage is higher than the primary voltage.

***Current Transformer*** – A type of transformer used as a current monitoring device.

***Power Transformer*** – A transformer that contains multiple primary windings to accommodate a variety of input voltages.

**Twisted Pair** – A cable consisting of two wires of a single circuit twisted around each other for the purposes of improving electromagnetic compatibility.

**Voltage** – The pressure or difference in electrical potential between two points in a circuit that causes current to flow.

**Volts** – The standard unit of measurement for Voltage. Symbol: V

**User Interface** – A device where interactions between operators and machines occur.

**Watts** – The standard measurement unit of electrical power. Symbol: W

**Watts Law** – power of an electrical circuit is the product of its voltage and current.  $P = I \times V$ .

**Weld Winding** – Stator winding that provides the power for the welding components.

**Welding Electrode** – A consumable component of the welding circuit through which current is conducted between the electrode holder and the arc that becomes part of the weldment.

**Welding Gun** – In semi-automatic or automatic welding, a device to transfer current and guide the electrode wire into the arc puddle.

**Wire Harness** – A system of insulated conducting wires bound together with insulating materials.

**Wiring Diagram** – a simple visual representation of the physical connections and physical layout of the electrical system of the machine.

**WFS (Wire Feed Speed)** – The speed at which the consumable wire is fed into the weld joint puddle.

<b>WARNING</b>	<ul style="list-style-type: none"> <li>● Do not touch electrically live parts or electrode with skin or wet clothing.</li> <li>● Insulate yourself from work and ground.</li> </ul>	<ul style="list-style-type: none"> <li>● Keep flammable materials away.</li> </ul>	<ul style="list-style-type: none"> <li>● Wear eye, ear and body protection.</li> </ul>
Spanish <b>AVISO DE PRECAUCION</b>	<ul style="list-style-type: none"> <li>● No toque las partes o los electrodos bajo carga con la piel o ropa mojada.</li> <li>● Aíslese del trabajo y de la tierra.</li> </ul>	<ul style="list-style-type: none"> <li>● Mantenga el material combustible fuera del área de trabajo.</li> </ul>	<ul style="list-style-type: none"> <li>● Protéjase los ojos, los oídos y el cuerpo.</li> </ul>
French <b>ATTENTION</b>	<ul style="list-style-type: none"> <li>● Ne laissez ni la peau ni des vêtements mouillés entrer en contact avec des pièces sous tension.</li> <li>● Isolez-vous du travail et de la terre.</li> </ul>	<ul style="list-style-type: none"> <li>● Gardez à l'écart de tout matériel inflammable.</li> </ul>	<ul style="list-style-type: none"> <li>● Protégez vos yeux, vos oreilles et votre corps.</li> </ul>
German <b>WARNUNG</b>	<ul style="list-style-type: none"> <li>● Berühren Sie keine stromführenden Teile oder Elektroden mit Ihrem Körper oder feuchter Kleidung!</li> <li>● Isolieren Sie sich von den Elektroden und dem Erdboden!</li> </ul>	<ul style="list-style-type: none"> <li>● Entfernen Sie brennbares Material!</li> </ul>	<ul style="list-style-type: none"> <li>● Tragen Sie Augen-, Ohren- und Körperschutz!</li> </ul>
Portuguese <b>ATENÇÃO</b>	<ul style="list-style-type: none"> <li>● Não toque partes elétricas e electrodos com a pele ou roupa molhada.</li> <li>● Isole-se da peça e terra.</li> </ul>	<ul style="list-style-type: none"> <li>● Mantenha inflamáveis bem guardados.</li> </ul>	<ul style="list-style-type: none"> <li>● Use proteção para a vista, ouvido e corpo.</li> </ul>
Japanese <b>注意事項</b>	<ul style="list-style-type: none"> <li>● 通電中の電気部品、又は溶材にヒフやぬれた布で触れないこと。</li> <li>● 施工物やアースから身体が絶縁されている様にして下さい。</li> </ul>	<ul style="list-style-type: none"> <li>● 燃えやすいものの側での溶接作業は絶対にしてはなりません。</li> </ul>	<ul style="list-style-type: none"> <li>● 目、耳及び身体に保護具をして下さい。</li> </ul>
Chinese <b>警告</b>	<ul style="list-style-type: none"> <li>● 皮肤或湿衣物切勿接触带电部件及焊条。</li> <li>● 使你自已与地面和工件绝缘。</li> </ul>	<ul style="list-style-type: none"> <li>● 把一切易燃物品移离工作场所。</li> </ul>	<ul style="list-style-type: none"> <li>● 佩戴眼、耳及身体劳动保护用具。</li> </ul>
Korean <b>위험</b>	<ul style="list-style-type: none"> <li>● 전도체나 용접봉을 젖은 헝겍 또는 피부로 절대 접촉치 마십시오.</li> <li>● 모재와 접지를 접촉치 마십시오.</li> </ul>	<ul style="list-style-type: none"> <li>● 인화성 물질을 접근시키지 마십시오.</li> </ul>	<ul style="list-style-type: none"> <li>● 눈, 귀와 몸에 보호장구를 착용하십시오.</li> </ul>
Arabic <b>تحذير</b>	<ul style="list-style-type: none"> <li>● لا تلمس الاجزاء التي يسري فيها التيار الكهربائي أو الألكترود بجند الجسم أو بالملابس المبللة بالماء.</li> <li>● ضع عازلا على جسمك خلال العمل.</li> </ul>	<ul style="list-style-type: none"> <li>● ضع المواد القابلة للاشتعال في مكان بعيد.</li> </ul>	<ul style="list-style-type: none"> <li>● ضع أدوات وملابس واقية على عينيك وأذنيك وجسمك.</li> </ul>

**READ AND UNDERSTAND THE MANUFACTURER'S INSTRUCTION FOR THIS EQUIPMENT AND THE CONSUMABLES TO BE USED AND FOLLOW YOUR EMPLOYER'S SAFETY PRACTICES.**

**SE RECOMIENDA LEER Y ENTENDER LAS INSTRUCCIONES DEL FABRICANTE PARA EL USO DE ESTE EQUIPO Y LOS CONSUMIBLES QUE VA A UTILIZAR, SIGA LAS MEDIDAS DE SEGURIDAD DE SU SUPERVISOR.**

**LISEZ ET COMPRENEZ LES INSTRUCTIONS DU FABRICANT EN CE QUI REGARDE CET EQUIPMENT ET LES PRODUITS A ETRE EMPLOYES ET SUIVEZ LES PROCEDURES DE SECURITE DE VOTRE EMPLOYEUR.**

**LESEN SIE UND BEFOLGEN SIE DIE BETRIEBSANLEITUNG DER ANLAGE UND DEN ELEKTRODENEINSATZ DES HERSTELLERS. DIE UNFALLVERHÜTUNGSVORSCHRIFTEN DES ARBEITGEBERS SIND EBENFALLS ZU BEACHTEN.**

			
<ul style="list-style-type: none"> <li>● Keep your head out of fumes.</li> <li>● Use ventilation or exhaust to remove fumes from breathing zone.</li> </ul>	<ul style="list-style-type: none"> <li>● Turn power off before servicing.</li> </ul>	<ul style="list-style-type: none"> <li>● Do not operate with panel open or guards off.</li> </ul>	<b>WARNING</b>
<ul style="list-style-type: none"> <li>● Los humos fuera de la zona de respiración.</li> <li>● Mantenga la cabeza fuera de los humos. Utilice ventilación o aspiración para gases.</li> </ul>	<ul style="list-style-type: none"> <li>● Desconectar el cable de alimentación de poder de la máquina antes de iniciar cualquier servicio.</li> </ul>	<ul style="list-style-type: none"> <li>● No operar con panel abierto o guardas quitadas.</li> </ul>	Spanish <b>AVISO DE PRECAUCION</b>
<ul style="list-style-type: none"> <li>● Gardez la tête à l'écart des fumées.</li> <li>● Utilisez un ventilateur ou un aspirateur pour ôter les fumées des zones de travail.</li> </ul>	<ul style="list-style-type: none"> <li>● Débranchez le courant avant l'entretien.</li> </ul>	<ul style="list-style-type: none"> <li>● N'opérez pas avec les panneaux ouverts ou avec les dispositifs de protection enlevés.</li> </ul>	French <b>ATTENTION</b>
<ul style="list-style-type: none"> <li>● Vermeiden Sie das Einatmen von Schweißrauch!</li> <li>● Sorgen Sie für gute Be- und Entlüftung des Arbeitsplatzes!</li> </ul>	<ul style="list-style-type: none"> <li>● Strom vor Wartungsarbeiten abschalten! (Netzstrom völlig öffnen; Maschine anhalten!)</li> </ul>	<ul style="list-style-type: none"> <li>● Anlage nie ohne Schutzgehäuse oder Innenschutzverkleidung in Betrieb setzen!</li> </ul>	German <b>WARNUNG</b>
<ul style="list-style-type: none"> <li>● Mantenha seu rosto da fumaça.</li> <li>● Use ventilação e exaustão para remover fumo da zona respiratória.</li> </ul>	<ul style="list-style-type: none"> <li>● Não opere com as tampas removidas.</li> <li>● Desligue a corrente antes de fazer serviço.</li> <li>● Não toque as partes elétricas nuas.</li> </ul>	<ul style="list-style-type: none"> <li>● Mantenha-se afastado das partes moventes.</li> <li>● Não opere com os painéis abertos ou guardas removidas.</li> </ul>	Portuguese <b>ATENÇÃO</b>
<ul style="list-style-type: none"> <li>● ヒュームから頭を離すようにして下さい。</li> <li>● 換気や排煙に十分留意して下さい。</li> </ul>	<ul style="list-style-type: none"> <li>● メンテナンス・サービスに取りかかる際には、まず電源スイッチを必ず切して下さい。</li> </ul>	<ul style="list-style-type: none"> <li>● パネルやカバーを取り外したままで機械操作をしないで下さい。</li> </ul>	Japanese <b>注意事項</b>
<ul style="list-style-type: none"> <li>● 頭部遠離煙霧。</li> <li>● 在呼吸區使用通風或排風器除煙。</li> </ul>	<ul style="list-style-type: none"> <li>● 維修前切斷電源。</li> </ul>	<ul style="list-style-type: none"> <li>● 儀表板打開或沒有安全罩時不準作業。</li> </ul>	Chinese <b>警告</b>
<ul style="list-style-type: none"> <li>● 얼굴로부터 용접가스를 멀리하십시오.</li> <li>● 호흡지역으로부터 용접가스를 제거하기 위해 가스제거기나 통풍기를 사용하십시오.</li> </ul>	<ul style="list-style-type: none"> <li>● 보수전에 전원을 차단하십시오.</li> </ul>	<ul style="list-style-type: none"> <li>● 판넬이 열린 상태로 작동치 마십시오.</li> </ul>	Korean <b>위험</b>
<ul style="list-style-type: none"> <li>● ابعد رأسك بعيداً عن الدخان.</li> <li>● استعمل التهوية أو جهاز ضغط الدخان للخارج لكي تبعد الدخان عن المنطقة التي تتنفس فيها.</li> </ul>	<ul style="list-style-type: none"> <li>● اقطع التيار الكهربائي قبل القيام بأية صيانة.</li> </ul>	<ul style="list-style-type: none"> <li>● لا تشغيل هذا الجهاز اذا كانت الاغطية الحديدية الواقية ليست عليه.</li> </ul>	Arabic <b>تحذير</b>

**LEIA E COMPREENDA AS INSTRUÇÕES DO FABRICANTE PARA ESTE EQUIPAMENTO E AS PARTES DE USO, E SIGA AS PRÁTICAS DE SEGURANÇA DO EMPREGADOR.**

使う機械や溶材のメーカーの指示書をよく読み、まず理解して下さい。そして貴社の安全規定に従って下さい。

請詳細閱讀並理解製造廠提供的說明以及應該使用的銀焊材料，並請遵守貴方的有關勞動保護規定。

이 제품에 동봉된 작업지침서를 숙지하시고 귀사의 작업자 안전수칙을 준수하시기 바랍니다.

اقرأ بتعمق وافهم تعليمات المصنع المنتج لهذه المعدات والمواد قبل استعمالها واتبع تعليمات الوقاية لصاحب العمل.

## **CUSTOMER ASSISTANCE POLICY**

The business of Lincoln Electric is manufacturing and selling high quality welding equipment, automated welding systems, consumables, and cutting equipment. Our challenge is to meet the needs of our customers, who are experts in their fields, and to exceed their expectations. On occasion, purchasers may ask Lincoln Electric for information or technical information about their use of our products. Our employees respond to inquiries to the best of their ability based on information and specifications provided to them by the customers and the knowledge they may have concerning the application. Our employees, however, are not in a position to verify the information provided or to evaluate the engineering requirements for the particular weldment, or to provide engineering advice in relation to a specific situation or application. Accordingly, Lincoln Electric does not warrant or guarantee or assume any liability with respect to such information or communications. Moreover, the provision of such information or technical information does not create, expand, or alter any warranty on our products. Any express or implied warranty that might arise from the information or technical information, including any implied warranty of merchantability or any warranty of fitness for any customers' particular purpose or any other equivalent or similar warranty is specifically disclaimed.

Lincoln Electric is a responsive manufacturer, but the definition of specifications, and the selection and use of specific products sold by Lincoln Electric is solely within the control of, and remains the sole responsibility of the customer. Many variables beyond the control of Lincoln Electric affect the results obtained in applying these types of fabrication methods and service requirements.

## **WELD FUME CONTROL EQUIPMENT**

The operation of welding fume control equipment is affected by various factors including proper use and positioning of the equipment, maintenance of the equipment and the specific welding procedure and application involved. Worker exposure level should be checked upon installation and periodically thereafter to be certain it is within applicable OSHA PEL and ACGIH TLV limits.



### **THE LINCOLN ELECTRIC COMPANY**

22801 St. Clair Avenue • Cleveland, OH • 44117-1199 • U.S.A.  
Phone: +1.216.481.8100 • [www.lincolnelectric.com](http://www.lincolnelectric.com)