

DOWN-DRAFT TABLE

DOWN-DRAFT TABLE

FOR MECHANICAL WELDING AND GRINDING

WITH MECHANICAL FILTRATION

SAFETY INSTRUCTIONS FOR USE AND MAINTENANCE

N° W000371223 – W000371222



EDITION : EN
REVISION : A
DATE : 05-2022

Instructions for use

REF : **8695 8012**

Original instructions



Thank for the trust you have expressed by purchasing this equipment, which will give you full satisfaction if you follow its instructions for use and maintenance.

Its design, component specifications and workmanship comply with applicable European directives.

Please refer to the enclosed CE declaration to identify the directives applicable to it.


The manufacturer will not be held responsible where items not recommended by themselves are associated with this product.

For your safety, there follows a non-restrictive list of recommendations or requirements, many of which appear in the employment code.

Finally we would ask you kindly to inform your supplier of any error which you may find in this instruction manual.

CONTENTS

A - INTRODUCTION	1
USING THE MANUAL	1
MACHINE GUARANTEE	1
ASSISTANCE	1
DESCRIPTION OF PICTOGRAMS	1
B - GENERAL SAFETY INSTRUCTIONS	2
ELECTRICAL SAFETY	2
PERSONAL PROTECTION	3
FILTRATION OF FUMES AND DUST	5
C - OVERALL DESCRIPTION	6
D - TECHNICAL DESCRIPTION	8
AMSFMD TABLE COMPOSITION	8
TABLE DIMENSIONS	9
OPERATING PRINCIPLE	10
HCAS FAN	11
E - INSTALLING THE AMSFM TABLE	12
ASSEMBLY	12
PUTTING INTO SERVICE	12
F - MAINTENANCE	13
PRE-FILTER	14
FINE FILTER	15
DUST DRUM	15
ELECTRICAL DIAGRAMS	16
SPARE PARTS AND OPTIONAL EQUIPMENT	17
PERSONAL NOTES	18

	AMSFM down-draft table
	DOWN-DRAFT TABLE FOR MECHANICAL WELDING AND GRINDING WITH MECHANICAL FILTRATION
	TYPE: W000371223 AND W000371222

1. CE/EU DECLARATION OF CONFORMITY

Dear customer,

This CE/EU declaration of conformity certifies that the supplied equipment complies with applicable laws and regulations when used in accordance with the enclosed instructions. Any other assembly or modification would void our certification. That is why you are asked to call in the manufacturer for any modifications you wish to make. Failing that, the company responsible for the modification must repeat the certification process. In that case, we would not be liable for the new certificate in any way. Please hand this document over to your technical department or purchasing department for filing.

DESCRIPTION	TYPE
AMSFM down-draft table for welding and grinding 1200 x 800	W000371223
AMSFM down-draft table for welding and grinding 2000 x 800	W000371222

NUMBER: See identification plate

2. This equipment complies with European directives.

☐ **N° 2006/42/CE** ☐ **N° 2011/65/UE** ☐ **N° 2014/30/UE**

3. Based on the following harmonised standards:

EN ISO 12100:2010
EN ISO 13850:2008
EN ISO 13857:2008
EN ISO 12499
EN 60204-1:2006 / AC:2010

4. Air Treatment Products Manager, authorised to compile the technical manufacturing document.

M. Patrick DEGROOTE
LINCOLN ELECTRIC FRANCE SAS
 Avenue Franklin Roosevelt
 76120 - LE GRAND QUEVILLY

5. The Manufacturer.

LINCOLN ELECTRIC FRANCE SAS
 Avenue Franklin Roosevelt
 76120 - LE GRAND QUEVILLY

CERGY , on 09/01/2020



A - INTRODUCTION

USING THE MANUAL

Please read this manual before you start handling, installing or using the machine. Keep the manual safe in a place known to the machine user and maintenance personnel until the machine is finally destroyed.

This manual explains how to transport, install, use and maintain the filter. It cannot in any event replace the experience of the user for operations of varying difficulty.

Before the filter is used by a new user, make sure that they have read this manual and understood all the explanations provided.

For any further information, please feel free to contact the technical departments of **LINCOLN ELECTRIC**.

MACHINE GUARANTEE

This machine is guaranteed for 12 months from the date of purchase.

During the first 12 months of use, defective parts shall be replaced free of charge providing the damage is not the result of improper use of the machine.

The machine guarantee shall cease automatically when the machine is no longer the property of the original buyer.

The terms of validity of the guarantee shall be subject to verification and acceptance by our sales department.

Any nonconforming use that could damage the machine shall not be covered by the guarantee.

For the guarantee to operate, the equipment must be inspected by our technical department.

ASSISTANCE

LINCOLN ELECTRIC is at your disposal for any work on your equipment.

Please send any requests to the technical department.

HOT LINE (+33) 825 132 132

DESCRIPTION OF PICTOGRAMS

To make this document easier to understand, it contains pictograms with the meanings given below :



DANGER: indication used when failure to follow the instructions could lead to a serious hazard for personnel.



WARNING: indication used when failure to follow the instructions could lead to damage to the machine, associated elements or the surroundings.



This symbol shows that the description is intended for specialised personnel.

B - GENERAL SAFETY INSTRUCTIONS

ELECTRICAL SAFETY

Connection to the mains

Before you connect your machine, please make sure that:

- The meter, the overintensity protection system and the electrical installation are compatible with its maximum power rating and its supply voltage.
- It can be connected, in a single-phase or three-phase with earth system, to a socket compatible with the plug on its power cord (mobile equipment).
- If the cable is connected to a fixed point, the earth connection, if there is one, may never be cut off by the system offering protection from electric shocks.
- The switch, if there is one, is set to OFF.

Workstation

Arc welding and cutting requires strict compliance with safety requirements in respect of electrical currents (Order of 14 December 1988).

Working on the machine

Before any internal checking or repairs, make sure that the machine has been disconnected from the electrical system by locking it out:

- Accidental connection of the cable of a fixed system has been made impossible
- Cutting off by means of a fixed connection device relates to all poles (phase and neutral. It must be in the OFF position, with no possibility of being put into service by mistake

Some machines have an HV/HF arc ignition circuit (indicated by a plate). Never work inside such a box.

Any work on electrical systems must be carried out by persons qualified for that purpose (Decree 88-1056 of 14 November 1988, Section VI, Art 46).

Maintenance

From time to time, check that the machinery and its electrical accessories - connectors, flexible cables and extension cords - are correctly insulated and connected.

Work for maintaining and repairing insulating enclosures and ducts may not be carried out in a haphazard manner (Section VI, Art. 47 Decree 88-1056 of 14 November 1988).

- All repairs are to be carried out by specialists, or better yet, defective accessories should be replaced.
- Regularly check that the electrical connections are tight, with no heating.

Any fans placed in a circuit in which the air is laden with dust must be cleaned from time to time. That is because the turbine may be fouled and become unbalanced, leading to increased noise and premature wear and tear of bearings. Maintenance is required at least after every six months, depending on the type of dust treated.

The fan is an essential element of your extraction system.

Incorrect operating or inadequate maintenance could make the operating position less safe. That is why the fan must be maintained in perfect condition.

Your installation has been selected for a specific application. The turbine is characterised by an operating point based on extraction speed (speed of air in the piping) and head loss.

In accordance with the regulations of CARSAT and INRS, the system must be inspected from time to time to make sure that it continues to comply with its reference values.

PERSONAL PROTECTION

Risks of external injury relating to welding operations

Whole body

- The operator must be clothed and protected to suit the requirements of the job.
- Make sure that no part of the bodies of operators and helpers can come in contact with metal pieces or parts that are live or are liable to become live accidentally.
- Do not wind electricity cables around the body.
- Keep safety guards and panels in place.
- The operator must always wear personal insulating protection (Order of 14 December 1988, Section III).
- The protection must be kept dry to prevent electric shocks if it is wet, or ignition in the presence of oil.

Personal protective equipment worn by operators and their helpers - gloves, aprons, safety shoes - offer the added benefit of protecting them from burns due to hot parts, splatter and slag.

Make sure the PPE is in good condition and replace it before it ceases to offer protection.

Face and eyes

It is indispensable to protect the following:

- Eyes, from arc injury (dazzling due to visible light from the arc, and infrared and ultraviolet radiation).
- Hair, face and eyes from welding splatter and projection of slag during weld cooling

The welding mask, when used under or without a helmet, must always be equipped with a protective filter, the shade of which depends on the intensity of the welding arc current (Standards NF S77-104 A 88-221 A88-222).

The coloured filter may be protected from impacts and splatter by a transparent glass located on the front of the mask.

If the filter is replaced, use another one with the same part number (shade number).

Persons in the vicinity of the operator, especially any helpers, must be protected by means of suitable screens, anti-UV goggles or, if needed, masks with suitable protective filters (EN 139).

Specific case of chlorine solvents in welding: (used for cleaning or degreasing).

- The fumes from these solvents can be changed into toxic gases when subjected to arc radiation, including from a distance.
- Such solvents may therefore not be used in locations where electric arcs occur, if the solvents are not in a sealed enclosure.

Work in confined spaces

Examples:

- Mine roads
- Piping and pipelines
- Ship docks, pits, manholes, cellars
- Tanks
- Ballast tanks
- Silos
- Reactors

Special precautions must be taken before undertaking welding operations in such enclosures, where suffocating and poisoning and fire and explosion risks are very great.

A work permit procedure setting out all the safety measures must systematically be set up.

Make sure that ventilation is appropriate, paying special attention to:

- under-oxygenation
- over-oxygenation
- excess fuel gas

FILTRATION OF FUMES AND DUST

Important

Mechanical or electrostatic filtration systems are effective for the filtration of solid but not gaseous particles (exterior discharge).

If recycling is effective (not recommended), make sure the workplace where the machine or machines are placed is properly ventilated, so as to not reach the OELV (occupational exposure limit values) for the specific gaseous pollutants generated by the process (welding, cutting).

Field of use

Filtration of solid particles and dry dust, non-flammable gas, with no risk of explosion.

- Zinc, paper, flour, plant leaves, graphite, aluminium and other such dust is to be excluded, because electrostatic discharge or welding splatter would present a risk for those using the filter.
- The air flow through the filter medium must not be at a temperature above 80 °C.
- This machine is not designed for extracting chemicals.
- The choice of machine is made to suit the pollutants to treat. Extraction at source of the pollutant is only effective if the machine is operating at its nominal power (air flow at the nozzle).

Take particular care to:

- Not obstruct the air outlet of the machine.
- Not introduce external elements into the filter (paper, cloths, cigarette butts etc.)
- Replace the filter medium with new original **LINCOLN ELECTRIC** medium, which alone can guarantee the filtration characteristics.
- Replace the hoses if they are pierced.
- Regularly clean the metal pre-filter on those machines that have one.

C - OVERALL DESCRIPTION

For your safety and optimum performance, please read this manual carefully before using the filter.



AMSFM (Aspirante Meulage Soudage Filtration Mécanique) tables are designed to catch and filter grinding dust and dry non-explosive welding fumes.

While welding, the filtered gas must be discharged outside the workshop. Discharge is via an outlet adapted at the rear or on the side. An optional silencer box for the discharge is available.

Particles and fumes are extracted by the table top and three extracting side panels.

The particles go through a retention grille and the heaviest of them drop into the hopper and the dust drum. Finer particles then go through a metal pre-filter and a large (40 m²) fine filter

Part numbers

Table AMSFM 1200x800	W000371223
Table AMSFM 2000x800	W000371222
Rear lateral or vertical outlet, Ø 250 mm	W000342588
Rear lateral or vertical outlet, Ø 250 mm	W000273464
TRC Ø 250 mm for 1 200x800table silencer	W000380507
TRC Ø 315 mm for 2 000x800table silencer	W000380508

Benefits :

- Compact, independent table that is quick to install and put into service
- Versatile, may be used for TIG, MIG, coated-electrode welding and grinding.
- Filtration included, absolute filtration box as an option
- Dust recovery drum
- Table supplied with disconnecting box
- Optional wheel kit for mobile table

Delivery :

The table is delivered on a pallet, ready to be connected to a duct system and the electrical system.

Safety alert



Never introduce incandescent particles into the extraction duct.

Example:

- Cigarette butts
- Burning paper
- Incandescent milling particles
- Plasma or air arc gouging particles
- Or any other incandescent product
- List not comprehensive



D - TECHNICAL DESCRIPTION

AMSFMD TABLE COMPOSITION

The table is made up of the following :

- 1 table top 1070 X 740 mm or 1870 x 740 mm
- Working height 920 mm.
- Max load capacity of the table: 200 kg.
- Lateral extraction panels, 500 mm high.
- 2 metal pre-filters, class EU2 - dimensions (610 x 610 x 24) mm
- 1 fine filter – filter surface area: 40 m² - class F8 - dimensions (610 x 610 x 24) mm
- Ø 250 mm or Ø 315 mm air outlet at the rear of the table
- Galvanised steel grating on the table top.
- Noise below 70 dB(A)
- Overall dimensions (L x W x H):
 - 1760 x 800 x 1420 mm
 - 2000 x 800 x 1420 mm
- Fan power: 2.2 kW - 400 V - 3 ph - 50 Hz in both models
- Weight of table: 240 kg
- The extraction rate is:
 - **2000 m³/h** with the 1200 x 800 table
 - **3000 m³/h** with the 2000 x 800 table




TABLE DIMENSIONS




Table AMSFM 1200 x 800 mm

Grating 1057 x 729 mm







Table AMSFM 2000 x 800 mm

Grating 1857 x 729 mm



OPERATING PRINCIPLE

The extracted air goes through the table grating and the grooved side panels. It enters the deflector hopper, where the heavier particles drop into the dust drum, and finer particles then go through the pre-filter and finally the fine filter; the air is then discharged by the fan and extracted outside the building, according to the configuration of the customer's duct system.



- Mechanical filtration is thus carried out in four stages:
 - Metal pre-filter, class EU2
 - Dust drum and hopper
 - Metal pre-filter, class EU2
 - Fine mechanical filter, 35 m² medium EU 8/9.
- Options:
 - Post filtration by Hepa H13 filter
 - Wheel kit for mobile table

HCAS FAN

USE

HCAS low-pressure centrifugal fans are designed to extract clean air or air with a low dust and fumes content.

SPECIFICATIONS OF STANDARD RANGE

- Class F MOTOR, IP55, 50Hz, B35, 400V three phase
- Forward curved type IMPELLER in painted steel
- Painted steel SCROLL


AMBIENT TEMPERATURE

Temperature between -20°C and +40°C (unless otherwise indicated on the motor identification plate)

TEMPERATURE OF TRANSPORTED FLUID

Temperature between -20°C and +80°C max. depending on surface pressure and temperature (see marking)

EXPLODED VIEW



E - INSTALLING THE AMSFM TABLE

ASSEMBLY

Move the table with a lift truck to its location, then remove the packaging and transport protection material. Connect the table to the Ø 250 or 315 mm air extraction duct leading outside or to a connected duct system. Electricity power must be provided nearby.

PUTTING INTO SERVICE

Mains connection

- Power supply : 400V. - 50 Hz - 3ph.
- Motor power : 2.2 kW 2.2 kW for tables 1200 x 800 et 2000 x 800

All the operations relating to the installation, such as those for assembly, installation, putting into service and maintenance, are to be carried out by qualified personnel under the control of a responsible technician.

This equipment must be connected to the distribution system using the original cable. If you need to extend or change the cable, make sure that the cross section is at least equal to the power cable of the table (1.5 mm²).

The power supply must have:

- A device for protecting personnel from indirect hazards:
30 mA residual-current circuit-breaker to isolate the machine after it is halted.
- A connector with the earth terminal (compulsory).

Before you make the electrical connections, check that no component has been damaged during transport.

IMPORTANT :

Before connecting the power, make sure that the machine is out of service (switch set to 0).



F - MAINTENANCE

Please read the manually carefully before you start any servicing work. Maintenance operations may only be carried out by specialised and qualified individuals. Behaviour that does not comply with the safety instructions provided could lead to major hazards for personnel and damage to property and/or the surroundings.



All routine and/or exceptional maintenance must be carried out with the machine disconnected from the supply system.

Advice for machine users: maintenance is to be carried out as described in the manual.

1. Electrical risks

2. Cutting and abrasion risks in filter area.

Mind the maintenance of the electrical cabinet. Hazards are indicated by a plate saying "HAZARDOUS VOLTAGE".

In order to ensure the proper working of the machine, defective spare parts must be replaced with original spare parts from **LINCOLN ELECTRIC**.



Before starting up the machine, make sure that the replaced parts are perfectly installed and that the tools used are removed from the machine.

Make sure that each safety device is in good condition and legible.

MAINTENANCE OF MECHANICAL PARTS

The machine requires negligible mechanical maintenance if it is used correctly in accordance with its technical characteristics.

Before any type of maintenance that is not clearly defined in these instructions, please make inquiries with the technical department of **LINCOLN ELECTRIC**.

The performance of operations that may not be carried out or are contrary to the standards and procedures described in the manual would release **LINCOLN ELECTRIC** from liability for any damage caused and would void the guarantee if it is still valid.

PRE-FILTER

For filter maintenance, always use protective goggles and a respiratory mask in order to prevent all risks of contact with or inhalation of the particles collected. The power supply must always be switched off using the disconnecter or via the fuses. If the filter has a power connector, it must be separated from its socket on the wall.



Pre-filter cleaning frequency ?

Maintenance depends on use.

We recommend inspecting the pre-filter after every two weeks at the start, while you determine the actual maintenance frequency.


Then you must inspect and clean the pre-filter every month.

PRINCIPLE :

To access the filter elements, please remove the grating and then the deflecting plate for the first pre-filter. The second one will be accessible after you remove the panel under the table top.

Cleaning the mechanical pre-filter?

Open the right-hand door under the table top
Use FILTER FILTERCLEAN cleaner, part no W000261362.
Dilute FILTER FILTERCLEAN cleaner in water
Part no W000261362. (15 or 20%)
Leave for about 10 minutes.
Clean with clean water, dry.



In no event may the machine be used without a pre-filter or with a pre-filter that is not the same as the original from LINCOLN ELECTRIC.

FINE FILTER




You must replace the fine filter after every 6 months.

REPLACE AFTER EVERY THREE MONTHS IF SUBJECT TO HEAVY-DUTY USE

Do not clean the filter manually (blowing compressed air)
Risk of destroying the medium

Replacing the fine filter :




The use of protective goggles and a respiratory mask is indispensable in order to prevent all risks of contact with or inhalation of the particles collected. The power supply must always be switched off using the disconnecter or via the fuses. If the filter has a power connector, it must be separated from its socket on the wall.

- 1: Open the filter compartment.
- 2: Unscrew the mechanical protection holding the filter.
- 3: Place a plastic bag around the filter and remove it.
- 4: Put the clogged filter in the packaging of the new filter.
- 5: Insert the new filter, screw back the mechanical protection and close the door.
- 6: Apply the starting up procedure.


DUST DRUM

Empty the dust drum once a week at the start, then adjust the frequency to once in every two weeks or once a month depending on the quantity and use of the table.

ELECTRICAL DIAGRAMS



SPARE PARTS AND OPTIONAL EQUIPMENT


B


Description	Part number	Quantity
Lateral and vertical table outlet, diam. 250 mm	W000342588	1
Vertical outlet with silencer box	W000273464	1
TRC Ø250 mm for silencer, 1200 x 800 mm table	W000380507	1
TRC Ø315 mm for silencer, 2000 x 800 mm table	W000380508	1
Optional HEPA H13 42 m ² absolute filtration box	EM61000432	1
Optional wheel kit for mobile table	EM61000431	1
Magnetothermal circuit breaker	W000342525	1
HCAS 240 fan – 2 poles- 2.2 kW	EM61000515	1
Motor, 2 poles – 2.2 kW – T – B35 – IE3	EM61000513	1
HCAS 240 x 90 impeller – AI 24 – A - LG	EM61000514	1

[illegible]

-18