


# INVERTEC V450 PRO MACHINE SCHEMATIC G4875 REV:C



Not recommended for single phase operation.

- LEGEND**
- ---
  - LEAD COLOR CODE:**
  - B-BLACK
  - G-GREEN
  - O-ORANGE
  - R-RED
  - U-BLUE
  - W-WHITE
  - Y-YELLOW
  - LABELS:**
  - COMMON
  - FRAME GROUND
  - EARTH GROUND


- COMPONENT VALUE UNITS:**
- CAPACITOR: MFD/VOLTS
  - RESISTOR: OHMS/WATTS
- CONNECTOR PIN NUMBERS:**
- EX. 12 PIN CONNECTOR
- |   |   |   |    |    |    |
|---|---|---|----|----|----|
| 1 | 2 | 3 | 4  | 5  | 6  |
| 7 | 8 | 9 | 10 | 11 | 12 |
- VIEW OF CONNECTOR ON PC BOARD

**Additional input / outputs are illustrated on schematic page 2.**

**Schematic numbers are given for reference only.**

NOTES:

N.E. THE REMOTE UI PCB ALWAYS RESPONDS AS A REMOTE SPI BOARD. CONNECTING PINS 1 & 2 OF J333 TOGETHER WILL ENABLE THE REMOTE UI PCB TO RESPOND AS A STATUS SPI. CONNECTING PINS 11 & 14 OF J332 TOGETHER WILL ENABLE THE REMOTE UI PCB TO RESPOND AS A MODE PCB.



LEDS - 10 TOTAL  
DIP SWITCH - 1 BANK OF 8  
SEE PAGE 3 FOR DETAILS

CONTROL BOARD  
Schematic: G3789  
Located on left side of control box

**Additional input / outputs are illustrated on schematic # 1.**

SPI CIRCUIT

Factory Install

Field Install

MODE PANEL  
Schematic: S25258-1B0

ADVANCED PROCESS PANEL (OPTIONAL)  
Schematic: G3872-1B1

OUTPUT CONTROL  
Led select pc board  
Schematic: S25259-1

WELD TERMINALS  
Led select pc board  
Schematic: S25259-1

DISPLAY PANEL  
Schematic: L11108-3

Open view of Control Panel

Located in the middle of Control Panel

Schematic numbers are given for reference only.


LEAD COLOR CODE:	LAST No. USED:	COMPONENT VALUE UNITS:
B-BLACK	R-6	CAPACITOR: MFD/VOLTS
G-GREEN	C-9	RESISTOR: OHMS/WATTS
O-ORANGE	S-2	
R-RED	TP-4	
U-BLUE	J-Numbers	
W-WHITE	J2,J3,J4,J5,J6,J7,J8,	
Y-YELLOW	J9,J10A,J10B,J11,	
	J40,J50,J42,J43,J51,	
	J52,J54,J59,	
	J60 and J61 (Input PCB),	
	J61 (Mode PCB),	
	J60A,J60B	
	J91,J331,	
	J332,J333	

CONNECTOR PIN NUMBERS:
EX: 12 PIN CONNECTOR
1 2 3 4 5 6
7 8 9 10 11 12
LATCH
VIEW OF CONNECTOR ON PCB BOARD


LEGEND  
DASHED = " " OPTION  
PHANTOM = " " PC BOARDS

1. STD DISPLAY PC BOARD ASSEMBLY
2. SPI ASSEMBLY
3. REMOTE PC BOARD ASSEMBLY
4. LED SELECT PC BOARD ASSEMBLY
5. FACTORY MODE PANEL ASSEMBLY




**Control Panel**


**Factory Mode Panel**



**Advance Process Panel (Optional)**



**CONTROL BOARD**



**Description of LED functions on the Invertec V450-PRO**

For reference only

L11088 Digital Control PC Board		
LED #	COLOR	FUNCTION
1	Green	Indicates +15VDC from power supply board is present
2	Green	Indicates -15VDC from power supply board is present
3	Green	Indicates +5VDC for +5SPI from power supply board is present
4	Green	Indicates +15VDC for +15SPI from power supply board is present
5	Green	Indicates +5VDC for +5V from power supply board is present
6	Green	Indicates +5VDC for +5VRS232 from power supply board is present
7	Red	FAULT Signal (See software group for coding)
8	Green	Indicates +5VDC for +5CAN from power supply board is present
9	Green	ArcLink Status Indicators (Main System Master ArcLink Connection) Solid Green only when functional (See software for error codes)
10	Red	

**POWER BOARDS**

**Description of LED functions on the Invertec V450-PRO**


For reference only

G3632 Digital Power Supply Board		
LED #	COLOR	FUNCTION
1	Red	Indicates +5VDC SPI supply is present
2	Red	Indicates +5VDC control supply is present

**Error codes for the Invertec V450-PRO**

The following is a list of possible error codes that the Power Wave can output via the status light

Error Code #	Indication
21	Unprogrammed Weld Mode. Contact the Service Department for instructions on reloading the Welding Software.
22	Empty Weld Table. Contact the Service Department for instructions on reloading the Welding Software.
23	Weld Table checksum error. Contact the Service Department for instructions on reloading the Welding Software.
31	Primary overcurrent error. Excessive Primary current present. May be related to a switch board or output rectifier failure.
32	Capacitor "A" under voltage (Left side facing machine). Low voltage on the main capacitors. May be caused by improper input configuration, or an open/short circuit in the primary side of the machine.
33	Capacitor "B" under voltage (Right side facing machine). Low voltage on the main capacitors. May be caused by improper input configuration, or an open/short circuit in the primary side of the machine.
34	Capacitor "A" over voltage (Left side facing machine). Excess voltage on the main capacitors. May be caused by improper input configuration, or an open/short circuit in the primary side of the machine.
35	Capacitor "B" over voltage (Right side facing machine). Excess voltage on the main capacitors. May be caused by improper input configuration, or an open/short circuit in the primary side of the machine.
36	Thermal error. Indicates over temperature. Usually accompanied by Thermal LED. Check fan operation. Be sure process does not exceed duty cycle limit of the machine.
37	Softstart error. Capacitor precharge failed. Usually accompanied by codes 32-35.
41	Secondary overcurrent error. The secondary (weld) current limit has been exceeded. When this occurs the machine output will phase back to 100 amps, typically resulting in a condition referred to as "noodle welding"
43	Capacitor delta error. The maximum voltage difference between the main capacitors has been exceeded. May be accompanied by errors 32-35.
49	Single phase error. Indicates machine is running on single phase input power. Usually caused by the loss of the middle leg (L2).
Other	Use Snap Shot to interpret other errors or Diagnostic Software



**Case front Detail**