


Schematic numbers are given for reference only.

ETHERNET BOARD



Description of LED functions on the Power Wave AC/DC

For reference only

G3894 Ethernet Gateway PC Board		
LED #	COLOR	FUNCTION
1	Green	Indicates Isolated Module Section Supply is ON
2	Green	Indicates DeviceNet Supply is ON
3	Green	Arclink Status Indicators (Main System <i>Slave</i> Arclink Connection) Solid Green only when functional. (See software for error codes)
4	Red	Reserved For Future Use
5	Green	DeviceNet Status Indicators (See software group for coding)
6	Red	Reserved For Future Use
7	Green	Indicates Isolated ArcLink Section Supply is ON
8	Red	10Base-T Link Status ON indicates functional ethernet link has been established
9	Green	Receiver Polarity ON indicates proper ethernet signal polarity
10	Green	Indicates I/O+5V Supply is ON This is used by differential I/O pair 4 circuitry, J712 pins 1 and 2.
11	Green	
12	Green	

Troubleshooting the PowerWave System Interface


Using the Status LED

LIGHT CONDITION	MEANING
Steady Green	System OK. Unit is operational, and is communicating normally with the ArcLink network.
Blinking Green	Occurs during power up or a system reset, and indicates the Power Wave is mapping (identifying) each component in the system. Normal for first 1-10 seconds after power is turned on, or if the system configuration is changed during operation.
Fast Blinking Green	Indicates Auto-mapping has failed
Alternating Green and Red	Non-recoverable system fault. If the Status lights are flashing any combination of red and green, errors are present. Read the error code(s) before the machine is turned off. Error Code interpretation through the Status light is detailed in the Service Manual. Individual code digits are flashed in red with a long pause between digits. If more than one code is present, the codes will be separated by a green light. Only active error conditions will be accessible through the Status Light. Error codes can also be retrieved with the <i>Diagnostics Utility</i> (included on the <i>Power Wave Submerged Arc Utilities</i> and <i>Service Navigator CD's</i>). This is the preferred method, since it can access historical information contained in the error logs. To clear the active error(s), turn power source off, and back on to reset.
Steady Red	Not applicable.
Blinking Red	Not applicable.


PowerWave System Interface Error Codes (partial listing)

Error Code #	Indication
118	DeviceNet connection error Lost Connection with DeviceNet Master
119	DeviceNet de-allocation error The DeviceNet Master de-allocated the connection
133	Write Arclink action failure May be caused by activating Cold Inch while welding through DeviceNet
145	Duplicate MAC ID error Check MAC ID assignments on DeviceNet Setup Dipswitch Bank (S2)
146	DeviceNet Bus off Check condition of onboard DeviceNet Status indicators
147	DeviceNet polled I/O error Problem changing attribute over polled I/O
149	DeviceNet I/O data error Received DeviceNet I/O data with wrong number of bytes
169	Ethernet Connection Timeout Loss of communication with PC Application.
171	Ethernet Socket Timeout
172	Ethernet Watch Dog Timeout
Other	Note: These errors are only valid when the System Interface is connected directly to an Ethernet network (typically for diagnostic purposes). During normal operation it communicates via Arclink or DeviceNet. Error codes that contain four (4) digits are defined as fatal errors. These codes generally indicate internal errors on the Ethernet PC Board. If cycling the input power on the machine does not clear the error, try reloading the operating system. If this fails, replace the Ethernet PC Board.


"Bank S1" ArcLink Configuration



"Bank S2" DeviceNet Configuration



"Bank S4" Master / Slave Config



"Bank S3" I/O Termination

