

## **Operator's Manual**

# POWER WAVE ® S350CE



For use with machines having Code Numbers:

11625, 11783\*, 12795\*



Register your machine: www.lincolnelectric.com/register

Authorized Service and Distributor Locator: www.lincolnelectric.com/locator

#### Save for future reference

Date Purchased

Code: (ex: 10859)

Serial: (ex: U1060512345)

**Need Help? Call 1.888.935.3877** to talk to a Service Representative

Hours of Operation: 8:00 AM to 6:00 PM (ET) Mon. thru Fri.

#### After hours?

Use "Ask the Experts" at lincolnelectric.com A Lincoln Service Representative will contact you no later than the following business day.

For Service outside the USA: Email: globalservice@lincolnelectric.com



**IM10029-D** | Issue Date Jan-22 © Lincoln Global, Inc. All Rights Reserved. THE LINCOLN ELECTRIC COMPANY 22801 St. Clair Avenue • Cleveland, OH • 44117-1199 • U.S.A. Phone: +1.216.481.8100 • www.lincolnelectric.com

## **Electromagnetic Compatibility (EMC)**

#### Conformance

Products displaying the CE mark are in conformity with European Community Council Directive of 15 Dec 2004 on the approximation of the laws of the Member States relating to electromagnetic compatibility, 2004/108/EC. It was manufactured in conformity with a national standard that implements a harmonized standard: EN 60974-10 Electromagnetic Compatibility (EMC) Product Standard for Arc Welding Equipment. It is for use with other Lincoln Electric equipment. It is designed for industrial and professional use.

#### Introduction

All electrical equipment generates small amounts of electromagnetic emission. Electrical emission may be transmitted through power lines or radiated through space, similar to a radio transmitter. When emissions are received by other equipment, electrical interference may result. Electrical emissions may affect many kinds of electrical equipment; other nearby welding equipment, radio and TV reception, numerical controlled machines, telephone systems, computers, etc. Be aware that interference may result and extra precautions may be required when a welding power source is used in a domestic establishment.

#### Installation and Use

The user is responsible for installing and using the welding equipment according to the manufacturer's instructions. If electromagnetic disturbances are detected then it shall be the responsibility of the user of the welding equipment to resolve the situation with the technical assistance of the manufacturer. In some cases this remedial action may be as simple as earthing (grounding) the welding circuit, see Note. In other cases it could involve construction of an electromagnetic screen enclosing the power source and the work complete with associated input filters. In all cases electromagnetic disturbances must be reduced to the point where they are no longer troublesome.

Note: The welding circuit may or may not be earthed for safety reasons according to national codes. Changing the earthing arrangements should only be authorized by a person who is competent to access whether the changes will increase the risk of injury, e.g., by allowing parallel welding current return paths which may damage the earth circuits of other equipment.

#### **Assessment of Area**

Before installing welding equipment the user shall make an assessment of potential electromagnetic problems in the surrounding area. The following shall be taken into account:

- a) other supply cables, control cables, signaling and telephone cables; above, below and adjacent to the welding equipment;
- b) radio and television transmitters and receivers;
- c) computer and other control equipment;
- d) safety critical equipment, e.g., guarding of industrial equipment;
- e) the health of the people around, e.g., the use of pacemakers and hearing aids;
- f) equipment used for calibration or measurement
- g) the immunity of other equipment in the environment. The user shall ensure that other equipment being used in the environment is compatible. This may require additional protection measures;
- h) the time of day that welding or other activities are to be carried out.



## THANK YOU FOR SELECTING A QUALITY PRODUCT BY LINCOLN ELECTRIC.

# PLEASE EXAMINE CARTON AND EQUIPMENT FOR DAMAGE IMMEDIATELY

When this equipment is shipped, title passes to the purchaser upon receipt by the carrier. Consequently, claims for material damaged in shipment must be made by the purchaser against the transportation company at the time the shipment is received.

#### SAFETY DEPENDS ON YOU

Lincoln arc welding and cutting equipment is designed and built with safety in mind. However, your overall safety can be increased by proper installation ... and thoughtful operation on your part. DO NOT INSTALL, OPERATE OR REPAIR THIS EQUIPMENT WITHOUT READING THIS MANUAL AND THE SAFETY PRECAUTIONS CONTAINED THROUGHOUT. And, most importantly, think before you act and be careful.

## 

This statement appears where the information must be followed exactly to avoid serious personal injury or loss of life.

## 

This statement appears where the information must be followed to avoid minor personal injury or damage to this equipment.

#### KEEP YOUR HEAD OUT OF THE FUMES.

**DON'T** get too close to the arc. Use corrective lenses if necessary to stay a reasonable distance away from the arc.

**READ** and obey the Safety Data Sheet (SDS) and the warning label that appears on all containers of welding materials.

**USE ENOUGH VENTILATION** or exhaust at the arc, or both, to

keep the fumes and gases from your breathing zone and the general area.

**IN A LARGE ROOM OR OUTDOORS**, natural ventilation may be adequate if you keep your head out of the fumes (See below).

**USE NATURAL DRAFTS** or fans to keep the fumes away from your face.

If you develop unusual symptoms, see your supervisor. Perhaps the welding atmosphere and ventilation system should be checked.



## WEAR CORRECT EYE, EAR & BODY PROTECTION

**PROTECT** your eyes and face with welding helmet properly fitted and with proper grade of filter plate (See ANSI Z49.1).

**PROTECT** your body from welding spatter and arc flash with protective clothing including woolen clothing, flame-proof apron and gloves, leather leggings, and high boots.

**PROTECT** others from splatter, flash, and glare with protective screens or barriers.

IN SOME AREAS, protection from noise may be appropriate.

**BE SURE** protective equipment is in good condition.

Also, wear safety glasses in work area **AT ALL TIMES.** 



#### **SPECIAL SITUATIONS**

**DO NOT WELD OR CUT** containers or materials which previously had been in contact with hazardous substances unless they are properly cleaned. This is extremely dangerous.

**DO NOT WELD OR CUT** painted or plated parts unless special precautions with ventilation have been taken. They can release highly toxic fumes or gases.



#### Additional precautionary measures

**PROTECT** compressed gas cylinders from excessive heat, mechanical shocks, and arcs; fasten cylinders so they cannot fall.

**BE SURE** cylinders are never grounded or part of an electrical circuit.

**REMOVE** all potential fire hazards from welding area.

ALWAYS HAVE FIRE FIGHTING EQUIPMENT READY FOR IMMEDIATE USE AND KNOW HOW TO USE IT.









#### **CALIFORNIA PROPOSITION 65 WARNINGS**



**WARNING:** Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects. or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an exposed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

#### For more information go to www.P65 warnings.ca.gov/diesel

WARNING: This product, when used for welding or cutting, produces fumes or gases which contain chemicals known to the State of California to cause birth defects and, in some cases, cancer. (California Health & Safety Code § 25249.5 et seq.)



WARNING: Cancer and Reproductive Harm www.P65warnings.ca.gov

#### ARC WELDING CAN BE HAZARDOUS. PROTECT YOURSELF AND OTHERS FROM POSSIBLE SERIOUS INJURY OR DEATH. KEEP CHILDREN AWAY. PACEMAKER WEARERS SHOULD CONSULT WITH THEIR DOCTOR BEFORE OPERATING.

Read and understand the following safety highlights. For additional safety information, it is strongly recommended that you purchase a copy of "Safety in Welding & Cutting -ANSI Standard Z49.1" from the American Welding Society, P.O. Box 351040, Miami, Florida 33135 or CSA Standard W117.2. A Free copy of "Arc Welding Safety" booklet E205 is available from the Lincoln Electric Company, 22801 St. Clair Avenue, Cleveland, Ohio 44117-1199.

#### BE SURE THAT ALL INSTALLATION, OPERATION, MAINTENANCE AND REPAIR PROCEDURES ARE PERFORMED ONLY BY QUALIFIED INDIVIDUALS.

# FOR ENGINE POWERED EQUIPMENT.



- 1.a. Turn the engine off before troubleshooting and maintenance work unless the maintenance work requires it to be running.
- 1.b. Operate engines in open, well-ventilated areas or vent the engine exhaust fumes outdoors.
- 1.c. Do not add the fuel near an open flame welding arc or when the engine is running. Stop the engine and allow it to cool before refueling to prevent spilled fuel from vaporizing on contact



with hot engine parts and igniting. Do not spill fuel when filling tank. If fuel is spilled, wipe it up and do not start engine until fumes have been eliminated.

1.d. Keep all equipment safety guards, covers and devices in position and in good repair. Keep hands, hair, clothing and tools away from V-belts, gears, fans and all other moving parts when starting, operating or repairing equipment.



- 1.e. In some cases it may be necessary to remove safety guards to perform required maintenance. Remove guards only when necessary and replace them when the maintenance requiring their removal is complete. Always use the greatest care when working near moving parts.
- 1.f. Do not put your hands near the engine fan. Do not attempt to override the governor or idler by pushing on the throttle control rods while the engine is running.
- 1.g. To prevent accidentally starting gasoline engines while turning the engine or welding generator during maintenance work, disconnect the spark plug wires, distributor cap or magneto wire as appropriate.
- 1.h. To avoid scalding, do not remove the radiator pressure cap when the engine is hot.



- 1.i. Using a generator indoors CAN KILL YOU IN MINUTES.
- 1.j. Generator exhaust contains carbon monoxide. This is a poison you cannot see or smell.
- 1.k. NEVER use inside a home or garage, EVEN IF doors and windows are open.



1.m. Avoid other generator hazards. READ MANUAL BEFORE USE.

windows, doors and vents.

## **ELECTRIC AND** MAGNETIC FIELDS MAY **BE DANGEROUS**

- 2.a. Electric current flowing through any conductor causes localized Electric and Magnetic Fields (EMF). Welding current creates EMF fields around welding cables and welding machines
- 2.b. EMF fields may interfere with some pacemakers, and welders having a pacemaker should consult their physician before welding.
- 2.c. Exposure to EMF fields in welding may have other health effects which are now not known.
- 2.d. All welders should use the following procedures in order to minimize exposure to EMF fields from the welding circuit:
  - 2.d.1. Route the electrode and work cables together Secure them with tape when possible.
  - 2.d.2. Never coil the electrode lead around your body.
  - 2.d.3. Do not place your body between the electrode and work cables. If the electrode cable is on your right side, the work cable should also be on your right side.
  - 2.d.4. Connect the work cable to the workpiece as close as possible to the area being welded.
  - 2.d.5. Do not work next to welding power source.



## ELECTRIC SHOCK CAN KILL.



- 3.a. The electrode and work (or ground) circuits are electrically "hot" when the welder is on. Do not touch these "hot" parts with your bare skin or wet clothing. Wear dry, hole-free gloves to insulate hands.
- 3.b. Insulate yourself from work and ground using dry insulation. Make certain the insulation is large enough to cover your full area of physical contact with work and ground.

In addition to the normal safety precautions, if welding must be performed under electrically hazardous conditions (in damp locations or while wearing wet clothing; on metal structures such as floors, gratings or scaffolds; when in cramped positions such as sitting, kneeling or lying, if there is a high risk of unavoidable or accidental contact with the workpiece or ground) use the following equipment:

- Semiautomatic DC Constant Voltage (Wire) Welder.
- DC Manual (Stick) Welder.
- AC Welder with Reduced Voltage Control.
- 3.c. In semiautomatic or automatic wire welding, the electrode, electrode reel, welding head, nozzle or semiautomatic welding gun are also electrically "hot".
- 3.d. Always be sure the work cable makes a good electrical connection with the metal being welded. The connection should be as close as possible to the area being welded.
- 3.e. Ground the work or metal to be welded to a good electrical (earth) ground.
- 3.f. Maintain the electrode holder, work clamp, welding cable and welding machine in good, safe operating condition. Replace damaged insulation.
- 3.g. Never dip the electrode in water for cooling.
- 3.h. Never simultaneously touch electrically "hot" parts of electrode holders connected to two welders because voltage between the two can be the total of the open circuit voltage of both welders.
- 3.i. When working above floor level, use a safety belt to protect yourself from a fall should you get a shock.
- 3.j. Also see Items 6.c. and 8.





- 4.a. Use a shield with the proper filter and cover plates to protect your eyes from sparks and the rays of the arc when welding or observing open arc welding. Headshield and filter lens should conform to ANSI Z87. I standards.
- 4.b. Use suitable clothing made from durable flame-resistant material to protect your skin and that of your helpers from the arc rays.
- 4.c. Protect other nearby personnel with suitable, non-flammable screening and/or warn them not to watch the arc nor expose themselves to the arc rays or to hot spatter or metal.

## **FUMES AND GASES** CAN BE DANGEROUS.



- 5.a. Welding may produce fumes and gases hazardous to health. Avoid breathing these
  - fumes and gases. When welding, keep your head out of the fume. Use enough ventilation and/or exhaust at the arc to keep fumes and gases away from the breathing zone. When welding hardfacing (see instructions on container or SDS) or on lead or cadmium plated steel and other metals or coatings which produce highly toxic fumes, keep exposure as low as possible and within applicable OSHA PEL and ACGIH TLV limits using local exhaust or mechanical ventilation unless exposure assessments indicate otherwise. In confined spaces or in some circumstances, outdoors, a respirator may also be required. Additional precautions are also required when welding
  - on galvanized steel.
- 5. b. The operation of welding fume control equipment is affected by various factors including proper use and positioning of the equipment, maintenance of the equipment and the specific welding procedure and application involved. Worker exposure level should be checked upon installation and periodically thereafter to be certain it is within applicable OSHA PEL and ACGIH TLV limits.
- 5.c. Do not weld in locations near chlorinated hydrocarbon vapors coming from degreasing, cleaning or spraying operations. The heat and rays of the arc can react with solvent vapors to form phosgene, a highly toxic gas, and other irritating products.
- 5.d. Shielding gases used for arc welding can displace air and cause injury or death. Always use enough ventilation, especially in confined areas, to insure breathing air is safe.
- 5.e. Read and understand the manufacturer's instructions for this equipment and the consumables to be used, including the Safety Data Sheet (SDS) and follow your employer's safety practices. SDS forms are available from your welding distributor or from the manufacturer.
- 5.f. Also see item 1.b.

## WELDING AND CUTTING SPARKS CAN CAUSE FIRE OR EXPLOSION.



- 6.a. Remove fire hazards from the welding area. If this is not possible, cover them to prevent the welding sparks from starting a fire. Remember that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas. Avoid welding near hydraulic lines. Have a fire extinguisher readily available.
- 6.b. Where compressed gases are to be used at the job site, special precautions should be used to prevent hazardous situations. Refer to "Safety in Welding and Cutting" (ANSI Standard Z49.1) and the operating information for the equipment being used.
- 6.c. When not welding, make certain no part of the electrode circuit is touching the work or ground. Accidental contact can cause overheating and create a fire hazard.
- 6.d. Do not heat, cut or weld tanks, drums or containers until the proper steps have been taken to insure that such procedures will not cause flammable or toxic vapors from substances inside. They can cause an explosion even though they have been "cleaned". For information, purchase "Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping That Have Held Hazardous Substances", AWS F4.1 from the American Welding Society (see address above).
- 6.e. Vent hollow castings or containers before heating, cutting or welding. They may explode.
- 6.f. Sparks and spatter are thrown from the welding arc. Wear oil free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes and a cap over your hair. Wear ear plugs when welding out of position or in confined places. Always wear safety glasses with side shields when in a welding area.
- 6.g. Connect the work cable to the work as close to the welding area as practical. Work cables connected to the building framework or other locations away from the welding area increase the possibility of the welding current passing through lifting chains, crane cables or other alternate circuits. This can create fire hazards or overheat lifting chains or cables until they fail.
- 6.h. Also see item 1.c.
- 6.I. Read and follow NFPA 51B "Standard for Fire Prevention During Welding, Cutting and Other Hot Work", available from NFPA, 1 Batterymarch Park, PO box 9101, Quincy, MA 022690-9101.
- 6.j. Do not use a welding power source for pipe thawing.

## CYLINDER MAY EXPLODE IF DAMAGED.

7.a. Use only compressed gas cylinders containing the correct shielding gas for the process used and properly operating regulators designed for the gas and pressure used. All hoses, fittings, etc. should be suitable for the application and maintained in good condition.



- 7.b. Always keep cylinders in an upright position securely chained to an undercarriage or fixed support.
- 7.c. Cylinders should be located:
  - Away from areas where they may be struck or subjected to physical damage.
  - A safe distance from arc welding or cutting operations and any other source of heat, sparks, or flame.
- 7.d. Never allow the electrode, electrode holder or any other electrically "hot" parts to touch a cylinder.
- 7.e. Keep your head and face away from the cylinder valve outlet when opening the cylinder valve.
- 7.f. Valve protection caps should always be in place and hand tight except when the cylinder is in use or connected for use.
- 7.g. Read and follow the instructions on compressed gas cylinders, associated equipment, and CGA publication P-I, "Precautions for Safe Handling of Compressed Gases in Cylinders," available from the Compressed Gas Association, 14501 George Carter Way Chantilly, VA 20151.

## FOR ELECTRICALLY POWERED EQUIPMENT.



- 8.a. Turn off input power using the disconnect switch at the fuse box before working on the equipment.
- 8.b. Install equipment in accordance with the U.S. National Electrical Code, all local codes and the manufacturer's recommendations.
- 8.c. Ground the equipment in accordance with the U.S. National Electrical Code and the manufacturer's recommendations.

### Refer to http://www.lincolnelectric.com/safety for additional safety information.

## **Electromagnetic Compatibility (EMC)**

The size of the surrounding area to be considered will depend on the structure of the building and other activities that are taking place. The surrounding area may extend beyond the boundaries of the premises.

#### **Methods of Reducing Emissions**

#### **Mains Supply**

Welding equipment should be connected to the mains supply according to the manufacturer's recommendations. If interference occurs, it may be necessary to take additional precautions such as filtering of the mains supply. Consideration should be given to shielding the supply cable of permanently installed welding equipment, in metallic conduit or equivalent. Shielding should be electrically continuous throughout its length. The shielding should be connected to the welding power source so that good electrical contact is maintained between the conduit and the welding power source enclosure.

#### Maintenance of the Welding Equipment

The welding equipment should be routinely maintained according to the manufacturer's recommendations. All access and service doors and covers should be closed and properly fastened when the welding equipment is in operation. The welding equipment should not be modified in any way except for those changes and adjustments covered in the manufacturers instructions. In particular, the spark gaps of arc striking and stabilizing devices should be adjusted and maintained according to the manufacturer's recommendations.

#### Welding Cables

The welding cables should be kept as short as possible and should be positioned close together, running at or close to floor level.

#### **Equipotential Bonding**

Bonding of all metallic components in the welding installation and adjacent to it should be considered. However, metallic components bonded to the work piece will increase the risk that the operator could receive a shock by touching these metallic components and the electrode at the same time. The operator should be insulated from all such bonded metallic components.

#### Earthing of the Workpiece

Where the workpiece is not bonded to earth for electrical safety, not connected to earth because of its size and position, e.g., ships hull or building steelwork, a connection bonding the workpiece to earth may reduce emissions in some, but not all instances. Care should be taken to prevent the earthing of the workpiece increasing the risk of injury to users, or damage to other electrical equipment. Where necessary, the connection of the workpiece to earth should be made by a direct connection to the workpiece, but in some countries where direct connection is not permitted, the bonding should be achieved by suitable capacitance, selected according to national regulations.

#### Screening and Shielding

Selective screening and shielding of other cables and equipment in the surrounding area may alleviate problems of interference. Screening of the entire welding installation may be considered for special applications<sup>1</sup>.

<sup>&</sup>lt;sup>1</sup> Portions of the preceding text are contained in EN 60974-10: "Electromagnetic Compatibility (EMC) product standard for arc welding equipment."

POWER W	/AVE®	S350CE
		)

## ECO design information

The equipment has been designed in order to be compliant with the Directive 2009/125/EC and the Regulation 2019/1784/EU.

Nam e	Efficiency when max power consumption / Idle power consumption	Equivalent model
Power Wave S350 CE	86% / 228W	No equivalent model

 $\label{eq:efficiency} \mbox{ Efficiency and idle power consumption:} \\$ 

Idle state; machine powered on regular start up without making output

#### Efficiency;

The Efficiency procedure itself requires the use of a grid. Pow er Wave Manager can be dow nloaded from pow erw avesoftware.com along with the Pow er Wave Manager instruction. The Pow er Wave Manager instructions explain how to test a machine using a resistive load. This is described in section 6 under calibration.

The value of efficiency and consumption in idle state have been measured by method and conditions defined in the product standard EN 60974-1

Manufacturer's name, product name, code number, product number, serial number and date of production can be read from rating plate and serial number label.



Wire DC electrode positive Wire Feeding Gas flow Material type diameter Shielding Gas Current Voltage [l/min] [m/min] [mm] [A] [V] Carbon, low alloy 0,9 - 1,1 95 - 200 18 - 22 Ar 75%, CO<sub>2</sub> 25% 3,5 - 6,512 steel Aluminum 0,8 - 1,6 90 - 240 18 - 26 5,5 - 9,5Argon 14 - 19 Austenitic stainless Ar 98%. O2 2% / 0,8 - 1,6 85 - 300 21 - 28 3 - 7 14 - 16 He 90%, Ar 7,5% CO2 2.5% steel Copper alloy 0,9 - 1,6 175 - 385 23 - 26 6 - 11 Argon 12 - 16 Magnesium 1,6 - 2,4 70 - 335 16 - 26 4 - 15 Argon 24 - 28

Typical gas usage for **MIG/MAG** equipment:

#### Tig Process:

In TIG welding process, gas usage depends on cross-sectional area of the nozzle. For comonly used torches:

Helium: 14-24 I/min

Argon: 7-16 l/min

**Notice:** Excessive flow rates causes turbulence in the gas stream which may aspirate atmospheric contaminantion into the welding pool.

**Notice:** A cross wind or draft moving can disrupt the shielding gas coverage, in the interest of saving of protective gas use screen to block air flow .



At end of life of product, it has to be disposal for recycling in accordance with Directive 2012/19/EU (WEEE), information about the dismantling of product and Critical Raw Material (CRM) present in the product, can be found at: www.lincolnelectriceurope.com



Item	Component	Material for recovery	CRM	Selective treatment
1	Enclosure	Steel	-	-
2	Heat sink	Aluminum	Si, 14 g Mg, 24 g	-
3	Rail	Aluminum	Si, 21 g Mg, 14 g	-
4	Handle	Aluminum	Si, 118 g Mg, 1 g	-
5	Output terminal	Brass	-	-
6	PC board	-	-	Required
7	Choke Internal cables, not shown	Copper	-	-
8	Mechanical components	Aluminum	Si, 2 g Mg, 47 g	-
9	External cables, not shown	Copper	-	Required

Reference: P-1247, code 12795

## **TABLE OF CONTENTS**

viii

Installation	Section A
Technical Specifications	A-1, A-2
Safety Precautions	A-3
Location, Lifting	A-3
Stacking	A-3
Tilting	A-3
Input and Ground Connections	A-3
Machine Grounding	A-3
High Frequency Protection	A-3
Input Connection	A-4
Input Fuse and Supply Wire	A-4
Input Voltage Selection	A-4
Power Cord Replacement	A-4
Connection Diagrams	A-5
Recommended Work Cable Sizes	A-6
Cable Inductance and its Effects on Welding	A-7
Remote Sense Lead Specifications	A-7, A-8
Voltage Sensing Considerations for Multiple Arc Systems	A-9, A-10
Control Cable Connections	Á-11
Operation	Section B
Safety Precautions	B-1
Graphic Symbols	B-1
Power-Up Sequence	
Duty Cycle	B-1
Product Description	B-2
Recommended Processes and Equipment	B-2
Equipment Limitations	B-2
Design Features	B-3
Case Front Controls	B-3
Case Back Controls	B-4
Common Welding Procedures	B-5 thru B-7
Accessories	Section C
Kite Options / Accessories	
Field lestelled Ontions	
Stick Operations	C-2
Maintenance	Section D
Safety Precautions	D-1
Routine Maintenance	D-1
Periodic Maintenance	D-1
Calibration Specification	D-1
Troubleshooting	Section E
Safety Precautions	E-1
How to Use Troubleshooting Guide	E-1
Using Status LED Error Fault Codes and Input Control Board	F-2 F-4
Troubloshooting Guido	E-5 thru E-8
Troubleshooting dulue	L-5 tinu L-0
Wiring Diagram and Dimension Print	Section F
Parts Pages	P-636 Series

## **TECHNICAL SPECIFICATIONS - POWER WAVE® S350CE**

	POWER SOURCE-INPUT VOLTAGE AND CURRENT											
Model	Duty Cycle	Input Voltage ± 10%			nput Am	out Amperes Idle		e Power	Power F	actor @		
					_						Output	
	40% rating											
K2823-2			230/380 460/5	-415/ 75		35/20/17/14			300 Watts Max		95	
	100% rating		50/60	Hz				(f	an on)			
						28/16/1	4/11					
				DA		итрит						
	INPUT			GMAW		UIPUI	SMAW		G	TAW-DC		
VOLT	AGE / PHASE	:/ T	40%	60%	100%	40%	60%	100%	40%	60%	100%	
FI	REQUENCY		40 /0		10070	1070	0070	10070	10 / 0	0070	100 /0	
			350	320	300	325	275	250	350	325	300	
380	)-415/3/50/60		Amps	Amps	Amps	Amps	Amps	Amps	Amps	Amps	Amps	
4	60/3/50/60		31.5 Volts	30 Volts	29 Volts	33 Volts	31 Volts	30 Volts	24 Volts	23 Volts	22 Volts	
	133330700		Volto	Volto	Volto	VOILO	Volto	VOILO	Volto	Volto	Volto	
		RECO	OMMEN		IPUT W	/IRE AN	ND FUS	E SIZE	S 1			
	INPUT			ΜΑΧΙΜυ	М		CORD S					
VOLTAGE / PHASE/					AWG SIZES (mm²) BRE			₹² GE				
Г	nequenci		AN									
230/3/50/60 35A 40%		1%	8 (10)			45						
380-415/3/50/60			19A, 40°	%		12 (4)		30				
	460/3/50/60			17A, 40°	%		12 (4 14 (2	) 5)		25		
575/3/50/60			147, 40	/0		14 (2.	5)		20			

1. Based on U.S. National electrical Code

2. Also called " inverse time" or "thermal / magnetic" circuit breakers; circuit breakers that have a delay in tripping action that decreases as the magnitude of the current increases 3. Type SO cord or similar in 30° C ambient

WELDING PROCESS						
PR	OCESS	OUTPUT RA	ANGE (AMPER	RES)	OCV (U₀)	
					Mean	Peak
	MAW				40-70	
GMA	AW-Pulse				40-70	
F	CAW		5-350		40-70	100V
GT	AW-DC				24	
5	SMAW			60		
PHYSICAL	DIMENSIONS					
MODEL	HEIGHT	V	VIDTH		DEPTH	WEIGHT
K2823-2	20.40 in ( 518 mm)	14.00in ( 356 mm)		24.8	30in ( 630mm)	85 lbs (39 kg)*
TEMPERATURE RANGES						
OPERATING TEMPERATURE RANGE -4°F to 104°F (-20C to 40C)			STO	RAGE -40°F	to 185°F(-40C to	<b>E RANGE</b> 9 85C)

IP23 155°(F) Insulation Class

\* Weight does not include input cord.

## SAFETY PRECAUTIONS

Read this entire installation section before you start installation.

## A WARNING



ELECTRIC SHOCK can kill.

- Only qualified personnel should perform this installation.
- Turn the input power OFF at the disconnect switch or fuse box

before working on this equipment. Turn off the input power to any other equipment connected to the welding system at the disconnect switch or fuse box before working on the equipment.

- Do not touch electrically hot parts.
- Always connect the POWER WAVE® S350CE grounding lug to a proper safety (Earth) ground.

## SELECT SUITABLE LOCATION

The POWER WAVE® S350CE will operate in harsh environments. Even so, it is important that simple preventative measures are followed in order to assure long life and reliable operation.

- The machine must be located where there is free circulation of clean air such that air movement in the back, out the sides and bottom will not be restricted.
- Dirt and dust that can be drawn into the machine should be kept to a minimum. The use of air filters on the air intake is not recommended because normal air flow may be restricted. Failure to observe these precautions can result in excessive operating temperatures and nuisance shutdown.
- Keep machine dry. Shelter from rain and snow. Do not place on wet ground or in puddles.
- Do not mount the POWER WAVE® S350CE over combustible surfaces. Where there is a combustible surface directly under stationary or fixed electrical equipment, that surface shall be covered with a steel plate at least .060" (1.6mm) thick, which shall extend not less than 5.90" (150mm) beyond the equipment on all sides.

## LIFTING

Both handles should be used when lifting POWER WAVE® S350CE. When using a crane or overhead device a lifting strap should be connected to both handles. Do not attempt to lift the POWER WAVE® S350CE with accessories attached to it.

## WARNING

- Lift only with equipment of adequate lifting capacity.
- Be sure machine is stable when lifting.
- Do not operate machine while suspended when lifting.

#### FALLING

EQUIPMENT can

cause injury.

## STACKING

The POWER WAVE® S350CE cannot be stacked.

### TILTING

Place the machine directly on a secure, level surface or on a recommended undercarriage. The machine may topple over if this procedure is not followed.

## INPUT AND GROUND CONNECTIONS

Only a qualified electrician should connect the POWER WAVE® S350CE. Installation should be made in accordance with the appropriate National Electrical Code, all local codes and the information in this manual.

## MACHINE GROUNDING



The frame of the welder must be grounded. A ground terminal marked with a ground symbol is located next to the input power connection block.

See your local and national electrical codes for proper grounding methods.

## **HIGH FREQUENCY PROTECTION**

The EMC classification of the POWER WAVE® S350CE is Industrial, Scientific and Medical (ISM) group 2, class A. The POWER WAVE® S350CE is for industrial use only. (See print L10093 for further details).

Locate the POWER WAVE® S350CE away from radio controlled machinery. The normal operation of the POWER WAVE® S350CE may adversely affect the operation of RF controlled equipment, which may result in bodily injury or damage to the equipment.



## INPUT CONNECTION

## 

Only a qualified electrician should connect the input leads to the POWER WAVE® S350CE. Connections should be made in accordance with all local and

national electrical codes and the connection diagrams. Failure to do so may result in bodily injury or death.

A 15 ft. (4.5m) power cord is provided and wired into the machine.

#### For Three Phase Input

Connect green lead to ground per National Electric Code.

Connect black, grey and brown leads to power.

# INPUT FUSE AND SUPPLY WIRE CONSIDERATIONS

Refer to Specification Section for recommended fuse, wire sizes and type of the copper wires. Fuse the input circuit with the recommended super lag fuse or delay type breakers (also called "inverse time" or "thermal/magnetic" circuit breakers). Choose input and grounding wire size according to local or national electrical codes. Using input wire sizes, fuses or circuit breakers smaller than recommended may result in "nuisance" shut-offs from welder inrush currents, even if the machine is not being used at high currents.

## INPUT VOLTAGE SELECTION

The POWER WAVE® S350CE automatically adjusts to work with different input voltages. No reconnect switches settings are required.

## 

The POWER WAVE® S350CE ON/OFF switch is not intended as a service disconnect for this equipment. Only a qualified electrician should connect the input leads to the POWER WAVE® S350CE.

Connections should be made in accordance with all local and national electrical codes and the connection diagram located on the inside of the reconnect access door of the machine. Failure to do so may result in bodily injury or death.

## POWER CORD REPLACEMENT

## 

Only a qualified electrician should connect the input leads to the POWER WAVE® S350CE. Connections should be made in accordance with all local and

national electrical codes and the connection diagrams. Failure to do so may result in bodily injury or death.

If the **input power cord** is damaged or needs to be replaced, remove right case side and remove cord from CE filter mounted to center divider shown in figure A.1.

ALWAYS CONNECT THE POWER WAVE **GROUND-ING LUG** (LOCATED AS SHOWN IN FIGURE A.1) TO A PROPER SAFETY (EARTH) GROUND.



## INSTALLATION

## **CONNECTION DIAGRAMS**

GTAW (TIG) WELDING

TIG welding from a LF-45 wire feeder can be used with the power source as shown in (Figure A.2),



#### SMAW (STICK) WELDING

Stick welding from a LF-45 wire feeder can be used with the power source as shown in (Figure A.3).



#### GMAW (MIG) WELDING

MIG welding from a LF-45 wire feeder can be used with the power source as shown in (Figure A.4).



## RECOMMENDED WORK CABLE SIZES FOR ARC WELDING

Connect the electrode and work cables between the appropriate output studs of the Power Wave® S350CE per the following guidelines:

- Most welding applications run with the electrode being positive (+). For those applications, connect the electrode cable between the wire drive feed plate and the positive (+) output stud on the power source. Connect a work lead from the negative (-) power source output stud to the work piece
- When negative electrode polarity is required, such as in some Innershield applications, reverse the output connections at the power source (electrode cable to the negative (-) stud, and work cable to the positive (+) stud).

## 

Negative electrode polarity operation WITHOUT use of a remote work sense lead (21) requires the Negative Electrode Polarity attribute to be set. See the Remote Sense Lead Specification section of this document for further details.

For additional Safety information regarding the electrode and work cable set-up, See the standard "SAFE-TY INFORMATION" located in the front of the Instruction Manuals.

#### General Guidelines

• Select the appropriate size cables per the "Output Cable Guidelines" below. Excessive voltage drops caused by undersized welding cables and poor connections often result in unsatisfactory welding performance. Always use the largest welding cables (electrode and work) that are practical, and be sure all connections are clean and tight.

Note: Excessive heat in the weld circuit indicates undersized cables and/or bad connections.

- Route all cables directly to the work and wire feeder, avoid excessive lengths and do not coil excess cable. Route the electrode and work cables in close proximity to one another to minimize the loop area and therefore the inductance of the weld circuit.
- Always weld in a direction away from the work (ground) connection.

Table A.1 shows copper cable sizes recommended for different currents and duty cycles. Lengths stipulated are the distance from the welder to work and back to the welder again. Cable sizes are increased for greater lengths primarily for the purpose of minimizing cable drop.

	OUTPUT CABLE GUIDELINES (Table A.1)					
A	Percent Duty	CABLE SIZ	ZES FOR COM	BINED LENGTHS		
Amperes	Cycle	CABLES [F		ERED COPPER -	RATED 16/°F (/5°	
		0 to 50 Ft.	50 to 100 Ft.	100 to 150 Ft.	150 to 200 Ft.	200 to 250 Ft.
200	60	2	2	2	1	1/0
200	100	2	2	2	1	1/0
250	30	3	3	2	1	1/0
250	40	2	2	1	1	1/0
250	60	1	1	1	1	1/0
250	100	1	1	1	1	1/0
300	60	1	1	1	1/0	2/0
300	100	2/0	2/0	2/0	2/0	3/0
350	40	1/0	1/0	2/0	2/0	3/0

\*\* Tabled values are for operation at ambient temperatures of 104°F (40°C) and below. Applications above 104°F (40°C) may require cables larger than recommended, or cables rated higher than 167°F (75°C).

# CABLE INDUCTANCE AND ITS EFFECTS ON WELDING

Excessive cable inductance will cause the welding performance to degrade. There are several factors that contribute to the overall inductance of the cabling system including cable size, and loop area. The loop area is defined by the separation distance between the electrode and work cables, and the overall welding loop length. The welding loop length is defined as the total of length of the electrode cable (A) + work cable (B) + work path (C) (See Figure A.6).

To minimize inductance always use the appropriate size cables, and whenever possible, run the electrode and work cables in close proximity to one another to minimize the loop area. Since the most significant factor in cable inductance is the welding loop length, avoid excessive lengths and do not coil excess cable. For long work piece lengths, a sliding ground should be considered to keep the total welding loop length as short as possible.

## REMOTE SENSE LEAD SPECIFICATIONS

#### Voltage Sensing Overview

The best arc performance occurs when the Power Wave® S350CE has accurate data about the arc conditions.

Depending upon the process, inductance within the electrode and work cables can influence the voltage apparent at the studs of the welder, and have a dramatic effect on performance. Remote voltage sense leads are used to improve the accuracy of the arc voltage information supplied to the control pc board. Sense Lead Kits (K940-xx) are available for this purpose.

The Power Wave® S350CE has the ability to automatically sense when remote sense leads are connected. With this feature there are no requirements for setting-up the machine to use remote sense leads. This feature can be disabled through the Weld Manager Utility (available at www.powerwavesoftware.com) or through the set up menu (if a user interface is installed into the power source).

## A CAUTION

If the auto sense lead feature is disabled and remote voltage sensing is enabled but the sense leads are missing, improperly connected extremely high welding outputs may occur.

**General Guidelines for Voltage Sense Leads** Sense leads should be attached as close to the weld as practical, and out of the weld current path when possible. In extremely sensitive applications it may be necessary to route cables that contain the sense leads away from the electrode and work welding cables.

Voltage sense leads requirements are based on the weld process (See Table A.2)

Process	Electrode Voltage Sensing <sup>(1)</sup> 67 lead	Work Voltage Sensing <sup>(2)</sup> 21 lead
GMAW	67 lead required	21 lead optional
GMAW-P	67 lead required	21 lead optional
FCAW	67 lead required	21 lead optional
GTAW	Voltage sense at studs	Voltage sense at studs
SMAW	Voltage sense at studs	Voltage sense at studs

TABLE A.2

 The electrode voltage sense lead (67) is automatically enabled by the weld process, and integral to the 5 pin arclink control cable (K1543xx).

(2) When a work voltage sense lead (21) is connected the power source will automatically switch over to using this feedback (if the auto sense feature is enable).

#### **FIGURE A.6**



#### Electrode Voltage Sensing

The remote ELECTRODE sense lead (67) is built into the 5-pin arclink control cable (K1543-xx) and is always connected to the wire drive feed plate when a wire feeder is present. Enabling or disabling electrode voltage sensing is application specific, and automatically configured by the active weld mode.

#### Work Voltage Sensing

The Power Wave® S350CE is configured at the factory to sense work voltage at the negative output stud (positive output polarity with remote Work Voltage Sensing disabled).

#### **Negative Electrode Polarity**

The Power Wave® S350CE has the ability to automatically sense the polarity of the sense leads. With this feature there are no set-up requirements for welding with negative electrode polarity. This feature can be disabled through the Weld Manager Utility (available at www.powerwavesoftware.com) or through the set up menu (if a user interface is installed into the power source).

#### 

If the auto sense lead feature is disabled and the weld polarity attribute is improperly configured extremely high welding outputs may occur.

While most applications perform adequately by sensing the work voltage directly at the output stud, the use of a remote work voltage sense lead is recommended for optimal performance. The remote WORK sense lead (21) can be accessed through the four-pin voltage sense connector located on the control panel by using the K940 Sense Lead Kit. It must be attached to the work as close to the weld as practical, but out of the weld current path. For more information regarding the placement of remote work voltage sense leads, see the section entitled "Voltage Sensing Considerations for Multiple Arc Systems."

## VOLTAGE SENSING CONSIDERATIONS FOR MULTIPLE ARC SYSTEMS

Special care must be taken when more than one arc is welding simultaneously on a single part. Multiple arc applications do not necessarily dictate the use of remote work voltage sense leads, but they are strongly recommended.

#### If Sense Leads ARE NOT Used:

• Avoid common current paths. Current from adjacent arcs can induce voltage into each others current paths that can be misinterpreted by the power sources, and result in arc interference.

#### If Sense Leads ARE Used:

- Position the sense leads out of the path of the weld current. Especially any current paths common to adjacent arcs. Current from adjacent arcs can induce voltage into each others current paths that can be misinterpreted by the power sources, and result in arc interference.
- For longitudinal applications, connect all work leads at one end of the weldment, and all of the work voltage sense leads at the opposite end of the weldment. Perform welding in the direction away from the work leads and toward the sense leads.

(See Figure A.7)



## INSTALLATION

• For circumferential applications, connect all work leads on one side of the weld joint, and all of the work voltage sense leads on the opposite side, such that they are out of the current path.

(See Figure 8.A)



FIGURE A.8

## CONTROL CABLE CONNECTIONS

#### **General Guidelines**

Genuine Lincoln control cables should be used at all times (except where noted otherwise). Lincoln cables are specifically designed for the communication and power needs of the Power Wave® / Power Feed® systems. Most are designed to be connected end to end for ease of extension. Generally, it is recommended that the total length not exceed 100ft. (30.5m). The use of non-standard cables, especially in lengths greater than 25 feet, can lead to communication problems (system shutdowns), poor motor acceleration (poor arc starting), and low wire driving force (wire feeding problems). Always use the shortest length of control cable possible, and DO NOT coil excess cable.

Regarding cable placement, best results will be obtained when control cables are routed separate from the weld cables. This minimizes the possibility of interference between the high currents flowing through the weld cables, and the low level signals in the control cables. These recommendations apply to all communication cables including ArcLink® and Ethernet connections.

#### **Product specific Installation Instructions**

Connection Between Power Source and ArcLink® Compatible Wirefeeders (K1543 – ArcLink Control Cable)

The 5-pin ArcLink control cable connects the power source to the wire feeder. The control cable consists of two power leads, one twisted pair for digital communication, and one lead for voltage sensing. The 5pin ArcLink connection on the Power Wave® S350CE is located on the rear panel above the power cord and on the front of machine. The control cable is keyed and polarized to prevent improper connection. Best results will be obtained when control cables are routed separate from the weld cables, especially in long distance applications. The recommended combined length of the ArcLink control cable network should not exceed 200ft. (61.0m).

# Connection Between Power Source and Ethernet Networks

The Power Wave® S350CE is equipped with an ODVA compliant RJ-45 Ethernet connector, which is located on the rear panel. All external Ethernet equipment (cables, switches, etc.), as defined by the connection diagrams, must be supplied by the customer. It is critical that all Ethernet cables external to either a conduit or an enclosure are solid conductor, shielded cat 5e cable, with a drain. The drain should be grounded at the source of transmission. For best results, route Ethernet cables away from weld cables, wire drive control cables, or any other current carrying device that can create a fluctuating magnetic field. For additional guidelines refer to ISO/IEC 11801. Failure to follow these recommendations can result in an Ethernet connection failure during welding.

## SAFETY PRECAUTIONS

READ AND UNDERSTAND ENTIRE SECTION **BEFORE OPERATING MACHINE.** 



- · ELECTRIC SHOCK CAN KILL.
- · Do not touch electrically live part or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.
- · Do not operate with covers, panels or guards removed or open.



 FUMES AND GASSES can be dangerous.

- Keep your head out of fumes.
- Use ventilation or exhaust to remove fumes from breathing zone.



WELDING SPARKS can cause fire or explosion.

Keep flammable material away.

ARC RAYS can burn. Wear eye, ear and body protection.

SEE ADDITIONAL WARNING INFORMATION UNDER ARC WELDING SAFETY PRECAUTIONS AND IN THE FRONT OF THIS OPERATING MAN-UAL.

## **GRAPHIC SYMBOLS THAT APPEAR ON** THIS MACHINE OR IN THIS MANUAL



COOLER



OUTPUT



**OPERATER'S** MANUAL





WORK



PROTECTIVE GROUND



**EXPLOSION** 

## **POWER-UP SEQUENCE**

When the POWER WAVE® S350CE is powered up, it can take as long as 30 seconds for the machine to be ready to weld. During this time period the user interface will not be active.

## **DUTY CYCLE**

The duty cycle is based on a ten-minute period. A 40% duty cycle represents 4 minutes of welding and 6 minutes of idling in a ten-minute period. Refer to the technical specification section for the Power Wave® S350CE's duty cycle ratings.

**B-1** 

POWER WAVE® S350CE

## **PRODUCT DESCRIPTION**

#### **PRODUCT SUMMARY**

The POWER WAVE® S350CE is a portable multiprocess power source with high-end functionality capable of Stick, DC TIG, MIG, Pulsed MIG and Flux-Cored welding. It is ideal for a wide variety of materials including aluminum, stainless, and nickel — where arc performance is critical.

The POWER WAVE® S350CE is designed to be a very flexible welding system. Like existing Power Wave's, the software based architecture allows for future upgrade ability. One significant change from the current range of Power Wave units is that the Ethernet communication feature is standard on the POWER WAVE® S350CE which allows for effortless software upgrades through Powerwavesoftware.com. The Ethernet communication also gives the POWER WAVE® S350CE the ability to run Production Monitoring<sup>™</sup> 2. Also a Devicenet option which will allow the POWER WAVE® S350CE to be used in a wide range of configurations. The POWER WAVE® S350CE can easily be upgraded to have advanced welding process with STT® Module, or have water Cooled capabilites with the Cool Arc 50 module.

# RECOMMENDED PROCESSES AND EQUIPMENT

The POWER WAVE® S350CE is recommended for semiautomatic welding, and may also be suitable for basic hard automation applications. The POWER WAVE® S350CE can be set up in a number of configurations, some requiring optional equipment or welding programs.

#### **RECOMMENDED EQUIPMENT**

The POWER WAVE® S350CE is designed to be compatible with the current range of Power Feed<sup>™</sup> systems including future versions of ArcLink® feeders.

#### **RECOMMENDED PROCESSES**

The Power Wave® S350CE is a high speed, multiprocess power source capable of regulating the current, voltage, or power of the welding arc. With an output range of 5 to 350 amperes, it supports a number of standard processes including synergic GMAW, GMAW-P, FCAW, FCAW-SS, SMAW, GTAW and GTAW-P on various materials especially steel, aluminum and stainless.

#### **PROCESS LIMITATIONS**

The software based weld tables of the Power Wave® S350CE limit the process capability within the output range and the safe limits of the machine. In general the processes will be limited to .030-.052 solid steel wire, .030-.045 stainless wire, .035-1/16 cored wire, and .035 and 1/16 Aluminum wire.

## **EQUIPMENT LIMITATIONS**

Only ArcLink compatible semiautomatic wire feeders and users interfaces may be used. If other Lincoln wire feeders or non-Lincoln wire feeders are used there will be limited process capability and performance and features will be limited.

## **DESIGN FEATURES**

#### Loaded with Standard Features

- Multiple process DC output range: 5 350 Amps
- 200 600 VAC, 1/3 phase, 50-60Hz input power
- New and Improved Line Voltage Compensation holds the output constant over wide input voltage fluctuations.
- Utilizes next generation microprocessor control, based on the ArcLink® platform.
- State of the art power electronics technology yields superior welding capability.
- · Electronic over current protection
- Input over voltage protection.
- F.A.N. (fan as needed). Cooling fan only runs when needed.
- Thermostatically protected for safety and reliability.
- Recessed connection panel for protection against accidental impact.
- Ethernet connectivity via ODVA compliant RJ-45 connector.
- Panel mounted Status and Thermal LED indicators facilitate quick and easy troubleshooting.
- Potted PC boards for enhanced ruggedness/reliability.
- Enclosure reinforced with heavy duty aluminum extrusions for mechanical toughness
- Waveform Control Technology<sup>™</sup> for good weld appearance and low spatter, even when welding nickel alloys.
- Compatible with stackable STT® and Water Cooled Modules upgrades.
- Devicenet relay.

### CASE FRONT CONTROLS (See Figure B.1)

- 1. (NO OPTIONAL) USER INTERFACE
- STATUS LED (See Troubleshooting Section for operational functions)
- **3. THERMAL LED -** Indicates when machine has thermal fault.
- 4. POWER SWITCH Controls power to the POWER WAVE® S350CE.
- 5. WORK STUD
- 6. ELECTRODE STUD
- 7. WORK SENSE LEAD
- 8. ARCLINK RECEPTACLE

#### FIGURE B.1



B-4	OPERATION	B-4
CASE BACK CONTROLS (See Figure B.2 for Code 11625)	CASE BACK CONTROLS (See Figure B.2a for Code 11783)	3
1. ETHERNET	1. ETHERNET	
2. ARCLINK (OPTIONAL)	2. 115 VAC KIT (OPTIONAL)	
3. SYNC-PULSE (OPTIONAL)	3. SYNC-PULSE (OPTIONAL)	
4. DEVICENET KIT (OPTIONAL)	4. CIRCUIT BREAKER	
5. INPUT POWER CORD	5. SYNC TANDEM/ STT CONNECT	FOR (OPTIONAL)
6. COOLER OUTPUT POWER PANEL (OP	PTIONAL) 6. DEVICENET KIT (OPTIONAL)	
7. CIRCUIT BREAKER	7. INPUT POWER CORD	
	8. RESERVED FOR FUTURE DEV	ELOPMENT
	9. COOLER OUTPUT POWER PAN	NEL (OPTIONAL)



## **COMMON WELDING PROCEDURES**

## A WARNING

#### **MAKING A WELD**

The serviceability of a product or structure utilizing the welding programs is and must be the sole responsibility of the builder/user. Many variables beyond the control of The Lincoln Electric Company affect the results obtained in applying these programs. These variables include, but are not limited to, welding procedure, plate chemistry and temperature, weldment design, fabrication methods and service requirements. The available range of a welding program may not be suitable for all applications, and the build/user is and must be solely responsible for welding program selection.

Choose the electrode material, electrode size, shielding gas, and process (GMAW, GMAW-P etc.) appropriate for the material to be welded.

Select the weld mode that best matches the desired welding process. The standard weld set shipped with the POWER WAVE® S350CE encompasses a wide range of common processes that will meet most needs. If a special weld mode is desired, contact the local Lincoln Electric sales representative.

All adjustments are made through the user interface. Because of the different configuration options your system may not have all of the following adjustments. See Accessories Section for Kits and Options avaliable to use with the POWER WAVE® S350CE.

#### **Definition of Welding Modes**

#### NON-SYNERGIC WELDING MODES

• A Non-synergic welding mode requires all welding process variables to be set by the operator.

#### SYNERGIC WELDING MODES

• A Synergic welding mode offers the simplicity of single knob control. The machine will select the correct voltage and amperage based on the Wire Feed Speed (WFS) set by the operator.

#### **Basic Welding Controls**

#### Weld Mode

Selecting a weld mode determines the output characteristics of the Power Wave power source. Weld modes are developed with a specific electrode material, electrode size, and shielding gas. For a more complete description of the weld modes programmed into the POWER WAVE® S350CE at the factory, refer to the Weld Set Reference Guide supplied with the machine or available at:

#### (www.powerwavesoftware.com.)

#### Wire Feed Speed (WFS)

In synergic welding modes (synergic CV, GMAW-P), WFS is the dominant control parameter. The user adjusts WFS according to factors such as wire size, penetration requirements, heat input, etc. The POWER WAVE® S350CE then uses the WFS setting to adjust the voltage and current according to settings contained in the Power Wave.

In non-synergic modes, the WFS control behaves like a conventional power source where WFS and voltage are independent adjustments. Therefore, to maintain proper arc characteristics, the operator must adjust the voltage to compensate for any changes made to the WFS.

#### Amps

In constant current modes, this control adjusts the welding amperage.

#### Volts

In constant voltage modes, this control adjusts the welding voltage.

#### Trim

In pulse synergic welding modes, the Trim setting adjusts the arc length. Trim is adjustable from 0.50 to 1.50. 1.00 is the nominal setting and is a good starting point for most conditions.

#### UltimArc<sup>™</sup> Control

UltimArc<sup>™</sup> Control allows the operator to vary the arc characteristics. UltimArc<sup>™</sup> Control is adjustable from -10.0 to +10.0 with a nominal setting of 0.0.

#### **SMAW (STICK) WELDING**

The welding current and Arc Force settings can be set through a Power Feed 10M, LF45 or Power Feed 25M wire feeder. Alternatively an optional Stick / TIG UI (K2828-1) can be installed into the power source to control these settings locally.

In a SMAW (STICK mode), Arc Force can be adjusted. It can be set to the lower range for a soft and less penetrating arc characteristic (negative numeric values) or to the higher range (positive numeric values) for a crisp and more penetrating arc. Normally, when welding with cellulosic types of electrodes (E6010, E7010, E6011), a higher energy arc is required to maintain arc stability. This is usually indicated when the electrode sticks to the work-piece or when the arc becomes unstable during manipulative technique. For low hydrogen types of electrodes (E7018, E8018, E9018, etc.) a softer arc is usually desirable and the lower end of the Arc Control suits these types of electrodes. In either case the arc control is available to increase or decrease the energy level delivered to the arc.

#### GTAW (TIG) WELDING

The welding current can be set through a Power Feed 10M, LF45 or Power Feed 25M wire feeder. Alternatively an optional Stick / TIG UI (K2828-1) can be installed into the power source to control these settings locally.

The TIG mode features continuous control from 5 to 350 amps with the use of an optional foot amptrol (K870). The POWER WAVE® S350CE can be run in either a Touch Start TIG mode or Scratch start TIG mode.

#### CONSTANT VOLTAGE WELDING Syneraic CV

For each wire feed speed, a corresponding voltage is preprogrammed into the machine through special software at the factory.

The nominal preprogrammed voltage is the best average voltage for a given wire feed speed, but may be adjusted to preference. When the wire feed speed changes, the POWER WAVE® S350CE automatically adjusts the voltage level correspondingly to maintain similar arc characteristics throughout the WFS range.

#### Non Synergic CV

In non-synergic modes, the WFS control behaves more like a conventional CV power source where WFS and voltage are independent adjustments. Therefore to maintain the arc characteristics, the operator must adjust the voltage to compensate for any changes made to the WFS.

#### All CV Modes

Pinch adjusts the apparent inductance of the wave shape. The "pinch" function is inversely proportional to inductance. Therefore, increasing Pinch Control greater than 0.0 results in a crisper arc (more spatter) while decreasing the Pinch Control to less than 0.0 provides a softer arc (less spatter).

#### **PULSE WELDING**

Pulse welding procedures are set by controlling an overall "arc length" variable. When pulse welding, the arc voltage is highly dependent upon the waveform. The peak current, back ground current, rise time, fall time and pulse frequency all affect the voltage. The exact voltage for a given wire feed speed can only be predicted when all the pulsing waveform parameters are known. Using a preset voltage becomes impractical and instead the arc length is set by adjusting "trim".

Trim adjusts the arc length and ranges from 0.50 to 1.50 with a nominal value of 1.00. Trim values greater than 1.00 increase the arc length, while values less than 1.00 decrease the arc length. (See figure B.3)

Trim .50 Trim 1.00 Trim 1.50 Arc Length Short Arc Length Medium Arc Length Long **POWER WAVE® S350CE** 

> LINCOLN ELECTRIC

**FIGURE B.3** 



Most pulse welding programs are synergic. As the wire feed speed is adjusted, the POWER WAVE® S350CE will automatically recalculate the waveform parameters to maintain similar arc properties.

The POWER WAVE® S350CE utilizes "adaptive control" to compensate for changes in the electrical stickout while welding. (Electrical stick-out is the distance from the contact tip to the work piece.) The POWER WAVE® S350CE waveforms are optimized for a 0.75" stick-out. The adaptive behavior supports a range of stick-outs from 0.50 to 1.25". At very low or high wire feed speeds, the adaptive range may be less due to reaching physical limitations of the welding process.

UltimArc<sup>™</sup> Control adjusts the focus or shape of the arc. UltimArc<sup>™</sup> Control is adjustable from -10.0 to +10.0 with a nominal setting of 0.0. Increasing the UltimArc<sup>™</sup> Control increases the pulse frequency and background current while decreasing the peak current. This results in a tight, stiff arc used for high speed sheet metal welding. Decreasing the UltimArc<sup>™</sup> Control decreases the pulse frequency and background current while increasing the peak current. This results in a soft arc good for out of position welding. (See Figure B.4)



## **KITS, OPTIONS AND ACCESSORIES**

All Kits Options and Accessories are found on the Web site: (www.lincolnelectric.com)

#### FACTORY INSTALLED

None Available

### FIELD INSTALLED OPTIONS

#### **GENERAL OPTIONS**

#### **DeviceNet Kit**

Mounts inside the back of the Power Wave® S350CE. Allows Devicenet objects to communicate with the Power Wave® S350CE. **Order K2827-1** 

#### Work Voltage Sense Lead Kit

Required to accurately monitor voltage at the arc. Order K940-XX Series Order K1811-XX Series

#### Deluxe Adjustable Gas Regulator & Hose Kit

Accommodates  $CO_2$ , Argon, or Argon-blend gas cylinders. Includes a cylinder pressure gauge, dual scale flow gauge and 4.3 ft. (1.3 m) gas hose. **Order K586-1** 

#### Work and Wire Feeder 2/0 Weld Cable Package

Includes Twist-Mate<sup>™</sup> connectors, work clamps, 15 ft. (4.5 m) work cable and 10 ft. (3.0 m) electrode cable. Rated 350 amps, 60% duty cycle. **Order K1803-1** 

#### Twist-Mate<sup>™</sup> Cable Plug

For connecting welding cable to output terminal receptacles. For 1/0-2/0 (50-70 mm<sup>2</sup>) cable. Order K852-70

#### Twist-Mate<sup>™</sup> Cable Plug

For connecting welding cable to output terminal receptacles. For 2/0-3/0 (70-95 mm<sup>2</sup>) cable.

#### Order K852-95

#### Twist-Mate<sup>™</sup> Cable Receptacle

For connecting welding cable to Twist-Mate<sup>™</sup> Cable Plug.

Order K1759-70 for 1/0-2/0 (50-70 mm2) cable Order K1759-95 for 2/0-3/0 (70-95mm2) cable

#### Twist-Mate<sup>™</sup> to Lug Adapter

For connection of lugged cable to Twist-Mate<sup>™</sup> connectors. 18" (457 mm) long. **Order K2176-1** 

#### **Dual Cylinder Kit**

Permits side-by-side mounting of two full size gas cylinders, with easy loading. For use with K1764-1 cart.

#### Order K1702-1

#### **Coaxial Welding Cable**

Optimum weld cables for minimizing cable inductance and optimizing welding performance.

Order K1796-25 for 25 feet 25 ft. (7.6 m) cable length.

Order K1796-50 for 50 feet 50 ft. (15.2 m) cable length.

Order K1796-75 for 75 feet 75 ft. (22.9 m) cable length.

Order K1796-100 for 100 feet 100 ft. (30.5 m) cable length.

#### Welding Fume Extractors

Lincoln offers a wide range of fume extraction environmental system solutions, ranging from portable systems easily wheeled around a shop to shop-wide central systems servicing many dedicated welding stations.

Request Lincoln publication E13.40 (See www.lincolnelectric.com)

#### STT<sup>®</sup> MODULE

Mounts directly below the power source, to enable the advance waveform control technology of STT<sup>®</sup>. STT<sup>®</sup> is a controlled GMAW short circuit transfer process that uses current controls to adjust the heat independent of the wire feed speed, resulting in superior arc performance, good penetration, low heat input control, reduced spatter and fumes.

## Order K2921-1

#### **COOLARC 50**

This module mounts directly under the power source and enables water-cooled MIG or TIG applications. The module is powered and controlled by the power source and is equipped with a pump and fan on demand features.

Order K14050-1.

## STICK OPTIONS

#### ACCESSORY KIT - 150 Amp

For stick welding. Includes 20 ft. (6.1m) #6 electrode cable with lug, 15 ft. (4.6m) #6 work cable with lugs, headshield, filter plate, work clamp, electrode holder and sample



pack of mild steel electrode. For use with K2176-1 (Twist-Mate™ to Lug Adapter)

ORDER K875

#### ACCESSORY KIT - 400 AMP

For stick welding. Includes 35 ft. (10.7m) 2/0 electrode cable with lug, 30 ft. (9.1m) 2/0 work cable with lugs, headshield, filter plate, work clamp and electrode holder.



For use with K2176-1 (Twist-Mate<sup>™</sup> to Lug Adapter) ORDER K704

#### **REMOTE OUTPUT CONTROL**

Portable current control provides the same dial range as the current control on the welder. Consists of a 6-pin Amphenol connector which plugs into the remote control Amphenol. 25 foot cable length. **ORDER K857** 



ORDER K857-1 for 100 ft. (30 m)

# STICK ELECTRODE HOLDER AND CABLE ASSEMBLY

Includes 200A stick electrode holder and Twist-Mate connector. 12.5 ft. cable length. **ORDER K2374-1** 

# STICK ELECTRODE HOLDER CABLE AND WORK CABLE ASSEMBLY

Includes 200A stick electrode holder, welding cable, work clamp and Twist-Mate adapter. **ORDER K2394-1** 

## TIG OPTIONS

Pro-Torch<sup>™</sup> TIG Torches A full line of air-cooled and water-cooled torches available. Request Lincoln publication E12.150 (See www.lincolnelectric.com)

#### Hand Amptrol®

Provides 25 ft. (7.6 m) of remote current control for TIG welding. (6-pin a plug connection) Order K963-3



#### Foot Amptrol®

#### Provides 25 ft. (7.6 m) of remote current control for TIG welding. (6pin plug connection). **Order K870**



#### Arc Start Switch

May be used in place of the Foot or Hand Amptrol<sup>®</sup>. Comes with a 25 ft. (7.6 m) cable. Attaches to the TIG torch for convenient finger control to start and stop the weld cycle at the current set on the machine. **Order K814** 

6-Pin to 12-Pin Adapter for Remote Applications. Order K2909-1

7-Pin to 12-Pin Adapter for Spool Gun Applications. Order K2910-1

## **MIG OPTIONS**

Work and Feeder Welding Cables 350 amps, 60% duty cycle with Twist-Mate connectors and Ground Clamp. Order K1803-1

### COMPATIBLE LINCOLN EQUIPMENT

Any Arclink compatible wire feeding equipment (See **www.lincolnelectric.com**)

## MAINTENANCE

## SAFETY PRECAUTIONS

## A WARNING

**ELECTRIC SHOCK can kill.** 

- Do not operate with covers removed.
- •Turn off power source before installing or servicing.
- Do not touch electrically hot parts.
- · Turn the input power to the welding power source off at the fuse box before working in the terminal strip.
- Only qualified personnel should install, use or service this equipment.

## **ROUTINE MAINTENANCE**

Routine maintenance consists of periodically blowing out the machine, using a low-pressure air stream, to remove accumulated dust and dirt from the intake and outlet louvers, and the cooling channels in the machine.

## PERIODIC MAINTENANCE

Calibration of the POWER WAVE® S350CE is critical to its operation. Generally speaking the calibration will not need adjustment. However, neglected or improperly calibrated machines may not yield satisfactory weld performance. To ensure optimal performance, the calibration of output Voltage and Current should be checked yearly.

## CALIBRATION SPECIFICATION

Output Voltage and Current are calibrated at the factory. Generally the machine calibration will not need adjustment. However, if the weld performance changes, or the yearly calibration check reveals a problem, use the calibration section of the Diagnostics Utility to make the appropriate adjustments.

The calibration procedure itself requires the use of a grid, and certified actual meters for voltage and current. The accuracy of the calibration will be directly affected by the accuracy of the measuring equipment you use. The Diagnostics Utility includes detailed instructions, and is available on the Service Navigator CD or at www.powerwavesoftware.com.



## HOW TO USE TROUBLESHOOTING GUIDE

## 🛕 WARNING

Service and Repair should only be performed by Lincoln Electric Factory Trained Personnel. Unauthorized repairs performed on this equipment may result in danger to the technician and machine operator and will invalidate your factory warranty. For your safety and to avoid Electrical Shock, please observe all safety notes and precautions detailed throughout this manual.

This Troubleshooting Guide is provided to help you locate and repair possible machine malfunctions. Simply follow the three-step procedure listed below.

#### Step 1. LOCATE PROBLEM (SYMPTOM).

Look under the column labeled "PROBLEM (SYMP-TOMS)". This column describes possible symptoms that the machine may exhibit. Find the listing that best describes the symptom that the machine is exhibiting.

#### Step 2. POSSIBLE CAUSE.

The second column labeled "POSSIBLE CAUSE" lists the obvious external possibilities that may contribute to the machine symptom.

#### Step 3. RECOMMENDED COURSE OF ACTION

This column provides a course of action for the Possible Cause, generally it states to contact your local Lincoln Authorized Field Service Facility.

If you do not understand or are unable to perform the Recommended Course of Action safely, contact your local Lincoln Authorized Field Service Facility.

## A WARNING



• Turn the input power OFF at the welding power source before installation or changing drive rolls and/or guides.

• Do not touch electrically live parts.

**ELECTRIC SHOCK can kill.** 

- When inching with the gun trigger, electrode and drive mechanism are "hot" to work and ground and could remain energized several seconds after the gun trigger is released.
- Welding power source must be connected to system ground per the National Electrical Code or any applicable local codes.
- Only qualified personnel should perform maintenance work.

Observe all additional Safety Guidelines detailed throughout this manual.

#### 

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your **Local Lincoln Authorized Field Service Facility** for technical troubleshooting assistance before you proceed.

## TROUBLESHOOTING

## USING THE STATUS LED TO TROUBLESHOOT SYSTEM PROBLEMS

Not all of the Power Wave® S350CE errors will be displayed on the user interface (if it is installed). There are two status lights that display error codes. If a problem occurs it is important to note the condition of the status lights. Therefore, prior to cycling power to the system, check the power source status light for error sequences as noted below.

There is one externally mounted status lights located on the case front of the machine. This status light corresponds to the main control board's status. A second status light is internal and is located on the input control board and can be seen by looking through the left case side louvers.

There is an audible beeper associated with this input control board's status light. So the error codes on the input board can be detected through either the status light or the status beeper.

Included in this section is information about the Status Lights and some basic troubleshooting charts for both machine and weld performance.

The status lights for the main control board is a dual-color LED's. Normal operation for each is steady green. Where as the status light on the input control board is one color. Normal operation is for the status light to be off ( and the buzzer to be off).

Error conditions are indicated in the following chart Table E.1.

Light	Meaning	-
Condition	Main control board status light	Input control board
Steady Green	System OK. Power source is operational, and is communicating normally with all healthy peripheral equipment connected to its ArcLink network.	Not applicable.
Blinking Green	Occurs during power up or a system reset, and indicates the POWER WAVE® S350CE is mapping (identifying) each component in the sys- tem. Normal for first 1-10 seconds after power is turned on, or if the system configuration is changed during operation.	Not applicable.
Fast Blinking Green	Indicates Auto-mapping has failed	Not applicable.
Alternating Green and Red	Non-recoverable system fault. If the Status lights are flashing any com- bination of red and green, errors are present. <b>Read the error code(s)</b> <b>before the machine is turned off.</b>	Not applicable.
	<b>Error Code interpretation</b> through the Status light is detailed in the Service Manual. Individual code digits are flashed in red with a long pause between digits. If more than one code is present, the codes will be separated by a green light. Only active error conditions will be accessible through the Status Light.	
	Error codes can also be retrieved with the <b>Diagnostics Utility</b> (includ- ed on the <b>Service Navigator</b> CD or available at <b>www.power-</b> <b>wavesoftware.com</b> ). This is the preferred method, since it can access historical information contained in the error logs.	
	To clear the active error(s), turn power source off, and back on to reset.	
Steady Red	Not applicable.	Not applicable.
Blinking Red	Not applicable.	Error Code interpretation - Individual code digits are flashed in red with a long pause between digits. These error codes are three digit codes that all start with a number three.
Status LED off	Not applicable.	System OK

#### TABLE E.1

## **A** CAUTION

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your **Local Lincoln Authorized Field Service Facility** for technical troubleshooting assistance before you proceed.



Observe all Safety Guidelines detailed throughout this manual

### ERROR CODES FOR THE POWER WAVE® S350CE

The following is a partial list of possible error codes for the POWER WAVE® S350CE. For a complete listing consult the Service Manual for this machine.

MAIN CONTR	MAIN CONTROL BOARD ( "STATUS" LIGHT)				
Error Code #	Indication				
36 Thermal error	Indicates over temperature. Usually accompanied by Thermal LED. Check fan operation. Be sure process does not exceed duty cycle limit of the machine				
54 Secondary (Output) over current error	The long term average secondary (weld) current limit has been exceeded. <b>NOTE:</b> The long term average secondary current limit is 325 amps.				
56 Chopper communication error	Indicates communication link between main control board and chop- per has errors. If cycling the input power on the machine does not clear the error, contact the Service Department.				
58 Primary Fault error	Review error code from input board status light or status beeper. Most likely caused by an over power condition which caused an under voltage on the primary bus. If cycling the input power on the machine does not clear the error, contact the Service Department.				
Other	Error codes that contain three or four digits are defined as fatal errors. These codes generally indicate internal errors on the Power Source Control Board. If cycling the input power on the machine does not clear the error, contact the Service Department.				

## **A** CAUTION

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your **Local Lincoln Authorized Field Service Facility** for technical troubleshooting assistance before you proceed.

Observe all Safety Guidelines detailed throughout this manual

	INPUT CONTROL BOARD				
	Error Code #	Indication			
331	Peak input current limit	Input current limit has been exceeded. Typically indicates short term power overload. If problem persists contact Service Department.			
333	Under-voltage lockout	+15 VDC supply on Input control board too low. Verify input voltage is within the acceptable range. If problem persists contact service department.			
336	Thermal Fault	Thermostat on primary module tripped. Typically caused by bottom fan not working.			
337	Pre-charge timeout	Problem with start-up sequence. If problem persists contact Service Department.			
346	Transformer primary over current	Transformer current too high. Typically indicates short term power overload. If problem persists contact service department.			
Othe	ſ	Contact the Service Department.			

## **A** CAUTION

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your **Local Lincoln Authorized Field Service Facility** for technical troubleshooting assistance before you proceed.



## TROUBLESHOOTING

Observe all Safety Guidelines detailed throughout this manual

PROBLEMS (SYMPTOMS)	POSSIBLE CAUSE	RECOMMENDED COURSE OF ACTION
	Basic Machine Problems	
Input fuses keep blowing	1. Improperly sized input fuses.	<ol> <li>Make sure fuses are properly sized. See installation section of this manual for recommended sizes.</li> </ol>
	<ol> <li>Improper Weld Procedure requir- ing output levels in excess of machine rating.</li> </ol>	2. Reduce output current, duty cycle, or both.
	<ol> <li>Major physical or electrical dam- age is evident when the covers are removed.</li> </ol>	3. Contact your local authorized Lincoln Electric Field Service facility for technical assistance.
Machine will not power up (no lights)	1. No Input Power	1. Make sure input supply discon- nect has been turned ON. Check input fuses. Make certain that the Power Switch (SW1) on the power source is in the "ON" posi- tion.
	2. Input voltage is too low or too high.	2. Make certain that input voltage is correct, according to the Rating Plate located on the rear of the machine.
Machine won't weld, can't get any output.	1. Input voltage is too low or too high.	<ol> <li>Make certain that input voltage is correct, according to the Rating Plate located on the rear of the machine.</li> </ol>
This problem will normally be accompanied by an error code. See "Status Light" section of this docu- ment for additional information.	2. Thermal Error.	2. See "Thermal LED is ON" sec- tion.
	<ol> <li>Secondary current limit has been exceeded. (see error 54)</li> <li>Input control board fault (see input control board error status).</li> </ol>	<ol> <li>Possible short in output circuit. If condition persists, contact an authorized Lincoln Electric Field Service facility.</li> </ol>

## **A** CAUTION

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your **Local Lincoln Authorized Field Service Facility** for technical troubleshooting assistance before you proceed.

## TROUBLESHOOTING

Observe all Safety Guidelines detailed throughout this manual

PROBLEMS (SYMPTOMS)	POSSIBLE CAUSE	RECOMMENDED COURSE OF ACTION		
1	Basic Machine Problems (Continued)			
Thermal LED is ON	1. Improper fan operation.	1. Check for proper fan operation. Fan should run in a low speed setting when the machine is idle and in a high speed when the output is triggered. Check for material blocking intake or exhaust louvers, or for excessive dirt clogging cooling channels in machine.		
	2. Open thermostat circuit.	2. Check for broken wires, open connections or faulty thermostats in the thermostat circuit.		
"Real Time Clock" no longer func- tioning	1. Control PC Board Battery.	1. Replace the battery (Type: BS2032)		
	Weld and Arc Quality Problems			
General degradation of weld perfor- mance	1. Wire feed problem.	<ol> <li>Check for feeding problems. Make sure proper gear ratio has been selected.</li> </ol>		
	2. Cabling problems.	2. Check for bad connections, excessive loops in cable, etc.		
		<b>NOTE:</b> The presence of heat in the external welding circuit indicates poor connections or undersized cables.		
	3. Loss of, or improper Shielding Gas.	<ol> <li>Verify gas flow and type are cor- rect.</li> </ol>		
	<ol> <li>Verify weld mode is correct for process.</li> </ol>	4.Select the correct weld mode for the application.		
	5. Machine calibration.	5. The power source may require calibration. (current, voltage, WFS).		
	6. Wire feed problem.	<ol> <li>Check for feeding problems. Make sure proper gear ratio has been selected.</li> </ol>		

## **A** CAUTION

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your **Local Lincoln Authorized Field Service Facility** for technical troubleshooting assistance before you proceed.

Observe all Safety Guidelines detailed throughout this manual

PROBLEMS (SYMPTOMS)	POSSIBLE CAUSE	RECOMMENDED COURSE OF ACTION
Wel	d and Arc Quality Problems (Contin	ued)
Wire burns back to tip at the end of the weld.	1. Burnback Time	<ol> <li>Reduce burnback time and/or work point.</li> </ol>
Machine output shuts down during a weld.	<ol> <li>Secondary current limit has been exceeded, and the machine shuts down to protect itself.</li> </ol>	<ol> <li>Adjust procedure or reduce load to lower current draw from the machine.</li> </ol>
	2. System Fault	<ol> <li>A non-recoverable fault will inter- rupt welding. This condition will also result in a status light blink- ing. See the Status Light section for more information.</li> </ol>
Machine won't produce full output.	<ol> <li>Input voltage may be too low, lim- iting output capability of the power source.</li> </ol>	<ol> <li>Make certain that the input voltage is proper, according to the Rating Plate located on the rear of the machine.</li> </ol>
	2. Machine calibration.	2. Calibrate secondary current and voltage.
Excessively long and erratic arc.	1. Wire feed problem.	<ol> <li>Check for feeding problems. Make sure proper gear ratio has been selected.</li> </ol>
	2. Loss of, or improper Shielding Gas	<ol> <li>Verify gas flow and type are cor- rect</li> </ol>
	3. Machine calibration.	<ol> <li>Calibrate secondary current and voltage.</li> </ol>

## **A** CAUTION

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your **Local Lincoln Authorized Field Service Facility** for technical troubleshooting assistance before you proceed.

## TROUBLESHOOTING

Observe all Safety Guidelines detailed throughout this manual

PROBLEMS (SYMPTOMS)	POSSIBLE CAUSE	RECOMMENDED COURSE OF ACTION
	Ethernet	
Cannot Connect	1. Physical connection.	<ol> <li>Verify that the correct patch cable or cross over cable is being used (refer to local IT department for assistance).</li> </ol>
		1a. Verify the cables are fully insert- ed into the bulk head connector.
		1b. The LED under the PC board ethernet connector will be lit when the machine is connected to another network device.
	2. IP address information.	<ol> <li>Use the appropriate PC utility to verify the correct IP address infor- mation has been entered.</li> </ol>
		2a. Verify no duplicate the IP addresses exist on the network.
	3. Ethernet Speed	<ol> <li>Verify that the network device connected to the Power Wave is either a 10-baseT device or a 10/100-baseT device.</li> </ol>
Connection Drops while welding	1. Cable Location	<ol> <li>Verify Network cable is not locat- ed next to current carrying con- ductors. This would include input power cables and welding output cables.</li> </ol>

## **A** CAUTION

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your **Local Lincoln Authorized Field Service Facility** for technical troubleshooting assistance before you proceed.





**DIMENSION PRINT** 

This page intentionally left blank.

WARNING	<ul> <li>Do not touch electrically live parts or electrode with skin or wet clothing.</li> <li>Insulate yourself from work and ground.</li> </ul>	• Keep flammable materials away.	• Wear eye, ear and body protection.
AVISO DE PRECAUCION	<ul> <li>No toque las partes o los electrodos bajo carga con la piel o ropa moja- da.</li> <li>Aislese del trabajo y de la tierra.</li> </ul>	<ul> <li>Mantenga el material combustible fuera del área de trabajo.</li> </ul>	<ul> <li>Protéjase los ojos, los oídos y el cuerpo.</li> </ul>
French ATTENTION	<ul> <li>Ne laissez ni la peau ni des vête- ments mouillés entrer en contact avec des pièces sous tension.</li> <li>Isolez-vous du travail et de la terre.</li> </ul>	<ul> <li>Gardez à l'écart de tout matériel inflammable.</li> </ul>	<ul> <li>Protégez vos yeux, vos oreilles et votre corps.</li> </ul>
German WARNUNG	<ul> <li>Berühren Sie keine stromführenden Teile oder Elektroden mit Ihrem Körper oder feuchter Kleidung!</li> <li>Isolieren Sie sich von den Elektroden und dem Erdboden!</li> </ul>	Entfernen Sie brennbarres Material!	<ul> <li>Tragen Sie Augen-, Ohren- und Kör- perschutz!</li> </ul>
ATENÇÃO	<ul> <li>Não toque partes elétricas e electrodos com a pele ou roupa molhada.</li> <li>Isole-se da peça e terra.</li> </ul>	<ul> <li>Mantenha inflamáveis bem guarda- dos.</li> </ul>	<ul> <li>Use proteção para a vista, ouvido e corpo.</li> </ul>
注意事項	<ul> <li>●通電中の電気部品、又は溶材にヒ フやぬれた布で触れないこと。</li> <li>●施工物やアースから身体が絶縁されている様にして下さい。</li> </ul>	<ul> <li>燃えやすいものの倒での溶接作業 は絶対にしてはなりません。</li> </ul>	● 目、耳及び身体に保護具をして下 さい。
Chinese	<ul> <li>●皮肤或濕衣物切勿接觸帶電部件及 銲條。</li> <li>●使你自己與地面和工件絶縁。</li> </ul>	●把一切易燃物品移離工作場所。	●保戴眼、耳及身體勞動保護用具。
Korean 위 험	<ul> <li>전도체나 응접봉을 젖은 형겁 또는 피부로 절대 접촉치 마십시요.</li> <li>모재와 접지를 접촉치 마십시요.</li> </ul>	●인화성 물질을 접근 시키지 마시요.	●눈,귀와 몸에 보호장구를 착용하십시요.
Arabic	لا تلمس الاجزاء التي يسري فيها التيار الكهرباني أو الالكترود بجلد الجسم أو بالملايس الميللة بالماء. ضع عاز لا على جسك خلال العمل.	<ul> <li>ضع المواد القابلة للاشتعال في مكان بعيد.</li> </ul>	فمع أدوات وملابس واقية على عينيك وأذنيك وجمعك.

READ AND UNDERSTAND THE MANUFACTURER'S INSTRUCTION FOR THIS EQUIPMENT AND THE CONSUMABLES TO BE USED AND FOLLOW YOUR EMPLOYER'S SAFETY PRACTICES.

SE RECOMIENDA LEER Y ENTENDER LAS INSTRUCCIONES DEL FABRICANTE PARA EL USO DE ESTE EQUIPO Y LOS CONSUMIBLES QUE VA A UTILIZAR, SIGA LAS MEDIDAS DE SEGURIDAD DE SU SUPERVISOR.

LISEZ ET COMPRENEZ LES INSTRUCTIONS DU FABRICANT EN CE QUI REGARDE CET EQUIPMENT ET LES PRODUITS A ETRE EMPLOYES ET SUIVEZ LES PROCEDURES DE SECURITE DE VOTRE EMPLOYEUR.

LESEN SIE UND BEFOLGEN SIE DIE BETRIEBSANLEITUNG DER ANLAGE UND DEN ELEKTRODENEINSATZ DES HER-Stellers. Die Unfallverhütungsvorschriften des Arbeitgebers sind ebenfalls zu beachten.

	بر		
<ul> <li>Keep your head out of fumes.</li> <li>Use ventilation or exhaust to remove fumes from breathing zone.</li> </ul>	• Turn power off before servicing.	<ul> <li>Do not operate with panel open or guards off.</li> </ul>	WARNING
<ul> <li>Los humos fuera de la zona de respiración.</li> <li>Mantenga la cabeza fuera de los humos. Utilice ventilación o aspiración para gases.</li> </ul>	<ul> <li>Desconectar el cable de ali- mentación de poder de la máquina antes de iniciar cualquier servicio.</li> </ul>	<ul> <li>No operar con panel abierto o guardas quitadas.</li> </ul>	AVISO DE PRECAUCION
<ul> <li>Gardez la tête à l'écart des fumées.</li> <li>Utilisez un ventilateur ou un aspirateur pour ôter les fumées des zones de travail.</li> </ul>	<ul> <li>Débranchez le courant avant l'entre- tien.</li> </ul>	<ul> <li>N'opérez pas avec les panneaux ouverts ou avec les dispositifs de protection enlevés.</li> </ul>	French ATTENTION
<ul> <li>Vermeiden Sie das Einatmen von Schweibrauch!</li> <li>Sorgen Sie für gute Be- und Entlüftung des Arbeitsplatzes!</li> </ul>	<ul> <li>Strom vor Wartungsarbeiten abschalten! (Netzstrom völlig öff- nen; Maschine anhalten!)</li> </ul>	<ul> <li>Anlage nie ohne Schutzgehäuse oder Innenschutzverkleidung in Betrieb setzen!</li> </ul>	German WARNUNG
<ul> <li>Mantenha seu rosto da fumaça.</li> <li>Use ventilação e exhaustão para remover fumo da zona respiratória.</li> </ul>	<ul> <li>Não opere com as tampas removidas.</li> <li>Desligue a corrente antes de fazer serviço.</li> <li>Não toque as partes elétricas nuas.</li> </ul>	<ul> <li>Mantenha-se afastado das partes moventes.</li> <li>Não opere com os paineis abertos ou guardas removidas.</li> </ul>	Portuguese ATENÇÃO
<ul> <li>● ヒュームから頭を離すようにして 下さい。</li> <li>● 換気や排煙に十分留意して下さい。</li> </ul>	<ul> <li>◆メンテナンス・サービスに取りか かる際には、まず電源スイッチを 必ず切って下さい。</li> </ul>	● パネルやカバーを取り外したまま で機械操作をしないで下さい。	注意事項
●頭部遠離煙霧。 ●在呼吸區使用通風或排風器除煙。	● 維修前切斷電源。	●儀表板打開或沒有安全罩時不準作 業。	Chinese 警告
<ul> <li>얼굴로부터 용접가스를 멀리하십시요.</li> <li>호흡지역으로부터 용접가스를 제거하기 위해 가스제거기나 통풍기를 사용하십시요.</li> </ul>	● 보수전에 전원을 차단하십시요.	● 판넬이 열린 상태로 작동치 마십시요.	Korean 위험
<ul> <li>ابعد رأسك بعيداً عن الدخان.</li> <li>استعمل التهوية أو جهاز ضغط الدخان للخارج</li> <li>لكي تبعد الدخان عن المنطقة التي تتنفس فيها.</li> </ul>	اقطع التيار الكهرباني قبل القيام بأية صياتة.	<ul> <li>لا تشغل هذا الجهاز إذا كانت الاغطية الحديدية الواقية ليمت عليه.</li> </ul>	Arabic

# LEIA E COMPREENDA AS INSTRUÇÕES DO FABRICANTE PARA ESTE EQUIPAMENTO E AS PARTES DE USO, E SIGA AS PRÁTICAS DE SEGURANÇA DO EMPREGADOR.

使う機械や溶材のメーカーの指示書をよく読み、まず理解して下さい。そして貴社の安全規定に従って下さい。

請詳細閱讀並理解製造廠提供的説明以及應該使用的銀捍材料,並請遵守貴方的有関勞動保護規定。

이 제품에 동봉된 작업지침서를 숙지하시고 귀사의 작업자 안전수칙을 준수하시기 바랍니다.

اقرأ بتمعن وافهم تعليمات المصنع المنتج لهذه المعدات والمواد قبل استعمالها واتبع تعليمات الوقاية لصاحب العمل.

#### CUSTOMER ASSISTANCE POLICY

The business of The Lincoln Electric Company is manufacturing and selling high quality welding equipment, consumables, and cutting equipment. Our challenge is to meet the needs of our customers and to exceed their expectations. On occasion, purchasers may ask Lincoln Electric for advice or information about their use of our products. We respond to our customers based on the best information in our possession at that time. Lincoln Electric is not in a position to warrant or guarantee such advice, and assumes no liability, with respect to such information or advice. We expressly disclaim any warranty of any kind, including any warranty of fitness for any customer's particular purpose, with respect to such information or advice. As a matter of practical consideration, we also cannot assume any responsibility for updating or correcting any such information or advice once it has been given, nor does the provision of information or advice create, expand or alter any warranty with respect to the sale of our products.

Lincoln Electric is a responsive manufacturer, but the selection and use of specific products sold by Lincoln Electric is solely within the control of, and remains the sole responsibility of the customer. Many variables beyond the control of Lincoln Electric affect the results obtained in applying these types of fabrication methods and service requirements.

Subject to Change – This information is accurate to the best of our knowledge at the time of printing. Please refer to www.lincolnelectric.com for any updated information.



THE LINCOLN ELECTRIC COMPANY 22801 St. Clair Avenue • Cleveland, OH • 44117-1199 • U.S.A. Phone: +1.216.481.8100 • www.lincolnelectric.com