


INSTRUCTION MANUAL

AUTODRIVE[®] 4R100



For use with Product/Code
Numbers:
12790

Save for future reference

Date Purchased

Code: (ex: 10859)

Serial: (ex: U1060512345)

Contents

INSTALLATION.....	SECTION A
TECHNICAL SPECIFICATIONS.....	A-1
SAFETY PRECAUTIONS.....	A-1
SELECT SUITABLE LOCATION.....	A-2
SOFTWARE.....	A-2
DUTY CYCLE.....	A-2
WELD CABLE SIZE.....	A-3
COAXIAL WELD CABLE.....	A-4
WIRE DRIVE CABLE, K1785-XX.....	A-5
SHIELDING GAS CONNECTION.....	A-6
PROCEDURE TO INSTALL DRIVE ROLLS AND WIRE GUIDES.....	A-7
PRESSURE ARM ADJUSTMENT.....	A-8
LOADING WIRE.....	A-8
CONDUIT INSTALLATION.....	A-9
SYSTEM SET-UP.....	A-10

OPERATION.....	SECTION B
SAFETY PRECAUTIONS.....	B-1
PRODUCT DESCRIPTION.....	B-2
RECOMMENDED PROCESSES.....	B-2
PROCESS LIMITATIONS.....	B-2
EQUIPMENT LIMITATIONS.....	B-2
RECOMMENDED POWER SOURCES.....	B-2
DEFINITION OF WELDING TERMS.....	B-3
GRAPHIC SYMBOLS THAT APPEAR ON THIS MACHINE OR IN THIS MANUAL	B-3

ACCESSORIES AND OPTIONS.....	SECTION C
DRIVE ROLL KITS 4 ROLL DRIVE	C-1

MAINTENANCE.....	SECTION D
SAFETY PRECAUTIONS.....	D-1
ROUTINE MAINTENANCE.....	D-1
BRUSHES.....	D-1

TROUBLESHOOTING.....	SECTION E
HOW TO USE TROUBLESHOOTING GUIDE.....	E-1
TROUBLESHOOTING GUIDE.....	E-2

APPENDIX

- WIRING DIAGRAM
- DIMENSIONS

CUSTOMER ASSISTANCE POLICY

SAFETY INFORMATION

SAFETY DEPENDS ON YOU

Lincoln welding, cutting, and heating equipment is designed and built with safety in mind. However, your overall safety can be increased by proper installation ... and thoughtful operation on your part. **DO NOT INSTALL, OPERATE OR REPAIR THIS EQUIPMENT WITHOUT READING THIS MANUAL AND THE SAFETY PRECAUTIONS CONTAINED THROUGHOUT.** And, most importantly, think before you act and be careful.

 DANGER	
	This statement indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

 WARNING	
	This statement indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

 CAUTION	
	This statement indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury.

Notice: This statement indicates the possibility of damage to equipment if the potential risk is not avoided.

PLEASE EXAMINE CARTON AND EQUIPMENT FOR DAMAGE IMMEDIATELY

When this equipment is shipped, title passes to the purchaser upon receipt by the carrier. Consequently, claims for material damaged in shipment must be made by the purchaser against the transportation company at the time the shipment is received.

KEEP YOUR HEAD OUT OF THE FUMES



- **DON'T** get too close to the weld. Use corrective lenses if necessary to stay a reasonable distance away from the weld.
- **USE ENOUGH VENTILATION** or exhaust at the weld, or both, to keep the fumes and gases from your breathing zone and the general area.
- **IN A LARGE ROOM OR OUTDOORS**, natural ventilation may be adequate if you keep your head out of the fumes.
- **USE NATURAL DRAFTS** or fans to keep the fumes away from your face.
- **READ** and obey the Safety Data Sheet (SDS) and the warning label that appears on all containers of welding materials.

If you develop unusual symptoms, see your supervisor. Perhaps the welding atmosphere and ventilation system should be checked.

WEAR CORRECT EYE, EAR AND BODY PROTECTION



- **PROTECT** your eyes and face with properly fitted and with proper grade of filter plate (See ANSI Z49.1).
- **PROTECT** your body from welding spatter and arc flash with protective clothing including woolen clothing, flame-proof apron and gloves, leather leggings, and high boots.
- **PROTECT** others from spatter, flash, and glare with protective screens or barriers.
- **PROTECT** your eyes and face with welding helmet
- **IN SOME AREAS**, protection from noise may be appropriate.
- **BE SURE** protective equipment is in good condition.
- **AT ALL TIMES**, wear safety glasses in work area.



- **DO NOT WELD, CUT, OR HEAT** containers or materials which previously had been in contact with hazardous substances unless they are properly cleaned. This is extremely dangerous.



SAFETY INFORMATION



- **DO NOT WELD, CUT, OR HEAT** painted or plated parts unless special precautions with ventilation have been taken. They can release highly toxic fumes or gases.
- **PROTECT** compressed gas cylinders from excessive heat, mechanical shocks, and arcs; fasten cylinders so they cannot fall.
- **BE SURE** cylinders are never grounded or part of an electrical circuit.
- **REMOVE** all potential fire hazards from welding area.



- **ALWAYS HAVE FIRE FIGHTING EQUIPMENT READY FOR IMMEDIATE USE AND KNOW HOW TO USE IT.**

CALIFORNIA PROPOSITION 65 WARNINGS

 WARNING	
	<p>Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects, or other reproductive harm.</p> <p>Always start and operate the engine in a well-ventilated area.</p> <p>If in an exposed area, vent the exhaust to the outside.</p> <p>Do not modify or tamper with the exhaust system.</p> <p>Do not idle the engine except as necessary.</p>

 WARNING	
	<p>This product, when used for welding or cutting, produces fumes or gases which contain chemicals known to the State of California to cause birth defects and, in some cases, cancer. (California Health & Safety Code § 25249.5 et seq.)</p>

For more information go to <https://www.p65warnings.ca.gov>

ARC WELDING CAN BE HAZARDOUS

PROTECT YOURSELF AND OTHERS FROM POSSIBLE SERIOUS INJURY OR DEATH. KEEP CHILDREN AWAY. PACEMAKER WEARERS SHOULD CONSULT WITH THEIR DOCTOR BEFORE OPERATING.

Read and understand the following safety highlights. For additional safety information, it is strongly recommended that you purchase a copy of "Safety in Welding & Cutting - ANSI Standard Z49.1" from the American Welding Society, P.O. Box 351040, Miami, Florida 33135 or CSA Standard W117.2. A Free copy of "Arc Welding Safety" booklet E205 is available from the Lincoln Electric Company, 22801 St. Clair Avenue, Cleveland, Ohio 44117-1199.

BE SURE THAT ALL INSTALLATION, OPERATION, MAINTENANCE AND REPAIR PROCEDURES ARE PERFORMED ONLY BY QUALIFIED INDIVIDUALS.

FOR ENGINE POWERED EQUIPMENT



- Turn the engine off before troubleshooting and maintenance work unless the maintenance work requires it to be running.



- Do not add the fuel near an open flame welding arc or when the engine is running. Stop the engine and allow it to cool before refueling to prevent spilled fuel from vaporizing on contact with hot engine parts and igniting. Do not spill fuel when filling tank. If fuel is spilled, wipe it up and do not start engine until fumes have been eliminated.



- Keep all equipment safety guards, covers and devices in position and in good repair. Keep hands, hair, clothing and tools away from V-belts, gears, fans and all other moving parts when starting, operating or repairing equipment.

- In some cases it may be necessary to remove safety guards to perform required maintenance. **REMOVE GUARDS ONLY** when necessary and replace them when the maintenance requiring their removal is complete. Always use the greatest care when working near moving parts.
- **DO NOT** put your hands near the engine fan. Do not attempt to override the governor or idler by pushing on the throttle control rods while the engine is running.
- To prevent accidentally starting gasoline engines while turning the engine or welding generator during maintenance work, disconnect the spark plug wires, distributor cap or magneto wire as appropriate.



- To avoid scalding, do not remove the radiator pressure cap when the engine is hot.



- Generator exhaust contains carbon monoxide. This is a poison you cannot see or smell.
- Using a generator indoors **CAN KILL YOU IN MINUTES**.
- **NEVER** use inside a home or garage, **EVEN IF** doors and windows are open.
- **ONLY** use **OUTSIDE** and far away from windows, doors and vents.



- Avoid other generator hazards. **READ MANUAL BEFORE USE.**

ELECTRIC AND MAGNETIC FIELDS MAY BE DANGEROUS



- Electric current flowing through any conductor causes localized Electric and Magnetic Fields (EMF). Welding and heating current creates EMF fields around cables and equipment.
- EMF fields may interfere with some pacemakers, and welders having a pacemaker should consult their physician before welding.
- Exposure to EMF fields in welding may have other health effects which are now not known. All welders should use the following procedures in order to minimize exposure to EMF fields from the welding circuit:
 - Route the electrode and work cables together - Secure them with tape when possible.

- Never coil the electrode lead around your body.
- Do not place your body between the electrode and work cables. If the electrode cable is on your right side, the work cable should also be on your right side.
- Connect the work cable to the workpiece as close as possible to the area being welded.
- Do not work next to welding power source.

ELECTRIC SHOCK CAN KILL



- The electrode and work (or ground) circuits are electrically "hot" when the welder is on. Do not touch these "hot" parts with your bare skin or wet clothing. Wear dry, hole-free gloves to insulate hands.
- Insulate yourself from work and ground using dry insulation. Make certain the insulation is large enough to cover your full area of physical contact with work and ground.

In addition to the normal safety precautions, if welding must be performed under electrically hazardous conditions (in damp locations or while wearing wet clothing; on metal structures such as floors, gratings or scaffolds; when in cramped positions such as sitting, kneeling or lying, if there is a high risk of unavoidable or accidental contact with the workpiece or ground) use the following equipment:

- Semiautomatic DC Constant Voltage (Wire) Welder.
- DC Manual (Stick) Welder.
- AC Welder with Reduced Voltage Control.
- In semiautomatic or automatic wire welding, the electrode, electrode reel, welding head, nozzle or semiautomatic welding gun are also electrically "hot".
- Always be sure the work cable makes a good electrical connection with the metal being welded. The connection should be as close as possible to the area being welded.
- Ground the work or metal to be welded to a good electrical (earth) ground.
- Maintain the electrode holder, work clamp, welding cable and welding machine in good, safe operating condition. Replace damaged insulation.
- Never dip the electrode in water for cooling.

SAFETY INFORMATION

- Never simultaneously touch electrically “hot” parts of electrode holders connected to two welders because voltage between the two can be the total of the open circuit voltage of both welders.
- When working above floor level, use a safety belt to protect yourself from a fall should you get a shock.
- **Also see [WELDING AND CUTTING SPARKS CAN CAUSE FIRE OR EXPLOSION](#) and [FOR ELECTRICALLY POWERED EQUIPMENT](#)**

ARC RAYS CAN BURN



- Use a shield with the proper filter and cover plates to protect your eyes from sparks and the rays of the arc when welding or observing open arc welding. Headshield and filter lens should conform to ANSI Z87.1 standards.
- Use suitable clothing made from durable flame-resistant material to protect your skin and that of your helpers from the arc rays.
- Protect other nearby personnel with suitable, non-flammable screening and/or warn them not to watch the arc nor expose themselves to the arc rays or to hot spatter or metal.

FUMES AND GASES CAN BE DANGEROUS



- Welding may produce fumes and gases hazardous to health. Avoid breathing these fumes and gases. When welding, keep your head out of the fume. Use enough ventilation and/or exhaust at the arc to keep fumes and gases away from the breathing zone.
- **When welding hardfacing (see instructions on container or SDS) or on lead or cadmium plated steel and other metals or coatings which produce highly toxic fumes, keep exposure as low as possible and within applicable OSHA PEL and ACGIH TLV limits using local exhaust or mechanical ventilation unless exposure assessments indicate otherwise. In confined spaces or in some circumstances, outdoors, a respirator may**

also be required. Additional precautions are also required when welding on galvanized steel.

- The operation of welding fume control equipment is affected by various factors including proper use and positioning of the equipment, maintenance of the equipment and the specific welding procedure and application involved. Worker exposure level should be checked upon installation and periodically thereafter to be certain it is within applicable OSHA PEL and ACGIH TLV limits.
- Do not weld in locations near chlorinated hydrocarbon vapors coming from degreasing, cleaning or spraying operations. The heat and rays of the arc can react with solvent vapors to form phosgene, a highly toxic gas, and other irritating products.
- Shielding gases used for welding can displace air and cause injury or death. Always use enough ventilation, especially in confined areas, to insure breathing air is safe.
- Read and understand the manufacturer’s instructions for this equipment and the consumables to be used, including the Safety Data Sheet (SDS) and follow your employer’s safety practices. SDS forms are available from your welding distributor or from the manufacturer.
- Also see [FOR ENGINE POWERED EQUIPMENT](#)

WELDING AND CUTTING SPARKS CAN CAUSE FIRE OR EXPLOSION



- Remove fire hazards from the welding area. If this is not possible, cover them to prevent the welding sparks from starting a fire. Remember that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas. Avoid welding near hydraulic lines. Have a fire extinguisher readily available.
- Where compressed gases are to be used at the job site, special precautions should be used to prevent hazardous situations. Refer to **“Safety in Welding and Cutting” (ANSI Standard Z49.1)** and the operating information for the equipment being used.

- When not welding, make certain no part of the electrode circuit is touching the work or ground. Accidental contact can cause overheating and create a fire hazard.
- Do not heat, cut or weld tanks, drums or containers until the proper steps have been taken to ensure that such procedures will not cause flammable or toxic vapors from substances inside. They can cause an explosion even though they have been “cleaned”. For information, purchase “Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping That Have Held Hazardous Substances”, **AWS F4.1** from the American Welding Society.
- Vent hollow castings or containers before heating, cutting or welding. They may explode.
- Sparks and spatter are thrown from the welding arc. Wear oil free protective garments such as leather gloves, heavy shirt, cuff-less trousers, high shoes and a cap over your hair. Wear ear plugs when welding out of position or in confined places. Always wear safety glasses with side shields when in a welding area.
- Connect the work cable to the work as close to the welding area as practical. Work cables connected to the building framework or other locations away from the welding area increase the possibility of the welding current passing through lifting chains, crane cables or other alternate circuits. This can create fire hazards or overheat lifting chains or cables until they fail.
- **Read and follow NFPA 51B** “Standard for Fire Prevention During Welding, Cutting and Other Hot Work”, available from NFPA, 1 Batterymarch Park, PO box 9101, Quincy, MA 02269-9101.
- **DO NOT** use a welding power source for pipe thawing.

CYLINDER MAY EXPLODE IF DAMAGED



- Use only compressed gas cylinders containing the correct shielding gas for the process used and properly operating regulators designed for the gas and pressure used. All hoses, fittings, etc. should be suitable for the application and maintained in good condition.

- Always keep cylinders in an upright position securely chained to an undercarriage or fixed support.

Cylinders should be located:

- Away from areas where they may be struck or subjected to physical damage.
- A safe distance from arc welding or cutting operations and any other source of heat, sparks, or flame.
- Never allow the electrode, electrode holder or any other electrically “hot” parts to touch a cylinder.
- Keep your head and face away from the cylinder valve outlet when opening the cylinder valve.
- Valve protection caps should always be in place and hand tight except when the cylinder is in use or connected for use.
- Read and follow the instructions on compressed gas cylinders, associated equipment, and CGA publication P-1, “Precautions for Safe Handling of Compressed Gases in Cylinders,” available from the Compressed Gas Association, 14501 George Carter Way Chantilly, VA 20151.

FOR ELECTRICALLY POWERED EQUIPMENT



- Turn off input power using the disconnect switch at the fuse box before working on the equipment.
- Install equipment in accordance with the U.S. National Electrical Code, all local codes and the manufacturer’s recommendations.
- Ground the equipment in accordance with the U.S. National Electrical Code and the manufacturer’s recommendations.

BATTERY HANDLING, STORAGE, AND DISPOSAL



Batteries can be flammable substances such as lithium or other organic solvents, which may result in overheating, rupture, or combustion. Failure to follow the battery manufactures instructions may result in fire, personal injury, and damage to property if used improperly.

SAFETY INFORMATION

- DO NOT short circuit, disassemble, deform, or heat batteries.
- DO NOT attempt to recharge batteries unless they are specifically marked as "rechargeable".
- DO NOT use or charge the battery if it appears to be leaking, deformed or damaged in any way.
- Store in a cool location. Keep batteries away from direct sunlight, high temperature, and high humidity.
- Immediately discontinue use of the battery if, while using, charging, or storing the battery, the battery emits an unusual smell, feels hot, changes color, changes shape, or appears abnormal in any other way.
- Keep batteries out of reach of children, should a child swallow a battery, consult a physician immediately.
- Recycle or dispose of batteries in accordance with local and federal laws.
- All persons inside LCA must wear proper PPE to avoid eye or skin exposure to laser radiation. The end user's LSO shall select proper PPE including, but not limited to, heat-resistant gloves, flame-resistant clothing, laser safety eye wear and laser-safe helmets that conform to ANSI Z136.1 Optical Density requirements for the wavelength and output power of the laser in use. Standard safety glasses and welding helmets DO NOT provide adequate protection from laser beam hazards. Always inspect PPE for damage or improper fit before use.
- Only qualified persons shall install, operate or service this unit per ANSI Z136.1 standards and your LSO's instruction. Read and follow all labels and manuals before installing, operating, or servicing hand held any laser welding equipment.
- Do not operate outside of a LCA, or if the laser protective housing is modified or damaged, or if safety interlocks have been bypassed or otherwise defeated. Inspect all equipment and LCA for damage or tampering prior to use.
- Reflected beams from the laser can damage eyes and skin and can pose a fire risk. Prior to use, the LCA should be assessed by the LSO to understand the surfaces where hazardous reflected beams can exist. Never position yourself or flammable material in the anticipated laser beam path and take extra precautions when working on reflective materials like aluminum and stainless steel.
- Follow all standards, individual facility or building regulations, and national, state, and local codes.

FOR LASER EMITTING EQUIPMENT



- Hazardous Class 4 (IV) laser products emit invisible, infrared laser radiation which can permanently damage the eye's retina and/or cornea, burn skin, and pose a fire risk. End users shall assign a qualified Laser Safety Officer (LSO) who has the certifications required by applicable law/standards, have a documented Laser Safety Program and have a Laser Controlled Area (LCA) that confirms to ANSI Z136.1 & Z136.9.
- Do not operate laser before end user's LSO has completed a risk assessment and all the prescribed Risk Mitigations measures have been fully implemented. Ensure the laser is operated/demonstrated safely by trained personnel and that the environment surrounding the laser welding cell or laser-controlled area is safe for people nearby when the laser is in operation.
- Never point the laser at yourself or others. Never look directly into a laser aperture, even if wearing full eye protection.

DEALER LOCATOR & PRODUCT REGISTRATION

Register your machine:



<https://www.lincolnelectric.com/register>

Authorized Service and Distributor Locator:

<https://www.lincolnelectric.com/locator>

ADDITIONAL SAFETY INFORMATION

Refer to <http://www.lincolnelectric.com/safety> for additional safety information

INSTALLATION

TECHNICAL SPECIFICATIONS

AutoDrive® 4R100 (K3561-1)

INPUT VOLTAGE, CURRENT	
Input Voltage ± 10%	Input Amperes
0 - 40 VDC	4 A

RATED OUTPUT @ 104° F (40° C)	
DUTY CYCLE	INPUT AMPERES
100% RATING	500


GEARING - WIRE FEED SPEED RANGE - WIRE SIZE			
GMAW		FCAW	
WFS Range	Wire Sizes	WFS Range	Wire Sizes
50 - 800 IPM (1.3 - 20.3 M / MIN)	.023 - .045" (0.6 - 1.2 MM)	50 - 800 IPM (1.3 - 20.3 M / MIN)	.035 - .045" (0.9 - 1.2 MM)

PHYSICAL DIMENSIONS			
Height	Width	Depth	Weight
8.4 INCHES (213 MM)	7.5 INCHES (191 MM)	9.1 INCHES (231 MM)	13.2 LBS (6.0 KG)

TEMPERATURE RANGES	
Operating	Storage
-40° F TO 104° F (-40° C TO 40° C)	-40° F TO 185° F (-40° C TO 85° C)

IP2X

SAFETY PRECAUTIONS

⚠ WARNING	
	<p>ELECTRIC SHOCK can kill.</p> <p>Turn the input power OFF at the welding power source before installation or changing drive rolls and / or guides.</p> <p>Do not touch electrically live parts.</p> <p>When inching with the gun trigger, electrode and drive mechanism are "hot" to work and ground and could remain energized several seconds after the gun trigger is released.</p> <p>Welding power source must be connected to system ground per the National Electrical Code or any applicable local codes.</p> <p>Only qualified personnel should perform maintenance work.</p>

SELECT SUITABLE LOCATION

Firmly secure the AutoDrive 4R220 wire feeder to a robot arm or fixture.

Feeder installation instructions are included with the robotic mounting bracket. For the mounting bracket specific to your robot, see the [Robot Compatibility Chart](#).

Table 1 :ROBOT COMPATIBILITY CHART

Robot	Mounting Bracket K#
FANUC	
FANUC iD	K3562-1
FANUC iC	K3562-2
ABB	
IRB1520ID	K3573-1
IRB1660ID	K3573-2
IRB2600ID	K3573-3
IRB1600	K3573-4
IRB2600	K3573-5
IRB4600	K3573-6
YASKAWA	
MA1440	K3572-1
MA2010	K3572-2
KUKA	
Kuka Thru-Arm	K3574-1
Kuka Over-Arm	K3574-2

Mount only in a dry environment.

This equipment is for industrial use only and it is not intended for use in residential locations where the electrical power is provided by the public low-voltage supply system. There can be potential difficulties in residential locations due to conducted as well as radiated radio-frequency disturbances. The EMC or RF classification of this equipment is Class A.

SOFTWARE

When the feeder is installed in a Power Wave or Robotic system, select “AutoDrive 4R220” from the list of feeders. Refer to the Power Wave or Robotic manual.

DUTY CYCLE

- The duty cycle is based upon the amount of welding performed in a 10 minute period.
- Thermal test have been performed at ambient temperature. The duty cycle (duty factory) @ 40° C (104° F) has been determined by simulation.

WELD CABLE SIZE

In the table located below are copper cable sizes recommended for different currents and duty cycles. Lengths stipulated are the distance from the welder to work and back to the welder again. Cable sizes are increased for greater lengths primarily for the purpose of minimizing cable drop.

Table 2 :RECOMMENDED CABLE SIZES

RECOMMENDED CABLE SIZES (RUBBER COVERED COPPER - RATED 167° F or 75° C)**						
AMPERES	PERCENT DUTY CYCLE	CABLE SIZES FOR COMBINED LENGTHS OF ELECTRODE AND WORK CABLES				
		0 to 50 Ft. (0 to 15 m)	50 to 100 Ft. (15 to 30 m)	100 to 150 Ft. (30 to 46 m)	150 to 200 Ft. (46 to 61 m)	200 to 250 Ft. (61 to 76 m)
200	60	2	2	2	1	1/0
200	100	2	2	2	1	1/0
225	20	4 or 5	3	2	1	1/0
225	40 & 30	3	3	2	1	1/0
250	30	3	3	2	1	1/0
250	40	2	2	1	1	1/0
250	60	1	1	1	1	1/0
250	100	1	1	1	1	1/0
300	60	1	1	1	1/0	2/0
325	100	2/0	2/0	2/0	2/0	3/0
350	60	1/0	1/0	2/0	2/0	3/0
400	60	2/0	2/0	2/0	3/0	4/0
400	100	3/0	3/0	3/0	3/0	4/0
500	60	2/0	2/0	3/0	3/0	4/0

** Tabled values are for operation at ambient temperatures of 104° F (40° C) and below. Applications above 104° F (40° C) may require cables larger than recommended, or cables rated higher than 167° F (75° C).

COAXIAL WELD CABLE

Coaxial welding cables are specially designed welding cables for STT and pulse welding. Coaxial weld cables feature low inductance, allowing fast changes in the weld current. Regular cables have a higher inductance which may distort the STT wave shape. Inductance becomes more severe as the weld cables become longer.

Coaxial weld cables are recommended for STT welding, especially when the total weld cable length (electrode cable + work cable) exceeds 50 feet (7.6 m). See [Table 3 :RECOMMENDED CABLE SIZES](#) on page A-4 .

A coaxial weld cable is constructed with multiple small leads wrapped around one large lead. The large inner lead connects to the electrode stud on the power source and the electrode connection on the wire feeder. The small leads combine together to form the work lead, one end attached to the power source and the other end to the work piece.


To install:

1. Turn the input power off at the welding power source.
2. Connect one end of the center lead to the power source electrode connection, and the other end to the wire feeder electrode connection.
3. Connect the outer lead bundle to the power source work connection, and the other end to the work piece. Minimize the length of any work lead extension for best results.
4. Insulate all connections.

Table 3 :RECOMMENDED CABLE SIZES

RECOMMENDED CABLE SIZES (RUBBER COVERED COPPER - RATED 75° C)**					
		COAXIAL CABLE LENGTH			
Amperes	Duty Cycle	0 to 25 Ft.	25 to 50 Ft.	50 to 75 Ft.	75 to 100 Ft.
250	100%	1	1	1	1
300	60%	1	1	1	1/0
350	60%	1/0	1/0	--	--


** Tabled values are for operation at ambient temperatures of 104° F (40° C) and below. Applications above 104° F (40° C) may require cables larger than recommended, or cables rated higher than 167° F (75° C).



WIRE DRIVE CABLE, K1785-XX

Wire drive cables are used to connect power sources and control boxes to remote wire drives.

The cables have a 14-pin connector at each end. **Both ends of the cable have a collar and the cables cannot be "daisy chained" to make a longer cable.**



POWER SOURCE	
Pin	Function
A	Motor Power
B	Motor Power
C	Gas Solenoid
D	Gas Solenoid
E	Reserved
F	Reserved
G	"2A" Differential Tachometer
H	"2B" Differential Tachometer
I	Reserved
J	Reserved
K	"1A" Differential Tachometer
L	"1B" Differential Tachometer
M	Reserved
N	"67" Electrode Sense Lead

WIRE FEEDER	
Pin	Function
A	Motor Power
B	Motor Power
C	Gas Solenoid
D	Gas Solenoid
E	"2A" Differential Tachometer
F	Reserved
G	+15 VDC Tech Supply
H	Tachometer Common
I	Reserved
J	Reserved
K	"1A" Differential Tachometer
L	"1B" Differential Tachometer
M	"2B" Differential Tachometer
N	"67" Electrode Sense Lead

SHIELDING GAS CONNECTION

⚠ WARNING



- CYLINDER may explode if damaged.
- Keep cylinder upright and chained to support.
- Keep cylinder away from areas where it may be damaged.
- Never lift welder with cylinder attached.
- Never allow welding electrode to touch cylinder.
- Keep cylinder away from welding or other live electrical circuits.

⚠ WARNING



- Build up of shielding gas may harm health or kill.
- Shut off shielding gas supply when not in use.
- See American National Standard Z-49.1, "Safety in Welding and Cutting" Published by the American Welding Society.


Maximum inlet pressure is 100 psi. (6.9 bar.)

Install the shielding gas supply as follows:

1. Secure the cylinder to prevent it from falling.
2. Remove the cylinder cap. Inspect the cylinder valves and regulator for damaged threads, dirt, dust, oil or grease. Remove dust and dirt with a clean cloth. **DO NOT ATTACH THE REGULATOR IF OIL, GREASE OR DAMAGE IS PRESENT!** Inform your gas supplier of this condition. Oil or grease in the presence of high pressure oxygen is explosive.
3. Stand to one side away from the outlet and open the cylinder valve for an instant. This blows away any dust or dirt which may have accumulated in the valve outlet.
4. Attach the flow regulator to the cylinder valve and tighten the union nut(s) securely with a wrench.

Note: if connecting to 100% CO₂ cylinder, insert regulator adapter between regulator and cylinder valve.

If adapter is equipped with a plastic washer, be sure it is seated for connection to the CO₂ cylinder.



5. Attach one end of the inlet hose to the outlet fitting of the flow regulator. Attach the other end to the welding system shielding gas inlet. Tighten the union nuts with a wrench.
6. Before opening the cylinder valve, turn the regulator adjusting knob counterclockwise until the adjusting spring pressure is released.
7. Standing to one side, open the cylinder valve slowly a fraction of a turn. When the cylinder pressure gage stops moving, open the valve fully.
8. The flow regulator is adjustable. Adjust it to the flow rate recommended for the procedure and process being used before making a weld.

PROCEDURE TO INSTALL DRIVE ROLLS AND WIRE GUIDES**⚠ WARNING**

ELECTRIC SHOCK can kill.


Turn the input power OFF at the welding power source before installation or changing drive rolls and / or guides.

Do not touch electrically live parts.

When inching with the gun trigger, electrode and drive mechanism are "hot" to work and ground and could remain energized several seconds after the gun trigger is released.

Do not operate with covers, panels or guards removed or open.

Only qualified personnel should perform maintenance work.

**To remove drive rolls and wire guides:**

1. Turn power off at the welding power source.
2. Remove the outer wire guide.
3. To unlock Drive Hub, lift up on the Leaf Spring tab 1/8". Twist the Twist Lock Ring (while the Leaf Spring tab is lifted) until the spline of the Twist Lock Ring is aligned with the spline of the Drive Hub Assembly. See Figure Above (drive roll not shown for clarity).
4. Move Pressure Arm down open the Idler Arms.
5. Remove the drive rolls and inner wire guide.

To install drive rolls and wire guides:

1. Turn off power at the welding power source.
2. Move Pressure Arm down open the Idler Arms.
3. Assemble the inner wire guide.
4. Slide the drive rolls onto the drive hubs.
5. Close the Idler Arms. Move Pressure Arm up.
6. Rotate all Twist Lock Rings to the locked position.
7. Assemble the outer wire guide.
8. Adjust the Pressure Arms to the recommended setting.

PRESSURE ARM ADJUSTMENT

WARNING



ELECTRIC SHOCK can kill.

Turn the input power OFF at the welding power source before installation or changing drive rolls and / or guides.

Do not touch electrically live parts.

When inching with the gun trigger, electrode and drive mechanism are "hot" to work and ground and could remain energized several seconds after the gun trigger is released.

Do not operate with covers, panels or guards removed or open.


Only qualified personnel should perform maintenance work.

The pressure arm controls the amount of force the drive rolls exert on the wire. Proper adjustment of the pressure arm gives the best welding performance.

Set the pressure arm as follows:

(See Figure Below)

- Aluminum wires between 1 and 3
- Cored wires between 3 and 4.
- Steel, Stainless wires between 4 and 6.



LOADING WIRE

WARNING



Keep hands, hair, clothing and tools away from rotating equipment.

Do not wear gloves when threading wire or changing wire spool.


Only qualified personnel should install, use or service this equipment.

CONDUIT INSTALLATION

The K1546-xx series of conduits are compatible with K515-xx, K565-xx, Wire Wizard and Electron Beam Technologies conduits.

To install conduit to the wire drive:

1. Slide the conduit bushing into the feed plate and secure with the set screw.



OPERATION

SAFETY PRECAUTIONS

Read and understand this entire section before operating your machine.

WARNING



ELECTRIC SHOCK can kill.

Unless using COLD FEED feature, when feeding with gun trigger, the electrode and drive mechanism are always electrically energized and could remain energized several seconds after the welding ceases.

Do not touch electrically live part or electrode with skin or wet clothing.

Insulate yourself from work and ground.

Always wear dry insulating gloves.

Do not operate with covers, panels or guards removed or open.

WARNING




FUMES AND GASSES can be dangerous.

Keep your head out of fumes.

Use ventilation or exhaust to remove fumes from breathing zone.

WARNING



WELDING SPARKS can cause fire or explosion.

Keep flammable material away.

WARNING



ARC RAYS can burn.

Wear eye, ear and body protection.

SEE ADDITIONAL WARNING INFORMATION UNDER ARC WELDING SAFETY PRECAUTIONS AND in the FRONT OF THIS OPERATING MANUAL.

PRODUCT DESCRIPTION

The AutoDrive® 4R220 wire feeder is fully controlled and operated by a robot, control box or user interface on the power source. Refer to the appropriate manual for operating the wire drive.

GENERAL PHYSICAL DESCRIPTION

The AutoDrive 4R220 wire feeder is powerful yet compact wire drive for robotic and hard automation applications.

The MAXTRAC 4 roll wire drive gives steady feeding of all wire sizes and types. The drive features split wire guides, tool-less drive roll changing, dual spring pressure arms and changeable gun bushings all mounted in a precision die cast aluminum frame. A right angle gear box efficiently transfers motor power for both high torque and high speed.

The AutoDrive 4R220 features a powerful motor with an efficient two stage gearbox. This feeder is best for feeding larger diameter wires, pulling wire through long conduits, and in applications requiring extra ruggedness. A door covers the wire drive, protecting it from dust.

Robotic mounting brackets are not included. Necessary mounting brackets can be found on the Robotic Compatibility Chart - See [Table 1 :ROBOT COMPATIBILITY CHART](#) on page A-2

GENERAL FUNCTIONAL DESCRIPTION

The AutoDrive 4R220 features a dual channel, high resolution tachometer for precision wire feeding both forwards and in reverse.

RECOMMENDED PROCESSES

- GMAW
- FCAW
- STT

PROCESS LIMITATIONS

- Maximum wire size = 0.45 (1.2 mm)

EQUIPMENT LIMITATIONS

- Maximum GMAW gun length = 10' (3.1 m).
- Maximum FCAW gun length = 10' (3.1 m).
- Maximum wire drive control cable length = 100 ft. (31 m).
- Robot and power source software may need to be updated.
- Drive rolls are not included with the feeder.
- Maximum Conduit Length 50 Ft. (15 m).

RECOMMENDED POWER SOURCES

- Power Wave R450
- Power Wave i400

DEFINITION OF WELDING TERMS

GMAW - Gas Metal Arc welding




FCAW - Flux Core Arc Welding

STT - Surface Tension Transfer




GRAPHIC SYMBOLS THAT APPEAR ON THIS MACHINE OR IN THIS MANUAL WIRE FEEDER POSITIVE OUTPUT NEGATIVE OUTPUT INPUT POWER DIRECT CURRENT OPEN CIRCUIT VOLTAGE INPUT VOLTAGE OUTPUT VOLTAGE INPUT CURRENT OUTPUT CURRENT PROTECTIVE GROUND WARNING OR CAUTION



ACCESSORIES AND OPTIONS

DRIVE ROLL KITS 4 ROLL DRIVE

WIRE TYPE	KITS	ELECTRODE SIZE		
Steel Wires:	KP1505-030S KP1505-035S KP1505-040S KP1505-045S	.023 - .030 (0.6 - 0.8 mm) .035 (0.9 mm) .040 (1.0 mm) .045 (1.2 mm)	Includes: 4 V groove drive rolls and inner wire guide.	
Cored Wires:	KP1505-035C KP1505-045C	.030 - .035" (0.8 - 0.9 mm) .040 - .045" (1.0 - 1.2 mm)	Includes: 4 Knurled drive rolls and inner wire guide.	
Aluminum Wires:	KP1507-3/64A	3/64" (1.2 mm)	Includes: 4 polished U groove drive rolls, outer wire guide and inner wire guide.	
K1500-1	Gun Receiver Bushing (for guns with K466-1 Lincoln gun connectors; Innershield and Subarc guns).		Includes: Gun receiver bushing, set screw and hex key wrench.	

ACCESSORIES AND OPTIONS

<p>K1500-2</p>	<p>Gun Receiver Bushing (for guns with K466-2, K466-10 Lincoln gun connectors; Magnum 200 / 300 / 400 guns and compatible with Tweco #2-#4).</p>	<p>Includes: Gun receiver bushing with hose nipple, set screw and hex key wrench.</p>	 <p>A silver-colored metal gun receiver bushing with a hose nipple on the side. It is shown with a set screw and a hex key wrench.</p>
<p>K1500-3</p>	<p>Gun Receiver Bushing (for guns with K613-7 Lincoln gun connectors; Magnum 550 guns and compatible with Tweco #5).</p>	<p>Includes: Gun receiver bushing with hose nipple, set screw and hex key wrench.</p>	 <p>A brass-colored metal gun receiver bushing with a hose nipple on the side. It is shown with a set screw and a hex key wrench.</p>
<p>K1500-4</p>	<p>Gun Receiver Bushing (for gun with K466-3 Lincoln gun connectors; compatible with Miller guns).</p>	<p>Includes: Gun receiver bushing with hose nipple, set screw and hex key wrench.</p>	 <p>A silver-colored metal gun receiver bushing with a hose nipple on the side. It is shown with a set screw and a hex key wrench.</p>

K1500-5	Gun Receiver Bushing (compatible with Oxo guns).	Includes: Gun receiver bushing with hose nipple, 4 guide tubes, set screw and hex key wrench.	
K489-7	Gun Receiver Bushing (for Lincoln Fast-Mate guns).	Includes: Gun receiver bushing with trigger connector.	
K515-xx	Wire Conduit.	Requires K1546-1.	
K565-xx	Wire Conduit.	Requires K1546-1.	
K1546-1	Incoming Bushing, for Lincoln Conduit .025 - 1/16" (0.6 - 1.6 mm) wire. Compatible with Electron Beam Conduit.	Includes: Incoming bushing and hex key wrench.	

K2175-1	500 lb. Accu-Pak Box Payoff Kit	
K2175-2	1000 lb. Accu-Pak Box Payoff Kit	
K895-2	Rotary Wire Dispenser	
K836-1	Dereeler Adapter	
K884-5	Accu-Trak Drum Payoff Kit - 20 inch diameter	
K884-6	Accu-Trak Drum Payoff Kit - 23 inch diameter	
K1796-xx	Coaxial Cables	Includes: 1 cable of length "xx" feet. 14-pin connectors on both ends. Cable length cannot be extended by connecting K1785 cables together.
K2593-xx	Coaxial Cables	

ACCESSORIES AND OPTIONS

K1785-xx	Wire Drive Cables	Includes: 1 cable of length "xx" feet. 14-pin connectors on both ends. Has collars at both ends. Used with FANUC arms that have an integrated cable.
K2709-xx	Wire Drive Cables	Includes: 1 cable of length "xx" feet. 14-pin connectors on both ends. May be daisy chained to make a longer cable. Used with FANUC arms that do not have an integrated cable.
K1733-1	Wire Straightener	Includes: 1 wire straightener.

MAINTENANCE

SAFETY PRECAUTIONS

WARNING



ELECTRIC SHOCK can kill.

Turn the input power OFF at the welding power source before installation or changing drive rolls and / or guides.

Do not touch electrically live parts.

When inching with the gun trigger, electrode and drive mechanism are "hot" to work and ground and could remain energized several seconds after the gun trigger is released.

Do not operate with covers, panels or guards removed or open.

Only qualified personnel should perform maintenance work.

ROUTINE MAINTENANCE

To Install or remove the AutoDrive 4R220 for servicing:

See [Installation Section](#) of this Instruction Manual.

BRUSHES

Every 6 months or every 2.5 million arc starts (which ever comes first), inspect the motor brushes. Replace if shorter than 0.5" (12.7 mm).

WARNING



Do not open this machine and do not introduce anything into its openings. Power supply must be disconnected from the machine before each maintenance and service. After each repair, perform proper tests to ensure safety.

WARNING



Power supply must be disconnected from the machine before each maintenance and service. Always use gloves in compliance with the safety standards.

TROUBLESHOOTING

HOW TO USE TROUBLESHOOTING GUIDE

WARNING



Service and Repair should only be performed by Lincoln Electric Factory Trained Personnel. Unauthorized repairs performed on this equipment may result in danger to the technician and machine operator and will invalidate your factory warranty. For your safety and to avoid Electrical Shock, please observe all safety notes and precautions detailed throughout this manual.

This Troubleshooting Guide is provided to help you locate and repair possible machine malfunctions. Simply follow the three-step procedure listed below.

1. LOCATE PROBLEM (SYMPTOM)

Look under the column labeled “PROBLEM (SYMPTOMS)”. This column describes possible symptoms that the machine may exhibit. Find the listing that best describes the symptom that the machine is exhibiting.

2. POSSIBLE CAUSE

The second column labeled “POSSIBLE CAUSE” lists the obvious external possibilities that may contribute to the machine symptom.

3. RECOMMENDED COURSE OF ACTION

This column provides a course of action for the Possible Cause, generally it states to contact your local Lincoln Authorized Field Service Facility.

CAUTION



If you do not understand or are unable to perform the Recommended Course of Action safely, contact your local Lincoln Authorized Field Service Facility.

Observe all additional safety guidelines detailed throughout this manual.

TROUBLESHOOTING GUIDE


Observe all Safety Guidelines detailed throughout this manual.

PROBLEMS (SYMPTOMS)	POSSIBLE AREAS OF MISADJUSTMENTS(S)	RECOMMENDED COURSE OF ACTION
WELDING PROBLEMS		
The wire feeder does not feed wire and the drive rolls do not spin.	<ol style="list-style-type: none"> 1. Verify the power source is turned on. 2. Verify the circuit breaker for the wire feeder on the power source has not tripped. 3. Verify power is being supplied to the wire feeder. 	<p>If all recommended possible areas of misadjustment have been checked and the problem persists, Contact your local Lincoln Authorized Field Service Facility.</p>
The wire feeds erratically.	<ol style="list-style-type: none"> 1. Verify the correct drive rolls and inner wire guide are installed in the wire drive. 2. Check for sharp bends in the gun liner or conduit. 3. Examine the contact tip for wear and proper size. Replace as necessary. 4. Check the gun liner and conduit. The welding electrode should slide easily through both. 5. Verify the proper gun liner is installed. 6. Verify the pressure arms are set properly. Too much pressure may crush the wire. 7. Inspect the motor for worn brushes. 	
No shielding gas.	<ol style="list-style-type: none"> 1. Verify the gas supply is turned on and not empty. 2. Check the gas hose for cuts. Make sure it is not crushed. 3. Verify the shielding gas hose is connected to the gun bushing or welding gun. 	

PROBLEMS (SYMPTOMS)	POSSIBLE AREAS OF MISADJUSTMENTS(S)	RECOMMENDED COURSE OF ACTION
WELDING PROBLEMS (CONT.)		
Variable or "hunting" arc.	<ol style="list-style-type: none"> 1. Check for proper size contact. Make sure the contact tip is not worn, free of spatter and not melted. 2. Clean and tighten all electrode and work connections. 3. Verify the proper polarity is being used for the weld procedure. 4. Make sure the proper electrode stick-out is being maintained. 5. Check the gas flow rate and mixture. 6. Verify the gun bushing is tightly mounted to the wire drive. 7. Verify the gun is tightly mounted to the gun bushing. 8. Verify the electrode lead is connected to the proper connection block on the feed head. 9. Inspect the motor for worn brushes. 	<p>If all recommended possible areas of misadjustment have been checked and the problem persists, Contact your local Lincoln Authorized Field Service Facility.</p>
The motor overload errors occur.	<ol style="list-style-type: none"> 1. Check for sharp bends in the gun liner and conduit. 2. Examine the contact tip for wear and proper size. Replace as necessary. 3. Check the gun liner and conduit. The welding electrode should slide easily through both. 4. Verify the proper gun liner is installed. 5. Reduce the pressure arm setting. 	




APPENDIX

WIRING DIAGRAM



NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual. The specific diagram for a particular code is pasted inside the machine on one of the enclosure panels. If the diagram is illegible, write to the Service Department for a replacement. Give the equipment code number.

DIMENSIONS



CUSTOMER ASSISTANCE POLICY

CUSTOMER ASSISTANCE POLICY

The business of Lincoln Electric is manufacturing and selling high quality welding equipment, automated welding systems, consumables, and cutting equipment. Our challenge is to meet the needs of our customers, who are experts in their fields, and to exceed their expectations. On occasion, purchasers may ask Lincoln Electric for information or technical information about their use of our products. Our employees respond to inquiries to the best of their ability based on information and specifications provided to them by the customers and the knowledge they may have concerning the application. Our employees, however, are not in a position to verify the information provided or to evaluate the engineering requirements for the particular weldment, or to provide engineering advice in relation to a specific situation or application. Accordingly, Lincoln Electric does not warrant or guarantee or assume any liability with respect to such information or communications. Moreover, the provision of such information or technical information does not create, expand, or alter any warranty on our products. Any express or implied warranty that might arise from the information or technical information, including any implied warranty of merchantability or any warranty of fitness for any customers' particular purpose or any other equivalent or similar warranty is specifically disclaimed.

Lincoln Electric is a responsive manufacturer, but the definition of specifications, and the selection and use of specific products sold by Lincoln Electric is solely within the control of, and remains the sole responsibility of the customer. Many variables beyond the control of Lincoln Electric affect the results obtained in applying these types of fabrication methods and service requirements.

WELD FUME CONTROL EQUIPMENT

The operation of welding fume control equipment is affected by various factors including proper use and positioning of the equipment, maintenance of the equipment and the specific welding procedure and application involved. Worker exposure level should be checked upon installation and periodically thereafter to be certain it is within applicable OSHA PEL and ACGIH TLV limits.

PARTS LIST

Content/Details may be changed or updated without notice. For most current Instruction Manuals, go to PARTS.LINCOLNELECTRIC.COM.

