

**SVM 3070**

Rev.00 08-2018

# **POWERTEC i250C STANDARD POWERTEC i250C ADVANCED POWERTEC i320C STANDARD POWERTEC i320C ADVANCED**

---

*For use with machines having code numbers: 50430, 50431, 50432, 50433*



---

## **SERVICE MANUAL**

---

---

---

---



LINCOLN ELECTRIC EUROPE  
[www.lincolnelectric.eu](http://www.lincolnelectric.eu)

# INDEX OF CONTENTS

---

TECHNICAL SPECIFICATIONS .....	2
INSTALLATION AND OPERATOR INSTRUCTIONS .....	5
DC BUS CAPACITOR DISCHARGE PROCEDURE .....	32
GENERAL DESCRIPTION .....	35
HOW TO USE TROUBLESHOOTING GUIDE .....	41
SIDE PANELS REMOVAL AND DC BUS CAPACITORS DISCHARGE PROCEDURE .....	44
DC BUS CAPACITOR DISCHARGE PROCEDURE .....	46
DISASSEMBLY OPERATIONS.....	64
RETEST AFTER REPAIR.....	72
CALIBRATION PROCEDURE FOR “ADV” VERSION .....	73
ELECTRICAL SCHEMATICS.....	74
Block Diagram: Powertec i250C – i320C STANDARD.....	74
Block Diagram: Powertec i250C – i320C ADVANCED.....	75
NOTE .....	76

# TECHNICAL SPECIFICATIONS

NAME		INDEX			
POWERTEC i250C STANDARD		K14157-1			
POWERTEC i250C ADVANCED		K14157-2			
POWERTEC i320C STANDARD		K14158-1			
POWERTEC i320C ADVANCED		K14158-2			
INPUT					
	Input Voltage $U_1$	EMC Class		Frequency	
<b>PTi250C STANDARD</b> <b>PTi250C ADVANCED</b> <b>PTi320C STANDARD</b> <b>PTi320C ADVANCED</b>	400V $\pm$ 10% 3-phase	A		50/60Hz	
	Input Power at Rated Cycle	Input Amperes $I_{1max}$		PF	
<b>PTi250C STANDARD</b> <b>PTi250C ADVANCED</b>	10,3 kVA @ 60% Duty Cycle (40°C)	14,7A		0,85	
<b>PTi320C STANDARD</b> <b>PTi320C ADVANCED</b>	13,6 kVA @ 40% Duty Cycle (40°C)	19,6A		0,90	
RATED OUTPUT					
		Open Circuit Voltage	Duty Cycle 40°C (based on a 10 min.	Output Current	Output Voltage
<b>PTi250C STANDARD</b> <b>PTi250C ADVANCED</b>	GMAW	49Vdc	60%	250A	26,5Vdc
			100%	195A	23,8Vdc
	FCAW	49Vdc	60%	250A	26,5Vdc
			100%	195A	23,8Vdc
	SMAW	49Vdc	60%	250A	30Vdc
			100%	195A	27,8Vdc
<b>PTi320C STANDARD</b> <b>PTi320C ADVANCED</b>	GMAW	49Vdc	40%	320A	30Vdc
			100%	195A	23,8Vdc
	FCAW	49Vdc	40%	320A	30Vdc
			100%	195A	23,8Vdc
	SMAW	49Vdc	40%	320A	32,8Vdc
			100%	195A	27,8Vdc
WELDING CURRENT RANGE					
	GMAW	FCAW		SMAW	
<b>PTi250C STANDARD</b> <b>PTi250C ADVANCED</b>	10A÷250A	10A÷250A		20A÷250A	
<b>PTi320C STANDARD</b> <b>PTi320C ADVANCED</b>	10A÷320A	10A÷320A		20A÷320A	
RECOMMENDED INPUT CABLE AND FUSE SIZES					
	Fuse Type gR or Circuit Breaker Type Z			Power Lead	
<b>PTi250C STANDARD</b> <b>PTi250C ADVANCED</b>	16A, 400V AC			4 Conductor, 2,5mm <sup>2</sup>	
<b>PTi320C STANDARD</b> <b>PTi320C ADVANCED</b>	20A, 400V AC			4 Conductor, 2,5mm <sup>2</sup>	
DIMENSION					
Weight	Height	Width	Length		
66 kg	535 mm	300 mm	635 mm		
Protection Rating	Operating Humidity (t=20°C)	Operating Temperature	Storage Temperature		
IP23	≤ 90 %	from -10 °C to +40 °C	from -25 °C to +55 °C		

# Electromagnetic Compatibility (EMC)

11/04

This machine has been designed in accordance with all relevant directives and standards. However, it may still generate electromagnetic disturbances that can affect other systems like telecommunications (telephone, radio, and television) or other safety systems. These disturbances can cause safety problems in the affected systems. Read and understand this section to eliminate or reduce the amount of electromagnetic disturbance generated by this machine.

## **WARNING**

Provided that the public low voltage system impedance at the point of common coupling is lower than:  
56,4 mΩ for the Powertec i250/320.

This equipment is compliant with IEC 61000-3-11 and IEC-3-12 and can be connected to public lowvoltage systems. It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the system impedance complies with the impedance restrictions.

Consider the following guidelines to reduce electromagnetic emissions from the machine.

Connect the machine to the input supply according to this manual. If disturbances occur it may be necessary to take additional precautions such as filtering the input supply.

The output cables should be kept as short as possible and should be positioned together. If possible connect the work piece to ground in order to reduce the electromagnetic emissions. The operator must check that connecting the work piece to ground does not cause problems or unsafe operating conditions for personnel and equipment.

Shielding of cables in the work area can reduce electromagnetic emissions. This may be necessary for special applications.

## **WARNING**

The Class A equipment is not intended for use in residential locations where the electrical power is provided by the public low-voltage supply system. There may be potential difficulties in ensuring electromagnetic compatibility in those locations, due to conducted as well as radiated disturbances.



## **WARNING**


While a high electromagnetic field occurs, a welding current can fluctuate.



## WARNING

This equipment must be used by qualified personnel. Be sure that all installation, operation, maintenance and repair procedures are performed only by qualified person. Read and understand this manual before operating this equipment. Failure to follow the instructions in this manual could cause serious personal injury, loss of life, or damage to this equipment. Read and understand the following explanations of the warning symbols. Lincoln Electric is not responsible for damages caused by improper installation, improper care or abnormal operation.

	<p><b>WARNING:</b> This symbol indicates that instructions must be followed to avoid serious personal injury, loss of life, or damage to this equipment. Protect yourself and others from possible serious injury or death.</p>
	<p><b>READ AND UNDERSTAND INSTRUCTIONS:</b> Read and understand this manual before operating this equipment. Arc welding can be hazardous. Failure to follow the instructions in this manual could cause serious personal injury, loss of life, or damage to this equipment.</p>
	<p><b>ELECTRIC SHOCK CAN KILL:</b> Welding equipment generates high voltages. Do not touch the electrode, work clamp, or connected work pieces when this equipment is on. Insulate yourself from the electrode, work clamp, and connected work pieces.</p>
	<p><b>ELECTRICALLY POWERED EQUIPMENT:</b> Turn off input power using the disconnect switch at the fuse box before working on this equipment. Ground this equipment in accordance with local electrical regulations.</p>
	<p><b>ELECTRICALLY POWERED EQUIPMENT:</b> Regularly inspect the input, electrode, and work clamp cables. If any insulation damage exists replace the cable immediately. Do not place the electrode holder directly on the welding table or any other surface in contact with the work clamp to avoid the risk of accidental arc ignition.</p>
	<p><b>ELECTRIC AND MAGNETIC FIELDS MAY BE DANGEROUS:</b> Electric current flowing through any conductor creates electric and magnetic fields (EMF). EMF fields may interfere with some pacemakers, and welders having a pacemaker shall consult their physician before operating this equipment.</p>
	<p><b>CE COMPLIANCE:</b> This equipment complies with the European Community Directives.</p>
	<p><b>ARTIFICIAL OPTICAL RADIATION:</b> According with the requirements in 2006/25/EC Directive and EN 12198 Standard, the equipment is a category 2. It makes mandatory the adoption of Personal Protective Equipments (PPE) having filter with a protection degree up to a maximum of 15, as required by EN169 Standard.</p>
	<p><b>FUMES AND GASES CAN BE DANGEROUS:</b> Welding may produce fumes and gases hazardous to health. Avoid breathing these fumes and gases. To avoid these dangers the operator must use enough ventilation or exhaust to keep fumes and gases away from the breathing zone.</p>
	<p><b>ARC RAYS CAN BURN:</b> Use a shield with the proper filter and cover plates to protect your eyes from sparks and the rays of the arc when welding or observing. Use suitable clothing made from durable flame-resistant material to protect you skin and that of your helpers. Protect other nearby personnel with suitable, non-flammable screening and warn them not to watch the arc nor expose themselves to the arc.</p>
	<p><b>WELDING SPARKS CAN CAUSE FIRE OR EXPLOSION:</b> Remove fire hazards from the welding area and have a fire extinguisher readily available. Welding sparks and hot materials from the welding process can easily go through small cracks and openings to adjacent areas. Do not weld on any tanks, drums, containers, or material until the proper steps have been taken to insure that no flammable or toxic vapors will be present. Never operate this equipment when flammable gases, vapors or liquid combustibles are present.</p>
	<p><b>WELDED MATERIALS CAN BURN:</b> Welding generates a large amount of heat. Hot surfaces and materials in work area can cause serious burns. Use gloves and pliers when touching or moving materials in the work area.</p>

<b>S</b>	SAFETY MARK: This equipment is suitable for supplying power for welding operations carried out in an environment with increased hazard of electric shock.
	CYLINDER MAY EXPLODE IF DAMAGED: Use only compressed gas cylinders containing the correct shielding gas for the process used and properly operating regulators designed for the gas and pressure used. Always keep cylinders in an upright position securely chained to a fixed support. Do not move or transport gas cylinders with the protection cap removed. Do not allow the electrode, electrode holder, work clamp or any other electrically live part to touch a gas cylinder. Gas cylinders must be located away from areas where they may be subjected to physical damage or the welding process including sparks and heat sources.

The manufacturer reserves the Right to make changes and/or improvements in design without upgrade at the same time the operator's manual.

## Introduction

### General Description

The welding machines

**POWERTEC i250C STANDARD**  
**POWERTEC i250C ADVANCED**  
**POWERTEC i320C STANDARD**  
**POWERTEC i320C ADVANCED**

enables welding:

- GMAW (MIG/MAG),
- FCAW (Flux-Cored),
- SMAW (MMA),

The following equipment has been added to  
**POWERTEC i250C STANDARD**  
**POWERTEC i250C ADVANCED**  
**POWERTEC i320C STANDARD**  
**POWERTEC i320C ADVANCED**

- Work lead – 3m,
- Gas hose – 2m,
- Driving roll V1.0/V1.2 for solid wire (mounted in the wire feeder).

Recommended equipment, which can be bought by user, was mentioned in the chapter "Accessories".

## INSTALLATION AND OPERATOR INSTRUCTIONS

Read this entire section before installation or operation of the machine.

### Location and Environment

This machine will operate in harsh environments. However, it is important that simple preventative measures are followed to assure long life and reliable operation.

- Do not place or operate this machine on a surface with an incline greater than 15° from horizontal.
- Do not use this machine for pipe thawing.
- This machine must be located where there is free circulation of clean air without restrictions for air movement to and from the air vents. Do not cover the machine with paper, cloth or rags when switched on.
- Dirt and dust that can be drawn into the machine should be kept to a minimum.
- This machine has a protection rating of IP23. Keep it dry when possible and do not place it on wet ground or in puddles.
- Locate the machine away from radio controlled machinery. Normal operation may adversely affect the operation of nearby radio controlled machinery, which may result in injury or equipment damage. Read the section on electromagnetic compatibility in this manual.
- Do not operate in areas with an ambient temperature greater than 40°C.

### Duty cycle and Overheating

The duty cycle of a welding machine is the percentage of time in a 10 minute cycle at which the welder can operate the machine at rated welding current.


Example: 60% duty cycle



Welding for 6 minutes.

Break for 4 minutes.

Excessive extension of the duty cycle will cause the thermal protection circuit to activate.



Minutes

or decrease  
Duty Cycle

# Input Supply Connection

**⚠ WARNING**

Only a qualified electrician can connect the welding machine to the supply network. Installation had to be made in accordance with the appropriate National Electrical Code and local regulations.

Check the input voltage, phase and frequency supplied to this machine before turning it on. Verify the connection of ground wires from the machine to the input source. The welding machine **POWERTEC i250C STANDARD/ ADVANCED, POWERTEC i320C STANDARD/ ADVANCED** must be connected to a correctly installed plug-in socket with an earth pin. Input voltage is 400 Vac 50/60Hz. For more information about input supply refer to the technical specification section of this manual and to the rating plate of the machine.

Make sure that the amount of mains power available from the input supply is adequate for normal operation of the machine. The necessary delayed fuse or circuit breaker and cable sizes are indicated in the technical specification section of this manual.

**⚠ WARNING**

The welding machine can be supplied from a power generator of output power at least 30% larger than input power of the welding machine.

**⚠ WARNING**

When powering the machine from a generator be sure to turn off welder first, before generator is shut down, in order to prevent damage to welder!

## Output Connections

Refer to points [3], [4] and [5] of the Figures below.

## Controls and Operational Features

### Front Panel Standard Version






Figure 1.

1. U0 User Interface: See "User Interfaces" Chapter.
2. Power Switch ON/OFF (I/O): Controls the input power to the machine. Be sure the power source is connected to the mains supply before turning power on ("I"). After input power is connected and the power switch is turned on, the indicator will light up to indicate the machine is ready to weld.
3. Negative Output Socket for the Welding Circuit: For connecting an electrode holder with lead / work lead. 
4. Positive Output Socket for the Welding Circuit: For connecting an electrode holder with lead / work lead. 
5. EURO Socket: For connecting a welding gun (for GMAW / FCAW process).

### Front Panel Advanced Version




Figure 2.

6. U7 User Interface: See User Interfaces chapter.
7. Remote Control Connector Plug: To install Remote Control Kit. This connector allows connection Remote Control. See "Accessories" chapter.

## Rear panel




Figure 3.

8. Wire Liner Entry: Enables installing liner for welding wire delivered in drum package.
9. Chain: To protect gas bottle.
10. Power Lead (5m): Connect the supply plug to the existing input cable that is rated for the machine as indicated in this manual, and conforms to all applicable standards. This connection shall be performed by a qualified person only.
11. Supply Plug: For CO2 gas heater kit (see "Accessories" chapter).
12. Gas Connector: Connection for gas line.
13. Gas Flow Regulator Plug: Gas flow regulator can be purchased separately (see "Accessories" chapter).
14. Gas hose
15. Work Lead

## Internal Controls




Figure 4.

16. Spooled Wire (for GMAW / FCAW): The machine does not include a spooled wire.
17. Wire Spool Support: Maximum 16kg spools. Accepts plastic, steel and fiber spools onto 51 mm spindle.  
**Note:** Plastic Brake Nut has a Left-hand thread.
18. Cold Inch/ Gas Purge Switch: This switch enables wire feeding or gas flow without turning on output voltage.
19. Wire drive feeding system: 4-Roll wire drive mechanisms with quick-change feed rolls.
20. Terminal Block of Changing Polarity Plug (for GMAW / FCAW-SS process): This terminal block enables to set the welding polarity (+ ; -), which will be given at the welding gun (see "Accessories" chapter).
- 21a. USB Receptacle Type A (Advanced only):  
For USB memory stick connection. For machine software update and service purpose.
- 21b. Fuse F1:  
Use the 1A/400V (6,3x32mm) low blow fuse.

## Standard User Interface (U0)




Figure 5.

22. Display:
  - Left display: Shows wire feed speed or welding current. During welding shows the actual welding current value.
  - Right display: Shows the welding voltage in volts units. During welding shows the actual welding voltage value.
23. Right Control: Adjusts values on the Right display.
24. Left Control: Adjusts values on the Left display.
25. Right Button: Enables scrolling, changing and setting welding parameters.
26. Left Button: Enables changing the welding process.



27. **Thermal Overload Indicator:** It indicates that the machine is overloaded or that the cooling is not sufficient.

28. **Status LED:** A two color light that indicates system errors. Normal operation is steady green light. Error conditions are indicated, per Table 1.

 **WARNING**

The status light will flash green, and sometimes red and green, for up to one minute when the machine is first turned on. When the power source is powered it can take as long as 60 seconds for the machine to be ready to weld. This is a normal situation as the machine goes through initialization.

**Table 1.**

LED Light Condition	Meaning
	Only machines which using ArcLink® protocol for communication
Steady Green	System OK. Power source is operational, and is communicating normally with all healthy peripheral equipment.
Blinking Green	Occurs during power up or a system reset, and indicates the power source is mapping (identifying) each component in the system. Normal for first 1-10 seconds after power is turned on, or if the system configuration is changed during operation.
Alternating Green and Red	If the status lights are flashing any combination of red and green, errors are present in the power source.
	Individual code digits are flashed in red with a long pause between digits. If more than one code is present, the codes will be separated by green light. Read the error code before the machine is turned off.  If occurs, to clear the error try to turn Off the machine, wait for a few seconds, then turn ON again. If the error remains, a maintenance is required. Please contact the nearest authorized technical service center or Lincoln Electric and report the error code read.
Steady Red	Indicate no communication between the power source and device which has been connected to this power source.

29. **LED Indicator:** Informs that the wire feed speed is on the Left display.

30. **LED Indicator:** Informs that the value on the Left display is in ampere units.

31. **LED Indicator:** Informs that the value on the Right display is in volts unit.










32. **Welding Programs Indicators:** lamps indicate the active weld mode. Descriptions of parameters are in Table 2.

33. **Welding parameters Indicators:** lamps indicate the active weld parameters. Descriptions of parameters are in Table 3.

## Welding Process Change

It is possible to quick recall of one of the six manual welding programs - Table 2.

**Table 2. Manual Weld Modes:**

Symbol	LED	Process
		GMAW MIX
		GMAW CO <sub>2</sub>
		GMAW AR
		FCAW MIX
		FCAW CO <sub>2</sub>
		SMAW

To set the welding process:

- Press the Left Button [26] to select an adequate welding process- the weld program indicator [32] the first weld program indicator [32] lights on.
- Again, press the Left Button [26] the weld program indicator will jump to the next mode.

 **WARNING**

During switching the displays show a “creeping line” on the screen.

## Quick Access and Configuration Menu for U0 User Interface

Users have access to the two menu levels:

- Quick Access – basic menu which is connected with setting the Welding Parameters.
- Configuration Menu – advanced menu, configures the device setting.

### WARNING

The Menu cannot be accessed if the system is welding, or if there is a fault (status LED is not solid green).

The availability parameters in the Quick Access and Configuration Menu depend on the selected welding program / welding process.

After the device has been restarted the user settings are restored.

Parameter Selection Mode – the Parameter Name on the Left Display blinking.

Parameter Change Value Mode – the parameter value on the Right Display blinking.

### Quick Access

To set the parameter of Quick Access (Table 3):

- Press the Right Button [25] to select mode.
- Turn the Right Knob [24] to set the value of parameter.
- Press the Left Button [26] to return to main menu.

### WARNING

If user do not press Left button, system return automatically to the main menu after few seconds.

**Table 3. The default settings of Quick Access**

Parameter		Definition
		<p><b>Inductance</b> – controls the arc characteristics when short-arc welding. increasing Inductance greater than 0.0 results in a crisper arc (more spatter) while decreasing the Inductance to less than 0.0 provides a softer arc (less spatter).</p> <ul style="list-style-type: none"> <li>• Adjust range: from -10 to +10.</li> <li>• Factory default, Pinch is OFF.</li> </ul>
		<p><b>The 2-Step - 4-Step</b> changes the function of the gun's trigger.</p> <ul style="list-style-type: none"> <li>• 2 Step trigger operation turns welding on and off in direct response to the trigger. Welding process is performed when the gun's trigger is pulled.</li> <li>• 4-Step mode allows to continue welding, when the gun's trigger is released. To stop welding, the gun's trigger is pulled again. 4-step mode facilitates to making long welds.</li> </ul> <p><b>Note:</b> 4-Step does not work during Spot Welding.</p>
		<p><b>Run-in WFS</b> – sets the wire feed speed from the time the trigger is pulled until an arc is established.</p> <ul style="list-style-type: none"> <li>• Factory default, Run-in is turned off.</li> <li>• Adjust range: from minimum to 3,81 m/min (150 in/min).</li> </ul>
		<p><b>Burnback Time</b> – is the amount of time that the weld output continues after the wire stops feeding. It prevents the wire from sticking in the puddle and prepares the end of the wire for the next arc start.</p> <ul style="list-style-type: none"> <li>• Factory default, Burnback Time is set at AUTO.</li> <li>• Adjust range: from 0 (OFF) to 0,25 seconds.</li> </ul>

### Configuration Menu:

To set the parameter of Configuration Menu:








- Press the Left Button [26] and the Right Button [25] simultaneously to get the access of menu.
- Turn the Left Knob [23] to choose the parameter.
- Press the Right Button [25] to confirm the selection.
- Turn the Right Knob [24] to choose the value of parameter.
- Press the Right Button [25] to confirm the selection.
- Press the Left Button [26] to back to the previous menu and confirm the chosen value.







### ⚠ WARNING

To exit the menu with changes saved, press the Left [26] and the Right [25] Buttons simultaneously.

After one minute of inactivity the Menu without saving will also exit.

























































**Table 4. The default settings of Configuration Menu**

Parameter	Definition
	<b>Spot Timer</b> – adjusts the time welding will continue even if the trigger is still pulled. This option has no effect in 4-Step Trigger Mode.
	<b>Crater Procedure</b> – turn ON/OFF the Crater Settings Procedure: <ul style="list-style-type: none"> <li>• ON (factory default) – Crater can be adjusted. The Crater Settings Procedure is assigned to the Right Button. During adjusting Crater, the LED Indicator [25] lights.</li> <li>• OFF – The Crater Settings Procedure is OFF. After press the Right Button, The Crater Settings Procedure is ignored.</li> </ul>
	<b>Preflow Time</b> – adjusts the time that shielding gas flows after the trigger is pulled and prior to feeding. <ul style="list-style-type: none"> <li>• Factory default, Preflow Time is set at 0 seconds.</li> <li>• Adjust range: from 0,1 seconds to 25 seconds.</li> </ul>
	<b>Postflow Time</b> – adjusts the time that shielding gas flows after the welding output turns off. <ul style="list-style-type: none"> <li>• Factory default, Postflow Time is set at 0 seconds.</li> <li>• Adjust range: from 0,1 seconds to 25 seconds.</li> </ul>
	<b>Arc/Loss Time</b> – this option can be used to optionally shut off output if an arc is not established, or is lost for a specified amount of time. Error 269 will be displayed if the machine times out. If the value is set to OFF, machine output will not be turned off if an arc is not established nor will output be turned off if an arc is lost. The trigger can be used to hot feed the wire (default). If a value is set, the machine output will shut off if an arc is not established within the specified amount of time after the trigger is pulled or if the trigger remains pulled after an arc is lost. To prevent nuisance errors, set Arc Start/Loss Error Time to an appropriate value after considering all welding parameters (run-in wire feed speed, weld wire feed speed, electrical stick out, etc). <ul style="list-style-type: none"> <li>• OFF (0) to 10 seconds (default = Off)</li> </ul> <b>Note:</b> This parameter is disabled while welding in Stick, TIG or Gouge.
	<b>Screen Brightness</b> – enables setting the displays brightness level. Adjust range from 1 to 10, where 5 is default.
	<b>Feedback Persist</b> – determines how feedback values are displayed following a weld: <ul style="list-style-type: none"> <li>• "Off" (factory default) – last recorded feedback values will blink for 5 seconds following a weld, then return to present display mode.</li> <li>• "On" – last recorded feedback values will blink indefinitely following a weld until a Control or button is touched, or an arc is struck.</li> </ul>

	<p><b>Wire Feed Speed (WFS) units</b> – enables change WFS units:</p> <ul style="list-style-type: none"> <li>• CE (factory default) = m/min;</li> <li>• US = in/min.</li> </ul>
	<p><b>Hot Start</b> – value in percentage of nominal value welding current during arc start current. The control is used to set the level of the increased current and arc start current is made easy.</p> <ul style="list-style-type: none"> <li>• Adjust range: from 0 to +10.</li> </ul>
	<p><b>Arc Force</b> – the output current is temporarily increased to clear short circuit connections between the electrode and the work piece.</p> <p>Lower values will provide less short circuit current and a softer arc. Higher settings will provide a higher short circuit current, a more forceful arc and possibly more spatter.</p> <ul style="list-style-type: none"> <li>• Adjust range: from -10 to +10.</li> </ul>
	<p><b>Restore to Factory Settings</b> – it allows to restore the factory settings.</p>
	<p><b>View Software version</b> – used for viewing the software version for user interface.</p> <ul style="list-style-type: none"> <li>• First view show effects after getting access to choose the parameter.</li> <li>• Second view show effects after getting access to edit parameter.</li> </ul>
	

# Guide's Marking Interface

Table 5. Symbols description

	Select Welding Process		Select Welding Program		SMAW Process (MMA)
	GMAW Process (MIG/MAG)		FCAW Process		Recall from the User Memory
	Save to the User Memory		User Setup		Advanced Setup
	Configuration		Arc Force		Hot Start
	Pinch		Prewflow Time		Postflow Time
	Burnback Time		Run-in WFS		Select Function of Gun Trigger (2-Step / 4-Step)
	Memory Limits		2-Step		Crater Procedure
	Spot Welding Settings		4-Step		Start Procedure
	Cold Feed		Brightness Level		Restore Factory Setting
	View Software and Hardware Version Information		A/B Procedure		USB Memory
	Check Mark		Resignation Mark		Lock / Unlock
	Error		ESCape Button		Confirm Button
	Wire Feed Speed in [in/min]		Welding Voltage		Welding Current
	Locked		Unlocked		Wire Feed Speed in [m/min]
	Set the Language		Support		Display Configuration Settings
	Standard UI look		Advanced UI look		Select Item
	Enable/ Disable Jobs Mode or Select Jobs for Jobs Mode		Enable/ Disable Jobs Save		Lock
	Weld History		Save		Service weld logs
	SnapShot		Load		

# User Interface Advanced (U7)



Figure 6.

34. **Display:** 7" TFT display shows welding processes parameters.

35. **Left Knob:** Sets the value in the top Left corner of the display. Cancel selection. Return to the previous menu.

36. **Right Knob:** Sets the value in the top Right corner of the display. Confirmation of changes.

37. **Button:** It enables return to main menu. Users have access to the two different views of interface:

- Standard view (Figure 7.)
- Advanced view (Figure 8)

To choose the view of interface:

- Press the Button [37] or Right Knob [36].
- Use the Right Knob [36] to highlight the "Configuration" icon.
- Press the Right Knob [36] to confirm decision.
- Use the Right Knob [36] to highlight "UI look" icon.
- Press the Right Knob [36] to confirm decision.
- Select one of the view (Standard – Figure 7 or Advanced – Figure 8).
- Press the button [37] or Left Knob [35] to return to main menu.

Table 6. Different display views

		Functions of Interface Components
		<p>38. Status bar.</p> <p>39. The measured value of current.</p> <p>40. The measured value of voltage.</p> <p>41. Parameter Value (wire feed speed or current) regulated by Left Knob [35].</p> <p>42. Parameter Value (voltage, trim or power) regulated by Right Knob [36].</p> <p>43. Welding Parameter Visualization.</p> <p>44. Welding Parameters Bar.</p>
<p>Figure 7.</p> <p>Figure 8.</p>		

## Status bar




Figure 9.

- A) Information about active welding mode
- B) 2/4 step
- C) USB Interface

## Welding Parameters Bar

The Welding Parameters Bar enables:

- Welding Program change.
- Wave Control Value change.
- The gun's trigger function change (GMAW, FCAW, SMAW).
- Add or hide functions and welding parameters – User Setup
- Change the Setup

Table 7. GMAW and FCAW Welding Parameters Bar

Symbol	Description
	Welding Process Choice
	Support
	The function of the gun's trigger change
	Pinch
	Configuration Menu (Setup)
	User Setup

### WARNING

The availability parameters depend on the selected welding program / welding process.

Table 8. SMAW Welding Parameters Bar

Symbol	Description
	Welding Process Choice
	Support
	Arc Force
	Hot Start
	Configuration Menu (Setup)
	User Setup

## Welding Program Choice

To select the Welding Program:

- Press the Button [37] or Right Knob [36] to get access of Welding Parameters Bar.
- Use the Right Knob [36] to highlight the icon "Welding Process Choice".
- Press the Right Knob [36] to confirm the selection.





Figure 10.

- Use the Right Knob [36] to highlight the icon "Select welding program".



Figure 11.

- Press the Right Knob [36] to confirm the selection.



**Figure 12.**



- Use the Right Knob [36] to highlight the program number.
- Press the Right Knob [36] to confirm the selection.

**! WARNING**

The Lists of available programs depends on the power source.

If a user does not know the Welding Program Number, it can be searched. In that case in subsequent steps are given:

- The Welding Process
- The Electrode Wire Type
- The Electrode Wire Diameter
- The Shielding Gas



## Support

To access the Support Menu:

- Press the Button [37] or Right Knob [36] to get access of Welding Parameters Bar.
- Use the Right Knob [36] to highlight the icon "Support".
- Press the Right Knob [36] to confirm the selection.

The Support Menu enables to get knowledge of the following points:

- Accessories:
  - Rolls for aluminum wire
  - Rolls for fluxed cored wire
  - Rolls for steel/stainless steel wire
  - TIG torches
  - Electrode & Ground cable
  - MIG/MAG LINC GUN Standard
- Tips and Tricks:
  - Tutorial
  - Welding variables effect MIG

## User Setup

To access the User Setup:

- Press the Button [37] or Right Knob [36] to get access of Welding Parameters Bar.
- Use the Right Knob [36] to highlight the icon "Settings".
- Press the Right Knob [36] to confirm the selection.














**Figure 13.**

The User Setting Menu enables to add the additional function and / or parameters to the Welding Parameters Bar [44]:



**Table 9.**


Symbol	Description
	Preflow
	Postflow
	Burnback Time
	Spot Welding
	Run-In WFS
	Start Procedure
	Crater Procedure
	A/B Procedure
	Load memory
	Save memory
	USB Memory

**! WARNING**

To change the Parameters or Functions Value, their icons had to be added to the Welding Parameters Bar [44].


To add the Parameter or Function to the Welding Parameters Bar [44]:

- Access to the User Setup (see the Figure 13).
- Use the Right Knob [36] to highlight the parameter or function icon which will be added to the Welding Parameters Bar [44], for example Run-in WFS.



**Figure 14.**

- Press the Right Knob [36] to confirm the selection. Run-in WFS icon will drop.




**Figure 15.**

**! WARNING**

To remove the icon - press the Right Knob [36] once again.

To exit the User Setup Menu – press the Left Button [35].


- The Selected parameters or function is added to the Welding Parameters Bar [44].



**Figure 16.**

To remove the selected parameter or function from the Welding Parameters Bar [44]:

- Access to the User Setup.
- Use the Right Knob [36] to highlight the parameter or function icon which is added to the Welding Parameters Bar [44].



**Figure 17.**

- Press the Right Knob [36] – The selected icon will disappear from the display bottom.



Figure 18.

- The Selected parameters or function was disappeared from the Welding Parameters Bar [44]





Figure 19.



**Preflow Time** adjusts the time that shielding gas flows after the trigger is pulled and prior to feeding.

- Adjust range: from 0 seconds (OFF) to 25 seconds (factory default is set at Auto mode).



**Postflow Time** adjusts the time that shielding gas flows after the welding output turns off.

- Adjust range: from 0 seconds (OFF) to 25 seconds (factory default is set at Auto mode).



**Burnback Time** is the amount of time that the weld output continues after the wire stops feeding. It prevents the wire from sticking in the puddle and prepares the end of the wire for the next arc start.

- Adjust range: from OFF to 0.25 seconds (factory default is set at Auto mode).



**Spot Timer**— adjusts the time welding will continue even if the trigger is still pulled. This option has no effect in 4-Step Trigger Mode.

- Adjust range: from 0 second (OFF) to 120 seconds (factory default is OFF).

**WARNING**

Spot Timer has no effect in 4-Step Trigger Mode.



**Run-in WFS** – sets the wire feed speed from the time the trigger is pulled until an arc is established.

- Adjust range: from minimum to maximum WFS (factory default is set at Auto mode).



**The Start Procedure** – controls the WFS and Volts (or Trim) for a specified time at the beginning of the weld. During the start time, the machine will ramp up or down from the Start Procedure to the preset Welding Procedure.

- Adjust time range: from 0 seconds (OFF) to 10 seconds.



**Crater Procedure** – controls the WFS (or value in ampere units) and Volts (or Trim) for a specified time at the end of the weld after the trigger is released. During the Crater time, the machine will ramp up or down from the Weld Procedure to the Crater Procedure.

- Adjust time range: from 0 seconds (OFF) to 10 seconds.



**A/B procedure** – enables quick weld procedure change. The sequence changes may occur between:

- Two different welding programs.
- Different settings for the same program.



**Save Memory:** Store the welding programs with their parameters to one of the fifty user Memories.

To save memory:

- Add Save Memory icon to Welding Parameters Bar.
- Use the Right Knob [36] to highlight the icon Save Memory.



Figure 20.

- Press the Right Knob [36] to confirm – the Save Memory Menu is shown on the display .
- Use the Right Knob to highlight the memory number where the program would be stored.



Figure 21.

- Confirm the selection – Press and hold for 3 second Right Knob [36].



**Figure 22.**

- Rename job – turn Right Knob [36] to select: numbers 0-9, letters A-Z, a-z. Press Right Knob [36] to confirm first character of the name.
- Next characters are selected in the same.
- To confirm the name of job and back to the main menu press Button [37] or Left Knob [35].



**Load memory**

Recall the stored programs from the user Memory.

To recall the Welding Program from the User Memory:  
**Note:** Before using, the Welding Program had to be assigned to the user memory



- Add the Load memory icon to the Welding Parameters Bar.
- Use the Right Knob [36] to highlight the Load memory icon.
- Press the Right Knob [36] to confirm – the Load Memory Menu is shown on the display.
- Use the Right Knob [36] to highlight the Memory number which from the Welding Program will be recall.
- Confirm the select – press the Right Button [36].



**USB**





When the USB storage device is connected to USB port – user have access to:

**Table 10. USB Menu**

Symbol	Description
	Save
	Load

**Save** - the following data can be save on a USB Memory Stick:

**Table 11. Save and restore selection**

Symbol	Description
	Current Welding Settings
	Advanced Parameters Configuration (P menu)
	All welding programs stored in user memory
	One of the welding programs stored in user memory


To save data into USB device:

- Connect the USB to welding machine.
- Add USB icon to the Welding parameters bar [44].
- Use the Right Knob [36] to highlight the icon "USB".



**Figure 23.**

- Press the Right Knob [36] to confirm the selection – the USB menu is shown on the display.
- Use the Right Knob [36] to highlight the icon "Save".



**Figure 24.**

- Press the Right Knob [36] to get access of Save option – the save menu is shown on the display.



Figure 25.

- Create or choose a file in which will be saved copies of the data.
- The display shows the Save Data Menu on a USB Memory Stick.




Figure 26.

- Use the Set Control [11] to highlight the data icon which will be saved in the file on a USB Memory Stick. For example: Configuration Menu icon.



Figure 27.

- Press the Right Knob [36] to confirm.



Figure 28.

- To confirm and save the data on a USB Memory Stick, highlight the Check Mark icon and then press the Right Knob [36].
- To exit the USB Menu – press the Left Button [37] or disconnect the USB Memory Stick from the USB receptacle.



**Load** – restore the data from the USB Device to the machine memory.

To load the data from USB Memory:

- Connect the USB to welding machine.
- Add USB icon to the Welding parameters bar [44].
- Use the Right Knob [36] to highlight the icon “USB”.



Figure 29.

- Press the Right Knob [36] to confirm the selection – the USB menu is shown on the display.
- Use the Right Knob [36] to highlight the icon “Load”.



Figure 30.

- Press the Right Knob [36] to get access of Load option – the load menu is shown on the display.
- Select the file name with the data to be loaded into interface. Highlight the file icon – use the Right Knob [36].




Figure 31.

- Press the Right Button [36] to confirm the file selection.
- The display shows the Load Data Menu from a USB Memory Stick to User Interface.
- Use the Right Knob [36] to highlight the data icon which will be loaded.




Figure 32.

- Press the Right Knob [36] to confirm the data selection.




Figure 33.

- To confirm and load the data from a USB Memory Stick, highlight the Check Mark icon and then press the Right Knob [36].




Figure 34.

- To exit the USB Menu – press the Left Button [37] or disconnect the USB Memory Stick from the USB receptacle.

## Settings and Configuration Menu

To access the Settings and Configuration Menu:

- Press the Button [37] or Right Knob [36] to get access of Welding Parameters Bar.
- Use the Right Knob [36] to highlight the icon “Configuration”.
- Press the Right Knob [36] to confirm the selection.




Figure 35.

Table 12.

Symbol	Description
	Set the Memory Limits
	Set the Display Configuration
	Set the Brightness Level
	Lock / Unlock
	Job Mode
	Set the Language
	Restore Factory Setting
	View Software and Hardware Version Information.
	Access to the Configuration Menu
	Service Menu



**Limits** – it allows the operator to set the limits of main welding parameters in selected job. The Operator is able to adjust the parameter value within specified limits.

**Note:** The Limits can be set only for the programs stored in the user memory.

The limits can be set for:

- Welding Current
- Wire Feed Speed
- Welding Voltage
- Wave Controls

To set the range:

- Enter to the Settings and Configuration Menu.
- Use The Right Knob [36] to highlight the “Limits” icon.




Figure 36.

- Press the Right Knob [36] to confirm. List with available job will be displayed on the screen.



Figure 37.

- Use the Right Knob [36] to highlight the job.
- Press the Right Knob [36] to confirm selection.



Figure 38.

- Use the Right Knob [36] to choose the parameter which will be changed.
- Press the Right Knob [36] to confirm.
- Use the Right Knob [36] to change the value. Press the Right Knob [36] to confirm.
- Figure 39 shows the effect of changing the values of parameters.



Figure 39.



- Press the Button [37] to exit with changes.



### Display Configuration

Two Display Configuration are available:

Table 13.

	Standard view
	Advanced view

To set the Display Configuration:

- Access to the Settings and Configuration Menu.
- Use the Right Knob [36] to highlight the Display Configuration icon.



Figure 40.

- Press the Right Knob [36]. The Display Configuration Menu is shown on the display.



Figure 41.

- Use the Right Knob [36] to choose the display configuration.



### The Brightness Level

- it allows to adjust the display brightness from 0 to 10.



Figure 42.



**Access Control**

This function allows following activities

Table 14.

Symbol	Description
	Lock
	Lock function
	Enable/ Disable Jobs
	Select Jobs for Job Work



**Lock** – it allows to set the password. To set the password:

- Access to the Settings and Configuration Menu.
- Use the Right Knob [36] to highlight the Lock icon.



Figure 43.

- Press the Right Knob [36]. The password setting menu is shown on the display.




Figure 44.

- Turn Right Knob [36] to select: numbers 0-9, Press Right Knob [36] to confirm first character of the password.
- Next numbers are selected in the same method.

**Note:** After setting last character system exit automatically.



**Lock function** – it allows to lock/unlock some functions on welding parameters bar.

To lock functions:

- Access to the Settings and Configuration Menu.
- Use the Right Knob [36] to highlight the Lock functions icon.




Figure 45.

- Press the Right Knob [36]. The Lock Function menu is shown on the display.
- Use the Right Knob [36] to highlight the function (for example “Advanced setup”).




Figure 46.

- Press the Right Knob [36]. The icon of chosen

parameter will disappear from the lower part of the display (Figure 47). Also this parameter disappear from the Welding parameters bar [44].




Figure 47.

**Note:** To unlock function user have to do the same steps as steps to lock function.



**Enable/ Disable Jobs** – it allows to switch off/on jobs to function Save Memory.  
To enable/ disable jobs:

- Access to the Settings and Configuration Menu.
- Use the Right Knob [36] to highlight the icon:



Figure 48.

- Press the Right Knob [36] to confirm. The Enable/Disable Jobs menu is shown on the display.




Figure 49.

- Use the Right Knob [36] to highlight the job number. The icon of chosen job will disappear from the lower part of the display.




Figure 50.

**Note:** The jobs which are disabled can not be using in “Save memory” function – shown in Figure 51 (job 2 is not available).



Figure 51.



**Select Jobs for Job Work** – it allows to choose which jobs will be enable when Job Mode will be activated.

To select Jobs for Job Work:

- Access to the Settings and Configuration Menu.
- Use the Right Knob [36] to highlight the icon.



Figure 52.

- Press the Right Knob [36] to confirm.
- Use the Right Knob [36] to highlight the job number.
- Press the Right Knob [36] to confirm – the icon of chosen parameter will appear on the lower part of the display.





Figure 53.

- Press Button [37] to return to main menu.



**Job Mode** – user has access to operate only with selected jobs.

**Note:** First of all user have to select jobs which can be used in Job Mode (*Access Control -> Select Jobs for Job Work*)

To activate Job Mode:

- Access to the Settings and Configuration Menu.
- Use the Right Knob [36] to highlight the Job Mode icon.



Figure 54.

- Press the Right Knob [36]. The Job Mode Menu is shown on the display.
- Use the Right Knob [36] to highlight one of the option shown on the figure below.
  - X - Cancel Job Mode
  - ✓ - Activate Job Mode




Figure 55.

- Press Right Knob [36] to confirm the selection.

**Note:** After activated Job Mode the icon of this function will be displayed on the Welding Parameters Bar. Also the Load Memory and Save Memory options will be blocked in this mode.



**Set the Language** – user can choose interface language (English, Polish, Finnish, French, German, Spanish, Italian, Dutch, Romanian).

To set the language:

- Access to the Settings and Configuration Menu.
- Use the Right Knob [36] to highlight the Set the Language icon.



Figure 56.

- Press the Right Knob [36]. The Language Menu is shown on the display.




Figure 57.

- Use the Right Knob [36] to choose the Language.
- Confirm the select – press the Right Knob [36].



### Restore Factory Settings

**Note:** After Factory Settings restore, the settings stored in user memory are deleted.

To restore Factory Settings:

- Access to the Settings and Configuration Menu.
- Use the Right Knob [36] to highlight the Restore Factory Settings icon.



Figure 58.

- Press the Right Knob [36]. The Restore Factory Settings Menu is shown on the display.
- Use the Right Knob [36] to highlight the Check Mark.




Figure 59.

- Confirm the select – press the Right Button [36]. The factory settings are restored.



### Diagnostic Information

Available information:

- Software Version
- Hardware Version
- Welding Software
- Ethernet IP Address
- Power Source Protocol
- Event Logs
- Fatal Logs.



### Advanced setup

This menu enables access to the configuration parameters of the device.

To set the configuration parameters:

- Access to the Settings and Configuration Menu.
- Use the Right Knob [36] to highlight the “configuration menu” icon.



Figure 60.

- Press the Right Knob [36]. The Configuration Menu is shown on the display.
- Use the Right Knob [36] to highlight the Parameter Number which will be changed, for example P.1 - allows change WFS units, factory default: "Metric" = m/min.




Figure 61.

- Press the Right Knob [36].
- Use the Right Knob [36] to highlight the "English" = in/min.




Figure 62.

- Confirm the select – press the Right Button [36].

**Table 15. The Configuration Parameters**

<b>P.0</b>	<b>The Menu Exit</b>	Enables exit from menu
<b>P.1</b>	<b>Wire Feed Speed (WFS) units</b>	Enables change WFS units: <ul style="list-style-type: none"> <li>• "Metric" (factory default) = m/min;</li> <li>• "English" = in/min.</li> </ul>
<b>P.4</b>	<b>Recall Memory with Trigger (PF46 only)</b>	This option allows a memory to be recalled by quickly pulling and releasing the gun trigger: <ul style="list-style-type: none"> <li>• "Enable" = Selecting memories 2 through 9 by quickly pulling and releasing the gun trigger. To recall a memory with the gun trigger, quickly pull and release the trigger the number of times that correspond to the memory number. For example, to recall memory 3, quickly pull and release the trigger 3 times. Trigger memory recall can only be performed when the system is not welding.</li> <li>• "Disable" (factory default) = Memory selection is performed only by the Panel Buttons.</li> </ul>
<b>P.7</b>	<b>Gun Offset Adjustment</b>	This option adjusts the wire feed speed calibration of the pull motor of a push-pull gun. This should only be performed when other possible corrections do not solve any push-pull feeding problems. An rpm meter is required to perform the pull gun motor offset calibration. To perform the calibration procedure do the following: <ol style="list-style-type: none"> <li>1. Release the pressure arm on both the pull and push wire drives.</li> <li>2. Set the wire feed speed to 200 ipm.</li> <li>3. Remove wire from the pull wire drive.</li> <li>4. Hold an rpm meter to the drive roll in the pull gun.</li> <li>5. Pull the trigger on the push-pull gun.</li> <li>6. Measure the rpm of the pull motor. The rpm should be between 115 and 125 rpm. If necessary, decrease the calibration setting to slow the pull motor, or increase the calibration setting to speed up the motor.</li> </ol> <ul style="list-style-type: none"> <li>• The calibration range is -30 to +30, with 0 as the default value.</li> </ul>
<b>P.9</b>	<b>Crater Delay</b>	This option is used to skip the Crater sequence when making short tack welds. If the trigger is released before the timer expires, Crater will be bypassed and the weld will end. If the trigger is released after the timer expires, the Crater sequence will function normally (if enabled). <ul style="list-style-type: none"> <li>• OFF (0) to 10.0 seconds (default = Off)</li> </ul>
<b>P.20</b>	<b>Display Trim as Volts Option</b>	Determines how trim is displayed <ul style="list-style-type: none"> <li>• "No" (factory default) = The trim is displayed in the format defined in the weld set.</li> <li>• "Yes" = All trim values are displayed as a voltage.</li> </ul> <b>Note:</b> This option may not be available on all machines. The power source must support this functionality, or this option will not appear in the menu.
<b>P.22</b>	<b>Arc Start/Loss Error Time</b>	This option can be used to optionally shut off output if an arc is not established, or is lost for a specified amount of time. Error 269 will be displayed if the machine times out. If the value is set to OFF, machine output will not be turned off if an arc is not established nor will output be turned off if an arc is lost. The trigger can be used to hot feed the wire (default). If a value is set, the machine output will shut off if an arc is not established within the specified amount of time after the trigger is pulled or if the trigger remains pulled after an arc is lost. To prevent nuisance errors, set Arc Start/Loss Error Time to an appropriate value after considering all welding parameters (run-in wire feed speed, weld wire feed speed, electrical stick out, etc). To prevent subsequent changes to Arc Start/Loss Error Time, the setup menu should be locked out by setting Preference Lock = Yes using the Power Wave Manager software. <b>Note:</b> This parameter is disabled while welding in Stick, TIG or Gouge.
<b>P.28</b>	<b>Display Workpoint as Amps Option</b>	Determines how workpoint is displayed: <ul style="list-style-type: none"> <li>• "No" (factory default) = The workpoint is displayed in the format defined in the weld set.</li> <li>• "Yes" = All workpoint values are displayed as an amperage.</li> </ul> <b>Note:</b> This option may not be available on all machines. The power source must support this functionality, or this option will not appear in the menu
<b>P.80</b>	<b>Sense From Studs</b>	Use this option for diagnostic purposes only. When power is cycled, this option is automatically reset to False. <ul style="list-style-type: none"> <li>• "False" (default) = Voltage sensing is automatically determined by the selected weld mode and other machine settings.</li> <li>• "True" = Voltage sensing is forced to "studs" of the power source.</li> </ul>

<b>P.81</b>	<b>Electrode Polarity</b>	Used in place of DIP switches for configuration of the work and electrode sense leads <ul style="list-style-type: none"> <li>• "Positive" (default) = Most GMAW welding procedures use Electrode Positive welding.</li> <li>• "Negative" = Most GTAW and some inner shield procedures use Electrode Negative welding.</li> </ul>
<b>P.99</b>	<b>Show Test Modes</b>	Uses for calibration and tests. <ul style="list-style-type: none"> <li>• "No" (factory default) = Turned off;</li> <li>• "Yes" = Allows to selection test modes.</li> </ul> <b>Note:</b> After the device has been restarted the P.99 is "NO".
<b>P.323</b>	<b>System Update</b>	This parameter is active only when the USB Memory Stick (with upgrade file) is connected to USB socket. <ul style="list-style-type: none"> <li>• Cancel – goes back to Configuration Parameters menu</li> <li>• Accept – starts updating process</li> </ul>




**Service Menu**

It allows the access to special service functions.



**WARNING**

Service Menu is available when USB storage device is connected.



**Figure 63.**

**Table 16.**

Symbol	Description
	Service weld logs
	Weld History
	SnapShot



**Service weld logs** – allows recording welding parameters which were using during the welding. To access the menu:

- Make sure that USB device is connected to welding machine
- Access to the Settings and Configuration Menu.
- Use the Right Knob [36] to highlight the Service Menu icon
- Press the Right Knob [36] – the recording process will started.



**Figure 64.**

- Press the Right Knob [36] to continue.



**Figure 65.**

- Press the Left Knob [35] or Button [37] to exit
- Recording icon will appear on the Status bar [38].




**Note:** To stop the recording go to Service Menu and press the **Service weld logs** icon again



**Weld history** – after recording, welding parameters are saved into the USB device folder. To access the Welding history:

- Make sure that USB device is connected.
- Access to the Settings and Configuration Menu.
- Go to *Service Menu* → *Weld History*



**Figure 66.**

- Press the Right Knob [36] to get access of *Weld history* – the list of used parameters:
  - Weld number
  - Average WFS
  - Average current [A]
  - Average voltage [V]
  - Arc time [s]
  - Welding program number
  - Job number/name



**SnapShot** - create a file that contains detailed configuration and debugging information collected from each module in the Powertec i250C/ i320C Advanced.

This file can be sent to Lincoln Electric Support to troubleshoot any possible issues that cannot be easily resolved by the user.


To obtain a SnapShot:

- Make sure that USB device is connected.
- Go to *Configuration* → *Service Menu* → *SnapShot*



**Figure 67.**

Press the Right Knob [36] to start Snapshot process



**Figure 68.**

## Welding GMAW and FCAW Process in non-synergic mode

During non-synergic mode wire feed speed and welding voltage are independent parameters and must be set by the user.

Procedure of begin welding of GMAW or FCAW-SS process:

- Determine the wire polarity for the wire to be used. Consult the wire data for this information.
- Connect output the gas-cooled gun to GMAW / FCAW process to Euro Socket [5].
- Depending on the using wire, connect the work lead [15] to output socket [3] or [4]. See [20] point – terminal block of changing polarity.
- Connect the work lead [15] to the welding piece with the work clamp.
- Install the proper wire.
- Install the proper drive roll.
- Make a sure if it is needed (GMAW process), that the gas shield has been connected.
- Turn the machine on.
- Push the gun trigger to feed the wire through the gun liner until the wire comes out of the threaded end.
- Install a proper contact tip.
- Depending on the welding process and the type of the gun, install the nozzle (GMAW process) or protection cap (FCAW process).
- Close the Left side panel.
- The welding machine is now ready to weld.
- By applying the principle of occupational health and safety at welding, welding can be begun.

### **WARNING**

Keep the gun cable as straight as possible when loading electrode through cable.

### **WARNING**

Never use defected gun.

- Check gas flow with Gas Purge Switch [18].
- Close the wire drive door.
- Close the spool wire case.
- Select the Right welding program.  
**Note:** The list of available programs depends on the power source.
- Set the welding parameters.
- The welding machine is now ready to weld.

### **WARNING**

The wire drive door and wire spool case have to be completely closed during welding.

### **WARNING**

Keep the gun cable as straight as possible when welding or loading electrode through cable.

### **WARNING**

Do not kink or pull cable around sharp corners.

- By applying the principle of occupational health and safety at welding, welding can be begun.

For non-synergic mode can set:

- Wire Feed Speed, WFS
- The welding voltage
- Burnback Time
- Run-in WFS
- Preflow Time/ Postflow Time
- Spot Time
- 2-Step/4-Step
- Start Procedure
- Crater Procedure
- Wave Control:
  - Pinch

## Welding GMAW and FCAW Process in synergic mode CV

In synergic mode, the welding voltage is not set by user.

The correct welding voltage will set by the machine's software.

This value was recalled on the basis of data (input data) had been loaded:

- Wire Feed Speed, WFS.

If it is needed, the welding voltage can be adjusted by the Right Control [36]. When the Right Control is rotated, the display will show a positive or negative bar indicates if the voltage is above or below the ideal voltage.

Additionally can manually set:

- Burnback
- Run-In WFS
- Preflow Time/ Postflow Time
- Spot Time
- 2-Step/4-Step
- Start Procedure (Advanced only)
- Crater Procedure
- Wave Control:
  - Pinch

## Welding SMAW Process

### POWERTEC i250C/i320C STANDARD/ ADVANCED

does not include the electrode holder with lead necessary for SMAW welding, but the one can be purchased separately.

Procedure of begin welding of SMAW process:

- First turn the machine off.
- Determine the electrode polarity for the electrode to be used. Consult the electrode data for this information.
- Depending on the polarity of using electrode, connect the work lead [15] and the electrode holder with lead to output socket [3] or [4] and lock them. See the Table 17.

Table 17.

		Output Socket	
POLARITY	DC (+)	The electrode holder with lead to SMAW	[4] <b>+</b>
		Work lead	[3] <b>-</b>
POLARITY	DC (-)	The electrode holder with lead to SMAW	[3] <b>-</b>
		Work lead	[4] <b>+</b>

- Connect the work lead to the welding piece with the work clamp.
- Install the proper electrode in the electrode holder.
- Turn the input power ON.
- Set the SMAW welding program.
- Set the welding parameters.
- The welding machine is now ready to weld.
- By applying the principle of occupational health and safety at welding, welding can be begun.

For SMAW program can set:

- Welding current
- Switch on / switch off the output voltage on the output lead
- Wave Controls:
  - ARC FORCE
  - HOT START

## Loading the Electrode Wire

- Turn the machine off.
- Open the Right panel of the machine.
- Unscrew the locking nut of the sleeve.
- Load the spool with the wire on the sleeve such that the spool turns anticlockwise when the wire is fed into the wire feeder.
- Make sure that the spool locating pin goes into the fitting hole on the spool.
- Screw in the fastening cap of the sleeve.
- Put on the wire roll using the correct groove corresponding to the wire diameter.
- Free the end of the wire and cut off the bent end making sure it has no burr.

### WARNING

Sharp end of the wire can hurt.

- Rotate the wire spool anticlockwise and thread the end of the wire into the wire feeder as far as the Euro socket.
- Adjust force of pressure roll of the wire feeder properly.

## Adjustments of Brake Torque of Sleeve

To avoid spontaneous unrolling of the welding wire the sleeve is fitted with a brake.

Adjustment is carried by rotation of its Allen screw M8, which is placed inside of the sleeve frame after unscrewing the fastening cap of the sleeve.




Figure 69.

- 45. Fastening cap.
- 46. Adjusting Allen screw M8.
- 47. Pressing spring.

Turning the Allen screw M8 clockwise increases the spring tension and you can increase the brake torque

Turning the Allen screw M8 anticlockwise decreases the spring tension and you can decrease the brake torque.

After finishing of adjustment, you should screw in the fastening cap again.

## Adjusting of Pressure Roll Force

The pressure arm controls the amount of force the drive rolls exert on the wire.

Pressure force is adjusted by turning the adjustment nut clockwise to increase force, counterclockwise to decrease force. Proper adjustment of pressure arm gives the best welding performance.

### WARNING

If the roll pressure is too low the roll will slide on the wire. If the roll pressure is set too high the wire may be deformed, which will cause feeding problems in the welding gun. The pressure force should be set properly. Decrease the pressure force slowly until the wire just begins to slide on the drive roll and then increase the force slightly by turning of the adjustment nut by one turn.

## Inserting Electrode Wire into Welding Torch

- Turn the welding machine off.
- Depending on welding process, connect the proper gun to the euro socket, the rated parameters of the gun and of the welding machine should be matched.
- Remote the nozzle from the gun and contact tip or protection cap and contact tip. Next, straighten the gun out flat.
- Turn the welding machine on.
- Hold the Cold Inch/Gas Purge Switch in the Cold Inch position.
- When the switch is released spool of wire should not unwind.
- Adjust wire spool brake accordingly.
- Turn the welding machine off.
- Install a proper contact tip.
- Depending on the welding process and the type of the gun, install the nozzle (GMAW process) or protection cap (FCAW process).

### WARNING

Take precaution to keep eyes and hands away from the end of the gun while the wire is being come out of the threaded end.

## Changing Driving Rolls

### WARNING

Turn the input power off before installation or changing drive rolls.

**POWERTEC i250C STANDARD/ ADVANCED, POWERTEC i320C STANDARD/ ADVANCED** is

equipped with drive roll V1.0/V1.2 for steel wire.

For others wire sizes, is available the proper drive rolls kit (see "Accessories" chapter) and follow instructions:

- Turn the input power OFF.
- Unlock 4 rolls by turning 4 Quick-Change Carrier Gear [52].
- Release the pressure roll levers [53].
- Change the drive rolls [51] with the compatible ones corresponding to the used wire.

### WARNING

Be sure that the gun liner and contact tip are also sized to match the selected wire size.

### WARNING

For wires with the diameter larger than 1.6mm, the following parts are to be changed:

- The guide tube of the feeding console [49] and [50].
- The guide tube of the Euro Socket [48].

- Lock 4 new rolls by turning 4 Quick-Change Carrier Gear [52].
- Manually feed the wire from the wire reel, the wire through the guide tubes, over the roller and through the guide tube of Euro Socket into liner of gun.
- Lock the pressure roll levers [53].




Figure 70.

## Gas Connection

A gas cylinder must be installed with a proper flow regulator. Once a gas cylinder with a flow regulator has been securely installed, connect the gas hose from the regulator to the machine gas inlet connector.

### WARNING

The welding machine supports all suitable shielding gases including carbon dioxide, argon and helium at a maximum pressure of 5,0 bars.

### WARNING

Always fasten gas cylinder properly in vertical position in a special holder on the wall or on a carriage. Remember to close gas cylinder valve after having finished welding.

### WARNING

Gas cylinder can be fasten on the machine's shelf, but the height of gas cylinder doesn't have to be higher than 43in/1,1m. The gas cylinder which is fastened on the machine's shelf has to be secured by attaching it to the machine using the chain.

 **WARNING**

Always fasten gas cylinder properly in vertical position in a special holder on the wall or on a carriage. Remember to close gas cylinder valve after having finished welding.

 **WARNING**

Gas cylinder can be fasten on the machine's shelf, but the height of gas cylinder doesn't have to be higher than 43in/1,1m. The gas cylinder which is fastened on the machine's shelf has to be secured by attaching it to the machine using the chain.

## Maintenance

 **WARNING**

For any repair operations, modifications or maintenance, it is recommended to contact the nearest Technical Service Center or Lincoln Electric. Repairs and modifications performed by unauthorized service or personnel will cause the manufacturer's warranty to become null and void.

Any noticeable damage should be reported immediately and repaired.

### Routine maintenance (everyday)

- Check condition of insulation and connections of the work leads and insulation of power lead. If any insulation damage exists replace the lead immediately.
- Remove the spatters from the welding gun nozzle. Spatters could interfere with the shielding gas flow to the arc.
- Check the welding gun condition: replace it, if necessary.
- Check condition and operation of the cooling fan. Keep clean its airflow slots.

### Periodic maintenance (every 200 working hours but at least once a year)

Perform the routine maintenance and, in addition:

- Keep the machine clean. Using a dry (and low pressure) airflow, remove the dust from the external case and from the cabinet inside.
- If it is required, clean and tighten all weld terminals.

The frequency of the maintenance operations may vary in accordance with the working environment where the machine is placed.

 **WARNING**

Do not touch electrically live parts.

 **WARNING**

Before the case of machine will be removed, the machine has to be turned off and the power lead has to be disconnected from mains socket.

 **WARNING**

Mains supply network must be disconnected from the machine before each maintenance and service. After each repair, perform proper tests to ensure safety.



# MAINTENANCE

## WARNING



**ELECTRIC SHOCK** can kill

Have an electrician install and service this equipment  
Turn the input power off at the fuse box before working on equipment  
Do not touch electrically hot parts  
Prior to performing preventive maintenance, perform the following capacitor discharge procedure to avoid electric shock.

## DC BUS CAPACITOR DISCHARGE PROCEDURE

1. Remove main input power to the POWERTEC® i250C or i320C.
2. Remove the left side panel following the case removal procedure available in this Service manual.
3. The capacitors are discharged by discharge resistors integrated into the main board in about 2 (two) minutes.
4. Locate the terminals **POS** and **NEG** on the Inverter board, **See Figure 1**.
5. Connect your multi-meter positive probe to **POS** terminal point and your negative probe to **NEG** terminal and check the voltage.
6. In case of presence of residual voltage follow the next steps
7. Obtain a high resistance and high wattage resistor (500-1000 ohms and 25 watts minimum). This resistor is NOT supplied with the machine. NEVER USE A SHORTING STRAP FOR THIS PROCEDURE.
8. Use electrically insulate gloves and insulated pliers. Hold the body of the resistor and connect the resistor leads across the two points POS and NEG. **See Figure 1**. Hold the resistor in place for 10 seconds. DO NOT TOUCH CAPACITOR TERMINALS WITH YOUR BARE HANDS.
9. Check again the voltage across the two terminals. Voltage should be zero. If any voltage remains, repeat this procedure.




Figure 1

# THERMAL PROTECTION


Thermal detection devices protect the machine from excessive operating temperatures. Excessive temperatures may be caused by a lack of cooling air or operating the machine beyond the duty cycle and output rating. If excessive operating temperatures should occur, the yellow LED will light and the detection device will prevent output voltage or current.

These detection devices are self-resetting once the machine cools sufficiently. If the thermostat shutdown was caused by excessive output or duty cycle and the fan is operating normally, the power switch may be left on and the reset should occur within a 15 minute period. If the fan is not turning or the air intake louvers were obstructed, then the power must be switched off and the fan problem or air obstruction must be corrected.

## MAJOR COMPONENTS LOCATION

### POWERTEC i250C and i320C


- |                        |                    |
|------------------------|--------------------|
| 1. EMI Filter          | 8. Gas solenoid    |
| 2. Supply Board        | 9. Control Board   |
| 3. Fans                | 10. Inverter Board |
| 4. Drive Motor         | 11. Wire drive     |
| 5. Output transformer  | 12. Output diodes  |
| 6. Output Choke        |                    |
| 7. User Interface (UI) |                    |




# THEORY OF OPERATION

- General description
- Main Board
- Output choke – Polarity change – User Interface
- Protection Circuits
- IGBT operation

## BLOCK DIAGRAM (Standard Version)



# GENERAL DESCRIPTION



Wiring diagram of Standard Version

## GENERAL DESCRIPTION

The POWERTEC i250C and i320C are industrial arc welding power sources which utilize three phases input power, to produce constant voltage or constant current output. The welding response of these units has been optimized for GMAW, FCAW-SS, SMAW and GTAW-lift TIG. The units are ideal for industrial applications.

The POWERTEC i250C and i320C, when connected to the input voltage of 400Vac, produce a welding output from 10 to 250 amperes (i250C) or 10 to 320 amperes (i320C) in GMAW-FCAW-SS and 20 to 250 amperes (i250C) or 20 to 320 amperes (i320C) in SMAW and GTAW.

They operate on three phases input power 400Vac only. They are environmentally hardened


to an IP23 rating for operating in difficult environments.

## EMI FILTER (Y051-1)

EMI filter circuit, prevents noise from the machine from being transmitted along the main power line and vice versa, necessary to be in accordance with all relevant directives and standards.

On the EMI filter are also located three relays (K1,K2,K3) that, when close are responsible to provide the power supply to the inverter board through the input bridge V1.

# VOLTAGE SUPPLY BOARD



## VOLTAGE SUPPLY BOARD (Y047-1)

The VOLTAGE SUPPLY BOARD receives the three phases 400Vac (L1,L2,L3) from the EMI filter board.

It generates all the auxiliary voltages needed by the machine circuits (24Vdc and 40Vdc).


It also provides, after checking the correctness of the input voltage supply applied to the machine, the OK, to the three relays that are located on the EMI filter, to close.

It also communicate via RS232 to the control board informing about the status of the input line.

When the machine ON/OFF switch is closed the AC input voltage (L1,L3) is applied to the Voltage Supply Board. Input voltage is verified and if correct (+/- 10%) micro controller gives command to close K1,K2,K3 relays on EMI filter.

After few milliseconds another command is generated from the Voltage Supply Board to close the relay RL1A on the Inverter Board, the contact of this relay by pass the PTC needed to provide a soft charge to the DC BUS capacitors.

# CONTROL BOARD



## CONTROL BOARD (Y042-1 or Y042-2)

The Control Board performs the primary interfacing functions to establish and maintain output control of the POWERTEC i250C or i320C machines.

Digital user command signals from the UI and feedback information are received and processed by the Control Board.

Software loaded in the Control Board processes the command and feedback information and sends the appropriate pulse width modulation (PWM) signals to the Inverter board IGBTs.


The Control Board is supplied by 40VDC generated by the Voltage Supply Board (Y047-1).

In addition, the Control Board performs the following functions:

- monitors output current
- monitors the thermostats status
- supply the fans
- supply the gas solenoid
- supply the wire drive motor

**NOTE=** The Y042-2 board does not have a remote controls components mounted (push-pull driver, analog input, ext. trigger)

# INVERTER AND MAIN TRANSFORMER



## INVERTER AND MAIN TRANSFORMER

When the DC Bus capacitors are fully charged they act as power supplies for the IGBT switching circuit.

The IGBT switch the DC power from the DC Bus capacitors "on and off," thus supplying pulsed DC current to the main transformer primary winding.

The full bridge inverter switching frequency is 34KHz.

Current transducer located on the inverter board monitor the primary current. If the primary current become abnormally high, the control board circuit will shut off the IGBTs, thus disabling the machine's output.

A thermal protector is also present, to the inverter heat-sink, to protect the IGBTs from overheating conditions.

The main transformer insulate the primary circuit from the secondary circuit; this secondary winding supplies the welding voltages and the welding currents.

This high current winding is capable of supplying maximum output current during the welding process.

## OVERLOAD PROTECTION

POWERTEC i250C and i320C are electrically protected from producing higher than normal output current. An electronic protection circuit limits the current to within the capabilities of the machine.

## THERMAL PROTECTION

There are two thermal devices located on the output diodes heat-sink; one on the main transformer and one on the IGBT heatsink of the inverter board. They protect the machine from excessive operating temperature. Excessive temperature may be caused by a lack of cooling air or by operating the machine beyond the duty cycle and output rating. If excessive

operating temperature should occur, the Thermal Overload indicator on the front panel, will turn ON and the thermostat will prevent output current. One PTC is also mounted on the output diodes heatsink to monitor the ambient temperature, if the temperature rise up, the control board will increase the fans speed.

The thermal protection devices are self-resetting once the machine cools sufficiently. If the shutdown was caused by excessive output or duty cycle and the fan is operating normally, the power switch may be left on and the reset should occur within about 8-10 minutes period. If the fan is not turning or the air intake louvers are obstructed, the input power must be removed and the fan problem or air obstruction must be corrected.

---


## INSULATED GATE BIPOLAR TRANSISTOR (IGBT) OPERATION

An IGBT is a type of transistor. IGBTs are semiconductors well suited for high frequency switching and high current applications. Drawing A shows an IGBT in a passive mode. There is no gate signal, zero volts relative to the source, and therefore, no current flow. The drain terminal of the IGBT may be connected to a voltage supply; but since there is no conduction the circuit will not supply current to components connected to the source. The circuit is turned off

like a light switch in the OFF position.

Drawing B shows the IGBT in an active mode. When the gate signal, a positive DC voltage relative to the source, is applied to the gate terminal of the IGBT, it is capable of conducting current. A voltage supply connected to the drain terminal will allow the IGBT to conduct and supply current to circuit components coupled to the source. Current will flow through the conducting IGBT to downstream components as long as the positive gate signal is present. This is similar to turning ON a light switch.

## IGBT





## **TROUBLESHOOTING AND REPAIR SECTION**

---

- How to use troubleshooting Guide
- Troubleshooting Guide
- Side panels removal and capacitor discharge procedure

# HOW TO USE TROUBLESHOOTING GUIDE

---

Service and repair should be performed by only Lincoln Electric Factory Trained Personnel. Unauthorized repairs performed on this equipment may result in danger to the technician and machine operator and will invalidate your factory warranty. For your safety and to avoid Electrical Shock, please observe all safety notes and precautions detailed throughout this manual.

.....

This Troubleshooting Guide is provided to help you locate and repair possible machine malfunctions. Simply follow the three-step procedure listed below.

**Step 1. LOCATE PROBLEM (SYMPTOM).** Look under the column labeled "PROBLEMS". This column describes possible symptoms that the machine may exhibit. Find the listing that best describes the symptom that the machine is exhibiting. Symptoms are grouped into three main categories: Output Problems, Function Problems, and LED Function Problems.

**Step 2. PERFORM EXTERNAL TESTS.** The second column, labeled "CHECKS", lists the obvious external possibilities that may contribute to the machine symptom. Perform these tests/checks in the order listed. In general, these tests can be conducted without removing the case wrap-around cover.

**Step 3. PERFORM COMPONENT TESTS.** The last column, labeled "RECOMMENDED COURSE OF ACTION " lists the most likely components that may have failed in your machine. It also specifies the appropriate test procedure to verify that the subject component is either good or bad. If there are a number of possible components, check the components in the order listed to eliminate one possibility at a time until you locate the cause of your problem.

All of the referenced test procedures referred to in the Troubleshooting Guide are described in detail at the end of this chapter. Refer to the Troubleshooting and Repair Table of Contents to locate each specific Test Procedure. All of the referred to test points, components, terminal strips, etc., can be found on the referenced electrical wiring diagrams and schematics. Refer to the Wiring Diagrams Section Table of Contents to locate the appropriate diagram.

## WARNING



**ELECTRIC SHOCK** can kill

- Have an electrician install and service this equipment
- Turn the input power off at the fuse box before working on equipment
- Do not touch electrically hot parts
- Prior to performing preventive maintenance, perform the following capacitor discharge procedure to avoid electric shock

---

Sometimes machine failures appear to be due to PC board failures. These problems can sometimes be traced to poor electrical connections. To avoid problems when troubleshooting and replacing PC boards, please use the following procedure:

1. Determine to the best of your technical ability that the PC board is the most likely component causing the failure symptom.
2. Check for loose connections at the PC board to assure that the PC board is properly connected.
3. If the problem persists, replace the suspect PC board using standard practices to avoid static electrical damage and electrical shock.

4. Test the machine to determine if the failure symptom has been corrected by the replacement PC board.

**NOTE:** Allow the machine to heat up so that all electrical components can reach their operating temperature.

5. Remove the replacement PC board and substitute it with the original PC board to recreate the original problem.
  - If the original problem does not reappear by substituting the original board, then the PC board was not the problem. Continue to look for bad connections in the control wiring harness, junction blocks, and terminal strips.
  - If the original problem is recreated by the substitution of the original board, then the PC board was the problem. Reinstall the replacement PC board and test the machine.
6. Always indicate that this procedure was followed when warranty reports are to be submitted.

**NOTE:** Following this procedure and writing on the warranty report, "INSTALLED AND SWITCHED PC BOARDS TO VERIFY PROBLEM," will help avoid denial of legitimate PC board warranty claims.

# TROUBLESHOOTING

**!! WARNING !! BEFORE CONNECT POWER SUPPLY, MAKE A CAREFUL VISUAL INSPECTION INSIDE THE MACHINE , CHECK ALL THE BOARDS AND HARNESES.**

PROBLEMS / SYMPTOMS	POSSIBLE AREAS OF MISADJUSTMENT(S)	CHECKS	RECOMMENDED COURSE OF ACTION
THE LINE CIRCUIT BREAKER TRIPS WHEN MACHINE ON/OFF SWITCH IS MOVED TO "ON"	<ul style="list-style-type: none"> <li>INPUT RECTIFIER BRIDGE IS IN SHORT CIRCUIT</li> <li>DC BUS CAPACITORS FAILURE</li> <li>IGBTs SHORT CIRCUITED</li> </ul>	<ul style="list-style-type: none"> <li>PERFORM THE INPUT RECTIFIER BRIDGE AND INVERTER BOARD RESISTANCE TEST</li> </ul>	<ul style="list-style-type: none"> <li>REPLACE THE INPUTC RECTIFIER BRIDGE OR THE INVERTER BOARD</li> </ul>
THE MACHINE IS DEAD, NO LIGHTS, NO DISPLAY, NO OUTPUT	<ul style="list-style-type: none"> <li>THERE IS NO POWER SUPPLY ON INPUT LINE</li> <li>THE INPUT POWER SUPPLY CABLE IS INTERRUPTED</li> <li>THE EMI FILTER IS DAMAGED</li> <li>LINE SWITCH FAILURE</li> <li>THE VOLTAGE SUPPLY BOARD IS DAMAGED</li> </ul>	<ul style="list-style-type: none"> <li>CHECK THE PHASE INPUT VOLTAGE ON THE MACHINE</li> <li>CHECK THE INPUT POWER SUPPLY CABLE</li> <li>PERFORM THE EMI FILTER BOARD RESISTANCE AND VOLTAGE TEST</li> <li>CHECK THE LINE SWITCH</li> <li>PERFORM THE VOLTAGE SUPPLY BOARD TEST</li> </ul>	<ul style="list-style-type: none"> <li>RECONNECT THE POWER SUPPLY</li> <li>REPLACE THE INPUT POWER CABLE</li> <li>REPLACE THE EMI FILTER BOARD</li> <li>REPLACE THE LINE SWITCH</li> <li>REPLACE THE VOLTAGE SUPPLY BOARD</li> </ul>
THERMAL INDICATOR LIT (ON) ON USER INTERFACE (UI)	<ul style="list-style-type: none"> <li>ONE OF THE THERMAL PROTECTIONS HAVE TRIPPED.</li> </ul>	<ul style="list-style-type: none"> <li>WAIT THE MACHINE TO COOL, THE RESET SHOULD OCCUR WITHIN ABOUT 8-10 MINUTES</li> <li>CHECK FANS AND THERMAL PROTECTION CIRCUIT</li> </ul>	<ul style="list-style-type: none"> <li>REPLACE THE DEFECTIVE FAN</li> <li>REPLACE THE BOARD /ASSEMBLY WHERE THE FAULTY THERMAL SENSOR IS MOUNTED</li> </ul>
THERE IS NO WIRE FEED WHEN THE TRIGGER IS ACTIVATED. OPEN CIRCUIT VOLTAGE IS PRESENT AND GAS SOLENOID WORKS PROPERLY	<ul style="list-style-type: none"> <li>IF THE DRIVE ROLL IS TURNING A MECCANICAL RESTRICTION IN THE WIRE FEED PATH CAN BE THE CAUSE</li> <li>THE GUN LINER MAY BE CLOGGED</li> <li>THE DRIVE ROLL IS NOT TURNING</li> </ul>	<ul style="list-style-type: none"> <li>CHECK THE WIRE FEED PATH FOR MECCANICAL RESTRICTION/PROBLEMS</li> <li>CHECK THE GUN LINER</li> <li>CHECK THE DRIVE ROLL PRESSURE</li> <li>PERFORM THE CONTROL BOARD VOLTAGE TEST</li> </ul>	<ul style="list-style-type: none"> <li>REMOVE ANY POSSIBLE RESTRICTION</li> <li>REPLACE THE GUN LINER</li> <li>SET THE CORRECT DRIVE ROLLS PRESSURE</li> <li>REPLACE THE WIRE DRIVE MOTOR OR CONTROL BOARD</li> </ul>
THE ARC IS UNSTABLE	<ul style="list-style-type: none"> <li>THE CONTACT TIP MAY BE WORN</li> <li>BAD OR LOOSE CONNECTIONS ON THE WORK OR GUN CABLE</li> <li>WELDING POLARITY MAY IS NOT CORRECT FOR THE PROCESS BEING USED</li> <li>WELDING WIRE MAY BE RUSTED OR DIRTY</li> </ul>	<ul style="list-style-type: none"> <li>CHECK THE STATUS OF THE CONTACT TIP</li> <li>CHECK THE STATUS OF THE WORK AND GUN CABLE</li> <li>CHECK THE WELDING POLARITY</li> <li>CHECK THE CONDITION OF THE WELDING WIRE</li> </ul>	<ul style="list-style-type: none"> <li>REPLACE THE CONTACT TIP IF WORN</li> <li>REPLACE THE WORK CABLE OR TORCH</li> <li>CHANGE THE POLARITY ACCORDINGLY TO THE USED PROCESS</li> <li>REPLACE THE WELDING WIRE IF DIRTY OR RUSTED</li> </ul>
POROSITY ARE PRESENT ON WELD BEAD	<ul style="list-style-type: none"> <li>WELDING POLARITY MAY IS NOT CORRECT FOR THE PROCESS BEING USED</li> <li>SHIELDING GAS OR FLOW MAY IS NOT CORRECT</li> <li>THE WELDING JOINT IS CONTAMINATED</li> </ul>	<ul style="list-style-type: none"> <li>CHECK THE WELDING POLARITY</li> <li>CHECK THE SHIELDING GAS OR THE GAS FLOW</li> <li>CHECK THE WELDING JOINT, FOR OIL, RUST OR ANY OTHER CONTAMINATIONS</li> </ul>	<ul style="list-style-type: none"> <li>CHANGE THE POLARITY ACCORDINGLY TO THE USED PROCESS</li> <li>CHANGE THE GAS TYPE OR FLOW RATE</li> <li>CHECK THE GAS CIRCUIT FOR LOOSEN CONNECTIONS OR BROKEN TUBE</li> <li>CLEAN THE JOINT</li> </ul>
THERE IS NO GAS FLOW WHEN GUN IS TRIGGER IS PULLED. WIRE FEEDS AND WELD VOLTAGE IS PRESENT	<ul style="list-style-type: none"> <li>THE GAS BOTTLE MAY BE EMPTY</li> <li>THE GAS HOSE MAY BE BROKEN</li> </ul>	<ul style="list-style-type: none"> <li>CHECK GAS SOURCE AND HOSES FOR LEAKS OR KINKS</li> <li>CHECK GAS REGULATOR ON THE BOTTLE FOR THE PRESSURE BEING SET TO HIGH</li> <li>THE GAS SOLENOID MAY BE FAULTY</li> <li>THE CONTROL BOARD MAY BE FAULTY</li> </ul>	<ul style="list-style-type: none"> <li>REPLACE THE GAS BOTTLE</li> <li>REPLACE THE GAS HOSE</li> <li>REDUCE THE PRESSURE OF THE GAS REGULATOR</li> <li>REPLACE THE GAS SOLENOID</li> <li>REPALCE THE CONTROL BOARD</li> </ul>

# SIDE PANELS REMOVAL AND DC BUS CAPACITORS DISCHARGE PROCEDURE

---

## WARNING

Service and repair should be performed only by Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact your Local Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed.

.....


## DESCRIPTION

This procedure will aid the technician in the removal and replacement of the left and right metal panels and discharging the DC Bus capacitors making it safe for the technician to work on the machine.

## MATERIALS NEEDED

Torx T25 wrench

## POWERTEC i250C & i320C – SIDE PANELS COVER REMOVAL



### Necessary tool:

- Torx T25 wrench

### Procedure:

1. Turn ON/OFF switch to OFF position.
2. Disconnect Input Power from the machine !
3. Remove the 4 screws (A) from the left and right side panel. **See Figure 1**
4. Remove the 2 screws (B) one from the right and one from the left side panel. **See Figure 2**
5. Open the half right side panel and remove the screw (C). **See Figure 2**
6. Remove the left and right panel sliding them to the back of the machine
7. Follow the next session to **perform the discharge procedure**

# DISCHARGE PROCEDURE

## WARNING



**ELECTRIC SHOCK** can kill

Have an electrician install and service this equipment  
Turn the input power off at the fuse box before working on equipment

Do not touch electrically hot parts

Prior to performing preventive maintenance, perform the following capacitor discharge procedure to avoid electric shock.

## DC BUS CAPACITOR DISCHARGE PROCEDURE

1. Remove main input power to the POWERTEC i250C or i320C.
2. Remove the left side panel following the case removal procedure available in this Service manual.
3. The capacitors are discharged by discharge resistors integrated into the main board in about 2 (two) minutes.
4. Locate the terminals **POS** and **NEG** on the Inverter board, **See Figure 1**.
5. Connect your multi-meter positive probe to **POS** terminal point and your negative probe to **NEG** terminal and check the voltage.
6. In case of presence of residual voltage follow the next steps
7. Obtain a high resistance and high wattage resistor (500-1000 ohms and 25 watts minimum). This resistor is NOT supplied with the machine. NEVER USE A SHORTING STRAP FOR THIS PROCEDURE.
8. Use electrically insulate gloves and insulated pliers. Hold the body of the resistor and connect the resistor leads across the two points POS and NEG. **See Figure 1**. Hold the resistor in place for 10 seconds. DO NOT TOUCH CAPACITOR TERMINALS WITH YOUR BARE HANDS.
9. Check again the voltage across the two terminals. Voltage should be zero. If any voltage remains, repeat this procedure.




Figure 1

# EMI FILTER BOARD RESISTANCE TEST

---

## WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual. If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact your Local Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed.

.....

### TEST DESCRIPTION


This test will determine if the EMI Filter Board (Y051-1) is good or defect.

### MATERIALS NEEDED

Volt / Ohmmeter



## EMI FILTER BOARD RESISTANCE TEST (continued)



### TEST PROCEDURE

1. Remove main input power to the POWERTEC i250C or i320C.
2. **WARNING !** EMI filter is directly connected to the main line, be sure to have the plug removed from the mains !
3. The following tests can be performed without removing the EMI filter from the machine, just disconnect all cables from points **X3,X4,X5,X6,X7,X8** and connectors **X1,X2** from it.
4. Visually check for burned or damaged components. If any components are physically damaged the EMI filter board has to be replaced.
5. Using the Volt-Ohmmeter (ohm mode) perform the tests following the below table test:

**EMI Filter Board - Table tests 1**

<i>Positive Probe (RED)</i>	<i>Negative Probe (BLACK)</i>	<i>Value</i>
X3	X4	OPEN
X4	X5	OPEN
X3	X5	OPEN
X6	X7	OPEN
X7	X8	OPEN
X6	X8	OPEN
X3	X6,X7,X8	OPEN
X4	X6,X7,X8	OPEN
X5	X6,X7,X8	OPEN
X3	X1/5	0 OHMS
X5	X1/3	0 OHMS
X6	X2/1	0 OHMS
X7	X2/8	0 OHMS
X8	X2/3	0 OHMS

# INPUT RECTIFIER BRIDGE RESISTANCE TEST

---

## WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual. If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact your Local Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed.

.....


### TEST DESCRIPTION

This test will determine if the Input Rectifier Bridge has failed.

### MATERIALS NEEDED

Volt / Ohmmeter  
Machine Wiring Diagram

# INPUT RECTIFIER BRIDGE RESISTANCE TEST (continued)



## TEST PROCEDURE

1. Remove main input power to the POWERTEC i250C or i320C.
2. Perform the **Discharge procedure**
3. Disconnect the cables 104 and 105 from the POS and NEG rectifier bridge terminals
4. Using the Volt-Ohmmeter (diode test mode) check the Input Rectifier **V1** (see **Table tests 1**)

Input Bridge V1 - Table tests 1

Positive Probe (RED)	Negative Probe (BLACK)	Value
AC1	+	0.3V - 0.7V
AC2	+	0.3V - 0.7V
AC2	+	0.3V - 0.7V
+	AC1	OPEN
+	AC2	OPEN
+	AC3	OPEN
-	AC1	0.3V - 0.7V
-	AC2	0.3V - 0.7V
-	AC3	0.3V - 0.7V
AC1	-	OPEN
AC2	-	OPEN
AC3	-	OPEN

# INVERTER BOARD RESISTANCE TEST

---

## WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual. If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact your Local Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed.

.....



### TEST DESCRIPTION

This test will determine if the Inverter board has failed.

### MATERIALS NEEDED

Volt / Ohmmeter  
Machine Wiring Diagram

## INVERTER BOARD RESISTANCE TEST (continued)



### TEST PROCEDURE

1. Remove main input power to the POWERTEC i250C or i320C.
2. Perform the **Discharge procedure**
3. Without disconnect any cables check Inverter IGBT **Q2,Q3,Q5,Q6,Q8,Q9,Q11 and Q12**, using the Volt-Ohmmeter (diode test mode), following the **Table tests 2**
4. Check the **NTC1** value using the ohmmeter, correct value is 11Kohms +/- 15%

**IGBT Q2,Q3,Q5,Q6,Q8,Q9,Q11,Q12 - Table tests 2**

Positive Probe (RED)	Negative Probe (BLACK)	Value
Emitter (E)	Collector (C)	0.3V - 0.7V
Collector (C)	Emitter (E)	OPEN
Emitter (E)	Gate (G)	0.15V - 0.4V

# OUTPUT RECTIFIER MODULES RESISTANCE TEST

---

## WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual. If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact your Local Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed.

.....


### TEST DESCRIPTION

This test will help determine if the output diode modules are functioning correctly.

### MATERIALS NEEDED

Volt / Ohmmeter  
Machine Wiring Diagram  
13 mm wrench

## OUTPUT RECTIFIER MODULES RESISTANCE TEST (continued)



### TEST PROCEDURE

1. Remove main input power to the POWERTEC i250C or i320C.
2. Perform the Discharge procedure
3. Locate the output diodes module on the right side of the machine
4. Visually check for burned or damaged components. If any components are physically damaged should be replaced.
5. Using a 13mm wrench remove the cables (A) and (B) as shown in the above picture.
6. Using the multi-meter in diode test mode check each rectifier module following the table tests below:

Output diode module Test – Table test 3

Positive Probe (RED)	Negative Probe (BLACK)	Value
1	2	0,3V-0,4V
2	1	OPEN
2	3	OPEN
3	2	0,3V-0,4V

7. To check the correct value of the PTC V1, disconnect the connector (C) and measure in ohm mode, correct value has to be 11Kohms +/- 15%

# EMI FILTER BOARD VOLTAGE TEST

---

## WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual. If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact your Local Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed.

.....

## TEST DESCRIPTION


This test will help to determine if the input voltage applied to the EMI filter is passing through it and arrive correctly to the main board.

## MATERIALS NEEDED

Volt/Ohmmeter  
Machine Wiring Diagram



## EMI FILTER BOARD VOLTAGE TEST (continued)



### TEST PROCEDURE

**⚠ Use always electrically insulate gloves during this test procedure**

1. Remove main input power to the POWERTEC i250C or i320C.
2. Follow the case removal procedure available in this Service Manual
3. Apply 400 Vac +/- 10% to the POWERTEC i250C or i320C.
4. **WARNING!** EMI filter is connected before the machine ON/OFF switch !
5. Check between EMI filter input voltage points **X3, X4 and X5** for 400Vac +/- 10% and between EMI output points **X6, X7, X8** also for 400Vac +/- 10%
6. Check also other voltages as per the following Table tests:

#### **X1: EMI filter Board to ON/OFF Switch**

Pin #	Description	Value	Notes
3	To ON/OFF switch	400Vac +/- 10%	Always also when switch is to OFF position
5			

#### **X2: EMI Filter Board to Voltage Supply Board**

Pin #	Description	Value	Notes
1	Power supply to Voltage Supply Board	400Vac between each of the three pins	Only after mains switch is ON
3			
8			
5	Power supply for relays K1,K2,K3	+ 24Vdc +/-10%	When Mains switch is to ON
6			

# VOLTAGE SUPPLY BOARD TEST

---

## WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual. If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact your Local Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed.

.....

## TEST DESCRIPTION

This test will help to determine if the correct input voltages are applied to the voltage supply board and also if the correct regulated voltages are being processed by the board.


## MATERIALS NEEDED

Volt/Ohmmeter  
Machine Wiring Diagram

# VOLTAGE SUPPLY BOARD TEST (continued)

## ⚠ WARNING

DO NOT CONNECT THE SAME SCOPE GROUND BETWEEN HIGH SIDE AND LOW SIDE



## TEST PROCEDURE

⚠ Use always electrically insulate gloves during this test procedure

1. Remove main input power to the POWERTEC i250C or i320C.
2. Follow the case removal procedure available in this Service Manual
3. Apply 400 Vac +/- 10% to the POWERTEC i250C or i320C.
4. Turn the machine mains switch to ON position
5. Follow the below tables tests:

### X1: Voltage Supply Board to EMI Filter

Pin #	Description	Value	Notes
1	Power supply to Voltage Supply Board	400Vac between each of the three pins	Only after mains switch is ON
3			
5			
7	Power supply for relays K1,K2,K3	+ 24Vdc +/-10%	When Mains switch is to ON
9			

### X4: Voltage Supply Board to Inverter Board (pin 6 is the GND)

Pin #	Description	Value	Notes
3	Inverter supply	+24 Vdc +/-10%	When Mains switch is to ON
6			
6	NTC1	+2,3 Vdc +/-10%	Normal condition , no over temperature condition
5			
6	RL1A power supply	+5Vdc +/-10%	After about 2 seconds after machine switch ON. Before the 2 seconds the value is 0 (zero) volt. It is the power supply for the relay RL! That is by-pass the capacitors pre-charge PTC
4			

### X6: Voltage Supply Board to Control Board

Pin #	Description	Value	Notes
1	Power supply to Control Board	+40Vdc +/- 0,1V	Power supply generated by the Voltage supply board for the Control Board
4			

# CONTROL BOARD VOLTAGE TEST

---

## WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual. If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact your Local Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed.

.....



## TEST DESCRIPTION

This test will help to determine if the correct input voltage is being applied to the control board and if it may be faulty.

## MATERIALS NEEDED

Volt/Ohmmeter  
Machine Wiring Diagram

# CONTROL BOARD TEST (continued)



## TEST PROCEDURE

⚠ **Use always electrically insulate gloves during this test procedure**

1. Remove main input power to the POWERTEC i250C or i320C.
2. Follow the case removal procedure available in this Service Manual
3. Apply 400 Vac +/- 10% to the POWERTEC i250C or i320C.
4. Turn the machine mains switch to ON position
5. Follow the below tables tests

### LEDs Table

LED	Description	Status	Notes
V301	+24 Vdc	Always ON GREEN	It indicates that the 24Vdc is present
V112	Status of the control board	Always ON (GREEN) if machine status is OK	Lit green steadily when machine became configured correctly, pulsating green with period 100 ms when lack of UI
V416 & V417	Standard Arclink LEDs as in every Arclink control board	V416 has to be green if machine status is OK. V417 has to be OFF	In case of machine error they start blinking V416 green and V417 RED providing together the error code number (Lincoln Standard error codes)
V320	3,3V dc	Always ON (GREEN)	It indicates that the 3,3 V dc is present
V519	Remote supply voltage	Always ON (GREEN)	It indicates that the remote voltage supply is present

### X11: Voltage Supply Board to Control Board (pin 6 is GND)

Pin #	Description	Value	Notes
5	Power supply to Control Board	+40Vdc +/- 0,1V	Power supply generated by the Voltage supply board for the Control Board
6			

### X7: Control Board to Gas Purge Switch

Pin #	Description	Value	Notes
8	Gas Purge	+15 Vdc +/-10%	When Gas purge switch is pressed the voltage drops to 0 (zero)
3			
8	Cold inch	+15 Vdc +/-10%	When cold inch switch is pressed the voltage drops to 0 (zero)
5			

### X12: Control Board to User Interface (pin 3 is GND)

Pin #	Description	Value	Notes
3	Power supply to UI	+40Vdc +/- 0,1V	Power supply generated by the Voltage supply board for the UI
4			

### X20: Control Board to Current transducer (use pin 4 is GND)

Pin #	Description	Value	Notes
1	Power supply	+15Vdc +/- 10%	Positive voltage supply for the current transducer
2	Power supply	-15Vdc +/- 10%	Negative voltage supply for the current transducer
3	Current feedback	Different values linked to the welding current	Welding current transducer feedback to control board

# CONTROL BOARD TEST (continued)

## X4: Control Board to LEDS


Pin #	Description	Value	Notes
7 10	Power supply for the internal LEDS	+24 Vdc +/- 10%	Always present

## X1: Control Board to Gas Solenoid

Pin #	Description	Value	Notes
1 2	Gas solenoid power supply	+22,5 Vdc +/- 10%	This is a PWM signal and the reading can be different from multimeter to multimeter, it is recommended to use the oscilloscope to perform this test -> see picture below

Gas Solenoid coil resistance is 50-60 ohms (with cables disconnected)



### Gas Solenoid Power supply: Oscilloscope reading



## X10: Control Board to Wire Drive Motor

Pin #	Description	Value	Notes
1 2	Wire Drive motor Power supply	2m/min = 2,9 Vdc 10 m/min = 12,5 Vdc 20 m/min = 25Vdc	This is a PWM signal, the reading can be different from multimeter to multimeter, it is recommended to use the oscilloscope to perform this test -> see pictures below

Motor coil resistance (with connector X10 disconnected) is 2-3 ohms



# INVERTER BOARD VOLTAGE TEST

---

## WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual. If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact your Local Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed.

.....


## TEST DESCRIPTION

This test will help to determine if the main inverter board is receiving the correct input voltages and if the correct regulated voltages are being processed and maintained by the inverter.

## MATERIALS NEEDED

Volt/Ohmmeter  
Machine Wiring Diagram

## INVERTER BOARD TEST (continued)



### TEST PROCEDURE


**⚠ Use always electrically insulate gloves during this test procedure**

1. Remove main input power to the POWERTEC i250C or i320C.
2. Follow the case removal procedure available in this Service Manual
3. Apply 400 Vac +/- 10% to the POWERTEC i250C or i320C.
4. Turn the machine mains switch to ON position
5. Follow the below tables tests

#### JC2: Inverter Board to Control Board

Pin #	Description	Value	Notes
1	Inverter circuit power supply	+ 24 Vdc +/- 10%	Generated by the Voltage supply Board
2			
1	Thermal sensor signal	+ 2,3 Vdc +/- 10%	ON/OFF thermal sensor signal
4			
1	Power Relay RL1A	+5 Vdc after 2 seconds from power up, before this time value is 0 (zero)	Control signal for the power Relay RL1A
5			


Gate Signal to each single IGBT:





# DISASSEMBLY OPERATIONS

## USER INTERFACE BOARD REMOVAL AND REPLACEMENT PROCEDURE




### **REMOVAL COMMON PROCEDURE for *STANDARD and ADVANCED VERSION***


#### **Necessary tool:**

- Torx T25 wrench
- 2mm allen wrench
- 10 and 14 mm wrench

1. Remove main input power to the POWERTEC i250C or i320C
2. Open the left and right side panel of the machine following the case cover removal procedure.
3. **WARNING!** EMI filter is connected before the machine ON/OFF switch! Be sure to have disconnected the machine plug from the power supply.
4. Using the T25 torx wrench remove the 8 screws (A). **See Figure 1**



5. Using the T25 torx wrench remove the 2 screws (B) on the top of the handle. **See Figure 2**




6. Using the T25 torx wrench remove the 2 screws (C) on the front of the handle. **See Figure 3**
7. Remove the plastic handle and the two rubber side parts (D). **See Figure 1**


# DISASSEMBLY OPERATIONS (continue)

## USER INTERFACE BOARD REMOVAL AND REPLACEMENT PROCEDURE

Use 2 mm Allen wrench to loosen the screw from the two knobs




8. For the **STANDARD** version (see below) use a 10 mm wrench to remove the two encoder nuts (A)



9. For **ADVANCED** version (see below) use a 14 mm wrench to remove the two encoder nuts (A)



10. Using the T25 torx wrench remove the 4 screws (B) that still hold the front panel in place




11. Remove the plastic front panel from the machine.


# DISASSEMBLY OPERATIONS (continue)

## USER INTERFACE BOARD REMOVAL AND REPLACEMENT PROCEDURE

### USER INTERFACE REMOVAL PROCEDURE FOR STANDARD VERSION



1. Using the PH02 Phillips screwdriver remove the 4 screws (**A**) that are fixing the UI frame to the machine front panel




2. Using the PH02 Phillips screwdriver remove the 4 screws (**B**) that are fixing the UI board to the plexiglass frame.
3. Disconnect the harness from the connector X100 and remove the UI board.
4. **For the UI board re-assembly operations, make the previous steps in the reverse order.**


# DISASSEMBLY OPERATIONS (continue)

## USER INTERFACE BOARD REMOVAL AND REPLACEMENT PROCEDURE

### USER INTERFACE REMOVAL PROCEDURE FOR ADVANCED VERSION





1. Using the PH02 Phillips screwdriver remove the 4 screws (**A**) that are fixing the UI frame to the machine front panel



2. Using the PH02 Phillips screwdriver remove the 4 screws (**B**) that are fixing the UI board to the plexiglass frame.
3. Disconnect the harness from the connector X1, and the USB cable (**C**) and remove the UI board.
4. **For the UI board re-assembly operations, make the previous steps in the reverse order**

# DISASSEMBLY OPERATIONS

## GAS SOLENOID REMOVAL AND REPLACEMENT PROCEDURE



### REMOVAL PROCEDURE



#### Necessary tool:

- 17mm wrench
- nippers

1. Remove main input power to the POWERTEC i250C or i320C
2. Open the left and right side panel of the machine following the case cover removal procedure.
3. **WARNING!** EMI filter is connected before the machine ON/OFF switch! Be sure to have disconnected the machine plug from the power supply.
4. Locate the gas solenoid, see picture above.
5. Remove the plastic tie (A) and disconnect the gas pipe from the gas solenoid
6. Remove the harness from the gas solenoid.
7. Disconnect the gas pipe from external part of the gas solenoid
8. Using a 17 mm wrench remove the nut (D) that fix the gas solenoid to the rear panel of the machine.
9. **For the gas solenoid re-assembly operations, make the previous steps in the reverse order.**

# DISASSEMBLY OPERATIONS

## FANS REMOVAL AND REPLACEMENT PROCEDURE



### REMOVAL PROCEDURE

#### Necessary tool:


- Phillips screwdriver PH02
- 8 mm wrench

1. Remove main input power to the POWERTEC i250C or i320C
2. Open the left side panel of the machine following the case cover removal procedure.
3. **WARNING!** EMI filter is connected before the machine ON/OFF switch! Be sure to have disconnected the machine plug from the power supply.
4. Locate the Inverter Board, see **FIGURE 2**.
5. Using a Phillips screwdriver PH2 remove the 4 screws (**A**) and remove the 4 cables.

## DISASSEMBLY OPERATIONS (continue)

### FANS REMOVAL AND REPLACEMENT PROCEDURE


6. Disconnect the two connectors **JC1** and **JC2**.
7. Using a 8 mm wrench remove the 4 nuts (**B**) that fix the inverter board to the machine frame.
8. Remove the inverter board from the machine.



9. Once removed the inverter board you have access to the Fans, see **Figure 3** and **Figure 4**.
10. Using the 8 mm wrench remove the 4 screws (**A**) or (**B**) of the defect fan and disconnect the related connector X3 or X16 from the Control Board, see **Figure 1**.
11. **For the Fan re-assembly operations**, make the previous steps in the reverse order.

# DISASSEMBLY OPERATIONS

## WIRE DRIVE MOTOR AND WIRE DRIVE PLATE REMOVAL AND REPLACEMENT PROCEDURE



### REMOVAL PROCEDURE

#### **Necessary tool:**

- Phillips screwdriver PH02
- 10 mm wrench

1. Remove main input power to the POWERTEC i250C or i320C
2. Open the left side panel of the machine following the case cover removal procedure.
3. **WARNING!** EMI filter is connected before the machine ON/OFF switch! Be sure to have disconnected the machine plug from the power supply.
4. Remove the Euro connector and wire drive metal plate
5. Remove the 3 screws (A), see **Figure 1**
6. Remove the wire drive motor.
7. To remove the wire drive plastic plate (C) remove the 4 screws (B)
8. **For the wire drive motor or wire drive plates re-assembly operations**, make the previous steps in the reverse order.



## RETEST AFTER REPAIR

---

Should a machine under test be rejected for any reason requiring the removal of any mechanical part that could affect the machine's electrical characteristics, or if any electrical components are repaired or replaced, the machine must be retested.

### Machine input and output

#### Powertec i250C STD & ADV

Input Voltage	Input Current	Rated Output
400Vac/3ph/50Hz	14,7A max	250A@60%

Output current range GMAW - FCAW	10 – 250 Amps
----------------------------------	---------------

Output current range SMAW	20 – 250 Amps
---------------------------	---------------

#### Powertec i320C STD & ADV

Input Voltage	Input Current	Rated Output
400Vac/3ph/50Hz	19,6A max	320A@40%

Output current range GMAW - FCAW	10 – 320 Amps
----------------------------------	---------------

Output current range SMAW	20 – 320 Amps
---------------------------	---------------

Maximum Open Circuit Voltage	49 Vdc
------------------------------	--------

### **IMPORTANT !**

After the repair the unit has to be tested accordingly to the norm **EN60974-4 Arc welding equipment “In-service inspection and testing”**


# CALIBRATION PROCEDURE FOR “ADV” VERSION

---

1. Prepare the external reference ammeter (A) and voltmeter (V). Connect a load to output with A and V.
2. Enter to Service Mode: to push the right button /adv: right encoder/ and switch machine on. Release button after end starting.
3. General information: left encoder is used for switch output **on/off** (clockwise: **on**, counter-clockwise: **off**)
4. There are 3 service modes (selected by right encoder and accepted by pushing right button /right encoder/):
  - a) Selecting test modes (**tEst**)
  - b) Voltmeter calibration (**CAL U**)
  - c) Ammeter calibration (**CAL I**)
5. **tEst**: you can select test mode numbers below:
  - a) **200** (CC)
  - b) **201** (CV)
  - c) **202** (CP)
  - d) **212**
6. **CAL U**: you can follow procedure:
  - a) Left display shows **rEF <-> oFF**
  - b) Switch the output on: display shows **rEF <-> on**
  - c) Set reference voltage to ca. 25,0V/200A on external meter by turning right encoder and adjusting load
  - d) Confirm the setting by pushing the right button (right encoder) – machine is switching off
  - e) Switch the output on: display shows **SEt <-> on**
  - f) Set voltmeter value (on right display) to ca. 25,0V by turning right encoder. WARNING: be sure that the setting value is the same as the external reference voltmeter value.
  - g) Confirm the setting value by pushing the right button (right encoder) – machine is switching off
  - h) After that machine goes into the service modes selection (point 4)
7. **CAL I**: you can follow procedure:
  - a) Left display shows **rEF <-> oFF**
  - b) Switch the output on: display shows **rEF <-> on**
  - c) Set reference current to ca. 25,0V/200A on external meter by turning right encoder and adjusting load
  - d) Confirm the setting by pushing the right button (right encoder) – machine is switching off
  - e) Switch the output on: display shows **SEt <-> on**
  - f) Set ammeter value (on right display) to ca. 200A by turning right encoder. WARNING: be sure that the setting value is the same as the external reference ammeter value
  - g) Confirm the setting value by pushing the right button (right encoder) – machine is switching off
  - h) After that machine goes into the service modes selection (point 4)
8. Exit from Service Mode: switch machine off.


# ELECTRICAL SCHEMATICS

## Block Diagram: Powertec i250C – i320C STANDARD



# ELECTRICAL SCHEMATICS

## Block Diagram: Powertec i250C – i320C ADVANCED



## NOTE

---