

# **Operator's Manual**

# **MAGNUM<sup>®</sup> & MAGNUM<sup>®</sup> PRO CURVE 200** GMA GUN and CABLE ASSEMBLY



# THANK YOU FOR SELECTING **A QUALITY PRODUCT BY** LINCOLN ELECTRIC.

#### PLEASE EXAMINE CARTON AND EQUIPMENT FOR DAMAGE IMMEDIATELY

When this equipment is shipped, title passes to the purchaser upon receipt by the carrier. Consequently, claims for material damaged in shipment must be made by the purchaser against the transportation company at the time the shipment is received.

#### SAFETY DEPENDS ON YOU

Lincoln arc welding and cutting equipment is designed and built with safety in mind. However, your overall safety can be increased by proper installation ... and thoughtful operation on your part. DO NOT INSTALL, OPERATE OR REPAIR THIS EQUIPMENT WITHOUT READING THIS MANUAL AND THE SAFETY PRECAUTIONS CONTAINED THROUGHOUT. And, most importantly, think before you act and be careful.

# WARNING

This statement appears where the information must be followed exactly to avoid serious personal injury or loss of life.

# /!\ CAUTION

This statement appears where the information must be followed to avoid minor personal injury or damage to this equipment.

#### **KEEP YOUR HEAD OUT OF THE FUMES.**

DON'T get too close to the arc. Use corrective lenses if necessary to stay a reasonable distance away from the arc.

READ and obey the Safety Data Sheet (SDS) and the warning label that appears on all containers of welding materials.

USE ENOUGH VENTILATION or exhaust at the arc. or both. to

keep the fumes and gases from your breathing zone and the general area.

IN A LARGE ROOM OR OUTDOORS, natural ventilation may be adequate if you keep your head out of the fumes (See below).

**USE NATURAL DRAFTS** or fans to keep the fumes away from your face.

If you develop unusual symptoms, see your supervisor. Perhaps the welding atmosphere and ventilation system should be checked.



#### WEAR CORRECT EYE, EAR & **BODY PROTECTION**

**PROTECT** your eyes and face with welding helmet properly fitted and with proper grade of filter plate (See ANSI Z49.1).

**PROTECT** your body from welding spatter and arc flash with protective clothing including woolen clothing, flame-proof apron and gloves, leather leggings, and high boots.

**PROTECT** others from splatter, flash, and glare with protective screens or barriers.

IN SOME AREAS, protection from noise may be appropriate.

BE SURE protective equipment is in good condition.

Also, wear safety glasses in work area AT ALL TIMES.

#### SPECIAL SITUATIONS

DO NOT WELD OR CUT containers or materials which previously had been in contact with hazardous substances unless they are properly cleaned. This is extremely dangerous.

DO NOT WELD OR CUT painted or plated parts unless special precautions with ventilation have been taken. They can release highly toxic fumes or gases.



#### Additional precautionary measures

**PROTECT** compressed gas cylinders from excessive heat, mechanical shocks, and arcs; fasten cylinders so they cannot fall.

**BE SURE** cylinders are never grounded or part of an electrical circuit.

**REMOVE** all potential fire hazards from welding area.

ALWAYS HAVE FIRE FIGHTING EQUIPMENT READY FOR IMMEDIATE USE AND KNOW HOW TO USE IT.









#### **CALIFORNIA PROPOSITION 65 WARNINGS**

#### **Diesel Engines**

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

#### **Gasoline Engines**

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

#### ARC WELDING CAN BE HAZARDOUS. PROTECT YOURSELF AND OTHERS FROM POSSIBLE SERIOUS INJURY OR DEATH. KEEP CHILDREN AWAY. PACEMAKER WEARERS SHOULD CONSULT WITH THEIR DOCTOR BEFORE OPERATING.

Read and understand the following safety highlights. For additional safety information, it is strongly recommended that you purchase a copy of "Safety in Welding & Cutting -ANSI Standard Z49.1" from the American Welding Society, P.O. Box 351040, Miami, Florida 33135 or CSA Standard W117.2-1974. A Free copy of "Arc Welding Safety" booklet E205 is available from the Lincoln Electric Company, 22801 St. Clair Avenue, Cleveland, Ohio 44117-1199.

BE SURE THAT ALL INSTALLATION, OPERATION, MAINTENANCE AND REPAIR PROCEDURES ARE PERFORMED ONLY BY QUALIFIED INDIVIDUALS.



# FOR ENGINE POWERED EQUIPMENT.

 Turn the engine off before troubleshooting and maintenance work unless the maintenance work requires it to be running.



- 1.b. Operate engines in open, well-ventilated areas or vent the engine exhaust fumes outdoors.
- 1.c. Do not add the fuel near an open flame welding arc or when the engine is running. Stop the engine and allow it to cool before refueling to prevent spilled fuel from vaporizing on contact with hot engine parts and igniting. Do not spill fuel when filling tank. If fuel is spilled, wipe it up and do not s



tank. If fuel is spilled, wipe it up and do not start engine until fumes have been eliminated. 1.d. Keep all equipment safety guards, covers and devices in position and in good repair. Keep hands, hair, clothing and tools away from V-belts, gears, fans and all other moving parts when starting, operating or repairing equipment.



- 1.e. In some cases it may be necessary to remove safety guards to perform required maintenance. Remove guards only when necessary and replace them when the maintenance requiring their removal is complete. Always use the greatest care when working near moving parts.
- 1.f. Do not put your hands near the engine fan. Do not attempt to override the governor or idler by pushing on the throttle control rods while the engine is running.
- 1.g. To prevent accidentally starting gasoline engines while turning the engine or welding generator during maintenance work, disconnect the spark plug wires, distributor cap or magneto wire as appropriate.
- 1.h. To avoid scalding, do not remove the radiator pressure cap when the engine is hot.



## ELECTRIC AND MAGNETIC FIELDS MAY BE DANGEROUS

- 2.a. Electric current flowing through any conductor causes localized Electric and Magnetic Fields (EMF). Welding current creates EMF fields around welding cables and welding machines
- 2.b. EMF fields may interfere with some pacemakers, and welders having a pacemaker should consult their physician before welding.
- 2.c. Exposure to EMF fields in welding may have other health effects which are now not known.
- 2.d. All welders should use the following procedures in order to minimize exposure to EMF fields from the welding circuit:
  - 2.d.1. Route the electrode and work cables together Secure them with tape when possible.
  - 2.d.2. Never coil the electrode lead around your body.
  - 2.d.3. Do not place your body between the electrode and work cables. If the electrode cable is on your right side, the work cable should also be on your right side.
  - 2.d.4. Connect the work cable to the workpiece as close as possible to the area being welded.
  - 2.d.5. Do not work next to welding power source.



### ELECTRIC SHOCK CAN KILL.



- 3.a. The electrode and work (or ground) circuits are electrically "hot" when the welder is on. Do not touch these "hot" parts with your bare skin or wet clothing. Wear dry, hole-free gloves to insulate hands.
- 3.b. Insulate yourself from work and ground using dry insulation. Make certain the insulation is large enough to cover your full area of physical contact with work and ground.

In addition to the normal safety precautions, if welding must be performed under electrically hazardous conditions (in damp locations or while wearing wet clothing; on metal structures such as floors, gratings or scaffolds; when in cramped positions such as sitting, kneeling or lying, if there is a high risk of unavoidable or accidental contact with the workpiece or ground) use the following equipment:

- Semiautomatic DC Constant Voltage (Wire) Welder.
- DC Manual (Stick) Welder.
- AC Welder with Reduced Voltage Control.
- 3.c. In semiautomatic or automatic wire welding, the electrode, electrode reel, welding head, nozzle or semiautomatic welding gun are also electrically "hot".
- 3.d. Always be sure the work cable makes a good electrical connection with the metal being welded. The connection should be as close as possible to the area being welded.
- 3.e. Ground the work or metal to be welded to a good electrical (earth) ground.
- 3.f. Maintain the electrode holder, work clamp, welding cable and welding machine in good, safe operating condition. Replace damaged insulation.
- 3.g. Never dip the electrode in water for cooling.
- 3.h. Never simultaneously touch electrically "hot" parts of electrode holders connected to two welders because voltage between the two can be the total of the open circuit voltage of both welders.
- 3.i. When working above floor level, use a safety belt to protect yourself from a fall should you get a shock.
- 3.j. Also see Items 6.c. and 8.





- 4.a. Use a shield with the proper filter and cover plates to protect your eyes from sparks and the rays of the arc when welding or observing open arc welding. Headshield and filter lens should conform to ANSI Z87. I standards.
- 4.b. Use suitable clothing made from durable flame-resistant material to protect your skin and that of your helpers from the arc rays.
- 4.c. Protect other nearby personnel with suitable, non-flammable screening and/or warn them not to watch the arc nor expose themselves to the arc rays or to hot spatter or metal.

# FUMES AND GASES CAN BE DANGEROUS.



- 5.a. Welding may produce fumes and gases hazardous to health. Avoid breathing these fumes and gases. When welding, keep your head out of the fume. Use enough ventilation and/or exhaust at the arc to keep fumes and gases away from the breathing zone. When welding hardfacing (see instructions on container or SDS) or on lead or cadmium plated steel and other metals or coatings which produce highly toxic fumes, keep exposure as low as possible and within applicable **OSHA PEL and ACGIH TLV limits using local** exhaust or mechanical ventilation unless exposure assessments indicate otherwise. In confined spaces or in some circumstances, outdoors, a respirator may also be required. Additional precautions are also required when welding on galvanized steel.
- 5. b. The operation of welding fume control equipment is affected by various factors including proper use and positioning of the equipment, maintenance of the equipment and the specific welding procedure and application involved. Worker exposure level should be checked upon installation and periodically thereafter to be certain it is within applicable OSHA PEL and ACGIH TLV limits.
- 5.c. Do not weld in locations near chlorinated hydrocarbon vapors coming from degreasing, cleaning or spraying operations. The heat and rays of the arc can react with solvent vapors to form phosgene, a highly toxic gas, and other irritating products.
- 5.d. Shielding gases used for arc welding can displace air and cause injury or death. Always use enough ventilation, especially in confined areas, to insure breathing air is safe.
- 5.e. Read and understand the manufacturer's instructions for this equipment and the consumables to be used, including the Safety Data Sheet (SDS) and follow your employer's safety practices. SDS forms are available from your welding distributor or from the manufacturer.
- 5.f. Also see item 1.b.





- 6.a. Remove fire hazards from the welding area. If this is not possible, cover them to prevent the welding sparks from starting a fire. Remember that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas. Avoid welding near hydraulic lines. Have a fire extinguisher readily available.
- 6.b. Where compressed gases are to be used at the job site, special precautions should be used to prevent hazardous situations. Refer to "Safety in Welding and Cutting" (ANSI Standard Z49.1) and the operating information for the equipment being used.
- 6.c. When not welding, make certain no part of the electrode circuit is touching the work or ground. Accidental contact can cause overheating and create a fire hazard.
- 6.d. Do not heat, cut or weld tanks, drums or containers until the proper steps have been taken to insure that such procedures will not cause flammable or toxic vapors from substances inside. They can cause an explosion even though they have been "cleaned". For information, purchase "Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping That Have Held Hazardous Substances", AWS F4.1 from the American Welding Society (see address above).
- 6.e. Vent hollow castings or containers before heating, cutting or welding. They may explode.
- 6.f. Sparks and spatter are thrown from the welding arc. Wear oil free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes and a cap over your hair. Wear ear plugs when welding out of position or in confined places. Always wear safety glasses with side shields when in a welding area.
- 6.g. Connect the work cable to the work as close to the welding area as practical. Work cables connected to the building framework or other locations away from the welding area increase the possibility of the welding current passing through lifting chains, crane cables or other alternate circuits. This can create fire hazards or overheat lifting chains or cables until they fail.
- 6.h. Also see item 1.c.
- 6.I. Read and follow NFPA 51B "Standard for Fire Prevention During Welding, Cutting and Other Hot Work", available from NFPA, 1 Batterymarch Park, PO box 9101, Quincy, MA 022690-9101.
- 6.j. Do not use a welding power source for pipe thawing.

# CYLINDER MAY EXPLODE IF DAMAGED.

7.a. Use only compressed gas cylinders containing the correct shielding gas for the process used and properly operating regulators designed for the gas and pressure used. All hoses, fittings, etc. should be suitable for the application and maintained in good condition.



- 7.b. Always keep cylinders in an upright position securely chained to an undercarriage or fixed support.
- 7.c. Cylinders should be located:
  - Away from areas where they may be struck or subjected to physical damage.
  - A safe distance from arc welding or cutting operations and any other source of heat, sparks, or flame.
- 7.d. Never allow the electrode, electrode holder or any other electrically "hot" parts to touch a cylinder.
- 7.e. Keep your head and face away from the cylinder valve outlet when opening the cylinder valve.
- 7.f. Valve protection caps should always be in place and hand tight except when the cylinder is in use or connected for use.
- 7.g. Read and follow the instructions on compressed gas cylinders, associated equipment, and CGA publication P-I, "Precautions for Safe Handling of Compressed Gases in Cylinders," available from the Compressed Gas Association, 14501 George Carter Way Chantilly, VA 20151.

# FOR ELECTRICALLY POWERED EQUIPMENT.



- 8.a. Turn off input power using the disconnect switch at the fuse box before working on the equipment.
- 8.b. Install equipment in accordance with the U.S. National Electrical Code, all local codes and the manufacturer's recommendations.
- 8.c. Ground the equipment in accordance with the U.S. National Electrical Code and the manufacturer's recommendations.

#### Refer to http://www.lincolnelectric.com/safety for additional safety information.

Pag	e

Installation	Section A
Safety Precautions	A-1
Connector Kit Installation to Gun Cable	A-1
K466-1	A-1
K466-2	
K466-3	A-1
K466-4	A-1
K466-5	A-1,A-2
Liner Installation	
Contact Tip and Gas Nozzle Installation	A-3
Connector to Feeder	A-3
Connection to Lincoln Feeders	A-3
Connection to Adapter Feeders	A-3
Connection to Miller feeders	A-3
Connection to Hobart feeders	A-3
Connection to L-Tec feeders	A-4

Operation	Section B
Safety Precautions	B-1
General Description	
Electrodes and Equipment	
Making a Weld	В-2
Avoid Wire Feeding Problems	В-2

Maintenance	Section D
Liner Removal	D-1
Removal, Installation and Trimming Installations for K497	D-1
Gun and Tube Nozzles	
Gun Cables	D-1
Cable Cleaning	D-1
Gun Tube End Repair	D-1, D-2
Wire Feeder End Repair	

Troubleshooting	Section E
Safety Precautions	
How to Use Troubleshooting Guide	
Troubleshooting Guide	
5	

Parts List ......parts.lincolnelectric.com

Content/details may be changed or updated without notice. For most current Instruction Manuals, go to parts.lincolnelectric.com.

Read this entire installation section before you start installation.

# **SAFETY PRECAUTIONS**

## A WARNING



#### ELECTRIC SHOCK can kill.

- Have an electrician install and service this equipment.
- Turn the input power off at the fuse box before working on equipment.
- Do not touch electrically hot parts.
- Be sure to discharge capacitors with the procedure outlined in the Maintenance Section of this manual before working in that area of the equipment.

# CONNECTOR KIT INSTALLATION TO GUN CABLE

The MAGNUM® & MAGNUM® PRO CURVE 200 cable is shipped as a generic assembly and must be assembled with either a K466-1, -2, -3, -4 or -5 Connector Kit.

#### K466-1 Installation (For Lincoln Feeders)

- a. Remove brass cable connector and insulation tube (see Figure A.1) from the K466-1 kit. Slide the insulation tube onto the connector from the threaded end and screw it onto the feeder end of the gun cable. Tighten the connection with wrench provided.
- b. Remove the molded gas plug fitting on the side of the feeder end handle and replace it with the barbed brass fitting provided in the kit. The included wrench will fit both the gas plug and barbed fitting.
- c. Attach the round connector of the gun control cable provided to the trigger connector on the front of the Lincoln feeder. **NOTE:** Both the plug and socket are keyed and must be properly oriented.
- d. Place one tubing clamp onto each end of the flexible tubing provided, approximately 2 inch. (51 mm) in from each end. Slide one end of the tubing onto the barbed connector on the feeder end cable handle (step b) and move the clamp down near the end of the tube to assure a good gas seal.

**NOTE:** An optional K481 MAGNUM® Fast-Connect Gas Tube Kit is available to provide tool-less gas tube connection to Lincoln wire feeders. Install per the instructions sent with the kit.

#### K446-2 Installation (For Adapted Feeders)

- a. Remove brass connector (see Figure A-1) from the K466-2 kit and screw it onto the feeder end of the gun cable. Tighten the connection with the wrench provided.
- b. Check that the molded gas plug fitting is sealing the gas fitting hole in the side of the feeder end handle.

#### K446-3 Installation (For Miller Feeders)

- Remove brass cable connector (see Figure A.1) from the K466-3 kit and screw it onto the feeder end of the gun cable. Tighten the connection with the wrench provided.
- b. Check that the molded gas plug fitting is sealing the gas fitting hole in the side of the feeder end handle.
- c. Attach the round connector or the gun control cable provided to the trigger connector on the front of the Miller feeder.

#### K446-4 Installation (For Hobart Feeders)

- Remove brass cable connector (see Figure A.1) from the K466-4 kit and screw it onto the feeder end of the gun cable. Tighten the connection with the wrench provided.
- b. Remove the molded gas plug fitting on the side of the feeder end handle and replace it with the barbed brass fitting provided in the kit. The included wrench will fit both the gas plug and barbed fitting.
- c. Attach the phone plug connector of the gun control cable provided to the trigger connector on the front of the Hobart feeder.
- d. Place one tubing clamp onto each end of the flexible tubing provided, approximately 2 inch. (51 mm) in from each end. Slide one end of the tubing onto the barbed connector on the feeder end cable handle (Step b) and move the clamp down near the end of the tube to assure a good gas seal.

**K446-5 Installation** (For L-Tec Feeders equipped with an L-Tec feeder connector assembly)

- Remove brass cable connector (see Figure A.1) from the K466-5 kit and screw it onto the feeder end of the gun cable. Tighten the connection with the wrench provided.
- b. Check that the molded gas plug fitting is sealing the gas fitting hole in the side of the feeder end handle.

c. For L-Tec machines that require lead connections to made at a terminal strip located within the machine (L-Tec 225), a gun control cable with forked terminals is provided. Connect the terminated leads to the terminal strip. For a machine that requires a twist-lock gun control cable connections, continue to use the L-Tec gun control cable provided with the L-Tec wire feeder connector assembly. Connect the twist-lock plug to the proper receptacle on the machine.

#### LINER INSTALLATION

- a. Lay the gun and cable straight on a flat surface.
- b. Make sure that the set screw in the connector end is backed out so as not to damage liner or liner bushing.
- c. Insert a new untrimmed liner into the connector end of the cable. Be sure the liner bushing is stencilled appropriately for the wire size being used.

#### NOTE: For liners series KP44N and KP45N

Before fully seating the liner bushing, it will be necessary to trim the liner's inner tube flush with the liner bushing using a sharp blade. After triming, remove any burrs from inner tube and insure that the opening is fully open.

 Before installing the gas diffuser, fully seat the liner bushing in the connector and: For K466-1, K466-2, K466-5 and K2950 tighten the set screw in the cable connector.

OR

For K466-3 and K466-4, screw in the connector cap provided in the kit until it seats on the face of the bushing. Then insert the appropriate piece of liner material into the connector cap and tighten the set screw. Three pieces of liner material are included in these connector kits to help guide the electrode through the connector cap. The piece with the smallest inner diameter is designed for .045 inch, (1.2 mm) maximum diameter electrode. The next largest diameter is for 1/16 inch (1.6 mm maximum diameter electrode. The largest diameter piece of liner material is for 5/64 inch (2.0 mm) maximum diameter electrode.

- Be sure the cable is straight and then trim the liner to the length shown in Figure A.1 for K497 or Figure A.2 for K2950. Remove any burrs from the end of the liner.
- f. Screw the gas diffuser onto the end of the gun tube and tighten with the wrench provided.
- g. Tighten the set screw in the side of the gas diffuser against the cable liner using the Allen wrench provided. **Note: Set screw is not found on Gun Handle end of K2950.**

# **CAUTION**

The screw should only be gently tightened. Overtightening will split or collapse the liner and cause poor wire feeding.







#### CONTACT TIP AND GAS NOZZLE INSTALLATION

- a. Choose the correct size contact tip for the electrode being used (wire size is stenciled on the side of the contact tip) and screw it snugly into the gas diffuser.
- b. Be sure the nozzle insulator is fully screwed onto the gas diffuser and does not block the gas holes in the diffuser.
- c. Slip the appropriate gas nozzle onto the nozzle insulator. Either a .62 inch (15.9 mm) or .50" (12.7 mm I.D. slip-on gas nozzle may be used and should be selected based on the welding application.

Choose the gas nozzle as appropriate for the GMAW process to be used. Typically, the contact tip end should be flush to .12 inch (3.1 mm) extended for the short-circuiting transfer process and .12 inch (3.1 mm) recessed for spray transfer. For the Outershield (FCAW) process, 1/4 inch (6.3 mm) recess is recommended.

#### **CONNECTION TO FEEDER**

**Connection to Lincoln Feeders** 

#### **SAFETY PRECAUTIONS**



Gun cable assemblies which were assembled with a K466-1 Connector Kit will connect easily to any Lincoln LN-7, LN-8, LN-9, SP200 or LN-25 feeder.

- a. Check that the drive roll(s) and feeder guide tubes are appropriate for the electrode size being used.
- b. Fully push the brass connector end of the gun cable into the conductor block on the outgoing side of the feeder wire drive. Secure the cable using the hand screw or set screw in the conductor block.
- c. Insert the control cable plug from the feeder trigger circuit into the mating socket on the feeder end cable handle (See K466-1connector kit installation to gun cable in this section).
- d. Slide the free end of the flexible hose onto the barbed gas fitting on the front of the Lincoln feeder (See K466-1 connector kit installation to gun cable in this section) Move the corresponding tubing clamp down near the end of the tube to assure a good gas seal

#### **Connection to Adapted Feeders**

Gun cable assemblies which were assembled with a K466-2 Connector Kit will connect easily to any properly adapted feeder.

- a. Check that the adapter and feeder outgoing guide, as well as the drive roll, are appropriate for the electrode size being used.
- b. Fully push the brass connector end of the gun cable into the brass adapter on the outgoing side of the feeder wire drive. Secure the cable using the hand screw or set screw in the adapter.
- c. Insert the control cable plug from the feeder trigger circuit into the mating socket on the gun cable connector handle.

#### **Connection to Miller Feeders**

Gun and cable assemblies which were assembled with a K466-3 Connector Kit will connect easily to a variety of popular Miller wire feeders.

- a. Check that the gun liner, connector cap liner, drive rolls and guide tubes are appropriate for the electrode size being used. Three different diameter pieces of liner material are included in each kit.
- b. Fully push the brass connector end of the gun and cable into the connector receptacle on the outgoing side of the feeder wire drive. Tighten the hand screw to clamp down on the connector.
- c. Insert the control cable plug from the feeder trigger circuit into the mating socket on the gun cable connector handle.

#### **Connection to Hobart Feeders**

Gun and cable assembles which were assembled with a K466-4 Connector Kit will connect easily to a variety of Hobart wire feeders.

- a. Check that the gun liner, connector cap liner, drive rolls and guide tubes are appropriate for the electrode size being used. These different diameter pieces of liner material are included in each kit.
- b. Fully push the brass connector end of the gun and cable into connector receptacle on the outgoing side of the feeder wire drive. Tighten the hand screw to clamp down on the connector.
- c. Insert the control cable plug from the feeder trigger circuit into the mating socket on the gun cable connector handle.
- d. Slide the free end of the flexible hose (mounted to the gun in K466-4 Installation Section) onto the gas fitting on the Hobart wire feeder. Move the corresponding tubing clamp down near the end of the tube to assure a good gas seal.

#### **Connection to L-Tec Adapted Feeders**

Gun cable assemblies which were assembled with a K466-5 Connector Kit will connect easily to an L-Tec feeder equipped with an L-Tec feeder connector assembly. L-Tec feeders require this connector assembly (similar to a Tweco<sup>®</sup> adapter) to connect with a gun and cable.

- a. Check that the adapter and feeder outgoing guide, as well as the drive roll, are appropriate for the electrode size being used.
- Fully push the brass connector end of the gun cable into the brass adapter on the outgoing side of the feeder wire drive.
   Secure the cable using the hand screw, set screw or pin.
- c. Insert the control cable plug from the feeder trigger circuit into the mating socket on the gun cable connector handle. For machines with a twist-lock trigger lead receptacle, if the L-Tec gun control cable does not easily connect with the socket, the gun control cable that came with the K466-5 kit can be used. To do this, cut off the gun control leads as close to the forked terminals as possible and skin back the leads 7/16 inch (11 mm). Remove the twist-lock plug from the L-Tec control cable and connect it to the K466-5 cable Make sure the outer jacket of the connector is caught within the plug's strain relief.

Read and understand this entire section before operating your machine.

# **SAFETY PRECAUTIONS**

A

## WARNING

#### ELECTRIC SHOCK can kill.



- Do not touch electrically live parts such as output terminals or internal wiring.
- Insulate yourself from the work and ground.
- Always wear dry insulating gloves.



# FUMES AND GASES can be dangerous.

- Keep your head out of fumes.
- Use ventilation or exhaust to remove fumes from breathing zone.



#### WELDING, CUTTING and GOUGING SPARKS can cause fire or explosion

- Keep flammable material away.
- Do not weld, cut or gouge on containers that have held combustibles.



## ARC RAYS

can burn.

 Wear eye, ear and body protection.

Only qualified personnel should operate this equipment. Observe all safety information throughout this manual.

# **GENERAL DESCRIPTION**

The MAGNUM® & MAGNUM® PRO CURVE 200 amp GMA gun and cable assembly has been designed to meet NEMA specification EW3 for welding with steel electrode using the GMAW (gas metal arc welding) and gas-shielded FCAW (flux-cored arc welding) processes: See Table B.1 and Table B.2.

The K497 MAGNUM® & K2950 MAGNUM® PRO CURVE gun is not factory equipped with a feeder end connector. With the K466-1 MAGNUM® Connector Kit, it can be used with any Lincoln LN-7, LN-8, LN-9, SP200 or LN-25 semiautomatic wire feeder. An optional K481 MAGNUM® Fast-Connect Gas Tube Kit is available to provide tool-less gas tube connection to Lincoln wire feeders. Non-GMA model wire feeders require an optional gas solenoid valve.

The K497 gun can also be used with any wire feeder equipped with a Tweco<sup>®</sup> # 1, 2, 3, 350 or 4 wire feed adapter kit by using the K466-2 Adapted Feeder Connector Kit.

A K466-3, Miller Feeder Connector Kit allows connection of the MAGNUM  $\circledast$  & MAGNUM  $\circledast$  PRO CURVE to popular Miller wire feeders.

A K466-4, Hobart Feeder Connector Kit allows connection of the MAGNUM® & MAGNUM® PRO CURVE to popular Hobart wire feeders.

A K466-5, L-Tec Feeder Connector Kit allows connection of the MAGNUM® & MAGNUM® PRO CURVE to popular L-Tec wire feeders.

For best results when welding mild and alloy steels, it is recommended that Lincoln solid wire electrodes be used for the GMAW process and OS71 Lincoln Outershield<sup>®</sup> cored electrodes for the gas-shielded FCAW process.

MAGNUM® 200 200 AMPS AT 60% DUTY CYCLE WITH CO <sub>2</sub> GAS 150 AMPS AT 60% DUTY CYCLE WITH MIXED GAS (TABLE B.1)								
Description Product Number	Gun Cable Length (m)	Wire Size in. (mm)	Contact Tips Standard Duty	Gas Diffuser Assembly	Gas Nozzle	Insulator	Cable Liner	Gun Tube 60°
K497-20	15 ft. (4.5)	.025 (0.6) .030 (0.8)	KP14-25 -30	KP52-23	KP22-50	KP32	KP42-25-15	KP2028-1
K497-2	10 ft. (3.0)	.035 (0.9) .045 (1.2)	KP14-35 -45	KP52	KP22-50	KP32	KP42-4045-15	KP2028-1
K497-6	12 ft. (3.6)	.035 (0.9) .045 (1.2)	KP14-35 -45	KP52	KP22-50	KP32	KP42-4045-15	KP2028-1
K497-1	15 ft. (4.5)	.035 (0.9) .045 (1.2)	KP14-35 -45	KP52	KP22-50	KP32	KP42-4045-15	KP2028-1
K497-21	15 ft. (4.5)	.035 (0.9) .045 (1.2)	KP14-35 -45	KP52	KP22-50	KP32	KP42-4045-15	KP2028-1

#### **OPERATION**

MAGNUM® PRO CURVE 200 200 AMPS AT 60% DUTY CYCLE WITH CO <sub>2</sub> GAS 150 AMPS AT 60% DUTY CYCLE WITH MIXED GAS (TABLE B.2)									
Description Product Number	Gun Cable Length(m)	Wire Size in. (mm)	Contact Tips Heavy Duty	Gas Diffuser Assembly	Gas Nozzle	INSULATOR	Cable Liner	Gun Tube 60°	Feeder** Type
K2950-2-10-45	15 ft. (4.5)	.035 (0.9) .045 (1.2)	KP2744-035 KP2744-045	KP2746-1	KP2742-1-62R	KP2773-2	KP44-3545-15	KP2924-60	Lincoln "10 Series" K466-10
K2950-1	10 ft. (3.1)	.045 (1.2)	KP2744-045	KP2746-1	KP2742-1-62R	KP2773-2	$\mathbf{\mathbf{X}}$	KP2924-60	$\ge$
K2950-2	15 ft. (4.5)	.045 (1.2)	KP2744-045	KP2746-1	KP2742-1-62R	KP2773-2	$\ge$	KP2924-60	$\ge$

\*\* Feeder Kits installed on the gun at the factory.

#### **ELECTRODES AND EQUIPMENT**

The MAGNUM® & MAGNUM® PRO CURVE 200 gun and cable has been designed for use with Lincoln L-50 and Super Arc L-56, solid steel wire electrodes for the GMAW process and Lincoln Outershield® cored electrodes for the gas-shielded FCAW process. Refer to the appropriate Lincoln Process and Procedure Guidelines for the electrode used for information on recommended electrical and visible stickouts.

#### **MAKING A WELD**

- a. Check that the welding power source is on and that the shielding gas supply is set for the proper flow rate.
- b. Position electrode over joint. End of the electrode should be slightly off the work.
- c. Lower welding helmet, close gun trigger and begin welding. Hold the gun so the contact tip to work distance gives the correct electrical stickout as required for the procedure being used.
- d. To stop welding, release the gun trigger and then pull the gun away from the work after the arc goes out. Follow wire feeder instruction manual if using a trigger interlock circuit.

#### **AVOIDING WIRE FEEDING PROBLEMS**

Wire feeding problems can be avoided by observing the following gun handling procedures:

- a. Do not kink or pull cable around sharp corners.
- b. Keep the electrode cable as straight as possible when welding or loading electrode through cable.
- c. Do not allow dolly wheels or trucks to run over cables.
- d. Keep cable clean by following maintenance instructions.
- e. Use only clean, rust-free electrode. The Lincoln electrodes have proper surface lubrication.
- f. Replace contact tip when the arc starts to become unstable or the contact tip end is fused or deformed.

#### LINER REMOVAL AND REPLACEMENT

**NOTICE**: The variation in cable lengths prevents the inter-changeability of liners. Once a liner has been cut for a particular gun, it should not be installed in another gun, unless it can meet the liner cut off length requirement. Liners are shipped with the jacket of the liner extended the proper amount.

# Removal, Installation and Trimming Instruction for K497 & K2950 (with K466 Connector Kit installed)

- a. For gun and cables using a K466-1, K466-2 or K466-5 connector kit, locate and loosen two set screws which are used to hold the old liner in place with a 5/64 inch (2.0 mm) Allen wrench (provided with the connector kit). One set screw is located in the connector at the wire feeder end. The gas nozzle and nozzle insulator must be removed to gain access to the second set screw which is located in the gas diffuser. Note: Set screw is not found on K2950.
- b. For gun and cables using a K466-3 or K466-4 connector kit, remove the connector cap with the wrench provided in the kit. Loosen the set screw located the gas diffuser with the Allen wrench provided in the connector kit. The gas nozzle and nozzle insulator must be removed to gain access to the diffuser.
- c. Remove the gas diffuser from the gun tube.
- d. Lay the gun cable on a flat surface with the cable straight and pull the liner out of the cable from the cable connector end.
- e. Install the new liner per Liner Installation Section.

#### **GUN TUBES AND NOZZLES**

- a. Replace worn contact tips as required.
- b. Remove spatter from inside of gas nozzle and from tip after each 10 minutes of arc time or as required.
- c. To remove gun tube from gun, loosen socket-head clamping screw in handle with 3/16 inch (4.8 mm) Allen wrench. Remove gas nozzle and nozzle insulator and also loosen small set screw in the diffuser using 5/64 inch (2.0 mm) Allen wrench. Set Screw not found on K2950. NOTE: Small set screw in the diffuser must be loosened, otherwise liner could be damaged when attempting to remove gun tube.

Pull gun tube out from gun handle. To reinstall, insert the gun tube, push in as far as possible and retighten screws.

#### **GUN CABLES**

#### **Cable Cleaning**

Clean cable liner after using approximately 300 pounds (136 kg) of electrode. Remove the cable from the wire feeder and lay it out straight on the floor. Remove the contact tip from the gun. Using an air hose and only partial pressure, gently blow out the cable liner from the gas diffuser end.

# A CAUTION

Excessive pressure at the start may cause the dirt to form a plug.

Flex the cable over its entire length and again blow out the cable. Repeat this procedure until no further dirt comes out.

#### **Cable Cleaning**

The MAGNUM® & MAGNUM® PRO CURVE 200 gun features the use of repairable cable connectors. If the cable ever gets severely damaged, it may be cut shorter and repaired by the user. Repair cables as follows:

Gun Tube End Repair (Requires 2 S19492-2 Terminals)

- a. Remove the cable liner per Removal, Installation and Trimming Instructions on page D-1.
- b. Remove the gun tube per Gun Tubes and Nozzles in this section.
- c. Remove three #6 screws from the gun handle, separate the two halves, and remove the cable from the handle along with the trigger assembly.
- d. Remove gun tube connector from cable by unscrewing connector nut from gun tube connector. If the cable inner tube is difficult to remove from the connector assembly, carefully slit it lengthwise with a knife up to the brass connector.
- e. Uncouple the strain relief by pushing its outer housing toward the middle of the cable. Move the strain relief and the cable boot toward the middle of the cable, past the damaged section.
- f. Cut off the damaged section of cable and strip off the outer jacket as shown in Figure D.1. Be careful not to cut the insulation on the control wires while stripping jacket. Strip the red and white control leads 1/4 inch (6.4mm) from the end and crimp a new S19492-2 terminal to each lead.







**NOTE:** The cable contains three control leads. Any two control leads can be used, provided the two color used are the same at both ends. The extra lead is a spare that can be used if one of the other leads breaks

g. Check that the cable boot and both halves of the strain relief are on the cable. Slip the connector nut over the copper strands with the thread end out. Orient gun tube connector so machined flat is on the same side of the cable as the red and white control leads. Assemble gun tube connector to cable by forcing the steel tube of the connector into the inside diameter of the cable inner tube until the copper strands are butted against the gun tube connector shoulder. Keeping the copper strands against the shoulder, pull the connector nut over the copper strands, engage the gun tube connector threads, and tighten in place. Figure D.2.

**NOTE:** For best results, insert a .175/.197 inch (4.5-5.0 mm) diameter rod through the connector and into core of cable approximately 5.00 inch (127 mm) when pushing the connector tube into the cable core tube. To tighten, hold the connector in place while turning the nut, and remove the rod from the core, The procedure ensures the inner core does not kink while

assembling or tightening.

- h. Pull the cut-off lead terminals off the trigger assemble and connect the replacement control lead terminals.
- Position the cable boot and strain relief on the cable so it fits in cable handle cavity and lock the strain relief in place by pushing the two halves together.
- Assemble cable in left side of gun handle. Assemble trigger into the proper handle cavity and connect the control leads. Assemble right side of gun handle and tighten the three screws that hold the handle together. Refer to Figure D.3.
- k. Install gun tube per Gun Tubes and Nozzles Section.
- I. Install and trim liner per Liner Installation Section.



**FIGURE D.3** 



#### **FIGURE D.4**

Wire Feeder End Repair (Requires 2 S19492-1 Terminals)

- a. Remove the cable liner per Removal, Installation, and Trimming Instructions in this section.
- b. Remove the feeder end connector, molded gas plug (or barbed fitting), cable handle nut, plastic tailpiece and connector cover (see Figure D.4). **NOTE:** In order to remove the cable handle nut, the tail of the connector cover must be depressed and the cable handle nut rotated 1/4 inch turn counterclockwise as viewed from the feeder end.
- c. Remove incoming connector from cable by unscrewing connector nut from incoming connector. If the cable inner tube is difficult to remove from the connector assembly, carefully slit it lengthwise with a knife up to the brass connector.
- d. Move the cable boot and cable handle toward the middle of the cable past the damaged section.
- e. Cut off the damaged section of cable and strip off the outer jacket as shown in Figure D.1. Be careful not to cut the insulation on the control wires while stripping jacket. Strip the red and white control leads 1/4 inch (6.4 mm) from the end and crimp a new S19492-1 terminal to each lead.

**NOTE:** The cable contains three control leads. Any two control leads can be used, provided the two colors used are the same at both ends. The extra lead is a spare that can be used if one of the other leads breaks.

f. Check that the cable boot and cable handle are on the cable. Slip the connector nut over the copper strands with the threaded end out. Assemble incoming connector to cable by forcing the steel tube of the connector into the inside diameter of the cable inner tube tube until the copper strands are butted against the incoming connector shoulder. Keeping the copper strands against the shoulder, pull the connector nut over the copper strands, engage the incoming connector threads, and tighten in place. Refer to Figure D.2.

**NOTE:** For best results, insert a .175/.197 inch (4.5-5.0 mm) diameter rod through the connector and into core of cable approximately 5.00" (127 mm) when pushing the connector tube into the cable core tube. To tighten, hold the connector in place while turning the nut, and remove the rod from the core. This procedure ensures the inner core does not kink while assembling or tightening.

- g. Position cable boot and cable handle on cable and assemble replacement control wire terminals in place on the cable handle. Insert connector cover in place. Install tailpiece and fasten to cable handle with cable handle nut. Refer Figure D.4.
- h. Replace the molded gas plug (or barbed fitting) and feeder end connector.
- i. Install and trim liner per Liner Installation in this section.

# WARNING



#### ELECTRIC SHOCK CAN KILL.

• Do not touch electrically live parts such as output terminals or internal wiring.

### HOW TO USE TROUBLESHOOTING GUIDE

### A WARNING

Service and Repair should only be performed by Lincoln Electric Factory Trained Personnel. Unauthorized repairs performed on this equipment may result in danger to the technician and machine operator and will invalidate your factory warranty. For your safety and to avoid Electrical Shock, please observe all safety notes and precautions detailed throughout this manual.

This Troubleshooting Guide is provided to help you locate and repair possible machine malfunctions. Simply follow the threestep procedure listed below.

#### Step 1. LOCATE PROBLEM (SYMPTOM).

Look under the column labeled "PROBLEM (SYMPTOMS)". This column describes possible symptoms that the machine may exhibit. Find the listing that best describes the symptom that the machine is exhibiting.

#### Step 2. POSSIBLE CAUSE.

The second column labeled "POSSIBLE CAUSE" lists the obvious external possibilities that may contribute to the machine symptom.

#### Step 3. RECOMMENDED COURSE OF ACTION

This column provides a course of action for the Possible Cause, generally it states to contact your local Lincoln Authorized Field Service Facility.

If you do not understand or are unable to perform the Recommended Course of Action safely, contact your local Lincoln Authorized Field Service Facility.

# **A** CAUTION

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your **Local Lincoln Authorized** Field Service Facility for technical troubleshooting assistance before you proceed.

#### **Observe all Safety Guidelines detailed throughout this manual**

Drive rolls turn, but wire will not feed of wire feed- ing is mugh     1. Gun cable kinked and/or hvisted. Keep as straight as possible. Inspect cable and ropice if necessary       2. Wire jammed in gun and cable. Remove wire from gun and cable. Bear the wire dimenter being used is stamped on drive rolls and guide tubes. Be sure the wire dimenter being used is stamped on drive rolls and guide tubes.     If all recommended possible adjustment have been chec problem persists. Contact II Replace or reverse split drive roll type.       4. Gun cable liner driv, Clean liner or replace.     5. Worn or improper size cable liner. Replace or reverse split drive roll type.     If all recommended possible adjustment have been chec problem persists. Contact II Replace or reverse split drive roll type.       5. Worn drive rolls. Replace class liner.     6. Electode rusty and/or driv, Replace class liner.     Incomet due to size contact ID. Replace liner.       8. Partally flashed, methed or improper size contact ID. Replace of morarize ground cables or problem persists. Contact ID.     Incomet due type.       9. Worn or undersize ground cables or proper succe, work cable to wire feeder contact ID.     1. Contact ID. Replace liner. Be sure the following connections and power feed rownections. Be sure the following connections and power feed accontect top. Be sure the following connections and power feed accontect top.       Poor arc striking with sticking or "blast-off", weld due or "blast-off", weld due contact tip to nozzie.     1. Improper procedures or techniques. See "Cas Neal Arc Weiding Guide" (GS-100) Improper gas shielding. Client gas contec. Make certain that gas diffuser is not rephice tubere saal for any sign of deteriora	RECOMMENDED COURSE OF ACTION		
Remoive wire from gun and cable			
Be sure the wire idiametic being used is stamped on thire rolls anguide tubes. Replace if necessary     If all recommended possible adjustment have been cheer from the rolls. Replace or reverse split drive roll type.     If all recommended possible adjustment have been cheer from the contact tip.       Is worn drive rolls.     Fectored rusty and/or dirty.     If all recommended possible adjustment have been cheer free split drive roll type.       Is better the part of the contact tip.     Fectored rusty and/or dirty.     If all recommended possible adjustment have been cheer free parts cable liner.       Is Partially flashed, metted or improper size cable liner.     Is Partially flashed, metted or improper size cable liner.     Is Contact tip. Replace the contact tip.       Variable or "hunting" arc     I. Contact tip worn or incorrect size. Replace the contact tip.     Is worn or undersize ground cables or poor ground connections. Inspect — repair or replace an ences sary.     Is Lose electrode cable to wire feeder and power source, work cable to power source work cable to be power source and work, gun cable to wire feeder and power source. Work gun cable to wire feeder and topy tooking (GS-100) Improper gas shielding. Clear gas cone. Make certain that gas diffuser is not rentry or turned of more source and topy tooking the certain gas flow rate is proper.       Persense in diffuser     I. Improper procedures or techniques. See "Gas Metal Arc Welding Guide" (GS-100) Improper gas shielding. Clear gas cone. Make certain that gas diffuser is not rentry or turned of more source source and topy tooking the certain gas flow rate is proper.       The seizes in diffuser     I. Top w			
Clean liner or replace.     5. Worn drive rolls.     Hall recommended possible adjustment have been checp pollem persists, Contact y replace or electrode if it is rusty.     If all recommended possible adjustment have been checp pollem persists, Contact y replace cable liner.       8. Partially flashed, melted or improper size cable liner.     8. Partially flashed, melted or improper size cable liner.     Facility.       Variable or "hunting" arc     1. Contact tip. Replace the contact tip.     Facility.       Variable or "hunting" arc     2. Worn or undersize ground cables or poor ground connections. Inspect — repair or replace as neces sary.     2. Loose electrode connections. Be sure the following connections are tight: electrode cable to wire feeder and power source, work cable to more feeder contact tip.       Poor arc striking with sticking or "blast-off", weld porsity, narrow and roy looking bate scylinder is no tengty or turned off. Make certain that gas diffuser is not restricted. Make certain that gas diffuser is no trast is noper.       There welding     1. Top overheating due to prolonged or excessive high current and/or duly cycle       Tip seizes in diffuser     1. Top overheating due to prolonged or excessive high current and duly cycle			
Replace or reverse split drive roll type.     In all recommendation of the problem persists.       6. Electode rusty and/or diry.     Replace or electrode if it is rusty.       7. Worn or improper size cable liner.     Replace cable liner.       8. Partially flashed, melted or improper size cable liner.     Replace contact tip.       8. Partially flashed, melted or improper size contact tip.     Incoln Authorized Field S       Variable or "hunting" arc     1. Contact tip worn or incorrect size.       Replace contact tip.     2. Worn or undersize ground cables or poor ground connections. Inspect — repair or replace as neces sary.       3. Loose electrode connections. Inspect — repair or replace as neces sary.     1. Improper procedures or techniques. See "Gas Metal Arc Welding Guide" (GS -100) Improper sas shielding. Clean gas solenoid valve is operating and gas flow rate is proper.       Poor arc striking with sticking or "blast-off", weld ported to sole of ower source, work cable to wire feeder contact tip to nozite.     1. Improper procedures or techniques. See "Gas Metal Arc Welding Guide" (GS -100) Improper gas solenoid valve is operating and gas flow rate is proper.       Remove gun liner and check rubber see alto raw sign of deterioration or damage. Be sure set store with brass connector is in place and tightened against the liner bushing.       Tip seizes in diffuser     1. Tip overheating due to prolonged or excessive high current and duly cycle			
• Electrode rusy and/or arry.     Problem persists, Contact is rusty.       • Worn or improper size cable liner.     Replace cable liner.       Replace cable liner.     Replace cable liner.       Replace cable liner.     Replace the contact tip.       • Partially flashed, melted or improper size cable liner.     Replace the contact tip.       • Variable or "hunting" arc     1. Contact tip worn or incorrect size.       • Replace contenct tip.     2. Worn or undersize ground cables or poor ground connections.       • Inspect — repair or replace as neces sary.     3. Loose electrode connections.       • Be sure the following connections are tight: electrode contact tip to nozzle.     Power source, work cable to wire feeder and power source and work, gun cable to wire feeder contact tip to nozzle.       • Poor arc striking with sticking or "blast-off", weld porsity, narrow and ropy looking bead, or electrode stubbing into plate     1. Improper procedures or techniques. See "Gas Metal Arc Welding Guide" (GS-100) Improper gas shielding. Clean gas cone. Make certain that gas clifteer is not empty or turned of Make certain that gas clifteer is not empty or turned of Make certain that gas clifteer is not empty or turned of finales as objenoid valve is operating and gas flow rate is proper.       Remove gun liner and check rubber against the liner bushing.     1. Tip overheating due to prolonged or excessive high current and/or duly cycle       Tip seizes in diffuser     1. Tip overheating due to prolonged or exceskedurrent and duly cycle <td></td>			
Province improper size cable liner.     Facility.       Replace contact tip. Replace the contact tip.     Facility.       Variable or "hunting" arc     1. Contact tip worn or incorrect size. Replace contact tip.       2. Worn or undersize ground cables or poor ground connections. Inspect — repair or replace as neces sary.     3. Loose electrode connections. Be sure the following connections are tight: electrode cable to wire feeder and power source, work cable to power source and work, gun cable to wire feeder contact tip to nozzle.       Poor arc striking with sticking or "blast-off", weld porosity, narrow and ropy looking bead, or electrode stubbing into plate while welding     1. Improper procedures or techniques. See "Gas Metal Arc Welding Guide" (GS -100) Improper gas shielding. Clean gas cone. Make certain that gas diffuser is not restricted. Make certain that gas cylinder is not mempty or turned of .f. Make certain gas solenoid valve is operating and gas flow rate is proper. Remove gun liner and check rubber seal for any sign of deterioration or damage. Be sure set screw in brass connector is in place and tightened against the liner bushing.       Tip seizes in diffuser     1. Tip overheating due to prolonged or excessive high current and/or duly cycle welding. Do not exceed current and duly cycle	your local		
size contact tip. Replace the contact tip.       Variable or "hunting" arc     1. Contact tip worn or incorrect size. Replace contact tip.       2. Worn or undersize ground cables or poor ground connections. Inspect — repair or replace as neces sary.     3. Losse electrode connections. Be sure the following connections are tight: electrode cable to wire feeder and power source and work, gun cable to wire feeder contact tip to nozzle.       Poor arc striking with sticking or "blast-off", weld porsity, narow and ropy looking bead, or electrode stubbing into plate while welding     1. Improper procedures or techniques. See "Gas Metal Arc Welding Guide" (GS-100) Improper gas shielding. Clean gas cone. Make certain that gas diffuser is not restricted. Make certain that gas cylinder is not empty or turned off. Make certain gas solenoid valve is operating and gas flow rate is proper. Remove gun liner and check rubber seal for any sign of deterioration or damage. Be sure set screw in brass connector is in place and tightened against the liner bushing.       Tip seizes in diffuser     1. Tip overheating due to prolonged or excessive high current and/or duly cycle welding. Do not exceed current and duly cycle	Service		
Replace contact tip.       2. Worn or undersize ground cables or poor ground connections. Inspect — repair or replace as neces sary.       3. Loose electrode connections. Be sure the following connections are tight: electrode cable to wire feeder and power source, work cable to power source and work, gun cable to wire feeder and power source and work, gun cable to wire feeder and power source and work, gun cable to wire feeder contact tip to nozzle.       Poor arc striking with sticking or "blast-off", weld prosity, narrow and ropy looking bead, or electrode stubbing into plate while welding     1. Improper procedures or techniques. See "Gas Metal Arc Welding Guide" (GS-100) Improper gas shielding. Clean gas cone. Make certain that gas diffuser is not restricted. Make certain that gas cylinder is not empty or turned off. Make certain gas solenoid valve is operating and gas flow rate is proper. Remove gun liner and check rubber seal for any sign of deterioration or damage. Be sure est screw in brass connector is in place and tightened against the liner bushing.       Tip seizes in diffuser     1. Tip overheating due to prolonged or excessive high current and/or duly cycle			
poor ground connections. Inspect — repair or replace as neces sary.3. Loose electrode connections. Be sure the following connections are tight: electrode cable to wire feeder and power source, work cable to power source and work, gun cable to wire feeder contact tip to nozzle.Poor arc striking with sticking or "blast-off", weld porosity, narrow and ropy looking bead, or electrode stubbing into plate while welding1. Improper procedures or techniques. See "Gas Metal Arc Welding Guide" (GS-100) Improper gas shielding. Clean gas cone. Make certain that gas diffuser is not restricted. Make certain that gas operating and gas flow rate is proper. Remove gun liner and check rubber seal for any sign of deterioration or damage. Be sure set screw in brass connector is in place and tightnend against the liner bushing.Tip seizes in diffuser1. Tip overheating due to prolonged or excessive high current and/or duly cycle welding. Do not exceed current and duly cycle			
Be sure the following connections are tight: electrode cable to wire feeder and power source, work cable to power source and work, gun cable to wire feeder contact tip to nozzle.Poor arc striking with sticking or "blast-off", weld poresity, narrow and ropy looking bead, or electrode stubbing into plate1. Improper procedures or techniques. See "Gas Metal Arc Welding Guide" (GS-100) Improper gas shielding. Clean gas cone. Make certain that gas diffuser is not restricted. Make certain that gas cylinder is not empty or turned off. Make certain gas solenoid valve is operating and gas flow rate is proper.Tip seizes in diffuser1. Tip overheating due to prolonged or excessive high current and/or duly cycle welding.Tip seizes in diffuser1. Tip overheating due to prolonged or excessive high current and/or duly cycle welding.			
porosity, narrow and ropy looking bead, or electrode stubbing into plate while weldingSee "Gas Metal Arc Welding Guide" (GS-100) Improper gas shielding. Clean gas cone. Make certain that gas diffuser is not restricted. Make certain that gas cylinder is not empty or turned off. Make certain gas solenoid valve is operating and gas flow rate is proper.Remove gun liner and check rubber seal for any sign of deterioration or damage. Be sure set screw in brass connector is in place and tightened against the liner bushing.Tip seizes in diffuser1. Tip overheating due to prolonged or excessive high current and/or duly cycle welding. Do not exceed current and duly cycle			
seal for any sign of deterioration or damage. Be sure set screw in brass connector is in place and tightened against the liner bushing.       Tip seizes in diffuser     1. Tip overheating due to prolonged or excessive high current and/or duly cycle welding.       Do not exceed current and duly cycle			
excessive high current and/or duly cycle welding. Do not exceed current and duly cycle			
l l			
A light application of high temperature antiseize lubricant (such as Lincoln E2607 Graphic Grease) may be applied to tip threads.			

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your Local Lincoln Authorized Field Service Facility for technical troubleshooting assistance before you proceed.

#### CUSTOMER ASSISTANCE POLICY

The business of The Lincoln Electric Company is manufacturing and selling high quality welding equipment, consumables, and cutting equipment. Our challenge is to meet the needs of our customers and to exceed their expectations. On occasion, purchasers may ask Lincoln Electric for advice or information about their use of our products. We respond to our customers based on the best information in our possession at that time. Lincoln Electric is not in a position to warrant or guarantee such advice, and assumes no liability, with respect to such information or advice. We expressly disclaim any warranty of any kind, including any warranty of fitness for any customer's particular purpose, with respect to such information or advice. As a matter of practical consideration, we also cannot assume any responsibility for updating or correcting any such information or advice once it has been given, nor does the provision of information or advice create, expand or alter any warranty with respect to the sale of our products.

Lincoln Electric is a responsive manufacturer, but the selection and use of specific products sold by Lincoln Electric is solely within the control of, and remains the sole responsibility of the customer. Many variables beyond the control of Lincoln Electric affect the results obtained in applying these types of fabrication methods and service requirements.

Subject to Change – This information is accurate to the best of our knowledge at the time of printing. Please refer to www.lincolnelectric.com for any updated information.



THE LINCOLN ELECTRIC COMPANY 22801 St. Clair Avenue • Cleveland, OH • 44117-1199 • U.S.A. Phone: +1.216.481.8100 • www.lincolnelectric.com