

Operator's Manual

Cooper Welding Cart - ABB Operator's Manual



Register your machine:
www.lincolnelectric.com/register

Authorized Service and Distributor Locator:
www.lincolnelectric.com/locator

Save for future reference

Date Purchased

Code: (ex: 10859)

Serial: (ex: U1060512345)

Need Help? Call 1.888.935.3878
to talk to a Service Representative

Hours of Operation:
8:00 AM to 6:00 PM (ET) Mon. thru Fri.

After hours?
Use "Ask the Experts" at lincolnelectric.com
A Lincoln Service Representative will contact you
no later than the following business day.

For Service outside the USA:
Email: Cobot_Service@LincolnElectric.com

THANK YOU FOR SELECTING A QUALITY PRODUCT BY LINCOLN ELECTRIC.

PLEASE EXAMINE CARTON AND EQUIPMENT FOR DAMAGE IMMEDIATELY

When this equipment is shipped, title passes to the purchaser upon receipt by the carrier. Consequently, claims for material damaged in shipment must be made by the purchaser against the transportation company at the time the shipment is received.

SAFETY DEPENDS ON YOU

Lincoln arc welding and cutting equipment is designed and built with safety in mind. However, your overall safety can be increased by proper installation ... and thoughtful operation on your part. **DO NOT INSTALL, OPERATE OR REPAIR THIS EQUIPMENT WITHOUT READING THIS MANUAL AND THE SAFETY PRECAUTIONS CONTAINED THROUGHOUT.** And, most importantly, think before you act and be careful.

WARNING

This statement appears where the information must be followed exactly to avoid serious personal injury or loss of life.

CAUTION

This statement appears where the information must be followed to avoid minor personal injury or damage to this equipment.



KEEP YOUR HEAD OUT OF THE FUMES.

DON'T get too close to the arc. Use corrective lenses if necessary to stay a reasonable distance away from the arc.


READ and obey the Safety Data Sheet (SDS) and the warning label that appears on all containers of welding materials.

USE ENOUGH VENTILATION or exhaust at the arc, or both, to keep the fumes and gases from your breathing zone and the general area.

IN A LARGE ROOM OR OUTDOORS, natural ventilation may be adequate if you keep your head out of the fumes (See below).

USE NATURAL DRAFTS or fans to keep the fumes away from your face.

If you develop unusual symptoms, see your supervisor. Perhaps the welding atmosphere and ventilation system should be checked.



WEAR CORRECT EYE, EAR & BODY PROTECTION

PROTECT your eyes and face with welding helmet properly fitted and with proper grade of filter plate (See ANSI Z49.1).

PROTECT your body from welding spatter and arc flash with protective clothing including woolen clothing, flame-proof apron and gloves, leather leggings, and high boots.

PROTECT others from splatter, flash, and glare with protective screens or barriers.

IN SOME AREAS, protection from noise may be appropriate.

BE SURE protective equipment is in good condition.

Also, wear safety glasses in work area **AT ALL TIMES.**



SPECIAL SITUATIONS

DO NOT WELD OR CUT containers or materials which previously had been in contact with hazardous substances unless they are properly cleaned. This is extremely dangerous.

DO NOT WELD OR CUT painted or plated parts unless special precautions with ventilation have been taken. They can release highly toxic fumes or gases.

Additional precautionary measures

PROTECT compressed gas cylinders from excessive heat, mechanical shocks, and arcs; fasten cylinders so they cannot fall.

BE SURE cylinders are never grounded or part of an electrical circuit.

REMOVE all potential fire hazards from welding area.

ALWAYS HAVE FIRE FIGHTING EQUIPMENT READY FOR IMMEDIATE USE AND KNOW HOW TO USE IT.



SECTION A: WARNINGS



CALIFORNIA PROPOSITION 65 WARNINGS



WARNING: Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects, or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an exposed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel

WARNING: This product, when used for welding or cutting, produces fumes or gases which contain chemicals known to the State of California to cause birth defects and, in some cases, cancer. (California Health & Safety Code § 25249.5 *et seq.*)



WARNING: Cancer and Reproductive Harm
www.P65warnings.ca.gov

ARC WELDING CAN BE HAZARDOUS. PROTECT YOURSELF AND OTHERS FROM POSSIBLE SERIOUS INJURY OR DEATH. KEEP CHILDREN AWAY. PACEMAKER WEARERS SHOULD CONSULT WITH THEIR DOCTOR BEFORE OPERATING.

Read and understand the following safety highlights. For additional safety information, it is strongly recommended that you purchase a copy of "Safety in Welding & Cutting - ANSI Standard Z49.1" from the American Welding Society, P.O. Box 351040, Miami, Florida 33135 or CSA Standard W117.2. A Free copy of "Arc Welding Safety" booklet E205 is available from the Lincoln Electric Company, 22801 St. Clair Avenue, Cleveland, Ohio 44117-1199.

BE SURE THAT ALL INSTALLATION, OPERATION, MAINTENANCE AND REPAIR PROCEDURES ARE PERFORMED ONLY BY QUALIFIED INDIVIDUALS.



FOR ENGINE POWERED EQUIPMENT.

- 1.a. Turn the engine off before troubleshooting and maintenance work unless the maintenance work requires it to be running.



- 1.b. Do not add the fuel near an open flame welding arc or when the engine is running. Stop the engine and allow it to cool before refueling to prevent spilled fuel from vaporizing on contact with hot engine parts and igniting. Do not spill fuel when filling tank. If fuel is spilled, wipe it



up and do not start engine until fumes have been eliminated.

- 1.c. Keep all equipment safety guards, covers and devices in position and in good repair. Keep hands, hair, clothing and tools away from V-belts, gears, fans and all other moving parts when starting, operating or repairing equipment.



- 1.d. In some cases it may be necessary to remove safety guards to perform required maintenance. Remove guards only when necessary and replace them when the maintenance requiring their removal is complete. Always use the greatest care when working near moving parts.
- 1.e. Do not put your hands near the engine fan. Do not attempt to override the governor or idler by pushing on the throttle control rods while the engine is running.
- 1.f. To prevent accidentally starting gasoline engines while turning the engine or welding generator during maintenance work, disconnect the spark plug wires, distributor cap or magneto wire as appropriate.

- 1.g. To avoid scalding, do not remove the radiator pressure cap when the engine is hot.



- 1.h. Using a generator indoors CAN KILL YOU IN MINUTES.

- 1.i. Generator exhaust contains carbon monoxide. This is a poison you cannot see or smell.

- 1.j. NEVER use inside a home or garage, EVEN IF doors and windows are open.



- 1.k. Only use OUTSIDE and far away from windows, doors and vents.



- 1.l. Avoid other generator hazards. READ MANUAL BEFORE USE.



ELECTRIC AND MAGNETIC FIELDS MAY BE DANGEROUS



- 2.a. Electric current flowing through any conductor causes localized Electric and Magnetic Fields (EMF). Welding current creates EMF fields around welding cables and welding machines
- 2.b. EMF fields may interfere with some pacemakers, and welders having a pacemaker should consult their physician before welding.
- 2.c. Exposure to EMF fields in welding may have other health effects which are now not known.
- 2.d. All welders should use the following procedures in order to minimize exposure to EMF fields from the welding circuit:
 - 2.d.1. Route the electrode and work cables together - Secure them with tape when possible.
 - 2.d.2. Never coil the electrode lead around your body.
 - 2.d.3. Do not place your body between the electrode and work cables. If the electrode cable is on your right side, the work cable should also be on your right side.
 - 2.d.4. Connect the work cable to the workpiece as close as possible to the area being welded.
 - 2.d.5. Do not work next to welding power source.



ELECTRIC SHOCK CAN KILL.



- 3.a. The electrode and work (or ground) circuits are electrically “hot” when the welder is on. Do not touch these “hot” parts with your bare skin or wet clothing. Wear dry, hole-free gloves to insulate hands.
- 3.b. Insulate yourself from work and ground using dry insulation. Make certain the insulation is large enough to cover your full area of physical contact with work and ground.

In addition to the normal safety precautions, if welding must be performed under electrically hazardous conditions (in damp locations or while wearing wet clothing; on metal structures such as floors, gratings or scaffolds; when in cramped positions such as sitting, kneeling or lying, if there is a high risk of unavoidable or accidental contact with the workpiece or ground) use the following equipment:

- Semiautomatic DC Constant Voltage (Wire) Welder.
 - DC Manual (Stick) Welder.
 - AC Welder with Reduced Voltage Control.
- 3.c. In semiautomatic or automatic wire welding, the electrode, electrode reel, welding head, nozzle or semiautomatic welding gun are also electrically “hot”.
 - 3.d. Always be sure the work cable makes a good electrical connection with the metal being welded. The connection should be as close as possible to the area being welded.
 - 3.e. Ground the work or metal to be welded to a good electrical (earth) ground.
 - 3.f. Maintain the electrode holder, work clamp, welding cable and welding machine in good, safe operating condition. Replace damaged insulation.
 - 3.g. Never dip the electrode in water for cooling.
 - 3.h. Never simultaneously touch electrically “hot” parts of electrode holders connected to two welders because voltage between the two can be the total of the open circuit voltage of both welders.
 - 3.i. When working above floor level, use a safety belt to protect yourself from a fall should you get a shock.
 - 3.j. Also see Items 6.c. and 8.



ARC RAYS CAN BURN.



- 4.a. Use a shield with the proper filter and cover plates to protect your eyes from sparks and the rays of the arc when welding or observing open arc welding. Headshield and filter lens should conform to ANSI Z87.1 standards.
- 4.b. Use suitable clothing made from durable flame-resistant material to protect your skin and that of your helpers from the arc rays.
- 4.c. Protect other nearby personnel with suitable, non-flammable screening and/or warn them not to watch the arc nor expose themselves to the arc rays or to hot spatter or metal.




FUMES AND GASES CAN BE DANGEROUS.



- 5.a. Welding may produce fumes and gases hazardous to health. Avoid breathing these fumes and gases. When welding, keep your head out of the fume. Use enough ventilation and/or exhaust at the arc to keep fumes and gases away from the breathing zone. **When welding hardfacing (see instructions on container or SDS) or on lead or cadmium plated steel and other metals or coatings which produce highly toxic fumes, keep exposure as low as possible and within applicable OSHA PEL and ACGIH TLV limits using local exhaust or mechanical ventilation unless exposure assessments indicate otherwise. In confined spaces or in some circumstances, outdoors, a respirator may also be required. Additional precautions are also required when welding on galvanized steel.**
5. b. The operation of welding fume control equipment is affected by various factors including proper use and positioning of the equipment, maintenance of the equipment and the specific welding procedure and application involved. Worker exposure level should be checked upon installation and periodically thereafter to be certain it is within applicable OSHA PEL and ACGIH TLV limits.
- 5.c. Do not weld in locations near chlorinated hydrocarbon vapors coming from degreasing, cleaning or spraying operations. The heat and rays of the arc can react with solvent vapors to form phosgene, a highly toxic gas, and other irritating products.
- 5.d. Shielding gases used for arc welding can displace air and cause injury or death. Always use enough ventilation, especially in confined areas, to insure breathing air is safe.
- 5.e. Read and understand the manufacturer’s instructions for this equipment and the consumables to be used, including the Safety Data Sheet (SDS) and follow your employer’s safety practices. SDS forms are available from your welding distributor or from the manufacturer.
- 5.f. Also see item 1.j.



WELDING AND CUTTING SPARKS CAN CAUSE FIRE OR EXPLOSION.



- 6.a. Remove fire hazards from the welding area. If this is not possible, cover them to prevent the welding sparks from starting a fire. Remember that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas. Avoid welding near hydraulic lines. Have a fire extinguisher readily available.
- 6.b. Where compressed gases are to be used at the job site, special precautions should be used to prevent hazardous situations. Refer to "Safety in Welding and Cutting" (ANSI Standard Z49.1) and the operating information for the equipment being used.
- 6.c. When not welding, make certain no part of the electrode circuit is touching the work or ground. Accidental contact can cause overheating and create a fire hazard.
- 6.d. Do not heat, cut or weld tanks, drums or containers until the proper steps have been taken to insure that such procedures will not cause flammable or toxic vapors from substances inside. They can cause an explosion even though they have been "cleaned". For information, purchase "Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping That Have Held Hazardous Substances", AWS F4.1 from the American Welding Society (see address above).
- 6.e. Vent hollow castings or containers before heating, cutting or welding. They may explode.
- 6.f. Sparks and spatter are thrown from the welding arc. Wear oil free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes and a cap over your hair. Wear ear plugs when welding out of position or in confined places. Always wear safety glasses with side shields when in a welding area.
- 6.g. Connect the work cable to the work as close to the welding area as practical. Work cables connected to the building framework or other locations away from the welding area increase the possibility of the welding current passing through lifting chains, crane cables or other alternate circuits. This can create fire hazards or overheat lifting chains or cables until they fail.
- 6.h. Also see item 1.b.
- 6.i. Read and follow NFPA 51B "Standard for Fire Prevention During Welding, Cutting and Other Hot Work", available from NFPA, 1 Batterymarch Park, PO box 9101, Quincy, MA 022690-9101.
- 6.j. Do not use a welding power source for pipe thawing.



CYLINDER MAY EXPLODE IF DAMAGED.



- 7.a. Use only compressed gas cylinders containing the correct shielding gas for the process used and properly operating regulators designed for the gas and pressure used. All hoses, fittings, etc. should be suitable for the application and maintained in good condition.
- 7.b. Always keep cylinders in an upright position securely chained to an undercarriage or fixed support.
- 7.c. Cylinders should be located:
 - Away from areas where they may be struck or subjected to physical damage.
 - A safe distance from arc welding or cutting operations and any other source of heat, sparks, or flame.
- 7.d. Never allow the electrode, electrode holder or any other electrically "hot" parts to touch a cylinder.
- 7.e. Keep your head and face away from the cylinder valve outlet when opening the cylinder valve.
- 7.f. Valve protection caps should always be in place and hand tight except when the cylinder is in use or connected for use.
- 7.g. Read and follow the instructions on compressed gas cylinders, associated equipment, and CGA publication P-1, "Precautions for Safe Handling of Compressed Gases in Cylinders," available from the Compressed Gas Association, 14501 George Carter Way Chantilly, VA 20151.



FOR ELECTRICALLY POWERED EQUIPMENT.



- 8.a. Turn off input power using the disconnect switch at the fuse box before working on the equipment.
- 8.b. Install equipment in accordance with the U.S. National Electrical Code, all local codes and the manufacturer's recommendations.
- 8.c. Ground the equipment in accordance with the U.S. National Electrical Code and the manufacturer's recommendations.

Refer to
<http://www.lincolnelectric.com/safety>
for additional safety information.

ELECTROMAGNETIC COMPATIBILITY (EMC)

CONFORMANCE

Products displaying the CE mark are in conformity with European Community Council Directive of 15 Dec 2004 on the approximation of the laws of the Member States relating to electromagnetic compatibility, 2014/30/EU. It was manufactured in conformity with a national standard that implements a harmonized standard: EN 60974-10 Electromagnetic Compatibility (EMC) Product Standard for Arc Welding Equipment. It is for use with other Lincoln Electric equipment. It is designed for industrial and professional use.

INTRODUCTION

All electrical equipment generates small amounts of electromagnetic emission. Electrical emission may be transmitted through power lines or radiated through space, similar to a radio transmitter. When emissions are received by other equipment, electrical interference may result. Electrical emissions may affect many kinds of electrical equipment; other nearby welding equipment, radio and TV reception, numerical controlled machines, telephone systems, computers, etc.

Warning: This Class A equipment is not intended for use in residential locations where the electrical power is provided by the public low-voltage supply system. There may be potential difficulties in ensuring electro-magnetic compatibility in those locations, due to conducted as well as radiated disturbances.

This machine has been designed to operate in an industrial area. The operator must install and operate this equipment as described in this manual. If any electromagnetic disturbances are detected the operator must put in place corrective actions to eliminate these disturbances with, if necessary, assistance from Lincoln Electric. This equipment does not comply with IEC 61000-3-12. If it is connected to a public low-voltage system, it is responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment may be connected.

INSTALLATION AND USE

The user is responsible for installing and using the welding equipment according to the manufacturer's instructions.

If electromagnetic disturbances are detected then it shall be the responsibility of the user of the welding equipment to resolve the situation with the technical assistance of the manufacturer. In some cases this remedial action may be as simple as earthing (grounding) the welding circuit, see Note. In other cases it could involve constructing an electromagnetic screen enclosing the power source and the work complete with associated input filters. In all cases electromagnetic disturbances must be reduced to the point where they are no longer troublesome.

Note: The welding circuit may or may not be earthed for safety reasons. Follow your local and national standards for installation and use. Changing the earthing arrangements should only be authorized by a person who is competent to assess whether the changes will increase the risk of injury, e.g., by allowing parallel welding current return paths which may damage the earth circuits of other equipment.

ASSESSMENT OF AREA

Before installing welding equipment the user shall make an assessment of potential electromagnetic problems in the surrounding area. The following shall be taken into account:

- a) other supply cables, control cables, signaling and telephone cables; above, below and adjacent to the welding equipment;
- b) radio and television transmitters and receivers;
- c) computer and other control equipment;
- d) safety critical equipment, e.g., guarding of industrial equipment;
- e) the health of the people around, e.g., the use of pacemakers and hearing aids;
- f) equipment used for calibration or measurement;
- g) the immunity of other equipment in the environment. The user shall ensure that other equipment being used in the environment is compatible. This may require additional protection measures;
- h) the time of day that welding or other activities are to be carried out.

The size of the surrounding area to be considered will depend on the structure of the building and other activities that are taking place. The surrounding area may extend beyond the boundaries of the premises.

METHODS OF REDUCING EMISSIONS

Public Supply System

Welding equipment should be connected to the public supply system according to the manufacturer's recommendations. If interference occurs, it may be necessary to take additional precautions such as filtering of the system. Consideration should be given to shielding the supply cable of permanently installed welding equipment, in metallic conduit or equivalent. Shielding should be electrically continuous throughout its length. The shielding should be connected to the welding power source so that good electrical contact is maintained between the conduit and the welding power source enclosure.

Maintenance of the Welding Equipment

The welding equipment should be routinely maintained according to the manufacturer's recommendations. All access and service doors and covers should be closed and properly fastened when the welding equipment is in operation. The welding equipment should not be modified in any way except for those changes and adjustments covered in the manufacturer's instructions. In particular, the spark gaps of arc striking and stabilizing devices should be adjusted and maintained according to the manufacturer's recommendations.

Welding Cables

The welding cables should be kept as short as possible and should be positioned close together, running at or close to the floor level.

Equipotential Bonding

Bonding of all metallic components in the welding installation and adjacent to it should be considered. However, metallic components bonded to the work piece will increase the risk that the operator could receive a shock by touching these metallic components and the electrode at the same time. The operator should be insulated from all such bonded metallic components.

Earthing of the Workpiece

Where the workpiece is not bonded to earth for electrical safety, nor connected to earth because of its size and position, e.g., ship's hull or building steelwork, a connection bonding the workpiece to earth may reduce emissions in some, but not all instances. Care should be taken to prevent the earthing of the workpiece increasing the risk of injury to users, or damage to other electrical equipment. Where necessary, the connection of the workpiece to earth should be made by a direct connection to the workpiece, but in some countries where direct connection is not permitted, the bonding should be achieved by suitable capacitance, selected according to national regulations.

Screening and Shielding

Selective screening and shielding of other cables and equipment in the surrounding area may alleviate problems of interference. Screening of the entire welding installation may be considered for special applications.

Preparation and Setup	1-1
Introduction to ABB Collaborative Robot/Controller	1-1
Introduction to Cooper Welding Cobot	1-2
Cooper Welding Cobot Power Requirements.....	1-2
Cooper Welding Cobot Universal Cart Layout.....	1-3
Cooper Welding Cobot Universal Cart Dimensions.....	1-4
Cooper Welding Cobot Unboxing and Setup.....	1-6
Collaborative Robot Working Envelope	1-7
Reference Materials	1-8
ABB GoFa Operation	2-1
Start-up Process	2-1
FlexPendent Operation–Controls	2-1
Troubleshooting	2-1
How to clear an error on ABB	2-2
Brake Release Tool	2-3
Lights on the Arm and Their Meanings	2-3
How to Navigate to ABB UI to Create a Custom Weld Definition	2-4
Switching from Auto to Manual and Back to Auto	2-5
Synchronization Process Steps	2-6
Shipping Mode Steps	2-8
GoFa & Cooper App Software Update Process	2-9
Cooper Welding Cobot Optional Equipment	3-1
Maintenance	4-1
Cooper Welding Cobot Parts Catalog	5-1
Consumable Parts List	5-1

Section 1

PREPARATION AND SETUP

INTRODUCTION TO ABB COLLABORATIVE ROBOT/CONTROLLER

The ABB Collaborative Controller (OmniCore C30) (1) is a computer that controls the movements of the cobot arm. Operators can create programs to dictate movement and angles of the cobot arm, and welding torch.



Figure 1-1

INTRODUCTION TO COOPER WELDING COBOT

The cobot is designed to safely operate along side an operator, so only one person should be operating the cobot at any time. In each axis, and/ or joint of the cobot arm there are force sensors, which trigger an immediate safety stop when it comes into contact with a human body or any other object.

The Cooper Welding Cobot Cart comes configured on Lincoln Electric's Generation II Universal Cart. The ABB GoFa-10 Cobot as either an air or water cooled welding system, that comes setup to weld 0.035" or 0.045" solid wire welding process; these are the most common wire diameter sizes and type used across many industries that weld. Operators are able to change our liners, drive-rolls, and contact tips in order to weld different size wires, along with other processes, like flux-cored wire welding.



Figure 1-2

To register the Cooper Cobot, Please visit lincolnelectric.com or use the QR code below:



COOPER WELDING COBOT POWER REQUIREMENTS

Power Requirements	
Cooper Welding Cobot	Single Phase 120v
Power Wave R450	Single Phase 120v or 3 Phase (Limited Single Phase Capability for 208/230)

Note: Please see the PowerWave R450 Operators Manual for all power configurations.

COOPER WELDING COBOT UNIVERSAL CART LAYOUT




Figure 1-3: Cooper GoFa-10 Water-Cooled Cobot Cart shown

1. ABB GoFa Pendant	4. Water-Cooled Welding Torch (1)	7. Power Wave R450
2. Gen II Universal Cooper Cart	5. AutoDrive 4R220 Wire Feeder (2)	8. Cool Wave 20S (3)
3. ABB GoFa-10 Cobot	6. OmniCore C30 Controller	9. Palm-Station Buttons

1. Air-Cooled Welding Torch is for Cooper Air-Cooled Welding Cobots.
2. Air-Cooled Welding Cobots will use an AutoDrive 4R100 Wire Feeder.
3. Cooper Air-Cooled Welding Cobots will not require a water cooler unit.

COOPER WELDING COBOT UNIVERSAL CART DIMENSIONS




Figure 1-4: PerfectPoint and Power Ream Plus Installed




Figure 1-5: PerfectPoint and Power Ream Plus Installed

COOPER WELDING COBOT UNBOXING AND SETUP

WARNING

Ensure that unboxing area is clean of any obstructions and that all personnel are wearing proper personal protective equipment (PPE). Always use appropriate lifting device(s) when raising or lowering the welding cart. Ensure that the welding cart is always secure when raising or lowering the welding cart. Failure to follow these instructions can cause serious injury or machine damage.

Note: When unboxing the welding cart, some components secured to the side of the welding cart may have shifted during transportation. Remove shrink wrap and banding carefully.

1. The Cooper Welding Cobot will come shrink wrapped and banded (1) to a LTL rated shipping pallet. Cut banding that secures the cobot cart to the pallet. Using a forklift, lift and move the welding cart to the appropriate location; remove shrink wrap.
2. Remove any loose items from the top of the welding cart.

Note: Before fully lifting the welding cart, ensure that the welding cart is well-balanced or secured to the lifting device.

3. Using an appropriate lifting device, raise the welding cart up from the bottom of the cart (2) and off of the shipping pallet.




Figure 1-6

4. Wheel the welding cart to the desired location.

NOTE: The PowerWave R450 does not come equipped with a power cord, it must be purchased separately. Please make note of cord length and size before purchasing.

5. Unpack the welding cart and ensure that all components are present and that there is no visible damage from shipping.
6. Plug in the PowerWave R450 and Cobot into their respective outlets.
7. Turn on all powered equipment and turn on all breakers on the welding cart.
8. Plug in the teach pendant and turn on the teach pendant by pressing and holding the power button located on the top right side. The teach pendant will load and bring the operator to the main control screen.

For more information on the Cobot components, please see *Cooper Welding Cobot Universal Cart Layout on page 1-3* and *Reference Materials on page 1-8*.

COLLABORATIVE ROBOT WORKING ENVELOPE

The Cobot work zone (1) for the Cobot Welding Arm is 64 in. (1620 mm). The safety zone (2) is 31 in. (800 mm). When setting up the Cobot cart, ensure that there are no obstacles within the Cobot work zone or the safety zone.

Note: It's important to be mindful of collaborative speeds. Teaching speeds can be up around 750 mm/ sec; operable speeds (i.e. While running a programming) should not exceed 250 mm/sec to ensure safety for operators working collaboratively with the Cobot.




Figure 1-7

REFERENCE MATERIALS

For more information on the following operator manuals, see the link below this list.

- Cooper App
- Lincoln Electric Power Wave R450 Welding Power Supply



Figure 1-8

- Lincoln Electric Auto Drive 4R100 or 4R220 Wire Feeder



Figure 1-9

- MagnumPro Air Cooled Wire Brake Torch



Figure 1-10

- MagnumPro Water Cooled Wire Brake Torch



Figure 1-11

For more information, see

<https://www.lincolnelectric.com/en/operators-manuals>

Or use the QR code below:



Section 2
ABB GOFA OPERATION

START-UP PROCESS

For more information on the Cobot welder start-up process, please see *Cooper Welding Cobot Unboxing and Setup* on page 1-6.

FLEXPENDENT OPERATION-CONTROLS




Figure 2-1

1. Mechanical Unit	7. Joystick	13. Stop Program
2. Linear/Reorient	8. Enabling Device	14. Step to Previous
3. Thumb Button (enable/disable lead-through)	9. Start Program	15. User Shortcut #3
4. Axis 1, 2, 3/Axis 4, 5, 6	10. User Shortcut #4	16. Emergency Stop
5. User Shortcut #2	11. Step to Next	17. Pendant
6. Quick Settings	12. USB Port and Reset Button	18. User Shortcut #1

TROUBLESHOOTING

When starting the welding Cobot, a few error notifications may appear on the screen and will cause the Cobot to malfunction. To help aid in clearing these errors, please see *Synchronization Process Steps* on page 2-6. If the errors do not clear, please contact your local Lincoln Electric representative.

HOW TO CLEAR AN ERROR ON ABB

1. Put the Cobot in Manual Mode. See *Switching from Auto to Manual and Back to Auto* on page 2-5.
2. Go in to Event Log (1) and select the Acknowledge Errors icon (2).




Figure 2-2

3. Go in to Domain menu (3) and select Clear all (4).




Figure 2-3

4. Put the Cobot in Auto Mode. See *Switching from Auto to Manual and Back to Auto* on page 2-5.

BRAKE RELEASE TOOL

1. Remove the brake release tool (1) that is attached to the power cord of the Cobot welder.

WARNING

Support welder arm with an appropriate device. Using the brake release tool will cause the Cobot arm brake to release and fall in a downward motion. Failure to support the welder arm will cause bodily harm or Cobot damage.

Note: The brake release tool is magnetic, when placed at certain joints in the axes, the brake in the joint will be released in order to move the Cobot arm.

2. Release the holding brake by placing the brake-release tool against the small recess at the axis (2). The brake will function correctly as soon as the tool is removed.




Figure 2-4

3. Place the brake-release tool back into the holder.

LIGHTS ON THE ARM AND THEIR MEANINGS

The light on the welding robot arm will illuminate three colors to mirror what the torch is doing:

- Green—Active weld or teaching a weld
- Blue—Recording/ programming Cobot arm movement
- Amber—Weld fault
- Light Blue/ White—Unlocked Cobot arm to move freely

HOW TO NAVIGATE TO ABB UI TO CREATE A CUSTOM WELD DEFINITION

For more information on the Cooper App and creating a custom weld, please see the links below:

[Cooper Welding Cobot Resources](#)

[Cooper App – Operators Manual](#)

SWITCHING FROM AUTO TO MANUAL AND BACK TO AUTO

1. Open the screen in the Cooper App and press the menu bar icon.
2. In the Control Panel (1), select the Manual icon (2).




Figure 2-5

3. In order to move the arm in manual mode, the operator will need to press the enabling button (3), which is located on the right side of the pendant.



Figure 2-6

4. When the enabling button is pressed, the Motors on icon will become highlighted. The operator should hear a “click” of the joint brakes on the Cobot arm.
5. To switch back into auto mode, open the Control Panel and select the Auto icon.

SYNCHRONIZATION PROCESS STEPS

1. Select the Settings icon (1).



Figure 2-7

Note: For Admin log in information, contact the local Lincoln Electric representative.

2. Select the Log out Default User icon (2) and log in as admin.




Figure 2-8

3. Select the Safety Controller icon (3).




Figure 2-9

Note: If the status light (4) is red, the robot is not synchronized.

4. Select the Synchronization tab (5).




Figure 2-10

5. Toggle the Enable Move to Sync Position (6) to On.




Figure 2-11

6. Enable manual mode, see *Switching from Auto to Manual and Back to Auto* on page 2-5.
7. With the dead man switch enabled, press the Press and hold to move (7) until all axis are at 0.
8. Once all axis are at 0, press the Synchronize icon (8).

Note: The status light will go green and the robot is now synchronized.




Figure 2-12

SHIPPING MODE STEPS

1. Move the Cobot joints to the following degrees:

Cobot Joint	Degrees
J1	+180
J2	-118.25
J3	+45
J4	+0
J5	-130
J6	+180

2. Place Cobot on shipping pallet and secure casters between 2x4 wood boards.

Note: Use cardboard protectors between banding and cart to prevent damage to the cart.

3. Secure the Cobot using metal and/or robust material banding at 2 or more places.
4. For shipping dimensions, please see *Cooper Welding Cobot Unboxing and Setup* on page 1-6.

GOFA & COOPER APP SOFTWARE UPDATE PROCESS

For more information on GoFa and Cooper App Software updates, please see the following links:

[Software Update Process](#)



Section 3

**COOPER WELDING COBOT OPTIONAL
EQUIPMENT**

For more information on the following products:

- Lincoln Electric Power Ream Torch Cleaner
- Lincoln Electric PerfectPoint Automated TCP Solution

Please see,

<https://www.lincolnelectric.com/en/operators-manuals>

Or use the QR code below:



Section 4
MAINTENANCE

Before Each Use	Complete
• Check the machine and remove all objects that are not necessary for operation.	
• Check that exposed cables are not damaged in any way.	
• Check the connector terminations.	
• Inspect there is no oil leaking from the sealed part of each seal.	
• Check that there are no abnormal noises or vibrations.	
• Inspect the following: <ul style="list-style-type: none"> • Condition of the welding torch • Wear of the nozzle contact tip • Condition of the gas diffuser and the wire guide sleeve • Condition of the torch bundle 	
Weekly Checks	Complete
• Check the working of all safety components.	
• Test the working of peripheral devices.	
• Clean the following: <ul style="list-style-type: none"> • Robot • Power source • Operating equipment • All the peripheral devices 	
Monthly Checks	Complete
• Inspect the body and components of the welding torch.	
• Inspect the cable of the teaching tablet.	
• Check that the cooling fan is operating silently. <ul style="list-style-type: none"> • If the fan has collected dust, clean the fan. 	
• Clean the wire feeder assembly.	
• Check that all the electrical terminals of the whole unit are tight.	
Yearly Checks	Complete
• Change the lithium cell of the processor or the front panel of the main control PCB.	

Section 5

COOPER WELDING COBOT PARTS CATALOG

CONSUMABLE PARTS LIST

Cooper Cobot ABB GoFa Welding Cobot		
Part Number	Description	Quantity
ABB GoFa		
A2054475	DSQC3124 FlexPendant	1
A2051611	Flex Teach Pendant 3M Cable	2
A2051803	FlexPendant Holder with E-Stop Cover	1
A2054477	FlexPendent Joystick Guard	2
A2054478	FlexPendent Power Cable Cover	1
A2054479	OmniCore C30 Small Size Silent Fan	1
A2055938	OmniCore C30 Standard Size Silent Fan	1
Lincoln Electric MAGNUMPRO Air Cooled Weld Torch		
K2647-11	A/C Robotic Torch (11 ft Long) GoFa-5	1
K2647-13	A/C Robotic Torch (13 ft Long) GoFa-10	2
KP45-3545-15	Liner - 15 ft for 0.035 in. & 0.045 in. Steel Wire	1
KP2747-1	Gas Diffuser	1
KP2743-1-62R	Gas Nozzle (Thread on, 1/8 in. Recessed, 5/8 in. ID)	1
KP2745-045	Contact Tip 0.045 in.	10
KP2745-035	Contact Tip 0.035 in.	10

Cooper Welding Cobot Parts Catalog



ED034270	SuperArc 0.035 in. L-59 WeldWire (33 lb Spool)	1
ED034271	SuperArc 0.045 in. L-59 WeldWire (33 lb Spool)	1
Lincoln Electric MAGNUMPRO Water-Cooled Weld Torch		
K5415-11	W/C Robotic Torch (11 ft Long) GoFa-5	1
K5415-13	W/C Robotic Torch (13 ft Long) GoFa-10	2
KP44-564-15	Liner - 15 ft for 0.035 in. and 0.045 in. Steel Wire	1
K5386-2	Nose Cone Assembly	1
KP4403-22	Gun Tube	1
KP4830-1	Gas Diffuser	1
KP2745-045	Contact Tip 0.045 in.	10
KP2745-035	Contact Tip 0.035 in.	10
KP4714-1	Gooseneck Nut Wrench	1
K4214-1	Water Fitting Tool	1
KP4215-1	Water Fitting Repair (K4214-1 Tool Required)	1
KP4216-1	Gooseneck O-Ring Kit	1
Lincoln Electric SmartTorch Bracket		
A2038074-10M	Female Cable Connector, 8 Pin/M8, 10M	1
A3118126	Control Buttons and Harness 8 Pin	1
Lincoln Electric Wire Feeder 4R220		
S28460	AutoDrive 4R220 Wire Drive - Motor Brush Kit	1
KP1505-035S	Drive Roll Kit (0.035 in., 4 roll)	1
KP1505-045S	Drive Roll Kit (0.045 in., 4 roll)	1

Spare Parts List Kits		
AD2498-26	Spare Parts, 0.035/0.045 AC WB Torch	1
AD2498-28	Spare Parts, 0.035/0.045 WC WB Torch	1

For more information see,
<https://www.lincolnelectric.com/en/operators-manuals>

Or use the QR code below:



CUSTOMER ASSISTANCE POLICY

The business of Lincoln Electric is manufacturing and selling high quality welding equipment, automated welding systems, consumables, and cutting equipment. Our challenge is to meet the needs of our customers, who are experts in their fields, and to exceed their expectations. On occasion, purchasers may ask Lincoln Electric for information or technical information about their use of our products. Our employees respond to inquiries to the best of their ability based on information and specifications provided to them by the customers and the knowledge they may have concerning the application. Our employees, however, are not in a position to verify the information provided or to evaluate the engineering requirements for the particular weldment, or to provide engineering advice in relation to a specific situation or application. Accordingly, Lincoln Electric does not warrant or guarantee or assume any liability with respect to such information or communications. Moreover, the provision of such information or technical information does not create, expand, or alter any warranty on our products. Any express or implied warranty that might arise from the information or technical information, including any implied warranty of merchantability or any warranty of fitness for any customers' particular purpose or any other equivalent or similar warranty is specifically disclaimed.

Lincoln Electric is a responsive manufacturer, but the definition of specifications, and the selection and use of specific products sold by Lincoln Electric is solely within the control of, and remains the sole responsibility of the customer. Many variables beyond the control of Lincoln Electric affect the results obtained in applying these types of fabrication methods and service requirements.

WELD FUME CONTROL EQUIPMENT

The operation of welding fume control equipment is affected by various factors including proper use and positioning of the equipment, maintenance of the equipment and the specific welding procedure and application involved. Worker exposure level should be checked upon installation and periodically thereafter to be certain it is within applicable OSHA PEL and ACGIH TLV limits.



THE LINCOLN ELECTRIC COMPANY

22801 St. Clair Avenue • Cleveland, OH • 44117-1199 • U.S.A.
Phone: +1.216.481.8100 • www.lincolnelectric.com