

AUTOPRO™ 20

For use with machines having Code Number: **11971**

Safety Depends on You

Marquette® arc welding and cutting equipment is designed and built with safety in mind. However, your overall safety can be increased by proper installation ... and thoughtful operation on your part. **DO NOT INSTALL, OPERATE OR REPAIR THIS EQUIPMENT WITHOUT READING THIS MANUAL AND THE SAFETY PRECAUTIONS CONTAINED THROUGHOUT.** And, most importantly, think before you act and be careful.



OPERATOR'S MANUAL

MARQUETTE
BY **LINCOLN**
ELECTRIC

Copyright © Lincoln Global Inc.

THANK YOU FOR SELECTING A QUALITY PRODUCT BY LINCOLN ELECTRIC.

PLEASE EXAMINE CARTON AND EQUIPMENT FOR DAMAGE IMMEDIATELY

When this equipment is shipped, title passes to the purchaser upon receipt by the carrier. Consequently, claims for material damaged in shipment must be made by the purchaser against the transportation company at the time the shipment is received.

SAFETY DEPENDS ON YOU

Lincoln arc welding and cutting equipment is designed and built with safety in mind. However, your overall safety can be increased by proper installation ... and thoughtful operation on your part. **DO NOT INSTALL, OPERATE OR REPAIR THIS EQUIPMENT WITHOUT READING THIS MANUAL AND THE SAFETY PRECAUTIONS CONTAINED THROUGHOUT.** And, most importantly, think before you act and be careful.

WARNING

This statement appears where the information must be followed exactly to avoid serious personal injury or loss of life.

CAUTION

This statement appears where the information must be followed to avoid minor personal injury or damage to this equipment.



KEEP YOUR HEAD OUT OF THE FUMES.

DON'T get too close to the arc. Use corrective lenses if necessary to stay a reasonable distance away from the arc.


READ and obey the Safety Data Sheet (SDS) and the warning label that appears on all containers of welding materials.

USE ENOUGH VENTILATION or exhaust at the arc, or both, to keep the fumes and gases from your breathing zone and the general area.

IN A LARGE ROOM OR OUTDOORS, natural ventilation may be adequate if you keep your head out of the fumes (See below).

USE NATURAL DRAFTS or fans to keep the fumes away from your face.

If you develop unusual symptoms, see your supervisor. Perhaps the welding atmosphere and ventilation system should be checked.



WEAR CORRECT EYE, EAR & BODY PROTECTION

PROTECT your eyes and face with welding helmet properly fitted and with proper grade of filter plate (See ANSI Z49.1).

PROTECT your body from welding spatter and arc flash with protective clothing including woolen clothing, flame-proof apron and gloves, leather leggings, and high boots.

PROTECT others from splatter, flash, and glare with protective screens or barriers.

IN SOME AREAS, protection from noise may be appropriate.

BE SURE protective equipment is in good condition.

Also, wear safety glasses in work area **AT ALL TIMES.**



SPECIAL SITUATIONS

DO NOT WELD OR CUT containers or materials which previously had been in contact with hazardous substances unless they are properly cleaned. This is extremely dangerous.

DO NOT WELD OR CUT painted or plated parts unless special precautions with ventilation have been taken. They can release highly toxic fumes or gases.

Additional precautionary measures

PROTECT compressed gas cylinders from excessive heat, mechanical shocks, and arcs; fasten cylinders so they cannot fall.

BE SURE cylinders are never grounded or part of an electrical circuit.

REMOVE all potential fire hazards from welding area.

ALWAYS HAVE FIRE FIGHTING EQUIPMENT READY FOR IMMEDIATE USE AND KNOW HOW TO USE IT.



SECTION A: WARNINGS



CALIFORNIA PROPOSITION 65 WARNINGS



WARNING: Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects, or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an exposed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel

WARNING: This product, when used for welding or cutting, produces fumes or gases which contain chemicals known to the State of California to cause birth defects and, in some cases, cancer. (California Health & Safety Code § 25249.5 *et seq.*)



WARNING: Cancer and Reproductive Harm
www.P65warnings.ca.gov

ARC WELDING CAN BE HAZARDOUS. PROTECT YOURSELF AND OTHERS FROM POSSIBLE SERIOUS INJURY OR DEATH. KEEP CHILDREN AWAY. PACEMAKER WEARERS SHOULD CONSULT WITH THEIR DOCTOR BEFORE OPERATING.

Read and understand the following safety highlights. For additional safety information, it is strongly recommended that you purchase a copy of "Safety in Welding & Cutting - ANSI Standard Z49.1" from the American Welding Society, P.O. Box 351040, Miami, Florida 33135 or CSA Standard W117.2-1974. A Free copy of "Arc Welding Safety" booklet E205 is available from the Lincoln Electric Company, 22801 St. Clair Avenue, Cleveland, Ohio 44117-1199.

BE SURE THAT ALL INSTALLATION, OPERATION, MAINTENANCE AND REPAIR PROCEDURES ARE PERFORMED ONLY BY QUALIFIED INDIVIDUALS.



FOR ENGINE POWERED EQUIPMENT.

- 1.a. Turn the engine off before troubleshooting and maintenance work unless the maintenance work requires it to be running.
- 1.b. Operate engines in open, well-ventilated areas or vent the engine exhaust fumes outdoors.
- 1.c. Do not add the fuel near an open flame welding arc or when the engine is running. Stop the engine and allow it to cool before refueling to prevent spilled fuel from vaporizing on contact



with hot engine parts and igniting. Do not spill fuel when filling tank. If fuel is spilled, wipe it up and do not start engine until fumes have been eliminated.

- 1.d. Keep all equipment safety guards, covers and devices in position and in good repair. Keep hands, hair, clothing and tools away from V-belts, gears, fans and all other moving parts when starting, operating or repairing equipment.
- 1.e. In some cases it may be necessary to remove safety guards to perform required maintenance. Remove guards only when necessary and replace them when the maintenance requiring their removal is complete. Always use the greatest care when working near moving parts.
- 1.f. Do not put your hands near the engine fan. Do not attempt to override the governor or idler by pushing on the throttle control rods while the engine is running.
- 1.g. To prevent accidentally starting gasoline engines while turning the engine or welding generator during maintenance work, disconnect the spark plug wires, distributor cap or magneto wire as appropriate.
- 1.h. To avoid scalding, do not remove the radiator pressure cap when the engine is hot.



ELECTRIC AND MAGNETIC FIELDS MAY BE DANGEROUS



- 2.a. Electric current flowing through any conductor causes localized Electric and Magnetic Fields (EMF). Welding current creates EMF fields around welding cables and welding machines
- 2.b. EMF fields may interfere with some pacemakers, and welders having a pacemaker should consult their physician before welding.
- 2.c. Exposure to EMF fields in welding may have other health effects which are now not known.
- 2.d. All welders should use the following procedures in order to minimize exposure to EMF fields from the welding circuit:
 - 2.d.1. Route the electrode and work cables together - Secure them with tape when possible.
 - 2.d.2. Never coil the electrode lead around your body.
 - 2.d.3. Do not place your body between the electrode and work cables. If the electrode cable is on your right side, the work cable should also be on your right side.
 - 2.d.4. Connect the work cable to the workpiece as close as possible to the area being welded.
 - 2.d.5. Do not work next to welding power source.



ELECTRIC SHOCK CAN KILL.



- 3.a. The electrode and work (or ground) circuits are electrically “hot” when the welder is on. Do not touch these “hot” parts with your bare skin or wet clothing. Wear dry, hole-free gloves to insulate hands.
- 3.b. Insulate yourself from work and ground using dry insulation. Make certain the insulation is large enough to cover your full area of physical contact with work and ground.

In addition to the normal safety precautions, if welding must be performed under electrically hazardous conditions (in damp locations or while wearing wet clothing; on metal structures such as floors, gratings or scaffolds; when in cramped positions such as sitting, kneeling or lying, if there is a high risk of unavoidable or accidental contact with the workpiece or ground) use the following equipment:

- Semiautomatic DC Constant Voltage (Wire) Welder.
 - DC Manual (Stick) Welder.
 - AC Welder with Reduced Voltage Control.
- 3.c. In semiautomatic or automatic wire welding, the electrode, electrode reel, welding head, nozzle or semiautomatic welding gun are also electrically “hot”.
 - 3.d. Always be sure the work cable makes a good electrical connection with the metal being welded. The connection should be as close as possible to the area being welded.
 - 3.e. Ground the work or metal to be welded to a good electrical (earth) ground.
 - 3.f. Maintain the electrode holder, work clamp, welding cable and welding machine in good, safe operating condition. Replace damaged insulation.
 - 3.g. Never dip the electrode in water for cooling.
 - 3.h. Never simultaneously touch electrically “hot” parts of electrode holders connected to two welders because voltage between the two can be the total of the open circuit voltage of both welders.
 - 3.i. When working above floor level, use a safety belt to protect yourself from a fall should you get a shock.
 - 3.j. Also see Items 6.c. and 8.



ARC RAYS CAN BURN.



- 4.a. Use a shield with the proper filter and cover plates to protect your eyes from sparks and the rays of the arc when welding or observing open arc welding. Headshield and filter lens should conform to ANSI Z87.1 standards.
- 4.b. Use suitable clothing made from durable flame-resistant material to protect your skin and that of your helpers from the arc rays.
- 4.c. Protect other nearby personnel with suitable, non-flammable screening and/or warn them not to watch the arc nor expose themselves to the arc rays or to hot spatter or metal.




FUMES AND GASES CAN BE DANGEROUS.



- 5.a. Welding may produce fumes and gases hazardous to health. Avoid breathing these fumes and gases. When welding, keep your head out of the fume. Use enough ventilation and/or exhaust at the arc to keep fumes and gases away from the breathing zone. **When welding hardfacing (see instructions on container or SDS) or on lead or cadmium plated steel and other metals or coatings which produce highly toxic fumes, keep exposure as low as possible and within applicable OSHA PEL and ACGIH TLV limits using local exhaust or mechanical ventilation unless exposure assessments indicate otherwise. In confined spaces or in some circumstances, outdoors, a respirator may also be required. Additional precautions are also required when welding on galvanized steel.**
- 5.b. The operation of welding fume control equipment is affected by various factors including proper use and positioning of the equipment, maintenance of the equipment and the specific welding procedure and application involved. Worker exposure level should be checked upon installation and periodically thereafter to be certain it is within applicable OSHA PEL and ACGIH TLV limits.
- 5.c. Do not weld in locations near chlorinated hydrocarbon vapors coming from degreasing, cleaning or spraying operations. The heat and rays of the arc can react with solvent vapors to form phosgene, a highly toxic gas, and other irritating products.
- 5.d. Shielding gases used for arc welding can displace air and cause injury or death. Always use enough ventilation, especially in confined areas, to insure breathing air is safe.
- 5.e. Read and understand the manufacturer’s instructions for this equipment and the consumables to be used, including the Safety Data Sheet (SDS) and follow your employer’s safety practices. SDS forms are available from your welding distributor or from the manufacturer.
- 5.f. Also see item 1.b.



WELDING AND CUTTING SPARKS CAN CAUSE FIRE OR EXPLOSION.



- 6.a. Remove fire hazards from the welding area. If this is not possible, cover them to prevent the welding sparks from starting a fire. Remember that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas. Avoid welding near hydraulic lines. Have a fire extinguisher readily available.
- 6.b. Where compressed gases are to be used at the job site, special precautions should be used to prevent hazardous situations. Refer to "Safety in Welding and Cutting" (ANSI Standard Z49.1) and the operating information for the equipment being used.
- 6.c. When not welding, make certain no part of the electrode circuit is touching the work or ground. Accidental contact can cause overheating and create a fire hazard.
- 6.d. Do not heat, cut or weld tanks, drums or containers until the proper steps have been taken to insure that such procedures will not cause flammable or toxic vapors from substances inside. They can cause an explosion even though they have been "cleaned". For information, purchase "Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping That Have Held Hazardous Substances", AWS F4.1 from the American Welding Society (see address above).
- 6.e. Vent hollow castings or containers before heating, cutting or welding. They may explode.
- 6.f. Sparks and spatter are thrown from the welding arc. Wear oil free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes and a cap over your hair. Wear ear plugs when welding out of position or in confined places. Always wear safety glasses with side shields when in a welding area.
- 6.g. Connect the work cable to the work as close to the welding area as practical. Work cables connected to the building framework or other locations away from the welding area increase the possibility of the welding current passing through lifting chains, crane cables or other alternate circuits. This can create fire hazards or overheat lifting chains or cables until they fail.
- 6.h. Also see item 1.c.
- 6.i. Read and follow NFPA 51B "Standard for Fire Prevention During Welding, Cutting and Other Hot Work", available from NFPA, 1 Batterymarch Park, PO box 9101, Quincy, MA 022690-9101.
- 6.j. Do not use a welding power source for pipe thawing.



CYLINDER MAY EXPLODE IF DAMAGED.



- 7.a. Use only compressed gas cylinders containing the correct shielding gas for the process used and properly operating regulators designed for the gas and pressure used. All hoses, fittings, etc. should be suitable for the application and maintained in good condition.
- 7.b. Always keep cylinders in an upright position securely chained to an undercarriage or fixed support.
- 7.c. Cylinders should be located:
 - Away from areas where they may be struck or subjected to physical damage.
 - A safe distance from arc welding or cutting operations and any other source of heat, sparks, or flame.
- 7.d. Never allow the electrode, electrode holder or any other electrically "hot" parts to touch a cylinder.
- 7.e. Keep your head and face away from the cylinder valve outlet when opening the cylinder valve.
- 7.f. Valve protection caps should always be in place and hand tight except when the cylinder is in use or connected for use.
- 7.g. Read and follow the instructions on compressed gas cylinders, associated equipment, and CGA publication P-1, "Precautions for Safe Handling of Compressed Gases in Cylinders," available from the Compressed Gas Association, 14501 George Carter Way Chantilly, VA 20151.



FOR ELECTRICALLY POWERED EQUIPMENT.



- 8.a. Turn off input power using the disconnect switch at the fuse box before working on the equipment.
- 8.b. Install equipment in accordance with the U.S. National Electrical Code, all local codes and the manufacturer's recommendations.
- 8.c. Ground the equipment in accordance with the U.S. National Electrical Code and the manufacturer's recommendations.

Refer to
<http://www.lincolnelectric.com/safety>
for additional safety information.

	Page
Installation	Section A
Technical Specifications	A-1
Safety Precautions	A-2
Select Proper Location	A-2
Stacking.....	A-2
Tilting	A-2
High Frequency Interference Protection.....	A-2
Input Electrical Connections.....	A-2
Compressed Air or Gas Input Connections.....	A-3
Connections to Ground Cable	A-3
Torch Connections	A-3
<hr/>	
Operation	Section B
Safety Precautions	B-1
Description	B-1
User Responsibility.....	B-2
Design Features and Advantages	B-2
Cutting Capability	B-2
Torch Consumables	B-2
Limitations	B-2
Controls and Settings	B-2
Cutting Operations	B-3
Check Air Quality.....	B-3
Cutting with a Hand Torch	B-3, B-4
Pilot Arc Discussion.....	B-5
Torch Consumable Parts Selection.....	B-5
<hr/>	
Maintenance	Section D
Safety Precautions	D-1
Routine Maintenance.....	D-1
Periodic Maintenance	D-1
Compressed Air Filter.....	D-2
<hr/>	
Troubleshooting	Section E
Safety Precautions.....	E-1
How to Use Troubleshooting Guide.....	E-1
Troubleshooting Guide	E-2
<hr/>	
Wiring Diagrams	Section F
Wiring Diagram	F-1
<hr/>	
Parts Lists	P-723 Series
<hr/>	

TECHNICAL SPECIFICATIONS - AUTOPRO™ 20

INPUT - SINGLE PHASE				
Standard Voltage		1Ø Input Current at Rated Output		
115/1/50/60Hz (15 Amp Branch)		115 V: 20A @ 50%		
115/1/50/60Hz (20 Amp Branch with 20 Amp Plug*)		115 V: 26A @ 40%		
RATED OUTPUT				
Duty Cycle		AMPS		
50% on 115V (15 Amp Branch)		15 A		
40% on 115V (20 Amp Branch with 20 Amp Plug*)		20 A		
OUTPUT				
Current Range		Open Circuit Voltage		Pilot Current
10-20 Amps		310 VDC		17 Amps
REQUIRED AIR FLOW RATE		REQUIRED AIR INLET PRESSURE		
3.5 cu. ft./min. (100L/min.)		72.5 to 150 PSI (5 Bar TO 10.3 Bar)		
RECOMMEND INPUT WIRE AND FUSE SIZES				
For all plasma cutting applications Based on U.S. National Electrical Code Ambient Temperature 30°C or Less				
Output	AC Input Voltage at 50/60 Hertz	Plug Size	Maximum Time-Delay Circuit Breaker or Fuse Size	Type SJT or Hard Usage Input Cord
20 A	115V-1Ø	5-20P*	20 AMPS	3 Conductor, #14 AWG
15 A	115V-1Ø	5-15P	15 Amps	
PHYSICAL DIMENSIONS				
Height	Width	Depth	Weight Including Torch Cable	
12 in. 305 mm	6 in. 152 mm	16 in. 406 mm	21 lbs. 9.5 kg.	

*5-20P plug must comply with the standard for attachment plugs and receptacles, UL498.

Read entire Installation Section before installing the AUTOPRO™ 20.

SAFETY PRECAUTIONS

⚠ WARNING

ELECTRIC SHOCK CAN KILL.



- Only qualified personnel should perform this installation.
- Only personnel that have read and understood the AUTOPRO™ 20 Operating Manual should install and operate this equipment.
- Machine must be plugged into a receptacle which is grounded per any national, local or other applicable electrical codes.
- The AUTOPRO™ 20 power switch is to be in the OFF (“O”) position when installing work cable and gun and when connecting power cord to input power.

SELECT PROPER LOCATION

Place the AUTOPRO™ 20 where clean cool air can freely circulate in and out the front, rear and side louvers. Dirt, dust, smoke, gas or any foreign material that can be drawn into the machine should be kept at a minimum. Insure open space of at least 15 ft. around the machine. Failure to observe these precautions can result in excessive operating temperatures and nuisance shutdown of the machine.

STACKING

The AUTOPRO™ 20 cannot be stacked.

TILTING

The AUTOPRO™ 20 must be placed on a stable, level surface so it will not topple over.

HIGH FREQUENCY INTERFERENCE PROTECTION

The AUTOPRO™ 20 employs a touch start mechanism for arc initiation which eliminates high frequency emissions from the machine as compared with spark gap and solid state type high frequency generators. Keep in mind, though, that these machines may be used in an environment where other high frequency generating machines are operating. By taking the following steps, high frequency interference into the AUTOPRO™ 20 can be minimized.

- (1) Make sure the power supply chassis is connected to a good earth ground. The work terminal ground does NOT ground the machine frame.
- (2) Keep the work clamp isolated from other work clamps that have high frequency.
- (3) If the work clamp cannot be isolated, then keep the clamp as far as possible from other work clamp connections.
- (4) When the machine is enclosed in a metal building, several good earth driven electrical grounds around the periphery of the building are recommended.

Failure to observe these recommended installation procedures may cause improper function of the AUTOPRO™ 20 or possibly even damage to the control system or power supply components.

INPUT ELECTRICAL CONNECTIONS

The AUTOPRO™ 20 must be connected to a Line-Neutral system with protective grounding wire. Check that the relevant electrical outlet is actually connected to the distribution system grounding.

The AUTOPRO™ 20 is rated for 115VAC input.

Use on 15 amp branch circuits will limit cutting output. When the output is set at 16 amps or greater, the input fuse or circuit breaker may “blow” in roughly 30 seconds or less (depending on fuse or circuit breaker type).

To achieve 16-20 amp output with 115VAC input, replace the 15 amp plug on the input cord with a 20 amp plug, and connect the unit to a 20 amp branch circuit with super lag fuses (or equivalent breaker). To install 20 amp plug: Connect the white (neutral) wire under terminal clamp with silver screw, and black (hot) wire under terminal clamp with brass screw. Connect green wire under terminal clamp with green screw. Tighten terminal wire clamp screws securely.

5-20P plug must comply with the standard for attachment plugs and receptacles, UL498. This product is acceptable for use only when an attachment plug as specified is properly attached to the supply cord.

⚠ WARNING

- Failure to wire as instructed may cause personal injury or damage to equipment.
- To be installed or checked by an electrician or qualified person only.

Use of normal 20 amp household breakers may result in over current trips. If breaker trips occur, reduce the cutting current output until nuisance trips stop.

COMPRESSED AIR OR GAS INPUT CONNECTION

A source of clean, dry air or nitrogen must be supplied to the AUTOPRO™ 20. Oil in the air is a severe problem and must be avoided. The supply pressure must be between 72.5 and 150 psi (5 and 10.3 bar). The flow rate is approximately 3.5 cu. ft./min. (100L/min.). Failure to observe these precautions could result in excessive operating temperatures or damage to the torch.

⚠ WARNING

Air with considerable quantity of humidity or oil may cause an excessive wear of the parts or even damage the torch.

If there are any doubts about the quality of the compressed air available, it is suggested that an air dryer be installed before the input filter. Using flexible airline, connect the compressed air to the rear of the machine. Do not exceed maximum entry pressure of 150 PSI (10.3 Bar). The pressure must be adjusted to 72.5 PSI (5 Bar), minimum.

- To use the air fitting supplied with the machine apply teflon tape to the fitting threads and install the fitting in the port at the rear of the machine.

NOTE: When using nitrogen gas from a cylinder, the cylinder must have a pressure regulator.

- Maximum psi from a nitrogen gas cylinder to the AUTOPRO™ 20 regulator should never exceed 150 psi (10.3 Bar).
- Install a hose between the nitrogen gas cylinder regulator and the AUTOPRO™ 20 gas inlet.

⚠ WARNING



CYLINDER could explode if damaged.

- Keep cylinder upright and chained to a fixed support.
- Keep cylinder away from areas where it could be damaged.
- Never lift machine with cylinder attached.
- Never allow the cutting torch to touch the cylinder.
- Keep cylinder away from live electrical parts.
- Maximum inlet pressure 150 PSI (10.3 Bar).

CONNECTION TO GROUND CABLE

Connect the work cable clamp to the piece to be cut or to the metallic workbench. Take the following precautions:

Verify that there is a good electrical contact particularly if insulated or oxidated coated sheets are cut.

Make ground connections as close as possible to the cutting area. The use of the metallic structures which are not part of the workpiece, such as return cable of the cutting current, may endanger the safety system and give poor cutting results.

Do not make a ground connection on the piece which is to be cut off.

TORCH CONNECTION

Before starting the cutting operations verify that the parts are properly assembled by inspecting the head of the torch as shown in the “Operations Section”(Torch Consumable Parts).

Read and understand this entire section before operating the machine.

SAFETY PRECAUTIONS

⚠ WARNING**ELECTRIC SHOCK can kill.**

- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.

**FUMES AND GASES can be dangerous.**

- Keep your head out of fumes.
- Use ventilation or exhaust to remove fumes from breathing zone.

**WELDING, CUTTING and GOUGING SPARKS can cause fire or explosion**

- Keep flammable material away.
- Do not weld, cut or gouge on containers that have held combustibles.

**ARC RAYS can burn.**

- Wear eye, ear and body protection.

**PLASMA ARC can injure**

- Keep your body away from nozzle and plasma arc.
- Operate the pilot arc with caution. The pilot arc is capable of burning the operator, others or even piercing safety clothing.

Observe additional Safety Guidelines detailed in the beginning of this manual.

DESCRIPTION

The AUTOPRO™ 20 is a constant current, continuous control plasma cutter power source.

The AUTOPRO™ 20 comes standard with an air regulator and pressure gauge. The unit is powered from a 115Vac, 20 amp input circuit with a 40% duty cycle rating on a 10 minute basis, with 20 amp output. The unit includes a hand-held torch with consumables and a work cable with clamp.

The AUTOPRO™ 20 utilizes a 3 second delay after pressing the trigger before arc initiation to ensure that the operator is ready. The unit will not function if consumables are not installed correctly or missing, protecting the user. The unit uses pneumatic-action for arc initiation and does not use high-frequency.

Plasma is a gas that is heated to an extremely high temperature and ionized so that it becomes a conductor of electricity.

This cutting procedure utilizes the plasma to transfer the electric arc to the metal workpiece. The arc melts a small amount of the work piece and the compressed air blows away the molten metal there by producing the cutting action.

The torch uses compressed air from a single source, for both the plasma, cooling and protective gas.

The start of the cycle is determined by an arc, called the pilot arc, which is struck between the moveable electrode (negative polarity) and the torch nozzle (positive polarity) due to a short circuit between these two elements.

When the torch is brought near the workpiece to be cut and the trigger is pressed the pilot arc is transferred between the electrode and the workpiece thus striking a plasma arc, also called the cutting arc.

The duration of the pilot arc is set in the factory at 3 seconds; if the transfer has not been made within this time, the cycle is automatically stopped except for the cooling air which is kept on.

USER RESPONSIBILITY

Variation such as plate chemistry, plate surface condition (oil, scale), plate thickness, preheat, quench, gas type, gas flow rate and equipment may produce results different than those expected. Some adjustments to procedures may be necessary to compensate for unique individual conditions. Test all procedures duplicating actual field conditions.

DESIGN FEATURES AND ADVANTAGES

- Light weight
- Continuous output control
- Indicator LEDs
- Cooling fan
- Rapid arc restrike for cutting across gaps
- 3 second arc delay for safety
- Adjustable air pressure regulator with locking feature
- Part-in-place verification for safety and proper operation
- Thermostatic protection with thermal indication
- Air inlet filter with water purge button to protect air path and torch
- Lighted ON/OFF switch
- High input voltage protection

CUTTING CAPABILITY

The AUTOPRO™ 20 is rated for 20A @ 40% duty cycle. The unit is designed to cut up to 3/8" inch mild steel, but has the capability to cut other metals such as stainless and aluminum (travel speed will vary).


TORCH CONSUMABLES

The torch consumables consist of an Electrode, Gas Distributor Ring, Nozzle, and Shield Cup. The consumable parts must be placed in the correct order and secured properly for the unit to operate.

LIMITATIONS

- For indoor use only.
- Do not exceed output current and duty cycle rating of machine. Do not use the AUTOPRO™ 20 for pipe thawing.
- Do not power with **generators** or **engine drives**.

CONTROLS AND SETTINGS



1. **ON/OFF Switch** – In the ON position the machine is ready for normal operation. All system control circuits are activated. OFF position deactivates control circuits.
2. **Output Current Knob**-Adjusts the cutting current supplied by the machine according to the thickness of material/speed.
3. **Green LED** – Turns ON when input voltage is applied within normal range – blinks slowly when input voltage goes above 130Vac, or below 95Vac.
4. **Red LED** – Turns ON when torch is triggered Blinks quickly during 3 second safety pre-flow prior to pilot arc ignition Blinks slowly if cutting arc is not initiated after 3 second pilot arc ignition.
5. **Yellow LED** – Turns ON when the thermal protection is activated. Blinks slowly when the under pressure protection is working (the pressure is under 55 PSI, 3.8 Bar)
6. **Air Regulator** – Adjusts the input air pressure – pull upward to unlock, press down to lock – nominal air pressure setting is 65 PSI, 4.5 Bar.
Note: Regulator should never be set above 87 PSI (6 Bar).
7. **Compressed Air Connection**
8. **Input Cord**
9. **Work cable with clamp**
10. **Torch**

CUTTING OPERATIONS

BEFORE CUTTING

⚠ WARNING



ELECTRIC SHOCK CAN KILL.
Disconnect input power by removing the plug from the receptacle before assembling or disassembling torch parts, or torch and lead assemblies.

Check and follow instructions listed in the "Safety and Installation" section of this manual.

TORCH PARTS

Check the torch for proper assembly. Install proper torch parts for the desired application (refer to the Torch Consumable Parts Selection Section).

NOTE: The power supply will not operate unless the torch shield cup is fully seated against the PIP (Parts in Place) pins in the torch head.

INPUT POWER

Check the power source for proper input voltage. Make sure the power source meets circuit protection and wiring requirements. Plug in power cord to supply input power to the unit.


GROUND CABLE

Check for a solid ground cable connection to the workpiece.

AUTOMATIC PURGE SYSTEM

Place the ON/OFF switch to the ON position. If the line voltage is OK, the green LED will turn on. Activate the torch trigger to initiate air purge. There will be a 3 second delay to remove any condensation that may have accumulated in the torch and air lines while the system was shut down. When the air purge (Air safety time) is complete, pilot arc will be initiated.

FIGURE B.1



CHECKING AIR QUALITY

To check air quality, deactivate the torch (post-flow) and place a welding filter lens in front of the torch. Any oil or moisture in the air will be visible on the lens. **DO NOT** initiate pilot arc while checking air quality.

When preparing to cut, position the machine as close to the work as possible. Make sure you have all materials needed to complete the job and have taken all safety precautions. It is important to follow these operating steps each time you use the machine.

• COMPRESSED AIR

The AUTOPRO™ 20 requires compressed air to be attached to the unit. The input air pressure minimum must be 72.5 PSI, 5 Bar and must not exceed 150 PSI, 10.3 Bar. An air regulator is included with the unit with optimum pressure setting set to 65 PSI, 4.5 Bar.

The unit is also equipped with an air filter which captures water and oil vapor. The vapor collected can be drained out of the bottom of the unit by turning the drain button. The unit will not operate if the input air pressure is below 55 PSI, 3.8 Bar.

Three Position Drain knob: (See Figure B.1)


1. Open
2. Open when no air pressure, closed when air pressure.
3. Closed

CUTTING WITH A HAND TORCH


- Turn the main power and the machine power switch on.
 - The fan should start.
 - The pre-charge circuit will operate for 3 seconds, then the green "Power" LED should turn on.
- Be sure that the work lead is clamped to the workpiece before cutting.
- Set the output current control knob at maximum position for higher cutting speed and less dross formation. Reduce the current, if desired to reduce the kerf (cut) width, heat affected zone or travel speed as required.

- When ready to cut, place the torch near the work, make certain all safety precautions have been taken and pull the trigger.
 - The air will flow for a preflow time of 3 seconds and the pilot arc will start.
 - The pilot arc will run for 3.0 seconds and shut off unless the arc is brought in contact with the work and the arc is transferred. Avoid excessive pilot arc time by transferring the arc to the workpiece quickly.
 - When the arc is brought within 1/8" - 1/4" from the work piece: the arc will transfer, the current will ramp to the setting on the control panel, and the cut can last indefinitely (or until the duty cycle of the unit is exceeded).
- Pierce the work piece by slowly lowering the torch onto the metal at a 30° angle away from the operator. This will blow the dross away from the torch nozzle. Slowly rotate the torch to vertical position as the arc becomes deeper.

NOTE: Graphics shown are for understanding torch angles for best results – the distances from the work piece are exaggerated. In actual operation, the nozzle should be held just above the work piece surface.



- Keep moving while cutting. Cut at a steady speed without pausing. Maintain the cutting speed so that the arc lag is 10° to 20° behind the travel direction.



- Use a 5° - 15° leading angle in the direction of the cut.
- Finish the cut to be made and release the trigger.

NOTE: For better torch control, it is acceptable to let the nozzle drag along the work piece surface. This will shorten nozzle life. Also, it is acceptable to place a non-conductive torch guide on the work piece in order to achieve a cleaner cut

- When the trigger is released, the arc will stop.
 - The gas will continue to flow for 20 seconds of postflow. If the trigger is activated within this time period, the pilot arc will restart after the 3 second delay.
- If the dross is difficult to remove, reduce the cutting speed. High speed dross is more difficult to remove than low speed dross.
- The right side of the cut is more square than the left as viewed along the direction of travel.
- Clean spatter and scale from the nozzle frequently.

Parts in place:

- Check the assembly of the torch consumables. If they are not properly in place, the machine will not start. **Make sure that the shield cup is hand tight. Do not use pliers or over tighten.**
- Check the conditions of the inside of the nozzle. If debris has collected, rub the electrode on the inside bottom of the nozzle to remove any oxide layer that may have built up. Refer to the "Routine Maintenance Section".
- Check the condition of the electrode. If the end has a crater-like appearance, replace it along with the nozzle. The maximum wear depth of the electrode is approximately .062". A green and erratic arc will indicate definite electrode failure and the electrode should be replaced immediately.
- Replace the nozzle when the orifice exit is eroded away or oval shaped.

⚠ WARNING



ELECTRIC SHOCK CAN KILL.
Disconnect input power by removing the plug from the receptacle before assembling or disassembling torch parts, or torch and lead assemblies.

- If the machine does not reset or continues to trip, consult the Troubleshooting Section.
- Use the proper cutting procedures referred to in Procedure Recommendations.

PILOT ARC DISCUSSION

The AUTOPRO™ 20 has a smooth, continuous pilot arc. The pilot arc is only a means of transferring the arc to the workpiece for cutting. Repeated pilot arc starts, in rapid succession, is not recommended as these starts will generally reduce consumable life. Occasionally, the pilot arc may sputter or start intermittently. This is aggravated when the consumables are worn or the air pressure is too high. Always keep in mind that the pilot arc is designed to transfer the arc to the workpiece and not for numerous starts without cutting.

When the pilot arc is started, a slight impulse will be felt in the torch handle. This occurrence is normal and is the mechanism which starts the plasma arc. This impulse can also be used to help troubleshoot a "no start" condition.

⚠ WARNING



ELECTRIC SHOCK CAN KILL.
Disconnect input power by removing the plug from the receptacle before assembling or disassembling torch parts, or torch and lead assemblies.

Be sure the operator is equipped with proper gloves, clothing, eye and ear protection. Make sure no part of the operator's body comes in contact with the work piece while the torch is activated.

⚠ CAUTION

Sparks from the cutting process can cause damage to coated, painted, and other surfaces such as glass, plastic and metal.

NOTE: Handle torch cable with care and protect it from damage.


TORCH CONSUMABLE PARTS SELECTION

To change the torch consumable parts use the following procedure:

NOTE: The nozzle, gas distributor, and electrode are held in place by the shield cup. Position the torch with the shield cup facing upward to prevent these parts from falling out when the cup is removed.

1. Unscrew and remove the shield cup from the Torch Head Assembly. Figure B.2 Consumable Parts.
2. Remove the nozzle, gas distributor, and electrode.
3. Install the electrode, gas distributor and nozzle.
4. Hand tighten the shield cup until it is seated on the torch head. If resistance is felt when installing the cup, check the threads before proceeding.

FIGURE B.2



OPERATING FAULTS

During cutting operations performance faults may arise, such as:

- Insufficient penetration:
 - too high cutting speed;
 - torch is tilted;
 - piece is too thick;
 - cutting current is too low;
 - torch parts are worn out;
 - non-genuine Manufacturer's parts.
- Interruption of the cutting arc:
 - cutting speed too slow;
 - excessive distance between torch and work piece;
 - Input Voltage too low-reduce output current;
 - torch parts are worn out;
 - non-genuine Manufacturer's parts;
 - poor work cable connection/disconnected.
- Excessive slag/dross:
 - too low cutting speed (bottom dross);
 - too high cutting speed (top dross);
 - excessive distance between torch and work piece;
 - cutting current too low;
 - torch parts are worn out;
 - non-genuine Manufacturer's parts.
- Tilted cutting (not perpendicular):
 - torch position not correct;
 - asymmetric wear of nozzle hole and/or incorrect assembly of the torch parts.
- Excessive wear of nozzle and electrodes:
 - air pressure too low;
 - exceeding system capability (material too thick);
 - contaminated air (humidity/oil);
 - excessive pilot arc ignitions in the air;
 - improperly assembled torch;
 - torch nozzle contacting workpiece;
 - damaged or loose torch head components;
 - non-genuine Manufacturer's parts.

⚠ WARNING

ELECTRIC SHOCK can kill.

- Have a qualified person service this equipment.
- Disconnect input power by removing plug from receptacle before assembling or disassembling torch parts, or torch and lead assemblies.
- Do not touch electrically hot parts.

ROUTINE MAINTENANCE

1. Keep the cutting or gouging area and the area around the machine clean and free of combustible materials. No debris should be allowed to collect which could obstruct air flow to the machine.
2. Every 3-4 months or so, the machine should be cleaned with a low pressure airstream. Keeping the machine clean will result in cooler operation and higher reliability. Be sure to clean these areas:
 - Printed circuit boards and heat sinks
 - Power switch

⚠ CAUTION

- When using a low pressure airstream, wear appropriate eye protection. Only use dry compressed air for cleaning. Do not point the jet of air at the electronic circuits.
3. Examine the sheet metal case for dents or breakage. Repair the case as required. Keep the case in good condition to insure that high voltage parts are protected and correct spacings are maintained. All external sheet metal screws must be in place to insure case strength and electrical ground continuity.
 4. Inspect the cable periodically for any slits or puncture marks in the cable jacket. Replace if necessary. Check to make sure that nothing is crushing the cable and blocking the flow of air through the air tube inside. Also, check for kinks in the cable periodically and relieve any so as not to restrict the flow of air to the torch.
 5. Inspect Torch Body and Handle, keep thoroughly clean **WITHOUT THE USE OF SOLVENTS**. In case of damage replace components for **SAFETY CONDITIONS**. If repairs cannot be made on site contact a local field service shop.

PERIODIC MAINTENANCE**⚠ WARNING**

ELECTRIC SHOCK CAN KILL.

- Turn off machine and disconnect input power by removing the plug from the receptacle switch before tightening, cleaning or replacing consumables.

Change consumables as required.

Torch:

- Periodically according to use, or if experiencing cutting faults, inspect consumable parts associated with the plasma arc.

Shield Cup:

- Unscrew manually from the head of the torch. Clean thoroughly and replace if damaged (burns, distortions or cracks).

Nozzle:

- Check wear of plasma arc thru-hole and inner & outer surfaces. If thru-hole is widened compared to it's original diameter, replace nozzle. If surfaces are particularly oxidized, clean them with extra fine sand paper.

Air Distribution Ring:

- Verify there are no burns or cracks and that air-flow holes are not obstructed. If damaged, replace immediately.

Electrode:

- Replace electrode when crater on emitting surface is about .08"(2mm).

⚠ WARNING

- Before making any adjustments to the torch, let it cool the entire post-flow time.
- Except for particular cases, it is advised to replace electrode and nozzle **AT THE SAME TIME**.
- Insure correct assembly order of torch parts.
- Be careful that gas distributor ring is assembled properly.
- Reassemble shield cup screwing it on manually (hand tighten)
- Never assemble shield cup without having included gas distributor ring and nozzle beforehand.
- Timely and appropriate maintenance on torch parts is essential for safety and proper functionality of the cutting system.

COMPRESSED AIR FILTER

The unit is supplied with a filter for the compressed air and fitted with a manual drain for condensation. (Drain is located on the bottom of the filter). Purge periodically to remove the water in the filter by opening the drain knob.

Do not use solvents to clean the filter; use soapy water only.

HOW TO USE TROUBLESHOOTING GUIDE

⚠ WARNING

Service and Repair should only be performed by Lincoln Electric Factory Trained Personnel. Unauthorized repairs performed on this equipment may result in danger to the technician and machine operator and will invalidate your factory warranty. For your safety and to avoid Electrical Shock, please observe all safety notes and precautions detailed throughout this manual.

This Troubleshooting Guide is provided to help you locate and repair possible machine malfunctions. Simply follow the three-step procedure listed below.

Step 1. LOCATE PROBLEM (SYMPTOM).

Look under the column labeled "PROBLEM (SYMPTOMS)". This column describes possible symptoms that the machine may exhibit. Find the listing that best describes the symptom that the machine is exhibiting.

Step 2. POSSIBLE CAUSE.

The second column labeled "POSSIBLE CAUSE" lists the obvious external possibilities that may contribute to the machine symptom.

Step 3. RECOMMENDED COURSE OF ACTION

This column provides a course of action for the Possible Cause, generally it states to contact your local Lincoln Authorized Field Service Facility.

If you do not understand or are unable to perform the Recommended Course of Action safely, contact your local Lincoln Authorized Field Service Facility.

⚠ WARNING**ELECTRIC SHOCK CAN KILL.**

- Turn off machine and disconnect input power by removing the plug from the receptacle switch before tightening, cleaning or replacing consumables.

⚠ CAUTION


If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your **Local Lincoln Authorized Field Service Facility** for technical troubleshooting assistance before you proceed.

Observe all Safety Guidelines detailed throughout this manual

PROBLEMS (SYMPTOMS)	POSSIBLE CAUSE	RECOMMENDED COURSE OF ACTION
GREEN LED OFF, Fan not operating. No Input Power.	<ol style="list-style-type: none"> 1. Plug unit into 115V outlet. 2. Reset Breaker. 	<p>If all recommended possible areas of misadjustment have been checked and the problem persists, Contact your local Authorized Field Service Facility.</p>
GREEN LED ON, YELLOW Overtemperature / under pressure LED ON. Unit is overheated.	<ol style="list-style-type: none"> 1. Make sure the unit has not been operated beyond duty cycle limits. 2. Air Flow obstructed. 	
GREEN LED ON, YELLOW Over temperature / under pressure LED blinks. No air flow in purge or pre-flow.	<ol style="list-style-type: none"> 1. Air not connected or pressure too low. Check source for at least 72.5 PSI (5 Bar) during purge or pre-flow, adjust air pressure to 65 PSI (4.5 Bar). 2. Air filter or air line blocked, torch blocked. Replace filter cartridge. Check that air line and torch leads are free of twists and kinks. 	
GREEN LED ON, YELLOW Over temperature / under pressure LED OFF, no air flow when torch switch pressed.	<ol style="list-style-type: none"> 1. Shield cup not properly installed on torch. Check that shield cup is fully seated against torch. 2. Faulty Torch Switch or Parts Assembly in torch holder. Refer to "Operations Section" (Torch Consumable Parts). 3. Faulty Main PC Board Repair / Replace Power Supply. 	
GREEN LED ON, YELLOW Over temperature / under pressure LED OFF. Air flows, Pilot arc does not start.	<ol style="list-style-type: none"> 1. Faulty torch parts. Inspect torch parts and replace if necessary. 2. Faulty main PC Board. Repair / replace. 	
Torch has pilot arc but does not cut.	<ol style="list-style-type: none"> 1. Work lead not connected. Make sure work lead is connected securely to bare metal. 2. AC input power too low. Use shortest distance to breaker panel possible. 3. Faulty Main PC Board. Repair/Replace. 	

⚠ CAUTION

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact your **Local Lincoln Authorized Field Service Facility** for technical troubleshooting assistance before you proceed.



S1	ON - OFF	INTERRUPTOR ON - OFF	ON - OFF	ELETTROVALVOLA
Y1	SOLENOID VALVE	ELEKTROVANNE	ELETTROVALVULA	PRESSOSTATO
P	PRESSOSTAT	LUFDRUCKSCHALTER	PRESSOSTATO	PULSANTE TORCIA
PT	TORCH PUSH BUTTON	BOUTON TORCHE	PULSADOR ANTORCHA	FILTRO-AIRE-REDUCIDOR
F	AIR FILTER-REDUCER	FILTRE AIR-MANOMETEMEUR	FILTRO-AIRE-REGULADOR	IMPEDANZA
XL	CHOKE	IMPEDANZ	IMPEDANZA	

NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual. The specific diagram for a particular code is pasted inside the machine on one of the enclosure panels. If the diagram is illegible, write to the Service Department for a replacement. Give the equipment code number.

NOTES

			
WARNING	<ul style="list-style-type: none"> ● Do not touch electrically live parts or electrode with skin or wet clothing. ● Insulate yourself from work and ground. 	<ul style="list-style-type: none"> ● Keep flammable materials away. 	<ul style="list-style-type: none"> ● Wear eye, ear and body protection.
Spanish AVISO DE PRECAUCION	<ul style="list-style-type: none"> ● No toque las partes o los electrodos bajo carga con la piel o ropa mojada. ● Aislese del trabajo y de la tierra. 	<ul style="list-style-type: none"> ● Mantenga el material combustible fuera del área de trabajo. 	<ul style="list-style-type: none"> ● Protéjase los ojos, los oídos y el cuerpo.
French ATTENTION	<ul style="list-style-type: none"> ● Ne laissez ni la peau ni des vêtements mouillés entrer en contact avec des pièces sous tension. ● Isolez-vous du travail et de la terre. 	<ul style="list-style-type: none"> ● Gardez à l'écart de tout matériel inflammable. 	<ul style="list-style-type: none"> ● Protégez vos yeux, vos oreilles et votre corps.
German WARNUNG	<ul style="list-style-type: none"> ● Berühren Sie keine stromführenden Teile oder Elektroden mit Ihrem Körper oder feuchter Kleidung! ● Isolieren Sie sich von den Elektroden und dem Erdboden! 	<ul style="list-style-type: none"> ● Entfernen Sie brennbares Material! 	<ul style="list-style-type: none"> ● Tragen Sie Augen-, Ohren- und Körperschutz!
Portuguese ATENÇÃO	<ul style="list-style-type: none"> ● Não toque partes elétricas e electrodos com a pele ou roupa molhada. ● Isole-se da peça e terra. 	<ul style="list-style-type: none"> ● Mantenha inflamáveis bem guardados. 	<ul style="list-style-type: none"> ● Use proteção para a vista, ouvido e corpo.
Japanese 注意事項	<ul style="list-style-type: none"> ● 通電中の電気部品、又は溶材にヒフやぬれた布で触れないこと。 ● 施工物やアースから身体が絶縁されている様にして下さい。 	<ul style="list-style-type: none"> ● 燃えやすいものの側での溶接作業は絶対にしてはなりません。 	<ul style="list-style-type: none"> ● 目、耳及び身体に保護具をして下さい。
Chinese 警告	<ul style="list-style-type: none"> ● 皮肤或湿衣物切勿接触带电部件及焊条。 ● 使你自已与地面和工件绝缘。 	<ul style="list-style-type: none"> ● 把一切易燃物品移离工作场所。 	<ul style="list-style-type: none"> ● 佩戴眼、耳及身体劳动保护用具。
Korean 위험	<ul style="list-style-type: none"> ● 전도체나 용접봉을 젖은 항갑 또는 피부로 절대 접촉치 마십시오. ● 모재와 접지를 접촉치 마십시오. 	<ul style="list-style-type: none"> ● 인화성 물질을 접근시키지 마십시오. 	<ul style="list-style-type: none"> ● 눈, 귀와 몸에 보호장구를 착용하십시오.
Arabic تحذير	<ul style="list-style-type: none"> ● لا تلمس الاجزاء التي يسري فيها التيار الكهربائي أو الالكترود بجسدك أو بالملابس المبللة بالماء. ● ضع عازلا على جسمك خلال العمل. 	<ul style="list-style-type: none"> ● ضع المواد القابلة للاشتعال في مكان بعيد. 	<ul style="list-style-type: none"> ● ضع أدوات وملابس واقية على عينيك وأذنيك وجسمك.

READ AND UNDERSTAND THE MANUFACTURER'S INSTRUCTION FOR THIS EQUIPMENT AND THE CONSUMABLES TO BE USED AND FOLLOW YOUR EMPLOYER'S SAFETY PRACTICES.

SE RECOMIENDA LEER Y ENTENDER LAS INSTRUCCIONES DEL FABRICANTE PARA EL USO DE ESTE EQUIPO Y LOS CONSUMIBLES QUE VA A UTILIZAR, SIGA LAS MEDIDAS DE SEGURIDAD DE SU SUPERVISOR.

LISEZ ET COMPRENEZ LES INSTRUCTIONS DU FABRICANT EN CE QUI REGARDE CET EQUIPMENT ET LES PRODUITS A ETRE EMPLOYES ET SUIVEZ LES PROCEDURES DE SECURITE DE VOTRE EMPLOYEUR.

LESEN SIE UND BEFOLGEN SIE DIE BETRIEBSANLEITUNG DER ANLAGE UND DEN ELEKTRODENEINSATZ DES HERSTELLERS. DIE UNFALLVERHÜTUNGSVORSCHRIFTEN DES ARBEITGEBERS SIND EBENFALLS ZU BEACHTEN.

			
<ul style="list-style-type: none"> ● Keep your head out of fumes. ● Use ventilation or exhaust to remove fumes from breathing zone. 	<ul style="list-style-type: none"> ● Turn power off before servicing. 	<ul style="list-style-type: none"> ● Do not operate with panel open or guards off. 	WARNING
<ul style="list-style-type: none"> ● Los humos fuera de la zona de respiración. ● Mantenga la cabeza fuera de los humos. Utilice ventilación o aspiración para gases. 	<ul style="list-style-type: none"> ● Desconectar el cable de alimentación de poder de la máquina antes de iniciar cualquier servicio. 	<ul style="list-style-type: none"> ● No operar con panel abierto o guardas quitadas. 	Spanish AVISO DE PRECAUCION
<ul style="list-style-type: none"> ● Gardez la tête à l'écart des fumées. ● Utilisez un ventilateur ou un aspirateur pour ôter les fumées des zones de travail. 	<ul style="list-style-type: none"> ● Débranchez le courant avant l'entretien. 	<ul style="list-style-type: none"> ● N'opérez pas avec les panneaux ouverts ou avec les dispositifs de protection enlevés. 	French ATTENTION
<ul style="list-style-type: none"> ● Vermeiden Sie das Einatmen von Schweißrauch! ● Sorgen Sie für gute Be- und Entlüftung des Arbeitsplatzes! 	<ul style="list-style-type: none"> ● Strom vor Wartungsarbeiten abschalten! (Netzstrom völlig öffnen; Maschine anhalten!) 	<ul style="list-style-type: none"> ● Anlage nie ohne Schutzgehäuse oder Innenschutzverkleidung in Betrieb setzen! 	German WARNUNG
<ul style="list-style-type: none"> ● Mantenha seu rosto da fumaça. ● Use ventilação e exaustão para remover fumo da zona respiratória. 	<ul style="list-style-type: none"> ● Não opere com as tampas removidas. ● Desligue a corrente antes de fazer serviço. ● Não toque as partes elétricas nuas. 	<ul style="list-style-type: none"> ● Mantenha-se afastado das partes moventes. ● Não opere com os painéis abertos ou guardas removidas. 	Portuguese ATENÇÃO
<ul style="list-style-type: none"> ● ヒュームから頭を離すようにして下さい。 ● 換気や排煙に十分留意して下さい。 	<ul style="list-style-type: none"> ● メンテナンス・サービスに取りかかる際には、まず電源スイッチを必ず切して下さい。 	<ul style="list-style-type: none"> ● パネルやカバーを取り外したままで機械操作をしないで下さい。 	Japanese 注意事項
<ul style="list-style-type: none"> ● 頭部遠離煙霧。 ● 在呼吸區使用通風或排風器除煙。 	<ul style="list-style-type: none"> ● 維修前切斷電源。 	<ul style="list-style-type: none"> ● 儀表板打開或沒有安全罩時不準作業。 	Chinese 警告
<ul style="list-style-type: none"> ● 얼굴로부터 용접가스를 멀리하십시오. ● 호흡지역으로부터 용접가스를 제거하기 위해 가스제거기나 통풍기를 사용하십시오. 	<ul style="list-style-type: none"> ● 보수전에 전원을 차단하십시오. 	<ul style="list-style-type: none"> ● 판넬이 열린 상태로 작동치 마십시오. 	Korean 위험
<ul style="list-style-type: none"> ● ابعد رأسك بعيداً عن الدخان. ● استعمل التهوية أو جهاز ضغط الدخان للخارج لكي تبعد الدخان عن المنطقة التي تتنفس فيها. 	<ul style="list-style-type: none"> ● اقطع التيار الكهربائي قبل القيام بأية صيانة. 	<ul style="list-style-type: none"> ● لا تشغيل هذا الجهاز اذا كانت الاغطية الحديدية الواقية ليست عليه. 	Arabic تحذير

LEIA E COMPREENDA AS INSTRUÇÕES DO FABRICANTE PARA ESTE EQUIPAMENTO E AS PARTES DE USO, E SIGA AS PRÁTICAS DE SEGURANÇA DO EMPREGADOR.

使う機械や溶材のメーカーの指示書をよく読み、まず理解して下さい。そして貴社の安全規定に従って下さい。

請詳細閱讀並理解製造廠提供的說明以及應該使用的銀焊材料，並請遵守貴方的有關勞動保護規定。

이 제품에 동봉된 작업지침서를 숙지하시고 귀사의 작업자 안전수칙을 준수하시기 바랍니다.

اقرأ بتمعن وافهم تعليمات المصنع المنتج لهذه المعدات والمواد قبل استعمالها واتبع تعليمات الوقاية لصاحب العمل.

MARQUETTE
BY **LINCOLN**
ELECTRIC

Copyright © Lincoln Global Inc.