故障排除指导 Troubleshooting Guide

# ROVER TRACTOR

## 不能送丝 WIRE DOES NOT FEED

(按下“启动”、“送丝”或“退丝”按钮，都不能送丝)

(The wire does not feed when “Start”, “Inch down” or “Inch up” button is pressed)

