故障排除指导 Troubleshooting Guide

Power Wave R350

“死机”--通电后风扇不转，状态指示灯不亮 FAN NOT WORK AND STATUS LED NOT LIGHT

