


AIR VANTAGE 500 WIRING DIAGRAM G6823 REV: B



AUXILIARY POWER LEAD 4 TO PASS THROUGH TOROID THREE TIMES IN DIRECTION SHOWN.
 AUXILIARY POWER LEAD 3 TO PASS THROUGH TOROID FIVE TIMES IN DIRECTION SHOWN.
 LEAD 32A TO PASS THROUGH TOROID TWO TIMES IN DIRECTION SHOWN.



CLEVELAND, OHIO, U.S.A.