





REPLACEMENT PARTS LIST
CENTURY 60/40/30/225 AMP FLEET CHARGER
MODEL 87603 141-219

ITEM	DESCRIPTION	PART NUMBER	ITEM	DESCRIPTION	PART NUMBER
1	BASE	440-295-016	8	RECTIFIER ASSEMBLY	865-682-666
2	(2) HUBS	068-013-666	9	CIRCUIT BREAKER	246-211-666
3	(2) WHEELS & (2) HUBS	413-044-666	10	TRANSFORMER	865-691-888
4	AXLE & (2) HUBS	413-043-666	11	TIMER	246-273-666
5	POWER CORD W/ STRAIN RELIEF	248-195-666	12	ROTARY SWITCH	246-057-666
6	POSITIVE CLAMP W/CABLE & STRAIN RELIEF	238-260-666	13	FRONT PANEL	440-245-096
7	NEGATIVE CLAMP W/CABLE & STRAIN RELIEF	238-261-666	14	CONTROL KNOB	246-041-666
-	POSITIVE & NEGATIVE CLAMPS W/GRIPS	249-066-666	15	AMMETER	247-075-666
			16	VOLTMETER	247-058-666
			17	FRONT FOOT	312-067-666
			18	COVER (NOT SHOWN)	440-256-066
			19	HANDLE (NOT SHOWN)	442-020-166


SERVICING SHOULD BE PERFORMED BY QUALIFIED SERVICE PERSONNEL.



REPLACEMENT PARTS LIST
CENTURY 60/40/30/225 AMP FLEET CHARGER
MODEL 87603 141-219-001A

ITEM	DESCRIPTION	PART NUMBER	ITEM	DESCRIPTION	PART NUMBER
1	BASE	440-320-010	8	RECTIFIER ASSEMBLY	865-682-666
2	(2) HUBS	068-013-666	9	CIRCUIT BREAKER	246-385-666
3	(2) WHEELS & (2) HUBS	413-044-666	10	TRANSFORMER	865-691-888
4	AXLE & (2) HUBS	413-043-666	11	TIMER	246-273-666
5	POWER CORD W/ STRAIN RELIEF	248-195-666	12	ROTARY SWITCH	246-057-666
6	POSITIVE CLAMP W/CABLE & STRAIN RELIEF	238-260-666	13	FRONT PANEL	440-246-290
7	NEGATIVE CLAMP W/CABLE & STRAIN RELIEF	238-261-666	14	CONTROL KNOB	246-041-666
-	POSITIVE & NEGATIVE CLAMPS W/GRIPS	249-066-666	15	AMMETER	247-074-666
			16	VOLTMETER	247-059-666
			17	FRONT FOOT	312-067-666
			18	COVER (NOT SHOWN)	440-256-060
			19	HANDLE (NOT SHOWN)	442-020-166

SERVICING SHOULD BE PERFORMED BY QUALIFIED SERVICE PERSONNEL.



WIRING DIAGRAM

CENTURY 60/40/30/225 AMP FLEET CHARGER
MODEL 87603 141-219-001A