


FLEXCUT 200 WIRING DIAGRAM G9164-2 REV: B



NOTES:
 N.A. PLACE "A" LEAD ON APPROPRIATE CONNECTION FOR INPUT VOLTAGE. CONNECTION SHOWN IS FOR 460 V OPERATION.

