故障排除指导 Troubleshooting Guide

ROVER TRACTOR

反抽丝 WIRE FEEDS UP INSTEAD DOWN

（按下“启动”按钮会退丝，“送丝”或“退丝”功能正常）

(The wire feeds up instead down when pressing the “Start” button, the wire inches up and down properly)

