故障排除指导 Troubleshooting Guide

ROVER TRACTOR

按“送丝”按钮不送丝，按“回丝”按钮可正常回丝

NO INCH DOWN BUT INCH UP PROPERLY

