
故障排除指导 Troubleshooting Guide

MAXsa 22/29
不送丝 WIRE NOT FEEDING



Lincoln Electric