
故障排除指导 Troubleshooting Guide

DC 1000
电源开关不能自锁 POWER SWITCH KEEP TRIPPING



Lincoln Electric