









POWER MIG 180 DUAL WIRING DIAGRAM M22576 REV: A



- Do not operate with covers removed.
- Disconnect input power before servicing
- Do not touch electrically live parts
- Only qualified persons should install, use or service this machine.
- Install equipment in accordance with the U.S. National Electrical Code, all local codes and the manufacturer's recommendations.



- NOTES:
- N.A. BOLTED ALUMINUM CONNECTIONS REQUIRE E2529 JOINT COMPOUND (PENETROX A13) WHEN REATTACHING.
 - N.B. WORK AND GUN CONNECTIONS SHOWN FOR GMAW WELDING.
 - N.C. CAVITY NUMBERING SEQUENCE VIEWED FROM INSERTION SIDE OF CONNECTORS.
 - N.D. SEE S26766 FOR SPOT TIMER KIT WIRING DIAGRAM.

