

INVERTEC® 160TPX

Spare Parts	1
Figure A: Machine Assembly	2
Electrical Schematic	3
Code 50576	3



Spare Parts

SP50576 Rev000
02/23

ASSEMBLY PAGE NAME			Machine Assembly					
CODE NO.:	K NO.:	FIGURE NO.:	A					
50576	K14299-1	INVERTEC® 160TPX	1					

*items highlighted in bold are recommended spare parts




Figure A

Figure A: Machine Assembly

Item	Description	Part Number	QTY	1	2	3	4	5	6	7
1	MAIN FRAME	W93X1379R	1	X						
1A	+ FRONT NAMEPLATE	+ R-0000-274-1R	1	-						
			1	X						
2	WRAPAROUND	R-1019-392-1R	1	X						
3	HANDLE	W92X0228-8R	1	X						
4	FRONT/REAR HANDLE	W95X1387R	2	X						
5	KIT 4 ANTI-SLIP FOOT	W95X1149R	1	X						
6	CONTROL P.C. BOARD	R-6042-099-1R	1	X						
7	INPUT P.C. BOARD	W05X1545R	1	X						
8	INVERTER P.C. BOARD	W05X1348-2R	1	X						
9	HF P.C. BOARD	W05X1615R	1	X						
10	HF TRANSFORMER	W59X1544R	1	X						
11	MAIN SWITCH	W7511710R	1	X						
12	INPUT CORD CE	R-5041-305-1R	1	X						
13	CABLE CLAMP WITH NUT	W8400006R	1	X						
14	KNOB WITH FELT	W8707653R	1	X						
15	FAN	W66X1369R	1	X						
16	TRIGGER TORCH CONNECTOR	R-5141-002-2R	1	X						
17	REMOTE CONTROL CONNECTOR	R-5041-312-2R	1	X						
18	DINSE CONNECTOR	C-2986-001-2R	2	X						
19	ASSEMBLE CAP. 4n7 250Vac	R-5141-025-1R	1	X						
20	SOLENOID VALVE	W8500011R	1	X						
21	FITTING 1/4-1/8 + NUT 1/4	W8896074R	1	X						
22	FITTING QUICK CONNECTION PU 1/8	W8800082R	1	X						
23	HALL SENSOR	W4900003R	1	X						
24	CAPACITORS ASSEMBLY	R-5141-088-1R	1	X						

Code 50576

