



POWER WAVE 655R WIRING DIAGRAM G3498 REV: A



NOTES:
 N.A. PIN NEAREST THE FLAT EDGE OF LED LENS (CATHODE) ALIGNS WITH BLACK LEAD OF LED SOCKET.
 N.B. CTs MUST BE ORIENTED IN THE PROPER DIRECTION. TRANSFORMER LEADS SHOULD GO FROM TRANSFORMER THROUGH THE DOTTED SIDE OF CT TO THE SWITCH BOARD. THE ARROW ON THE CT SHOULD POINT FROM THE SWITCH BOARD TO THE TRANSFORMER.
 N.C. PLACE "A" LEAD ON APPROPRIATE CONNECTION FOR INPUT VOLTAGE. CONNECTION SHOWN IS FOR 550-575V OPERATION.

ELECTRICAL SYMBOLS PER E1537
 LEAD COLOR CODING
 B=BLACK
 G=GREEN
 N=BROWN
 R=RED
 U=BLUE
 W=WHITE

COMPONENT VALUES:
 CAPACITORS-MFD/VOLTS
 RESISTORS-OHMS/WATTS



CLEVELAND, OHIO, U.S.A.